

LOT NODE

Full Manual · v1 · 2026-09-06 · Planning-stage edition

This manual documents LOT Node as designed in Session 1 of the hardware program: plan, bill of materials, and roadmap. No physical prototype exists yet. Photographs and step-by-step diagrams will be added once hardware ships (see the program roadmap in *docs/hardware/LOT-COMPUTER-PLAN.md*).

1. Welcome

LOT Node is the physical counterpart to the Memory Engine and Quantum Operating System (QOS) running on lot-systems.com. Where the web app builds a growing Memory Story from your answers, LOT Node brings that intelligence into the room with you: a short, autonomous notification on a small screen, and one button to send a moment straight back into your Log.

It does not replace the app. It is a single-purpose object: notifications in, one signal out, plus ambient weather sensing — consistent with LOT's approach of understanding patterns rather than accumulating data for its own sake.

2. Physical Layout

LOT Node is a flat, two-piece stainless steel enclosure, 40×40mm, designed to sit on a desk like a coaster.

Face	Contents
Front	Camera lens, round display (center), single button (“Copy”)
Rear	Mirror-polished stainless steel, laser-etched LOT wordmark, accepts wireless charging

Finish: front plate bead-blasted matte SUS304 stainless steel; rear plate mirror-polished SUS304. SUS304 is used specifically because it is non-magnetic, which is required for the wireless charging coil behind the rear plate to couple correctly.

3. First-Time Setup

- Charge LOT Node fully before first use (see Section 7).
- Hold the button for 3 seconds to enter pairing mode; a QR code appears on screen.
- Scan the QR code with your phone's own camera app — not LOT Node's camera.
- The link opens a setup page to choose your Wi-Fi network and sign in to your LOT account.
- Once connected, LOT Node requests a device pairing token from lot-systems.com and shows a checkmark.

4. Using the Screen

State	What you see
Idle	Small clock / weather glyph, dimmed
Notification	Full-brightness short text (e.g. “Coffee time!”), auto-dims after ~15s

State	What you see
Copy confirmed	Brief checkmark, then returns to the previous state
Offline	Small disconnect glyph in the corner; last notification stays visible

5. Using the Copy Button

A single press of the button sends one signal to your Log tab on lot-systems.com, the same log stream that already records notes, answers, and check-ins from the web app. Use it to mark a moment worth remembering without opening your phone or laptop.

6. Weather Sensing

LOT Node includes an ambient temperature, humidity, and barometric-pressure sensor. Readings update roughly every 10 minutes and feed the same weather concept already shown on your public profile (temperature, sky, humidity), giving that reading a physical, on-desk source rather than a remote weather API alone.

7. Charging & Battery Care

- Charge using the included Qi puck; rest LOT Node polished-side down on the puck.
- A full charge from empty takes a few hours on the included 5W puck.
- The battery is a sealed internal cell; it is not user-replaceable.
- Avoid leaving LOT Node in direct sunlight or above 45°C for extended periods.

8. Privacy

LOT Node's camera is used only for two things: reading a QR code during setup, and an optional low-resolution presence check used to dim the screen when no one is at the desk. No image is ever stored on the device or uploaded anywhere — this mirrors the broader LOT principle that your data lives in your own account, not a third party's servers. Device network calls are limited to lot-systems.com over an encrypted connection, authenticated with a per-device token that can be revoked at any time from your account settings.

9. Troubleshooting

Symptom	Try this
Won't pair	Hold the button 3s to re-enter pairing mode; confirm your phone's Wi-Fi network matches what you see
Won't charge	Confirm the puck itself is powered; center LOT Node on the puck; clean the rear plate of any residue
Screen blank	Check charge level; hold the button 8s for a hard reset
Button not logging	Confirm the offline glyph is not showing; check Wi-Fi; re-pair if the device token was revoked

10. Specifications

Property	Value
Footprint	40 × 40 mm
Height	~11 mm (revised from initial 5 mm concept; see program plan, Section 7)
Enclosure	2-piece SUS304 stainless steel: matte front, mirror-polished rear
Display	1.3" round IPS LCD
Camera	2MP, fixed focus (setup + presence only)
Sensor	Temperature / humidity / barometric pressure
Connectivity	Wi-Fi (2.4GHz), BLE for setup
Battery	500mAh LiPo, rechargeable
Charging	Qi wireless, 5W puck (included)
Input	Single tactile button ("Copy")

11. Regulatory & Safety

LOT Node is currently a pilot-scale (100-unit) build for internal and beta use and has not yet undergone formal regulatory certification (e.g. FCC, CE). Certification will be completed before any retail sale to the general public. Do not disassemble the device; the internal battery is not user-serviceable.

12. Support

Email support@lot-systems.com for setup help, hardware issues, or feedback on this planning-stage manual.

Document status: Session 1 of the LOT Node hardware program (plan → BOM → roadmap). See docs/hardware/ in the LOT-Computer repository for the underlying plan, bill of materials, mechanical spec, firmware architecture, and software connector design this manual is drawn from.