

COSMO® TILE

Model CT-1

Operator Manual — v0 Pilot Build

LOT SYSTEMS CORPORATION
Made in the USA · brand.lot-systems.com

A small physical companion for your LOT account — one message at a time, the way a pager does, not the way a phone does.

What CT-1 Is

COSMO® TILE is a small physical companion for your LOT account. It sits on your desk, charges wirelessly, and shows you exactly one message at a time — the way a pager does, not the way a phone does. When LOT's AI has something worth telling you, the screen lights up with a single short line. Press **COPY** to acknowledge it; the moment is saved to your Log tab at lot-systems.com automatically.

CT-1 does not run apps, does not stream video, and does not notify you about anything except what your own LOT Index of Systems decides is worth a line of text.

In the Box

- 1× COSMO® TILE (CT-1) — polished stainless steel top, matte stainless steel underside
 - 1× Wireless charging puck (USB-C powered; cable included)
 - 1× Quick-start card
-

Physical Layout

FACE A -- Polished

```
+-----+
|               |
|       (mirror)       |
|               |
+-----+
```

Rests here. This is the side you see when the Tile is charging, screen down, on its puck.

FACE B -- Matte

```
+-----+
| [CAM]  screen  [COPY] |
|               |
+-----+
```

Camera, screen, and the COPY button live here. This is the working side.

40mm × 40mm footprint. Two-piece stainless steel body, no adhesive seams — the shell is held together with four stainless screws so it can be opened for service.

Setup

1. Place CT-1 on the charging puck, polished face (Face A) down.
2. Plug the puck into any USB-C power source.
3. The screen (Face B) will show a short pairing code.
4. On lot-systems.com, go to **Settings** → **Devices** → **Add COSMO® TILE** and enter the code shown on-screen.
5. Once paired, the screen goes dark. This is normal — a dark screen means “nothing to tell you right now,” not “something is wrong.”

Using CT-1

When a message appears: the screen shows one short line — for example, “Coffee time!” or “Memory question ready.” — with a small timestamp in the corner.

To acknowledge it: press **COPY**. The screen clears, and the moment is written to your Log tab at lot-systems.com, so you always have a permanent record even though the Tile itself only ever shows you one line at a time.

If you don’t press COPY: the message will clear on its own after a timeout, and (if still relevant) may reappear later. Nothing is lost — your Log tab is the durable record either way.

The camera: CT-1’s camera does not stream or record continuously. It only activates briefly, either when you interact with the Tile directly or when your LOT account explicitly requests a presence check. No frame is ever stored anywhere except your own account, and never by a third party.

The weather reading: CT-1 quietly reads the temperature, humidity, and pressure at your desk and reports it back to your LOT profile, alongside your existing location-based weather data.

Care

- Wipe the polished face (Face A) with a soft cloth; avoid abrasive cleaners, which will dull the mirror finish.
- The matte face (Face B) is more forgiving of fingerprints by design.
- Keep CT-1 on its charging puck when not carried — it is not designed for long off-charger runtime (see Technical Notes).
- Do not submerge. Do not open the shell yourself; service is handled through LOT Systems support.

Troubleshooting

Symptom	What it means	What to do
Screen never lights up	No messages pending, OR device not paired	Check Settings → Devices at lot-systems.com to confirm pairing
Screen shows a pairing prompt again	Device was unpaired or its access was revoked	Re-pair using the code shown on-screen
COPY doesn't seem to do anything	Acknowledgment is queued and will sync once the Tile reconnects	No action needed — it will catch up automatically
Tile feels warm on the charging puck	Normal during wireless charging	No action needed

Technical Notes (for the curious)

CT-1 is intentionally a thin client — nearly all of its intelligence lives on LOT's servers, not inside the device. This keeps the object small, repairable, and inexpensive, and means the Tile itself never needs to “understand” anything about your Index of Systems; it just displays the one line it's given and reports back what you do with it.

Full engineering documentation:

- Plan & roadmap: [docs/corporate/LOT-COSMO-TILE-v1.md](#)
- Components list: [docs/hardware/COSMO-TILE-BOM.md](#)
- Firmware spec: [docs/hardware/COSMO-TILE-FIRMWARE.md](#)
- Software / API spec: [docs/hardware/COSMO-TILE-SOFTWARE.md](#)

Support

support@lot-systems.com

lot-systems.com/status

COSMO® TILE (CT-1) — LOT Systems Corporation

© 2025-2026 LOT Systems. All rights reserved.

This manual describes a v0 pilot build (100 units). Specifications may change before wider production — see the roadmap in [LOT-COSMO-TILE-v1.md](#) Section 12.