

COSMO® Cube

User Manual — v1.0 — The LOT Computer

What it is

COSMO® Cube is a small stainless-steel LOT® terminal that sits on your desk. It shows one short line from lot-systems.com when the system has something for you — a badge, a reminder, a weather note — and it has one button: **Copy**.

It is not a phone. It has no feed, no unread count, and no apps. One line, one button.

In the box

- 1× COSMO® Cube (40 × 40 × 5mm, stainless steel)
- 1× wireless charging dock
- 1× quick-start card with your device's pairing code

Setup

1. Place COSMO® Cube polished-side-down on the charging dock.
2. The screen shows a 6-character pairing code.
3. On your phone or computer, go to lot-systems.com/hardware/pair and sign in to your LOT® account.
4. Enter the pairing code shown on the device.
5. Enter your Wi-Fi network name and password when prompted.
6. The screen briefly shows the LOT® wordmark, then goes to standby. Setup is complete.

Using it

When a notice arrives, one line appears on the screen — for example “Coffee time!” or “Badge unlocked — check your Log.”

Press the button (short press) to copy the notice to your Log tab at lot-systems.com and clear the screen. Your Log tab shows the entry within a few seconds.

Hold the button (2 seconds) to attach a photo to that Log entry using the onboard camera. This is off by default — turn it on in Settings > Hardware.

Charging: rest the device polished-side-down on the dock. A full charge from empty takes a few hours; the device sips power between notices.

Privacy

- The camera is unpowered except during an explicit long-press capture, or an optional presence check you control.
- No raw camera image ever leaves the device unless you trigger a snapshot with a long press.
- Weather readings give the AI a hyperlocal read of your desk — not tracked or sold.
- Revoke your device's access anytime from Settings > Hardware at lot-systems.com — instantly.

Care

- The polished face is stainless steel — it will show fingerprints; a soft cloth restores the shine.
- Splash-resistant, not waterproof — do not submerge.
- No user-serviceable parts inside; do not open the shell.

Troubleshooting

Symptom	What to try
Screen stays blank	Confirm it's seated on the charging dock; check for a low-battery glyph
Pairing code won't accept	Codes expire after a few minutes — hold the button 5s for a new one
Notices stop arriving	Check Wi-Fi; check Settings > Hardware to confirm the device isn't revoked
Copy doesn't appear in Log	Check your connection — offline presses sync once reconnected

Support: support@lot-systems.com