

LOT Computer — User Manual

(Concept-stage manual — written ahead of hardware, to be revised against a real production unit before Phase 4 launch. Specs below reflect the plan in `./01-PRODUCT-PLAN.md` and `./03-BOM.md`.)

What it is

LOT Computer is a small physical companion to your Memory Engine on lot-systems.com. It has one screen, one button, and one camera. It shows you short, context-aware nudges the same way an old pager showed a message — and gives you exactly one way to respond: press **Copy** to save the moment to your Log.

What it is not

- Not a smart speaker — no microphone, no voice.
- Not a security camera — the camera only activates on an explicit long

press, never continuously, never in the background, and its indicator LED is hardware-tied to the camera's power line, not software-controlled.

- Not a general notification hub — it only ever speaks for your own Memory

Engine, not email, texts, or other apps.

Physical description

- Flat square, approx. 40mm × 40mm, two-piece stainless steel body.
- **Back (polished):** mirror-finish stainless steel, brand mark, sits

against the charging dock.

- **Front (brushed):** camera lens, small round display, one button.

The screen

A low-power e-ink display. It shows either nothing (idle) or a short line of text (an active notification). E-ink holds its image without power, so don't worry about it "staying on" — that costs almost nothing.

The button

- **Short press — Copy:** saves the currently displayed text (plus a

timestamp and, if available, the room's temperature/humidity from the built-in sensor) into your Log tab on lot-systems.com.

- **Long press — Camera:** takes one photo and attaches it to that same Log

entry. The shutter light confirms every capture.

The sensor

An onboard temperature/humidity/pressure sensor gives hyper-local context (is it actually warm in the room right now) alongside your account's city- level weather already shown elsewhere on lot-systems.com. It only ever travels with a Copy or Camera event — it does not report on its own schedule.

Charging

Place the puck polished-side-down on the included wireless charging dock. No cable to plug into the puck itself.

Care

- Wipe the polished face with a soft cloth; avoid abrasive cleaners which will dull the mirror finish.
- Keep it dry — the gasket between the two halves resists dust and light splashes, it is not a waterproof rating.
- Do not disassemble — there are no user-serviceable parts inside.

Privacy

- The camera cannot be triggered remotely — only the physical long-press on the device itself activates it.
- Everything the device sends goes to your own account's Log tab, under the same privacy rules as anything else you write there (see lot-systems.com's own privacy documentation for how your Log/Memory Story data is handled).
- You can unpair the device at any time from Settings → Devices, which immediately revokes its ability to write to your account.

Troubleshooting

Symptom	Likely cause	What to try
Screen shows nothing, ever	Not paired, or battery depleted	Re-pair via Settings → Devices; place on charging dock for several hours
Copy press doesn't appear in Log tab	WiFi out of range, or device unpaired	Move closer to your WiFi router; check Settings → Devices shows it as connected
Camera LED doesn't light on long-press	Hardware fault	Contact support — the LED is hardware-tied and should not be possible to disable in software

Specifications (planning-stage — see ../03-BOM.md for sourcing)

Spec	Value
Dimensions	~40mm × 40mm × 5–9mm (see product plan for the height note)
Body material	304 stainless steel, 2-piece
Display	1.54", 200×200, e-ink
Camera	2MP, fixed focus
Connectivity	WiFi 2.4GHz
Charging	Qi wireless
Sensors	Temperature, humidity, pressure