

Demon spawn remote

A

A

B


B

C

C

D

D



Vagarth Gaurav



Sheet: /
File: demonSpawn.kicad_sch

Title: Demon Spawn Remote

Size: A4 | Date: 2026-01-05
KiCad E.D.A. 9.0.6

Rev:
Id: 1/5

Battery Charger



Sheet: /Battery Charger/
File: battery_charger.kicad_sch


Title:

KiCad E.D.A. 9.0.6


Rev:
Id: 2/5

Microcontroller


Microcontroller



Buttons



3.3V LDO



Sheet: /Microcontroller/
File: microcontroller.kicad_sch


Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6


Rev:
Id: 3/5

Connectors and Buttons


USB C




Buttons



Connectors



Battery Holder and switch



Mounting holes



Sheet: /Connectors and Buttons/
File: connectors.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 9.0.6


Rev:
Id: 4/5

Charge Level LED's

A

A


Wing battery level LED's



B

B

Remote battery level LED's



C

C

D

D

Sheet: /Battery_Level_Indicators/
File: battery_level_indicators.kicad_sch

Title:

Size: A4 Date:

KiCad E.D.A. 9.0.6

Rev:

Id: 5/5