

Assignment-2.3

“Peripheral Troubleshooting”

TASK-1 List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

1.Keyboard/mouse is not responding—Unplug the USB device and reconnect it to another USB port.

2.USB device is not detected — Restart the laptop and reconnect the keyboard/mouse.

3.Some keys or mouse buttons do not work — Check the device on another computer to see whether the device itself is faulty.

4.Mouse cursor is moving incorrectly — Clean the mouse sensor and use it on a suitable flat surface.

5.Device keeps disconnecting — Try another USB port and check whether the USB cable is damaged.

TASK-2 Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

1.Check the headphones

- Make sure the headphones are switched ON.
- Check whether their battery has enough charge.

2.Check Bluetooth on the phone

- Open Settings → Bluetooth.
- Make sure Bluetooth is ON.

3.Check pairing mode

- Put the headphones into Bluetooth pairing mode.
- Look for a flashing Bluetooth/pairing indicator on the headphones.

4.Look for the headphones on the phone

- Check the list of available Bluetooth devices.
- Select the headphones when they appear.

5.If they were previously connected

- Tap the headphones in the Bluetooth device list.
- Choose Forget/Unpair, then search for them again.

6.Restart both devices

- Turn the headphones off and on again.
- Restart the phone.

7. Check the connection

- After pairing, check that the headphones show as Connected.
- Play a sound to confirm that audio is coming through them.

TASK-3 A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem. Consider device manager, privacy settings, and app permissions.

1. **Check the USB connection**
 - Make sure the webcam's USB cable is firmly connected.
 - Try another USB port.
2. **Check Device Manager**
 - Right-click **Start** → **Device Manager**.
 - Look under **Cameras, Imaging devices**, or **Sound, video and game controllers**.
 - Check whether the webcam appears or has a warning symbol.
3. **Check Windows camera privacy settings**
 - Go to **Settings** → **Privacy** → **Camera**.
 - Make sure **Allow apps to access your camera** is turned on.
4. **Check Zoom camera settings**
 - Open Zoom.
 - Go to **Settings** → **Video**.
 - Check whether the external webcam is selected as the camera.
5. **Close other applications**
 - Close apps such as Camera, Teams, Skype, or other programs that might already be using the webcam.
 - Restart Zoom.
6. **Restart the computer**
 - Disconnect and reconnect the webcam.
 - Restart Windows and test the webcam again.

TASK-4 You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

- **Check the printer**
 - Make sure the printer is powered ON.
 - Check the USB cable or Wi-Fi connection.
- **Open Windows Settings**
 - Click **Start** → **Settings**.
- **Open Printers**
 - Go to **Devices** → **Printers & scanners** in Windows 10.
- **Select the printer**
 - Click the printer that is showing **Offline**.
- **Run the troubleshooter**

- Select **Manage** and look for the available troubleshooting option, or open **Settings → Update & Security → Troubleshoot → Additional troubleshooters → Printer**.
- Run the **Printer Troubleshooter**.
- **Follow the instructions**
 - Windows checks the printer connection and related settings.
 - Follow any recommended fixes.

What information does the Troubleshooter provide?

The Windows Troubleshooter can identify problems such as:

- Printer connection problems
- USB or network connection issues
- Incorrect printer settings
- Print queue problems
- Driver-related problems
- Printer being unavailable/offline