Lecture 22: Introduction to Unsteady Gas Dynamics

ENAE311H Aerodynamics I


Christoph Brehm

Propagating shock waves

Consider a constant area duct, with a piston that is impulsively started to u_p at t=0 (with zero velocity before that).

We note the following:

- Since the flow won't have time to respond in a smooth fashion, a shock wave must propagate ahead of the piston at a speed $v_{s}>u_{p}$.
- The flow conditions behind the shock are uniform, so the fluid velocity must be equal to the fluid velocity, u_p .
- The shock speed will be precisely that required to accelerate the flow to u_p , according to the normal-shock relations.




Propagating shock waves

Consider a constant area duct, with a piston that is impulsively started to u_p at t=0 (with zero velocity before that).

We note the following:

- A useful way to visualize such unsteady, one-dimensional flow phenomena is through an x-t diagram (note the similarity to the 2-D flow over a compression corner).
- Knowing the conditions in region 1 and the shock speed, v_s , all conditions in region 2 can be determined using the normal shock relations. One further expression that will be useful relates the pressure jump to the piston speed:

$$u_p = a_1 \left(\frac{p_2}{p_1} - 1\right) \left(\frac{2/\gamma}{(\gamma + 1)\frac{p_2}{p_1} + \gamma - 1}\right)^{1/2}.$$



Propagating shock waves


Consider a constant area duct, with a piston that is impulsively started to u_p at t=0 (with zero velocity before that).

We note the following:

- A useful way to visualize such unsteady, one-dimensional flow phenomena is through an x-t diagram (note the similarity to the 2-D flow over a compression corner).
- Knowing the conditions in region 1 and the shock speed, v_s , all conditions in region 2 can be determined using the normal shock relations. One further expression that will be useful relates the pressure jump to the piston speed:

$$u_p = a_1 \left(\frac{p_2}{p_1} - 1\right) \left(\frac{2/\gamma}{(\gamma + 1)\frac{p_2}{p_1} + \gamma - 1}\right)^{1/2}.$$

• Even if the piston acceleration is gradual, the compression waves will eventually coalesce to form a shock wave.




Propagating expansion waves

Now imagine that the piston is impulsively withdrawn away from the fluid at speed $|u_p|$, rather than accelerated into it.

We now note the following:

An expansion wave must propagate into the fluid.



Propagating expansion waves

Now imagine that the piston is impulsively withdrawn away from the fluid at speed $|u_p|$, rather than accelerated into it.


We now note the following:

- An expansion wave must propagate into the fluid.
- Since a finite expansion wave is forbidden by the second law of thermodynamics, we must have a gradual (isentropic) expansion through a centered expansion fan. This can again be represented in an x-t diagram.
- The leading wave will have a propagation speed of a_4 . For all other waves, the propagation speed (in the lab frame) is

$$c = a_4 + \frac{\gamma + 1}{2}u,$$

where u is the local fluid velocity. Since the final velocity matches the piston speed, the terminal wave propagates at

$$c_{terminal} = a_4 - \frac{\gamma + 1}{2} |u_p|.$$



Propagating expansion waves


Now imagine that the piston is impulsively withdrawn away from the fluid at speed $|u_p|$, rather than accelerated into it.

We now note the following:

- The flow velocity decreases linearly through the expansion fan (and of course matches the piston speed at the trailing end).
- The strength of the expansion can be characterized in terms of the pre- and post-expansion pressures:


$$\frac{p_3}{p_4} = \left(1 - \frac{\gamma - 1}{2} \frac{|u_p|}{a_4}\right)^{2\gamma/(\gamma - 1)}.$$

• Note that this entails a maximum velocity that the flow can achieve through an unsteady expansion.



Now consider a constant area duct with high- and lowpressure regions (possibly of different compositions) separated by a diaphragm.

If the diaphragm is suddenly burst, the unsupported pressure difference will cause the fluid interface (also referred to as the *contact surface*) to start propagating towards the low-pressure region.



Now consider a constant area duct with high- and lowpressure regions (possibly of different compositions) separated by a diaphragm.


If the diaphragm is suddenly burst, the unsupported pressure difference will cause the fluid interface (also referred to as the *contact surface*) to start propagating towards the low-pressure region.

The contact surface will act as a fluid piston, causing a shock wave to propagate into the low-pressure region and an expansion wave into the high-pressure region. This can again be represented on an x-t diagram.

A contact surface is the 1-D, unsteady equivalent of a shear layer; the conditions across it are

$$p_2 = p_3$$

 $u_2 = u_3 (= u_{cs}).$



If we treat the contact surface as an equivalent fluid piston, we can rewrite our earlier equations for the propagating shock and expansion waves as:


$$u_{2} = a_{1} \left(\frac{p_{2}}{p_{1}} - 1 \right) \left(\frac{2/\gamma_{1}}{(\gamma_{1} + 1)\frac{p_{2}}{p_{1}} + \gamma_{1} - 1} \right)^{1/2}$$

$$u_{3} = \frac{2a_{4}}{\gamma_{4} + 1} \left[1 - \left(\frac{p_{3}}{p_{4}} \right)^{(\gamma_{4} - 1)/2\gamma_{4}} \right].$$

Matching pressures and velocities, we can then derive the shock-tube equation:

$$\frac{p_4}{p_1} = \frac{p_2}{p_1} \left[1 - \frac{(\gamma_4 - 1)\frac{a_1}{a_4} \left(\frac{p_2}{p_1} - 1\right)}{\left\{ 2\gamma_1 \left[2\gamma_1 + (\gamma_1 + 1) \left(\frac{p_2}{p_1} - 1\right) \right] \right\}^{1/2}} \right]^{-2\gamma_4/(\gamma_4 - 1)}.$$

This gives the shock strength (p_2/p_1) implicitly as a function of the initial pressure ratio and sound speeds.



If we treat the contact surface as an equivalent fluid piston, we can rewrite our earlier equations for the propagating shock and expansion waves as:

$$u_{2} = a_{1} \left(\frac{p_{2}}{p_{1}} - 1 \right) \left(\frac{2/\gamma_{1}}{(\gamma_{1} + 1)\frac{p_{2}}{p_{1}} + \gamma_{1} - 1} \right)^{1/2}$$

$$u_{3} = \frac{2a_{4}}{\gamma_{4} + 1} \left[1 - \left(\frac{p_{3}}{p_{4}} \right)^{(\gamma_{4} - 1)/2\gamma_{4}} \right].$$

Matching pressures and velocities, we can then derive the shock-tube equation:

$$\frac{p_4}{p_1} = \frac{p_2}{p_1} \left[1 - \frac{(\gamma_4 - 1)\frac{a_1}{a_4} \left(\frac{p_2}{p_1} - 1\right)}{\left\{ 2\gamma_1 \left[2\gamma_1 + (\gamma_1 + 1) \left(\frac{p_2}{p_1} - 1\right) \right] \right\}^{1/2}} \right]^{-2\gamma_4/(\gamma_4 - 1)}.$$

This gives the shock strength (p_2/p_1) implicitly as a function of the initial pressure ratio and sound speeds.

Once we know p_2/p_1 , the shock Mach number can be derived using the shock-jump relation

$$M_s = \left[1 + \frac{\gamma_1 + 1}{2\gamma_1} \left(\frac{p_2}{p_1} - 1\right)\right]^{1/2}.$$

All other properties in region 2 can then be easily derived.

Shock tubes are used for studying, e.g., unsteady flow phenomena and combustion ignition. They are also used to generate high-enthalpy conditions for shock tunnels.