

Data Filters Applied

Instrument: ApexZ50 (1903144011), ApexZ50 (1903144012)
 Location: ALAT BERSIH, ARE LANTAI 3, AREA ALT BRSIH 2, Area blender, AREA BLENDER, AREA BLENDER 2, AREA BLENDER 1, AREA BLENDER 2, AREA DILATASI, Area discharge, Area docking lt2, AREA DOCKING LT2, Area K1R6 Lt 4, Area K1T4, Area K1T6 Lt 3, AREA LIFTER, AREA LT 3, AREA LT 3M, AREA LT-1, AREA LT-3 , AREA LT-3M, AREA LT-4, AREA LWB 1, Area Mezanine 3M, area mezzanin, AREA MIXING, AREA MODUWASH, AREA

Status Legend

F = Flow Error
 L = Laser Error
 S = Service Required
 = Alarm Triggered
 = Warning Triggered

Sample Data Report

Generated at: 18/08/2025 09:51:31

Generated by user:

Timestamp	Model	Serial #	Name	Location	Status	Sample Time	0,5 m³	5,0 m³	
18/08/2025 08:28:17	ApexZ50	1903144012		R-RAO KELAS -E		00:01:00	42570	4830	
18/08/2025 08:29:17	ApexZ50	1903144012		R-RAO KELAS -E		00:01:00	30150	2370	
18/08/2025 08:30:17	ApexZ50	1903144012		R-RAO KELAS -E		00:01:00	24620	1490	
18/08/2025 08:33:18	ApexZ50	1903144012		R-KORIDOR KLS E		00:01:00	49960	2950	
18/08/2025 08:34:18	ApexZ50	1903144012		R-KORIDOR KLS E		00:01:00	39270	1860	
18/08/2025 08:35:18	ApexZ50	1903144012		R-KORIDOR KLS E		00:01:00	34670	2040	
18/08/2025 08:37:23	ApexZ50	1903144012		R-KORIDOR KLS E		00:01:00	38370	3930	
18/08/2025 08:38:23	ApexZ50	1903144012		R-KORIDOR KLS E		00:01:00	33200	3480	
18/08/2025 08:39:23	ApexZ50	1903144012		R-KORIDOR KLS E		00:01:00	31180	3140	
18/08/2025 08:40:23	ApexZ50	1903144012		R-KORIDOR KLS E		00:01:00	33800	3390	
18/08/2025 08:41:23	ApexZ50	1903144012		R-KORIDOR KLS E		00:01:00	30390	3620	
18/08/2025 08:42:23	ApexZ50	1903144012		R-KORIDOR KLS E		00:01:00	23820	2560	
18/08/2025 08:43:23	ApexZ50	1903144012		R-KORIDOR KLS E		00:01:00	19280	1540	
18/08/2025 08:46:42	ApexZ50	1903144012		R-PERSIAPAN OVEN		00:01:00	20220	1950	
18/08/2025 08:47:42	ApexZ50	1903144012		R-PERSIAPAN OVEN		00:01:00	19680	2060	
18/08/2025 08:48:42	ApexZ50	1903144012		R-PERSIAPAN OVEN		00:01:00	24940	3460	
18/08/2025 08:49:42	ApexZ50	1903144012		R-PERSIAPAN OVEN		00:01:00	23900	3280	
18/08/2025 08:50:42	ApexZ50	1903144012		R-PERSIAPAN OVEN		00:01:00	21850	2930	
18/08/2025 08:51:42	ApexZ50	1903144012		R-PERSIAPAN OVEN		00:01:00	19990	2830	
18/08/2025 08:55:47	ApexZ50	1903144012		R INKUBASI		00:01:00	22250	3550	
18/08/2025 08:56:53	ApexZ50	1903144012		R INKUBASI		00:01:00	19200	3330	
18/08/2025 08:57:59	ApexZ50	1903144012		R INKUBASI		00:01:00	19480	2740	
18/08/2025 08:59:05	ApexZ50	1903144012		R INKUBASI		00:01:00	25070	2290	
18/08/2025 09:00:11	ApexZ50	1903144012		R INKUBASI		00:01:00	34270	2350	
18/08/2025 09:01:17	ApexZ50	1903144012		R INKUBASI		00:01:00	38010	2670	
18/08/2025 09:04:36	ApexZ50	1903144012		R-ALAT		00:01:00	73970	10570	
18/08/2025 09:05:42	ApexZ50	1903144012		R-ALAT		00:01:00	47940	5630	
18/08/2025 09:06:48	ApexZ50	1903144012		R-ALAT		00:01:00	34010	3780	
18/08/2025 09:07:54	ApexZ50	1903144012		R-ALAT		00:01:00	24550	2380	
18/08/2025 09:10:07	ApexZ50	1903144012		R-GANTI KELAS E		00:01:00	36610	6390	
18/08/2025 09:11:13	ApexZ50	1903144012		R-GANTI KELAS E		00:01:00	33080	5830	
18/08/2025 09:12:19	ApexZ50	1903144012		R-GANTI KELAS E		00:01:00	25900	3970	



Data Filters Applied

Instrument: ApexZ50 (1903144011), ApexZ50 (1903144012)

Location: ALAT BERSIH, ARE LANTAI 3, AREA ALT BRSIH 2, Area blender, AREA BLENDER, AREA BLENDER 2, AREA BLENDER 1, AREA BLENDER 2, AREA DILATASI, Area discharge, Area docking lt2, AREA DOCKING LT2, Area K1R6 Lt 4, Area K1T4, Area K1T6 Lt 3, AREA LIFTER, AREA LT 3, AREA LT 3M, AREA LT-1, AREA LT-3 , AREA LT-3M, AREA LT-4, AREA LWB 1, Area Mezanine 3M, area mezzanin, AREA MIXING, AREA MODUWASH, AREA

Status Legend

F = Flow Error
L = Laser Error
S = Service Required
■ = Alarm Triggered
■ = Warning Triggered

Sample Data Report

Generated at: 18/08/2025 09:51:31

Generated by user:

Timestamp	Model	Serial #	Name	Location	Status	Sample Time	0,5 m³	5,0 m³	
18/08/2025 09:13:25	ApexZ50	1903144012		R-GANTI KELAS E		00:01:00	22510	3260	
18/08/2025 09:14:31	ApexZ50	1903144012		R-GANTI KELAS E		00:01:00	17740	2580	