- Using APPLOAD command load the file app file code eg: "make3dpoly.txt"
 Type MAKE3DPOLYFROMCSV at the autocad command prompt and press ENTER
- This should create the polyline using the coordinates created by .csv file.