AQL - AQWA Interface for Excel

Version 5.7A 22/09/2006

AQWA Support Manager Century Dynamics Limited Dynamics House, 86 Hurst Road Horsham, West Sussex, England, RH12 2DT

Tel: +44 (0)1403 270066 Fax: +44 (0)1403 270099 Email centdyn-uk@ansys.com www.century-dynamics.com

> Copyright 2006. Century Dynamics Limited. All Rights Reserved. Century Dynamics is a subsidiary of ANSYS, Inc. Unauthorised use, distribution or duplication is prohibited

Revision Information

The information in this guide applies to all ANSYS, Inc. products released on or after this date, until superseded by a newer version of this guide. This guide replaces individual product installation guides from previous releases.

Copyright and Trademark Information

ANSYS, ANSYS Workbench, CFX, AUTODYN, ASAS, AQWA and any and all ANSYS, Inc. product and service names are registered trademarks or trademarks of ANSYS, Inc. or its subsidiaries located in the United States or other countries. ICEM CFD is a trademark licensed by ANSYS, Inc. ABAQUS is a registered trademark of ABAQUS, Inc

Adobe and Acrobat are registered trademarks of Adobe Systems Incorporated

Compaq is a registered trademark of Compaq Computer Corporation

Delphi is a registered trademark of Borland Software Corporation

DXF is a trademark of Autodesk, Inc

FEMGV, FEMGEN and FEMVIEW are trademarks of Femsys Limited

FLEXIm and FLEXnet are registered trademarks of Macrovision Corporation

Formula One is a trademark of Visual Components, Inc

GINO is a registered trademark of Bradly Associates Ltd

IGES is a trademark of IGES Data Analysis, Inc

Intel is a registered trademark of Intel Corporation

Mathcad is a registered trademark of Mathsoft Engineering & Education, Inc.

Microsoft, Windows, Windows 2000, Windows XP and Excel are registered trademarks of Microsoft Corporation

NASTRAN is a registered trademark of the National Aeronautics and Space Administration.

PATRAN is a registered trademark of MSC Software Corporation

SentinelSuperProTM is a trademark of Rainbow Technologies, Inc

SESAM is a registered trademark of DNV Software

Softlok is a trademark of Softlok International Ltd

All other trademarks or registered trademarks are the property of their respective owners.

Disclaimer Notice

THIS ANSYS SOFTWARE PRODUCT AND PROGRAM DOCUMENTATION INCLUDE TRADE SECRETS AND ARE CONFIDENTIAL AND PROPRIETARY PRODUCTS OF ANSYS, INC., ITS SUBSIDIARIES, OR LICENSORS. The software products and documentation are furnished by ANSYS, Inc., its subsidiaries, or affiliates under a software license agreement that contains provisions concerning non-disclosure, copying, length and nature of use, compliance with exporting laws, warranties, disclaimers, limitations of liability, and remedies, and other provisions. The software products and documentation may be used, disclosed, transferred, or copied only in accordance with the terms and conditions of that software license agreement.

ANSYS, Inc. and ANSYS Europe, Ltd. are UL registered ISO 9001:2000 Companies.

U.S. Government Rights

For U.S. Government users, except as specifically granted by the ANSYS, Inc. software license agreement, the use, duplication, or disclosure by the United States Government is subject to restrictions stated in the ANSYS, Inc. software license agreement and FAR 12.212 (for non-DOD licenses).

Third-Party Software

The products described in this document contain the following licensed software that requires reproduction of the following notices.

Copyright 1984-1989, 1994 Adobe Systems Incorporated. Copyright 1988, 1994 Digital Equipment Corporation. Permission to use, copy, modify, distribute and sell this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notices appear in all copies and that both those copyright notices and this permission notice appear in supporting documentation, and that the names of Adobe Systems and Digital Equipment Corporation not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission. Adobe Systems & Digital Equipment Corporation make no representations about the suitability of this software for any purpose. It is provided "as is" without express or implied warranty.

Microsoft, Windows, Windows 2000 and Windows XP are registered trademarks of Microsoft Corporation

The ANSYS third-party software information is also available via download from the Customer Portal on the ANSYS web page. If you are unable to access the third-party legal notices, please contact ANSYS, Inc.

Published in the United Kingdom

AQL User Manual Contents

Table of Contents

Section		Page
1.1 Introduct	tion	1-1
1.2 Compatib	bility	1-1
2.1 Installing	g AQL	2-2
3.1 Using AC	QL Functions	3-3
)	
4. AQL Function	ns	4-1
	nal Interface	
4.2 Function	n Description	4-2
4.3 Problem	Solving	4-7
4.4 Restriction	ons	4-8
4.5 Performa	ance	4-8
4.6 Model U	Jpdates	4-8
5. Error Codes	*	5-1

i

AQL - AQWA Interface for Excel¹

1. Overview

1.1 Introduction

AQL is an interface from AQWA to Excel. It is intended to facilitate the development of Excel spreadsheets that require data from AQWA databases. The interface consists of a series of Excel functions that can be accessed within the spreadsheet to recover data directly from the AQWA database. A typical example might be an application that tabulates motions of a particular structure and then undertakes a post-processing exercise.

Key features are:

- Direct access to the AQWA database information using Excel Function calls
- Recovery of RAOs using structure number, frequency and direction
- Recovery of time history results
- Error trapping
- Simple installation

1.2 Compatibility

AQL is available for Excel variants designed to run under Windows 98² or Windows 2000³.

The interface program does not require an AQWA dongle or security file to operate.

¹ The Microsoft Excel logo is a registered trademark of Microsoft Corporation.

Windows 98 is a registered trademark of Microsoft Corporation.

Windows 2000 is a registered trademark of Microsoft Corporation.

2. Installation

2.1 Installing AQL

Installation of AQL is straightforward. It is assumed that the reader is reasonably familiar with Windows. The notes below relate to Version 5.0 of Excel. Later versions may vary slightly from the suggested installation.

Install the files AQL32.DLL and AQL32.XLA from the setup file onto your computer. AQL32.DLL must be placed in a directory that is listed in the PATH so that Windows can find it. If AQWA is loaded on the computer, the directory \aqwa\utils will almost certainly be on the PATH, so the DLL file should be stored there.

The AQL32.XLA file is best placed in the directory Program Files\Microsoft Office\Diffice\Library. Once installed, it is necessary to set up the location in Excel\Tools\Add-ins\Browse and in Excel\Edit\Links.

If a spreadsheet, which already has calls to AQL in it, is copied from another computer, Excel may not work properly on the new computer if AQL is installed in different directories on the two machines.

3. Running AQL

3.1 Using AQL Functions

AQL is reasonably simple to use as follows:

- start Excel as usual
- if the AQL32.XLA worksheet file is not auto-loaded at startup, open the AQL32.XLA file (using the normal Excel File Open command)
- use the AQL.... functions in a standard Excel worksheet

When the AQL32.XLA file is loaded nothing appears on the screen. This is normal. If the file is not loaded, any worksheet formulae using AQL.... functions will display as #REF!. If a function is used and #VALUE! is displayed, text has probably been entered for an argument which should be a number or vice versa. If #N/A appears, one of the arguments has probably been omitted.

AQL functions are included in formulae just like ordinary Excel functions (such as sine, sum, max, etc.). If you cannot remember the order or meaning of the arguments to the function, use Excel's function wizard - the AQL functions are listed in a category called AQWA-Excel32.

A simple example is shown below:

```
=AQLposition("C:\Alpha\adtest01", 1, z, 100)
```

This function returns the Z displacement at time-step 100 for structure number 1, in model adtest01, stored in directory C:\Alpha.

To avoid typing such long formulae, it is a good idea to use absolute and relative row and column references in Excel as much as possible. This is illustrated in the example below where the user requires the displacement of one structure in all six degrees of freedom for every thousand time-steps. The directory and the model name are entered into cells A1 and A2 (splitting these up makes changing to a different model easy). These items are then concatenated into a single string in cell A3. The number of the structure is entered into cell B4. The six degrees of freedom, namely X, Y, Z, RX, RY and RZ are entered into cells B5, C5, D5, E5, F5 and G5. The time-steps are entered into cells A6, A7, A8, A9, A10, A11 and A12.

The full formula for displacement in cell B6 would be:

```
=AQLposition("C:\Alpha\adtest01", 1, x, 1)
```

which entered using cell references as:

```
=AQLposition(A3,B4,B5,A6)
```

This is much shorter and can be entered by clicking on the appropriate cells. However, if this formula is copied to from cell B6 to cell C7, it becomes:

```
=AQLposition(B4,C5,C6,B7)
```

which is completely wrong! The required formula in cell C7 is:

```
=AOLposition(A3,B4,C5,A7)
```

Column and row numbers in a formula can be made absolute by prefixing them with dollar signs. Therefore the formula in cell B6 can be rewritten as:

```
=AQLposition($A$3,$B$4,B$5,$A6)
```

which when copied to C7 gives:

```
=AQLposition($A$3,$B$4,C$5,$A7)
```

which evaluates to:

```
=AQLposition("C:\Alpha\adtest01",1,"Y",1000)
```

as required.

Use of named cells can also be useful when requiring invariant data access. By naming cell A3 'model', use can be made of this name in the function calls and it behaves as though giving an absolute address. Thus 'model' is synonymous with \$A\$3.

The formula in cell B6 becomes:

```
=AQLposition (model, $B$4, B$5, $A6)
```

The formula in cell B6 can be copied over the whole of the table B6:G12 to give the required table as follows:

	A:	B:	C:	D:	E:	F:	G:
1:	C:\ALPHA\						
2:	ADTEST01						
3:	=(A1&A2)						
4:	Structure Number	1					
5:	Time-Step	X	Y	Z	RX	RY	RZ
6:	1	=AQLposition(model,\$B\$4,B\$5,\$A6))					
7:	1000						
8:	2000						
9:	3000						
10:	4000						
11:	5000						
12:	6000						

3.2 Example

There is an example spreadsheet in the training directory that is included with the standard AQWA installation. This spreadsheet displays several results from the "takbuy" model in the training directory. It will probably be necessary to modify the path in cell B4.

4. AQL Functions

4.1 Functional Interface

The AQWA interface for Excel consists of two main parts:

- a dynamic link library called AQL32.dll
- an Excel add-in macro sheet called AQL32.xla

The dynamic link library (or dll) is a set of functions written in the FORTRAN language. These functions understand enough about the AQWA file system to extract information from it. They do all the hard work.

The add-in macro sheet provides a set of spreadsheet functions that use the dynamic link library to access the AQWA file system. These spreadsheet functions can be used like any other functions in an Excel spreadsheet (or 'worksheet' in Microsoft's terminology). All the functions have names starting with the prefix *aql*...

The functions are designed to be relatively straightforward to use. All arguments are in terms of user numbers (structure number, frequency number, etc.) rather than AQWA internal numbers.

The AQL interface requires no special configuration, no start up macros, etc.

4.2 Function Description

All the function information in this section can be obtained using the help button from the Function Wizard in Excel.

The list of functions below is complete at the time of writing, but more functions will be added as and when necessary.

FUNCTIONS	DESCRIPTION	
Aqlcogcoord	Returns x, y or z coordinate of the centre of gravity of a structure	
Aqlcoord	Returns x, y or z coordinate of a node	
Aqlelcent	Returns x, y, or z coordinate of an element centroid	
Aqlelpres	Returns pressure at element centroid	
Aqlfrequency	Returns wave frequencies analyzed in AQWA-LINE	
Aqlmessage	Returns an error message for a given aql error flag number	
Aqlndirns	Returns the number of wave directions for a structure	
Aqlnfreqs	Returns the number of wave frequencies for a structure	
Aqlnlines	Returns the number of mooring lines in a model	
Aqlnstructs	Returns the number of structures in a model	
Aqlposition	Returns the position of a structure for a time history analysis	
Aqlrao	Returns RAO information from the hydrodynamic database	
Aqlrao2	Returns interpolated RAO information from the hydrodynamic database	
Aqlstatmooring	Returns mooring line information for a static (AQWA-LIBRIUM) analysis	
Aqlstatposcog	Returns position of the CoG for a static (AQWA-LIBRIUM) analysis	
Aqlstatposnod	Returns position of a specified node for a static (AQWA-LIBRIUM) analysis	
Aqlthacccog	Returns the acceleration of the cog for a time history analysis	
Aqlthmooring	Returns mooring line information for a time history analysis	
Aqlthposcog	Returns the position of the CoG for a time history analysis	
Aqlthtime	Returns the time associated with a time step in a time history analysis	
Aqlthvelcog	Returns the velocity of the cog for a time history analysis	
Aqlwavedirn	Returns wave directions analyzed in AQWA-LINE	

Aqlcogcoord

Purpose: Returns the initial coordinate of the centre of gravity

Syntax: aqlcogcoord(model,structure,freedom)

Notes: Only one coordinate is returned according to the freedom specified.

Example: aqlcogcoord(model,1,x) returns the x coordinate of the centre of gravity of structure 1 in the

model specified in the named cell Model.

Aqlcoord

Purpose: Returns the initial coordinate of a node

Syntax: aqlcoord(model,structure,node,freedom)

Notes: Only one coordinate is returned according to the freedom specified.

Example: aqlcoord(model,1,101,x) returns the x coordinate of node 101 on structure 1 in the model

specified in the named cell Model.

Aqlelcent

Purpose: Returns the initial coordinate of the centroid of an element

Syntax: aqlelcent(model,structure,element,xsym,ysym,freedom)

Notes: Only one coordinate is returned according to the freedom specified.

Xsym and ysym are used to define the region in a model with symmetry. Use 1 to specify the

modelled region, 2 to specify the reflected region.

Example: aqlelcent(model,1,101,2,1,x) returns the x coordinate of element 101 on structure 1 in the

model specified in the named cell Model. The element will be in the region reflected in the X-Z plane (i.e usually on the starboard side for a conventional ship model with one axis of

symmetry and nodes defined with positive y coordinates).

Aqlpres

Purpose: Returns the pressure at the centroid of an element

Syntax: aqlelpres(model,structure,direnum,freqnum,element,xsym,ysym,component,amp/pha)

Notes: Xsym and ysym are used to define the region in a model with symmetry. Use 1 to specify the

modelled region, 2 to specify the reflected region.

Valid components are Hydrostatic, Incident, Diffraction, Radiation, Total. The names can be

abbreviated to the first 3 letters. Hydrostatic is the dynamically varying component of

hydrostatic pressure caused by the motion of the ship.

Example: aqlelpres(model,1,2,5,101,2,1,Tot,Amp) returns the amplitude of the total pressure at the

centroid of element 101 on structure 1 in the model specified in the named cell Model, for the

2nd direction and the 5th frequency

Aqlfrequency

Purpose: Returns the frequencies utilized in the radiation/diffraction analysis

Syntax: aqlfrequency(model,structure,freqnum)

Notes: frequum is the frequency identifier as specified in the AQWA-LINE analysis

Aqlmessage

Purpose: Returns the definition of an AQL error code

Syntax: aqlmessage(Errorcode)

Notes:

Example: aqlmessage(#AQL:101) returns the error message connected with AQL error number 101.

Aqlndirns

Purpose: Returns the number of wave directions for a structure

Syntax: aqlndirns(model,structure)

Aqlnfreqs

Purpose: Returns the number of wave frequencies for a structure

Syntax: aqlnfreqs(model,structure)

Aqlnlines

Purpose: Returns the number of mooring lines in a model

Syntax: aqlnlines(model)

Aqlnstructs

Purpose: Returns the number of structures in a model

Syntax: aqlnstructs(model)

Aqlposition

Purpose: Returns the position of the centre of gravity of a structure at a given time.

Syntax: aqlposition(model,structure,freedom,timestep)

Notes: Only applies to time domain programs, Naut and Drift. Freedom is in terms of the Fixed

Reference Axis. Timestep is the timestep number rather than the actual time.

Example: aqlposition(Model,1,x,2) returns the x coordinate of the centre of gravity of structure 1 at

timestep number 2 in the model specified in the named cell Model.

Aqlrao

Purpose: Returns RAO data

Syntax: aqlrao(model,structure,direnum,freqnum,freedom,Amp/Phase)

Notes: direnum is the wave direction number rather than the actual wave angle.

Example: aqlrao(Model,1,2,5,rx,Amp) returns the amplitude of the roll RAO of structure 1 in waves

of frequency no. 5 and direction no. 2

Aqlrao2

Purpose: Returns interpolated RAO data

Syntax: aqlrao2(model,structure,dire,freq,freedom,Amp/Phase)

Notes: This function interpolates between data points in the AQWA database.

dire is the wave angle (degrees) and freq is the frequency (rad/s). Compare with aqlrao above

Example: aqlrao2(Model, 1, 15, 0.35, x, Amp) returns the RAO based motion of structure 1 in the x

direction, in waves with a frequency of 0.35 rad/s and direction 15 deg.

Aqlstatmooring

Purpose: Returns the mooring line information from a static (AQWA-LIBRIUM) analysis

Syntax: aqlthmooring(model,structure,configuration,spectrum,line,freedom)

Notes: Valid freedoms are, X, Y, Z, tension, laid length and uplift. Long freedom names can be

abbreviated to the 1st four letters. Requires the .PLD file for the model. AQWA-LIBRIUM does not produce a .PLD file so it is necessary to open the AGS and read in the .PLT file. A

.PLD file will then be generated automatically.

Example: aqlstatmooring(Model,1,2,2,4,TENS) returns the tension in line 4 connected to structure 1

for mooring configuration no.2 and spectrum no. 2.

Aqlstatposcog

Purpose: Returns the final position of the centre of gravity from a static (AQWA-LIBRIUM) analysis

Syntax: aqlthmooring(model,structure,configuration,spectrum,freedom)

Notes: Valid freedoms are, X, Y, Z, RX, RY, RZ. Requires the .PLD file for the model. AQWA-

LIBRIUM does not produce a .PLD file so it is necessary to open the AGS and read in the

.PLT file. A .PLD file will then be generated automatically.

Example: aglstatposcog(Model,1,2,2,RX) returns the angle about the X axis of the centre of gravity of

structure 1 for mooring configuration no.2 and spectrum no. 2.

Aqlstatposnod

Purpose: Returns the final position of a specified node from a static (AQWA-LIBRIUM) analysis

Syntax: aqlthmooring(model,structure,configuration,spectrum,node,freedom)

Notes: Valid freedoms are, X, Y, Z, RX, RY, RZ. Output for the specified node must have been

requested in the AQWA-LIBRIUM run using the NODE card in deck 18. Requires the .PLD file for the model. AQWA-LIBRIUM does not produce a .PLD file so it is necessary to open

the AGS and read in the .PLT file. A .PLD file will then be generated automatically.

Example: aqlstatposnod(Model,1,2,2,548,Y) returns the Y position of node 548 on structure 1 for

mooring configuration no.2 and spectrum no. 2.

Aqlthacccog

Purpose: Returns the acceleration of a structure's centre of gravity at a given time step in a time history

analysis

Syntax: aqlthacccog(model,structure,freedom,timestep)

Notes: Requires the .PLD file for the model. The freedom refers to the FRA. Valid freedoms are, X,

Y, Z, RX, RY and RZ. Note that these do not necessarily refer to surge, sway, heave etc.

Aqlthmooring

Purpose: Returns the mooring line information associated with a given time step in a time history

analysis

Syntax: aqlthmooring(model,structure,line,freedom,timestep)

Notes: Requires the .PLD file for the model. Valid freedoms are, X, Y, Z, tension, laid length and

uplift. Long freedom names can be abbreviated to the 1st four letters.

Aqlthposcog

Purpose: Returns the position of a structure's centre of gravity associated with a given time step in a

time history analysis

Syntax: aqlthposcog(model,structure,freedom,timestep)

Notes: Requires the .PLD file for the model. The freedom refers to the FRA. Valid freedoms are, X,

Y, Z, RX, RY and RZ. Note that these do not necessarily refer to surge, sway, heave etc.

Aqlthtime

Purpose: Returns the time (in seconds) associated with a given time step in a time history analysis

Syntax: aqlthtime(model,timestep)

Notes: Requires the .PLD file for the model

Aqlthvelcog

Purpose: Returns the velocity of a structure's centre of gravity associated with a given time step in a

time history analysis

Syntax: aqlthvelcog(model,structure,freedom,timestep)

Notes: Requires the .PLD file for the model. The freedom refers to the FRA. Valid freedoms are, X,

Y, Z, RX, RY and RZ. Note that these do not necessarily refer to surge, sway, heave etc.

Aqlwavedirn

Purpose: Returns the wave directions utilized in the radiation/diffraction analysis, units are degrees.

Syntax: aqlwavedirn(model,structure,direnum)

Notes: direnum is the direction identifier as specified in the AQWA-LINE analysis

4.3 Problem Solving

When using AQL functions, several different types of problem might arise. These fall into three main groups:

- errors in function names and arguments
- errors in values given to a function
- errors in accessing the AQWA files

Some problems may cause Excel to display one of its standard error indicators. #NAME? usually means that you have mis-typed the name of the function, or that the AQL32.xla add-in has not been loaded. #N/A usually means that too few arguments have been given to a function. #VALUE! usually means that the wrong type of arguments have been given (such as text where a number is expected) or a wrong value for an argument with a restricted range of valid values (such as "Q" or 8 for a freedom name, where only "X", "Y", "Z", would be acceptable).

Some general rules for solving problems are:

#NAME? - check that the function name is spelled correctly and that the AQL32.xla add-in has been loaded

#N/A - check that the correct number and type of arguments have been given to the function - use the Formula|Paste Function... command in Excel to check what the arguments mean

#VALUE! - if the cell contains a formula which does a calculation, the AQL function may be returning an error code and Excel is signalling that it cannot perform arithmetic on text values; if the cell simply calls a function check that arguments which can only take a few possible values, such as axis names, force names, etc. have been correctly specified

#REF! - this error is generally nothing to do with AQL

- If the AQWA analysis has been re-run since the spreadsheet was last used, make a null edit of the cell where the AQWA files are defined (simply put the cursor on the cell, press F2, enter) and Excel will recalculate as if you had changed the cell (even though you know that you have not). This may clear up problems due to Excel displaying out-of-date results.
- Many errors in tables come from confusion about absolute and relative cell addresses, so check that a
 formula that you have copied does reference appropriate rows and columns for element, node, etc.
 numbers.

The individual functions in the DLL are designed to be fairly robust so they will not cause Excel or Windows to crash in the event of problems. They only read from AQWA files, so cannot corrupt any data. However it is not advisable to attempt to read from an AQWA backing file at the same time as an AQWA program is trying to write to it.

4.4 Restrictions

Excel sometimes returns spurious error codes from functional calls. All results should be checked by the user.

There are no facilities for writing information back to the AQWA files.

The DLL functions can be accessed directly from Excel using the CALL function. However, this is not recommended because errors in the parameters to CALL can easily lead to Excel or Windows crashing. Don't do it!

4.5 Performance

The AQL functions are designed for convenience, not speed. The functions in the DLL do include some local caching to reduce the amount of file access when a single model is being used. However, as they comply with the general Windows recommendation for not keeping files open between calls (which also means that they do not require initialisation or close down and should not cause system problems if the AQWA files are updated while Excel is running), they do perform a lot of input from the AQWA file system to retrieve even small amounts of data.

The amount of physical disk input can be minimised by use of disk caching (Smartdrive in MS-DOS). This should be enabled when Windows is in use anyway.

Excel does have an unpleasant habit of performing a full recalculation when not necessary (especially when a row or column is inserted or deleted, or after moves or copies). If a worksheet has a table containing thousands of numbers retrieved by AQL, this can take some time. One way of avoiding the recalculation is to create the table using AQL functions and then replace the formulae with the results so the cells contain only numbers thereafter - which require no recalculation. To do this, select the main body of the table, then the copy command (Edit | Copy on the menu). Immediately after this give the paste special command specifying values only (Edit | Paste Special | Values | OK on the menu). It's a good idea to save a single copy of the original formula somewhere in case the table has to be reconstructed.

4.6 Model Updates

Like all spreadsheet programs, Excel tries to avoid doing unnecessary recalculation. If nothing has changed in a spreadsheet, it does not automatically recalculate it. Even the Excel command Options | Calculate Calc Now (F9) will not force a spreadsheet to recalculate if nothing has changed in the spreadsheet itself.

This can be a problem with AQWA results where models may be rerun: as far as Excel is concerned a function asking for (say) the position of structure 1 at a particular time-step does not need recalculating if none of these numbers have changed - it does not take account of the fact that the data in files outside Excel may have changed. This consideration applies even when a spreadsheet is closed and re-opened or Excel restarted.

To force all the results to be reloaded, make a null edit of the model name (as used in the first argument to each AQL function) by clicking on the cell, then pressing F2 to edit the cell, then enter to accept the edit. Excel will recalculate the spreadsheet and update all the values.

AQL User Manual Error Codes

5. Error Codes

The error codes on the left below can be translated into the text on the right with the AQL message function, described above. Some of these error messages relate to problems within the AQL interface that cannot be corrected by the user. These may arise due to errors within the AQL code, corrupt AQWA files, or lack of resources such as free memory or file handles.

	· ·
#AQL:101	Invalid or missing node number for specified structure
#AQL:102	Structure does not exist in specified model
#AQL:103	Unable to locate or open .RES file for specified model
#AQL:108	Invalid directory path for specified model
#AQL:109	Invalid or missing frequency for specified structure
#AQL:110	Invalid or missing direction for specified structure
#AQL:111	Phase or Amplitude keyword required
#AQL:202	Phase or Amplitude keyword required
#AQL:204	Unable to locate .POS file for specified model
#AQL:205	Unable to open .POS file for specified model
#AQL:212	Invalid time-step requested
#AQL:213	Results are not available for this time-step
#AQL:215	Invalid freedom requested
#AQL:305	Unable to locate .PLD file for specified model
#AQL:314	Invalid or missing plot information requested
#AQL:402	Unable to locate file

The .dll makes use of several standard AQWA routines for file access, and these may generate error messages that are not covered by the codes above. In this case the AQWA error messages are echoed to the spreadsheet. As they were not intended for output to a spreadsheet they are usually too long for the cells, so it is necessary to enlarge the cell so that the message can be read.