

MARUCCI

2/

To: MR. H. HOSOKAWA  
FM: T. NISHIKAWA

281-496-9442

# Applied Offshore Structural Engineering

## Teng H. Hsu



Gulf Publishing Company  
Book Division  
Houston, London, Paris, Tokyo

3/

## APPLIED OFFSHORE STRUCTURAL ENGINEERING

Copyright © 1984 by Gulf Publishing Company, Houston, Texas. All rights reserved. Printed in the United States of America. This book, or parts thereof, may not be reproduced in any form without permission of the publisher.

### Library of Congress Cataloging in Publication Data

Hsu, Teng H.

Applied Offshore Structural Engineering

Includes index.

1. Offshore structures. I. Title.

TC1665.H79 1984

627'.9

84-628

ISBN 0-87201-750-8

Prefac

Notati

1. C

T

2. W

A

3. W

S

4. E

R

5. F

U

6. O

P

B

# CONTENTS

Preface .....	VII
Notation .....	IX
1. Conversion of Units .....	1
The International System of Units. References.	
2. Wind Forces .....	7
API Wind Force Formula. ABS Wind Force Formula. DNV Wind Force Formula. Unsteady Wind Forces. References.	
3. Wave Forces .....	17
Small Amplitude Waves. Stokes' Second and Third-Order Waves. Stokes' Fifth-Order Waves. Wave Forces by Morrison's Equation. Stream Function Wave Theory. Wave Slamming. Vortex Shedding Due to Waves. References.	
4. Energy Spectrum of the Sea .....	37
Energy of the Sea. Wave Histogram. Wave Spectra. References.	
5. Fundamental Naval Architecture .....	46
Definition of Terms. Transverse Stability. Stability Under Wind Forces. Longitudinal Stability. Rolling in Calm Water. Free Undamped Heaving Motion. References.	
6. Offshore Platform Topsides Structures .....	55
Plate Design. Shear Lag and Effective Width Concept. Buckling of Plates. Girders with Transverse Stiffeners. Web Crippling. Lifting Pad Eye Design. References.	

5/

<b>7. Offshore Platform Jacket Structures</b>	<b>74</b>
Layouts and Preliminary Sizing. Tubular Members. Tubular Joints. Hydrostatic Pressure. Conical Transition Between Tubular Sections. Corrosion Protection of Jacket Structures. Boat Landings and Barge Bumpers. References.	
<b>8. Offshore Platform Pile Foundation</b>	<b>95</b>
Pile Capacity for Axial Loads. Soil—Pile Interaction. Pile Design. Pile Make-Up. Pile Drivability Analysis. References.	
<b>9. Offshore Platform Marine Operations</b>	<b>127</b>
Loadout and Seafastening. Transportation. References.	
<b>10. Fabrication and Installation of Offshore Platforms</b>	<b>131</b>
Structural Steel. Welding. Fabrication. Launching and Floating. Flooding and Upending. Lifting. References.	
<b>11. Seismic Analysis of Offshore Platforms</b>	<b>140</b>
Step-by-Step Analysis Method. Mode Superposition Method. Response Spectrum Method. References.	
<b>12. Dynamic Analysis of Offshore Platforms</b>	<b>152</b>
Natural Frequency of a Structural System. Dynamic Response of Offshore Platforms. Dynamic Response by the Time Domain Approach. Dynamic Response by the Frequency Domain Approach. References.	
<b>13. Fatigue Analysis of Offshore Platforms</b>	<b>167</b>
Fatigue Analysis and Hotspot Stress. Fatigue Analysis by the Discrete Spectrum Approach. Fatigue Analysis by the Power Spectral Approach. References.	
<b>14. Mooring Design</b>	<b>196</b>
Mooring Buoys. Mooring Line with Hydrodynamic Resistance. References.	
<b>Index</b>	<b>203</b>

The b  
applicati  
cal back  
forces, e  
tion and  
equation  
showing

In ord  
basic un  
wind an  
design o  
covering  
practice  
platform  
offshore  
scribe th  
for offsh

The bo  
of API,  
not inten  
obliged t  
the parti

While  
cal infor  
help fill  
tural eng

6/

- $k$  = Distance from outer face of flange to web toe of fillet, in.  
 $t$  = Web thickness, in.

### Lifting Padeye Design

Lifting Padeye design should consider the impact from vessel motion. Load factors should be applied to the lifting weight. API RP 2A recommends that for lifts to be made at open sea, a factor of two should be applied. Most offshore lifting is performed by using four slings. It is conservative in practical design to consider that one sling will sag during lifting. The sling load  $P$  can be calculated by

$$2W = nP \cos \alpha$$

$$P = 2W/(n \cos \alpha)$$

where:  $\alpha$  = Angle between the sling and vertical line  
 $W$  = Lifting weight  
 $n$  = Number of slings

The procedure of Padeye design is expressed as follows:

1. Check bearing stress.

$$\text{Allowable bearing } F_p = 0.9F_y$$

$$d(T + 2t)F_p \geq P$$

where:  $d$  = Pin diameter  
 $T$  = Main plate thickness  
 $t$  = Cheek plate thickness

$$T + 2t \geq \frac{P}{dF_p} \quad (6-17)$$

- From Equation 6-17, the thickness of the main plate and cheek plates can be properly selected.
2. Check shear stress.

$$\text{Allowable shear } F_v = 0.4F_y$$

$$2[T(R - r_0) + 2(r - r_0)t]F_v \geq P$$

## 68 Applied Offshore Structural Engineering

$$T(R - r_0) + 2(r - r_0)t \geq \frac{P}{2F_v} \quad (6-18)$$

where:  $R$  = Radius of main plate

$r_0$  = Radius of pin hole

$r$  = Radius of cheek plates

From Equation 6-18, proper plate thickness can be selected. In most cases, the plate thickness selected from Equation 6-17 will govern the design.

3. Check welding between the main plate and cheek plates. If the welding size is  $w$  and the allowable welding stress is  $F_w$ , then

$$2\pi r \times 0.707w \times F_w \geq P \frac{t}{T + 2t}$$

$$w \geq \frac{Pt}{4.44F_w(T + 2t)r} \quad (6-19)$$

From Equation 6-19, the required welding (fillet) between the main plate and the cheek plates can be calculated.

4. Check axial and shear stress along a section cutting through the main plate. If a section is cut through the main plate at  $b$  distance from the center of the hole, the section is  $h$  units high:

$$\text{Axial stress } f_a = \frac{P \cos \theta}{Th}$$

where  $P$  = Force on padeye

$\theta$  = angle of force on padeye from horizontal.

$T$  = Main plate thickness

$h$  = Length of padeye section cut by plane distance "b" from center of hole and parallel to base of main plate

$$\text{Bending stress } f_b = \frac{Mc}{I}$$

$$\text{Shear stress } f_v = P \sin \theta \frac{Q}{IT}$$

$b$  = distance from center of pin hole to the cut-plane  $\parallel$  to padeye base.


where:  $\theta$  = Angle between slings, and the horizontal

$Q$  = Static moment of the cross-sectional area beyond the point where the shear is calculated (taken about the neutral axis of the section)

$$M = P \sin \theta b - P \cos \theta \left( \frac{h}{2} - R \right)$$



$$Q = \text{Cross-hatch Area} \times \bar{y}$$



## Offshore Platform Toppide Structures 69

8/

- 18) The maximum bending stress  $f_b = 6M/(Th^2)$   
 The average shear stress  $f_v' = P \sin \theta/(Th)$  is calculated and the principal stress at the edge of the section can be calculated:

$$\sigma_{\text{MAX}} = \frac{f_a + f_b}{2} + \sqrt{\left(\frac{f_a + f_b}{2}\right)^2 + (f_v')^2} \quad (6-20)$$

In practical design a horizontal force of 5% of the static sling load should be applied simultaneously with the sling load.

Padeye design should provide sufficient clearance for easy installation. The following clearances are recommended:

1. The Padeye pin-hole diameter should be one-quarter inch larger than the pin diameter.
2. The Padeye thickness should be one-half inch less than the jaw width of the shackle (Figure 6-6).
3. The outer radius of Padeye main plate should allow about one-quarter-inch clearance between the main plate and the sling.




Figure 6-6. Padeye clearance.

## 70 Applied Offshore Structural Engineering

4. It is important to locate the Padeye such that the shackle, the pin, and slings clear the adjacent structural members.

P  
2F.**Example 6-3**It i  
4. C

The topside structure of a offshore platform weighs 800 t. Four Pad-eyes are needed for the lift. Design the Padeyes.

Given:  $\alpha = 30^\circ$   
 $\theta = 60^\circ$   
 $F_y = 42 \text{ ksi}$   
 $d = 6 \text{ in.}$

1. Calculate sling loads (consider one sling sags).

$$P = \frac{2W}{3 \cos \alpha} = \frac{2 \times 1,600}{3 \times \cos 30} = 1,232 \text{ kips}$$

2. Check bearing stress.


$$F_p = 0.9F_y = 37.8 \text{ ksi}$$

$$\begin{aligned} d(T + 2t)F_p &\geq P \\ 6(T + 2t) \times 37.8 &\geq 1,232 \\ T + 2t &\geq 1,232/(6 \times 37.8) = 5.43 \text{ in.} \end{aligned}$$

Try 2 in. main plate.

1.75 cheek plates

$$T + 2t = 2 + 3.5 = 5.5 > 5.43 \text{ in.}$$



3. Check shear stress.

$$F_v = 0.4 \times 42 = 16.8 \text{ ksi}$$


Try

$$\begin{aligned} R &= 11 \text{ in.} \\ r &= 10 \text{ in.} \end{aligned}$$

$$\text{Use } 2r_0 = d + 1/4 = 6.25 \text{ in.}$$

$$T(R - r_0) + 2(r - r_0)t \geq P/(2F_v)$$

$$2(11 - 3.13) + 2(10 - 3.13) \times 1.75 = 39.78$$



9/

## Offshore Platform Topsides Structures 71

$$\frac{P}{2F_y} = \frac{1,232}{2 \times 16.8} = 36.67 < 39.78$$

It is noted that bearing governs the design.

4. Check welding of the cheek plates. Assume E60 welds are used.

$$w \geq \frac{Pt}{4.44F_w(T + 2t)r}$$

$$w \geq \frac{1,232 \times 1.75}{4.44 \times 13.6(2 + 3.5) \times 10} = 0.65 \text{ in.}$$

Use three-quarter-inch fillet welds around the cheek plates.

5. Check stress at a section 11 in. from hole center.

Try  $h = 48$  in.

$$\begin{aligned} M &= P \sin \theta b - P \cos \theta (h/2 - R) \\ &= 1232 \times 0.87 \times 11 - 1232 \times 0.5(24 - 11) \\ &= 3782 \text{ k-in.} \end{aligned}$$

$$f_a = \frac{P \cos \theta}{Th} = \frac{1232 \times 0.50}{2 \times 48} = 6.42 \text{ ksi}$$

$$f_b = \frac{6M}{Th^2} = \frac{6 \times 3782}{2 \times 48^2} = 4.92 \text{ ksi}$$

Five percent of static sling load =  $0.05 \times 616 = 30.8$  kips

$$M = 31 \times 12 = 372 \text{ k-in.}$$

$$f_b = 6 \times 372/(48 \times 4) = 11.63 \text{ ksi}$$

$$f = 6.42 + 4.92 + 11.63 = 22.97 \text{ ksi}$$

$$\frac{D}{2} = \frac{3}{4}h$$

$$\text{Shear at N.A.} = \frac{VQ}{IT} = \frac{3V}{4Th} = \frac{3 \times 1,072}{4 \times 2 \times 48} = 8.38 \text{ ksi}$$

Shear stress at edge = 0

$$\text{Maximum stress} = \frac{6.42 + 11.63}{2} + \sqrt{9.03^2 + 8.38^2} = 21.35 \text{ ksi}$$

It is suggested that sufficient stiffeners be provided to reduce the lateral bending stress (11.63 ksi). The designed Pad Eye is shown in Figure 6-7.

1. Tie  
Sh  
2. Sc  
De  
rin  
3. Br  
U.  
4. Al  
Str  
5. Ru  
sig




Figure 6-7. Padeye design.

12/12

### References

1. Timoshenko, S. and Woinowsky-Krieger, S., *Theory of Plates and Shells*, McGraw-Hill Book Co., 1959.
2. Schade, H. A., "The Effective Breadth Concept in Ship Structure Design," Annual Meeting of the Society of Naval Architects and Marine Engineers, 1953.
3. Brockenbrough, R. L. and Johnston, B. G., *Steel Design Manual*, U.S. Steel, 1968.
4. AISC, *Specification for the Design, Fabrication and Erection of Structural Steel for Buildings*, 1980.
5. Russo, E. and Hall, R., "Systematic Approach to Lifting Eye Design," Ocean Resources Engineering, Nov. 1977.