والمراوية والمتعاري والمتعاري والمتاريخ

# Tanks, Bins and Hoppers

#### SCOPE

This is a broad classification; covering many types of containers. However, principles and formulas relating to their design are best discussed as a single group. Some of these containers have flat surfaces; some have curved surfaces; some have both. Some carry steam, gasses, or pressurized fluids that exert uniform pressure in all directions; others carry bulk materials such as grain, the weight of which exerts a varying horizontal pressure against the side walls.

anichu t

The first requisite of a container is that it be tight. It must have sufficient strength to withstand the internal pressure to which it is subjected. In arc-welded construction, the joints are made as tight and strong as the plates joined. In large tanks built up from a number of plates or sheets, butt welds are customarily specified.

Many containers must be designed and fabricated according to the minimum requirements of certain codes, for example ASME. Most containers have thin

shells in comparison to their diameters and come under the classification of thin-wall shells.

	 	s of Containers /or Curved Surfaces				
tanks vats hoppers	 drums bins silos	chutes stacks pipe and piping systems and many others				

## 2. ELEMENTS OF THE CONTAINER

The surfaces of any container must withstand pressure of some type, so it would be well to consider the strength and stiffness of various shapes and forms of plates under uniform pressure.

In analysis of a given container, the designer explodes it into its various elements and applies the corresponding formulas.

## Flat Surfaces of Containers

### 3. GENERAL

Some containers are of box construction, made up entirely of flat surfaces. Other containers, many tanks for example, consist of a cylinder closed at each end by a flat plate.


Table 1 presents design formulas applicable to various flat plates subjected to internal pressure.

## Problem I

Determine the required plate thickness of the following tank to hold water, Figure 1.

Since the varying pressure against side walls is due to the weight of a liquid:

$$p = .4336 \text{ H s}$$
  
= .4336(6)(1)  
= 2.6 psi



where:

H = the maximum height of the liquid, in feet

s = the specific gravity of the liquid

It is necessary to consider only the longest side plate, having the greatest span between supports:

## 6.5-2 / Miscellaneous Structure Design

120". The top edge is free, the other three are supported. This is recognized as condition 4D in Table 1. Since the ratio of plate height to width is—

$$\frac{a}{b} = \frac{72}{120} = .6$$

values are estimated from Table I to be-

$$\beta = .14$$
 and  $\gamma = .030$ 

Then the required plate thickness is derived from the maximum stress formula:

$$\sigma_{\max} = \frac{\beta p b^2}{t^2}$$

or, assuming an allowable stress of 20,000 psi-

$$t^{2} = \frac{\beta p b^{2}}{\sigma}$$

$$= \frac{(.14)(2.6)(120)^{2}}{20,000}$$

$$= .262$$

$$\therefore t = \sqrt{.262}$$

$$= .512'', \text{ or use } \frac{1}{2}'' P.$$

Checking the deflection of this plate-


$$\Delta_{\max} = \frac{\gamma p b^4}{E t^3}$$

$$= \frac{(.030)(2.6)(120)^4}{(30 \times 10^6)(.5)^3}$$

$$= 4.3''$$

Since this deflection would be excessive, a stiffening bar must be added along the top edge of the tank to form a rectangular frame, Figure 2.

## Tank with Top Edge Stiffener



The modified tank now satisfies the condition 5A on Table 1, because the critical plate is supported on all four edges.

The ratio of plate height to width still being .6, values are estimated from Table 1 to be—

$$\beta = .102$$
 and  $\gamma = .0064$ 

Since the same maximum stress formula applies-

$$t^{2} = \frac{\beta p b^{2}}{\sigma}$$

$$= \frac{(.102)(2.6)(120)^{2}}{20,000}$$

$$= .191$$

$$t = \sqrt{.191}$$

$$= .437'', \text{ or use } \%_{16}'' \ P.$$

Checking the deflection of this plate-

$$\Delta_{\text{max}} = \frac{\gamma p b^4}{E t^3}$$

$$= \frac{(.0064)(2.6)(120)^4}{(30 \times 10^6)(.4375)^3}$$

$$= 1.37''$$

It might be advisable to go back to the ½" plate thickness, still using the top edge stiffener, in which case the bending stress and deflection would be reduced to—

$$\sigma_{\rm max} = 15{,}300~{
m psi}$$
 and  $\Delta_{\rm max} = .92''$ 

There is another method of determining the bending stress and deflection. A description of this follows immediately.

## Considering Plate Section as a Beam

A narrow section of the tank's side panel (width m=1") can be considered as a beam, Figure 3, using formulas taken from Reference Section 8.1 on Beam Diagrams.




FIGURE 3

# TABLE 1—Stress and Deflection, Flat Plates\* Subjected to Internal Pressure (p), psi

CIRCULAR PLATE



### (1A) Edges supported; uniform load

At center:

(mox) 
$$\sigma_r = \sigma_t = -\frac{1.24 \text{ p } r^2}{t^2}$$

$$\Delta_{\text{max}} = -\frac{.695 \text{ p } r^4}{\text{E } t^2}$$

## (1B) Edges fixed; uniform lood

At center:

$$\sigma_{r} = \sigma_{t} = -\frac{.488 \text{ p } r^{2}}{r^{2}}$$


$$\Delta_{max} = -\frac{.1705 \text{ p } r^{4}}{\text{E } t^{2}}$$

At edge:

$$\sigma_r = \frac{3 p r^2}{4 t^2}$$

$$\sigma_t = \frac{.225 p r^2}{r^2}$$

ELLIPTICAL PLATE



#### (2A) Edges supported; uniform load

At center:

(max) 
$$\sigma_b = -\frac{.3125 (2 - a) p b^2}{r^2}$$
  
(opprox)  $\Delta_{max} = \frac{(.146 - .1 a) p b^4}{E r^2}$ 

### (2B) Edges fixed; uniform load

At center:

$$\sigma_{a} = -\frac{.075 \text{ p b}^{2} (10 \text{ a}^{2} + 3)}{r^{2} (3 + 2 \text{ a}^{2} + 3 \text{ a}^{4})}$$


$$\sigma_{b} = -\frac{.075 \text{ p b}^{2} (3 \text{ a}^{2} + 10)}{r^{2} (3 + 2 \text{ a}^{2} + 3 \text{ a}^{4})}$$

$$\Delta_{max} = -\frac{.1705 \text{ p b}^{4}}{E r^{2} (6 + 4 \text{ a}^{2} + 6 \text{ a}^{4})}$$

At edge:

(Span a) 
$$\sigma_a = \frac{1.5 \text{ p b}^2 \text{ a}^2}{1^2 (3 + 2 \text{ a}^2 + 3 \text{ a}^4)}$$
  
(max)  
(Span b)  $\sigma_b = \frac{1.5 \text{ p b}^2}{1^2 (3 + 2 \text{ a}^2 + 3 \text{ a}^4)}$ 

SQUARE PLATE



## (3B) Edges fixed; uniform load

At center:

$$a_{\bullet} = -\frac{.166 \text{ p } a^2}{t^2}$$

$$\Delta_{\text{max}} = -\frac{.0138 \text{ p } a^4}{\text{E } t^2}$$

At midpoint of each edge:  

$$(max) \sigma_n = + \frac{.308 \text{ p } a^2}{t^2}$$

At center:

$$(mox) \sigma_{s} = -\frac{.2570 \text{ p o}}{t^{2}}$$

$$\Delta_{max} = \frac{.0443 \text{ p o}}{\text{F t}^{3}}$$


<sup>(3</sup>A) Edges supported (and held down); uniform load

# 6.5-4. / Miscellaneous Structure Design

Table I continued

RECTANGULAR PLATES





(4A) Edges supported; uniform load

At center:

$$\sigma_{4} = -\frac{p \ b^{2} \ (.225 \ + \ .382 \ a^{2} \ - \ .320 \ a^{3})}{t^{2}}$$

$$(mox) \ \sigma_{b} = -\frac{.75 \ p \ b^{2}}{t^{2} \ (1 \ + \ 1.61 \ a^{3})} \ or = \frac{\beta \ p \ b^{2}}{t^{2}}$$

$$\Delta_{max} = -\frac{.1422 \ p \ b^{4}}{F \ t^{3} \ (1 \ + \ 2.21 \ a^{3})} \ or = -\frac{\gamma \ p \ b}{F \ t^{3}}$$

(4B) Edges fixed; uniform load

At center:

$$\sigma_{A} = -\frac{.054 \text{ p b}^{2} (1 + 2a^{2} - a^{4})}{r^{2}}$$

$$\sigma_{b} = -\frac{.75 \text{ p b}^{3}}{r^{2} (3 \div 4 a^{4})}$$

$$\Delta_{max} = -\frac{.0284 \text{ p b}^{4}}{\text{E t}^{3} (1 + 1.056 a^{5})} \text{ or } = -\frac{\gamma \text{ p b}^{4}}{\text{E t}^{2}}$$

At midpoint of long edges: 
$$(mox) \ \sigma_b \ = \ \frac{.5 \ p \ b^2}{t^2 \ (1 \ + \ .623 \ a^4)} \ or \ = \ \frac{\beta \ p \ b^2}{t^2}$$


At midpoint of short edges: 
$$\sigma_z \; = \; \frac{.25 \; p \; b^2}{r^2} \label{eq:sigmaz}$$


See the following sub-tables for values of  $\beta$  and  $\gamma$ :

<u>а</u> Ь	1.0	1.1	1.2	1,3	1.4	1.5	1.6	1.7	1.8	1.9	2.0	<b>∞</b>
	FOR EDGES SUPPORTED											
β	.2874	.3318	.3756	.4158	.4518	.4542	.5172	.5448	.5638	.5910	.6102	.7500
γ	.0443	.0530	.0616	.0697	.0770	.0843	.0906	.0964	.1017	.1064	.1106	.1422
					FC	R EDGES I	FIXED	•	•		•	
β	.3078	.3486	.3834	.4122	.4356	.4252	.4680	.4794	.4872	.4932	.4974	
γ	.0138	.0164	.0188	.0209	.0226	.0240	.0251	.0260	.0267	.0272	.0277	

#### (4C) All edges supported; varying laad Load increasing uniformly from zero at one edge to a maximum of (p) psi at apposite edge (triangular load)







The following values apply to Condition 4C;

β .024 .031 .041 .056 .080 .116 .16 .26 .32 .35 .37 .38	<u>o</u> .	.25	.286	.333	.4	.5	.667	1.0	1.5	2.0	2.5	3.0	3.5	4.0
2 00007 00046 00007 0014 0005 0002 027 042 056 043 067 069	· <i>β</i>	.024	.031	.041	.056	.080	.116	.16	.26	.32	.35 ;	.37	.38	.38
7 .00027 .00048 .00083 .0018 .0035 .0083 .022 .042 .035 .035 .007	γ	.00027	.00046	.00083	.0016	.0035	.0083	.022	.042	.056	.063	067	.069	.070

Table I continued on facing page


Table 1 continued

### (4D) Top edge free, other three edges supported; varying load

Load increosing uniformly from zero ot top edge to a maximum of (p) psi at a bottom edge (triongulor load)

$$\sigma_{\text{max}} = \frac{\beta p b^2}{r^2}$$
$$\Delta_{\text{max}} = \frac{\gamma p b^4}{E r^2}$$

The following values apply to Condition 40;



					_				
<u>а</u>	.5	.667	1.0	1.5	2.0	2.5	3.0	3.5	4.0
β	.11	.16	.20	.28	.32	.35	.36	.37	.37
β	.026	.033	.040	.050	.058	.064	.067	.069	.070

Since the maximum bending moment here is-

$$M_{max} = .0642 \text{ p h}^2 \text{ m (with h expressed in inches)}$$
  
= .0642 (2.6)(72)<sup>2</sup>(1)  
= 865 in.-lbs

$$\sigma_{\text{max}} = \frac{M}{s} = \frac{M}{t^2}$$

= 20,800 ps

instead of the 15,300 psi obtained by considering the entire plate width; and—

$$\begin{split} \Delta_{max} &= \frac{.0625 \text{ p h}^4 \text{ m}}{\text{E I}} \\ &= \frac{.0625(2.6)(72)^4(1)(12)}{(30 \times 10^6)(.5)^3} \\ &= 1.39 \text{"} \end{split}$$

instead of the .92" obtained by considering the entire plate width.

This method of isolating a 1" strip of the panel and considering it as a beam will indicate greater bending stress and deflection than actually exists. The reason is that the stiffening effect of the surrounding panel has been neglected for simplicity.

The previous method of considering the entire panel is recommended for its accuracy and for a more efficient design wherever it can be applied.

## Adding Another Stiffener

When a panel is divided into two parts by a large stiffener, it becomes a continuous panel, triangularly loaded with a rather high negative moment at the stiffener which acts as a support. There is no simple formula for this; therefore the method of considering a 1" strip will be used, and of course will result in a slightly greater stress value than actually exists.

The plate thickness in the tank being considered can probably be reduced by adding such a stiffener around the middle of the tank, Figure 4.




FIGURE 4

The first step is to locate the stiffener at the height which will produce the minimum bending moment in the panel, both above and below the stiffener.

## 6.5-6 / Miscellaneous Structure Design

(Again use formulas from Reference Section 8.1 on Beam Diagrams.) This dimension (a), the distance between the two stiffeners, is—

$$a = .57 h = .57(72) = 41''$$

Then, at the middle stiffener-

$$M_{max} = .0147 \text{ p h}^2 \text{ m}$$
  
= .0147 (2.6)(72)<sup>2</sup>(1)  
= 198 in.-lbs

Trying 
$$\frac{\%_6}{\%_6}$$
"  $\stackrel{\square}{\triangleright}$ 

$$\sigma_{\max} = \frac{M}{s} = \frac{M}{t^2}$$

$$= \frac{(198)6}{(\frac{5}{12})^2}$$

$$= \underline{12,200 \text{ psi}} \qquad \text{OK}$$

# Container Surfaces Formed By A Figure of Revolution

## 4. STRESSES IN SHELL

The various container shapes illustrated in Table 2 are formed by a figure of revolution.

In any of these containers, the internal pressure (p) along with the weight of the gas, liquid or other media within the container produces three types of tensile stresses in the container's shell. These are:

1.  $\sigma_{mp}$  = tensile stress in the direction of a

TABLE 2—Container Surfaces Formed By A Figure of Revolution

TH	IN WALL CONT					
CONTAINER SHAPE	UNIT WALL SEGMENT	TENSILE STRESS FORMULAE				
CYLINDER	Q <sub>re</sub> Q <sub>re</sub>	$O_{mp} = \frac{p \cdot r_c}{2 \cdot t_s}$ $O_{cp} = \frac{p \cdot r_c}{c_s}$				
SPHERE ts	and one	$G_{m,\rho} \cdot G_{C,\rho} : \frac{P \cdot r_{C}}{Z \cdot t_{S}}$				
ANY FIGURE OF REVOLUTION	and an	$\frac{\sigma_{c_p}}{r_{e_p}} = \frac{\sigma_m}{r_m} = \frac{\rho}{c_s}$ $\sigma_{m_p} = \frac{\rho}{2c_s}$ $\sigma_{c_p} = \frac{\rho}{c_s} \left(1 - \frac{r_c}{2r_m}\right)$				
CONE	a, la,	$ \mathcal{O}_{mp} = \frac{\rho r_c}{2t_s \cos \alpha} $ $ \mathcal{O}_{cp} = \frac{\rho r_c}{t_s \cos \alpha} $				


meridian. (A meridian is the curve formed by the intersection of the shell and a plane through the longitudinal axis of the container.) This stress is referred to as longitudinal stress.

2.  $\sigma_{\rm cp}$  = tensile stress in the direction of a tangent to a circumference. (A circumference is the curve formed by the intersection of the shell and a plane perpendicular to the longitudinal axis of the container.) This stress is referred to as tangential or circumferential stress but is commonly called the hoop stress.

3.  $\sigma_{rp}$  = tensile stress in the radial direction.

For containers having relatively thin shells (generally considered as less than 10% of the mean radius) and no abrupt change in thickness or curvature, the radial tensile stress ( $\sigma_{\rm rp}$ ) and any bending stress may be neglected.

TABLE 3-Stresses in Thick-Wall Cylinders





The biaxial tensile stresses  $(\sigma_{mp})$  and  $(\sigma_{cp})$  in thin-wall containers can be calculated with the basic formulas shown in Table 2, where:

t<sub>s</sub> = thickness of shell, in.

r<sub>c</sub> = mean radius of a circumference of the shell, in.

 $r_m = mean radius of the meridian of the shell, in.$ 

... -p = internal pressure, psi

#### 5. THICK-WALLED CONTAINERS

In thin-walled containers, the hoop stress is assumed

to be uniformly distributed across the shell thickness without serious error occurring in stress calculations. However, in a thick-walled container generated by a figure of revolution the decreasing variance of hoop stress from the inner surface to the outer surface of the shell wall must be considered.

Table 3 presents formulas for calculating the stresses in two common thick-walled cylinders. In the first condition, the internal pressure parallel to the structural (longitudinal) axis is balanced by the external force against the moving piston and by the resistance of the cylinder's support, and the resultant longitudinal stress ( $\sigma_{mp}$ ) is zero. In the second condition, there is a longitudinal stress ( $\sigma_{mp}$ ).

# Unfired Pressure Vessels

#### 6. ASME CODE—SECTION 8

Any pressure container of any importance undoubtedly must conform to the minimum requirements of the ASME, so it would be well to use ASME Section 8 "Unfired Pressure Vessels" as a guide. In general this covers containers for pressures exceeding 15 psi up to a maximum of 3,000 psi, and having a diameter exceeding 6".

Table 4 presents the formulas for calculating the minimum required wall thickness of cylindrical shells

and spherical shells, where:

p = internal pressure, psi


 $\sigma_a$  = allowable stress (See ASME Sec. 8, par USC-23)

E = joint efficiency (See ASME Sec. 8, par UW-12)

Table 5 presents the formulas for calculating the minimum required thickness of various types of heads. Turn to next page for Table 5.

TABLE 4—Wall Thickness of Shells Subjected to Internal Pressure (p), psi (ASME-8: Unfired Pressure Vessels)

CYLINDRICAL SHELLS (UG-27c and UA-1)




Thin shell — when t.  $< \frac{1}{2}$  r, and p < .385 F. E

$$t_{s} = \frac{p r_{1}}{\sigma_{s} E - .6 p}$$
Thick shell — when  $t_{s} > \frac{1}{2} r_{1}$  and  $p > .385 \sigma_{s} E$ 

$$= r_{1}(\sqrt{Z} - 1)$$
where  $Z = \frac{\sigma_{s} E + p}{2}$ 

SPHERICAL SHELLS (UG-27d and UA-3)




Thin shell — when  $t_{\rm s}$  < .356  $r_{\rm t}$  and p < .665  $\sigma_{\rm s}$  E

$$t_{s} = \frac{p r_{1}}{2(\sigma_{s} E - .1 p)}$$
Thick shell — when  $t_{s} > .356 r_{1}$  and  $p > .665 \sigma_{s} E$ 

$$t_{s} = r_{1}(\sqrt[3]{Y} - 1)$$
where  $Y = \frac{2(\sigma_{s} E + p)}{2 \sigma_{s} E - p}$ 

## TABLE 5—Thickness of Formed Heads Subjected to Internal Pressure (p) on Concave Side (ASME-8: Unfired Pressure Vessels)

ELLIPSOIDAL HEAD (UG-32d and UA-4c)



Standard head — where  $h = d_1/4$ 

(h == minor axis: inside depth of head minus skirt)

$$t_k = \frac{p d_1}{2(\sigma_1 \in -...) p}$$


Head of other proportions

$$t_h = \frac{p \, d_1 \, K}{2(\sigma_e \, E - .1 \, p)}$$

where:

$$K = \frac{1}{6} \left[ 2 + \left( \frac{d_1}{2h} \right)^2 \right]$$

TORISPHERICAL HEAD (UG-329 and UA-4d)



Standard head - where re = .06 rs

(rk == knuckle radius)

$$t_h = \frac{.835 \text{ p r}_0}{\sigma_e \text{ E} - .1 \text{ p}}$$


Head of other proportions

$$t_h = \frac{p r_1 M}{2(\sigma_n E - .1 p)}$$

where

$$M = \frac{1}{4} \left[ 3 + \sqrt{\frac{r_1}{r_k}} \right]$$

HEMISPHERICAL HEAD (UG-32f and UA-3)



Thin head — when  $t_h < .356 r_1$ 

$$t_h = \frac{p r_t}{2(\sigma_a E - .1 p)}$$


Thick head - when th > .356 rt

$$b_1 = c_1 \left( \frac{3}{\sqrt{2}} - 1 \right)$$


where:

$$Y = \frac{2(\sigma_{A} E + p)}{2 \sigma_{A} E - p}$$

FLAT HEAD (UG-34)



c = .30 lop weld  $r_{min} = 3 t_c$ 



tw = twice required thickness of spherical shell or 1.25 t, and not greater than th

$$c = .25$$
bolted

こうけいにはなっている おおないない かんしゅう かっちょう マラック・ウェー

 $t_h = d_1 - \sqrt{\frac{c p}{\sigma_h}}$ 

