
Quick and Easy Installation Instructions for the SunPass® Mini Transponder



FOLLOW THESE 4 EASY STEPS

- Choose location from illustrations shown below.
- 2. Clean area using window cleaner.


Mirror Mounted to Header



Mirror Mounted to Windshield



Large Truck, No Rearview Mirror



3. Peel off backing.





Note: When you apply the Mini to your windshield, be sure to remove all of the air bubbles from under your Mini or it may not work as designed.

4. Apply

Make sure you have the Mini in the right location (Step 1 above) before touching it to the glass. Hold the Mini away from the glass with one hand and press one edge to the glass.





Stick the Mini to the glass by rubbing your thumb up and down in a zigzag motion across the entire Mini surface. Be sure to rub over the Mini's center chip to remove as much air as possible. Step outside your vehicle and look at the Mini through the windshield. If your Mini looks like PHOTO A, with air trapped between the Mini and windshield, continue rubbing the Mini from the center to the edges to remove trapped air.

If your Mini looks like PHOTO B, you're done.





YOU'RE DONE!

After completing these four easy steps you are ready to use your Mini on Florida's toll roads.

- ◆Remember to buckle up and obey the posted roadway speed limits.
- ♦If you have a metalized windshield, please contact the SunPass Customer Service Center for assistance.
- ♦ You **MUST** correctly and permanently install the Mini on the windshield before driving to the toll plaza. Do not attach the Mini to your visor or other temporary location.
- ♦ Do not wave the Mini or hold it inside or outside your vehicle as you approach the toll plaza.
- ♦ Install the Mini when the windshield's temperature is above 50°F (10°C). In colder climates, use your heater/defroster to warm the windshield before installing the Mini. Also, wipe the windshield dry before installing the Mini.

Removing Your Mini

If you want to remove the Mini from your windshield, first peel off the Mini. Then scrape off any remaining residue, and finally clean that area of your windshield with an alcohol wipe or windshield cleaner. Once you remove your Mini, it CANNOT be reused.



Please remember to contact the SunPass Service Center when removing and disposing of your Mini.

SunPass® is a registered trademark of the Florida Department of Transportation.