ZX Spectrum Next Programming Notes

Theodore (Alex) Evans

 $\mathrm{June}\ 1,\ 2022$

Contents

1	Intr	oduct	ion	1
2	\mathbf{Vid}	eo		3
	2.1	Gener	al Features	3
		2.1.1	Video Layering and Transparency	3
		2.1.2	Palette	5
		2.1.3	Scrolling	6
		2.1.4	Clipping	7
	2.2	Layer	1	7
		2.2.1	Colour Attributes	7
		2.2.2	Layer 1 Scrolling	12
		2.2.3	Layer 1 Clipping	13
		2.2.4	ZX Spectrum Mode	13
		2.2.5	Alternate Page Mode	14
		2.2.6	Timex Hi-Colour Mode	15
		2.2.7	Timex Hi-Resolution Mode	16
		2.2.8	Lo-Resolution Mode	17
	2.3	Layer	2	18
		2.3.1	Configuration	18
		2.3.2	Scrolling	21
		2.3.3	Clipping	22
	2.4	Laver	3 (Tileman) Mode	22

iv CONTENTS

		2.4.1	General Description	22
		2.4.2	Data Structures	23
		2.4.3	Memory Organization & Display Layer	24
		2.4.4	Combining ULA & Tilemap	25
		2.4.5	Configuration	25
		2.4.6	Scrolling	29
		2.4.7	Clipping	29
	2.5	Sprite	s	31
		2.5.1	Sprite Patterns	32
		2.5.2	Sprite Palette	34
		2.5.3	Sprite Attributes	35
		2.5.4	Relative Sprites	37
		2.5.5	Programming Sprites	38
		2.5.6	Global Control of Sprites	42
3	Aud	lio		45
	3.1	ZX Sp	pectrum 1-bit	45
	3.2	Sampl	ed 8-bit	45
	3.3	Turbo	sound	46
		3.3.1	Pi Audio	48
4	Bas	ic Inpi	$\mathrm{ut}/\mathrm{Output}$	49
	4.1	Keybo	oard	49
	4.2	Game	Controllers	51
	4.3	Mouse	·	53
	4.4	Keyma	apping	54
		4.4.1	Keyboard	55
		4.4.2	Joystick	55
5	Mei	mory		57
	5.1	·	ry Management	57
			Default Layout	57

CONTENTS	v
----------	---

		5.1.2 RAM	57
		5.1.3 ROM	60
	5.2	Interactions between paging methods	62
	5.3	Memory Map	63
		5.3.1 Global Memory Map	63
		5.3.2 Z80 Visible Memory Map	63
	5.4	Memory Decoding	63
6	zxnl	DMA	65
	6.1	Overview	65
	6.2	Accessing the zxnDMA	65
	6.3	Description	65
	6.4	Modes of Operation	66
	6.5	Programming the zxnDMA $\ \ldots \ \ldots \ \ldots \ \ldots$	66
	6.6	zxnDMA Registers	67
	6.7	Programming examples	72
7	Сор	per and Display Timing	7 9
	7.1	Timing	80
	7.2	Instructions	84
	7.3	Control	86
	7.4	Configuration	88
8	Inte	m rrupts	93
	8.1		93
	8.2	Interrupt Modes	96
	8.3	Z80 CTC	99
9	Seri	al Communication	101
10	$\mathbf{Ras}_{\mathbf{j}}$	pberry Pi0 Acceleration	105
11	Syst	em Software	111

vi	CONTENTS	

	11 1	CP/M	111
	11.1	11.1.1 Utilities	
		11.1.2 BDOS	
		11.1.3 BIOS	
	11.0	11.1.4 Memory Select and Move Functions	
		NextZXOS	
	11.3	NextZXOS	
		11.3.1 +3DOS compatible API	
		11.3.2 esxDOS compatible API	
		11.3.3 Next Extensions	
		11.3.4 esxDOS compatible API	186
\mathbf{A}	Por	${f ts}$	193
	A.1	8-bit	194
	A.2	16-bit	198
В	Reg	isters	205
	B.1	ZX Spectrum Next Registers	205
	B.2	AY-3-8912	233
	В.3	zxDMA	235
\mathbf{C}	Ext	ended Opcodes to Mnemonics	237
	C.1	Single Byte Opcodes	237
	C.2	\$CBxx Bit Operations	241
	C.3	\$DDxx IX	244
	C.4	\$EDxx Block/Port	
	C.5	\$FDxx IY	
	C.6	\$DDCBxx IX Bit Operations	248
	C.7	\$FDCBxx IY Bit Operations	
D	Mne	emonics to Extended Opcodes	249
${f E}$	File	Formats	261

COMPENIE	••
CONTENTS	V11
001,121,12	, 11

E.1 AKY
E.2 BAS
E.3 BMP
E.4 DOT, DOTX, DOTN, DOTN-X
E.5 DSK
E.6 ESP
E.7 GDE
E.8 MOD
E.9 NDR
E.10 NEX
E.11 O
E.12 P3D
E.13 PT3
E.14 P
E.15 SDH
E.16 SID
E.17 SCR
E.18 SHC, MC, MLT
E.19 SHR
E.20 SL2, NXI
E.21 SLR
E.22 SNA
E.23 SND
E.24 SNX
E.25 SPR
E.26 TAP
E.27 TXT,DOC,ASM,INI,CFG,MD
E.28 TZX
E.29 WAV
E.30 XM
E.31 Z3 to Z8

viii	CONTENTS

		Z80	
\mathbf{F}	Call	Tables 26s	9
	F.1	BDOS Call Table	9
	F.2	BIOS Call Table	0
	F.3	NextZXOS Calls	0
		F.3.1 +3DOS Compatible Calls	1
		F.3.2 $+3$ DOS compatible error codes	2
		F.3.3 esxDOS Compatible Calls	3
\mathbf{G}	Key	board Codes 27	5
	G.1	ZX Spectrum Next (keymap data) $\dots \dots \dots$	5
	G.2	PS/2 (keymap address)	6

Chapter 1

Introduction

The ZX Spectrum Next is an extension of the original ZX Spectrum implemented in FPGA which implements many of the common additions to the system includin the characteristics of all of the original ZX Spectrum line, including the Timex/Sinclair 2068, along with a number of characteristics to modernize the design.

This document is an attempt to consolidate the programming interface for the ZX Spectrum Next into a single location. This document started when much of the documentation on the ZX Spectrum Next site (https://www.specnext.com/) was out of date and/or difficult to figure out. The way to figure out how things actually worked was to either dig through the forums and ask questions or find someones code that implemented a particular bit of functionality and reverse engineer it. The situation has greatly improved and this document may even be redundant at this point.

Description from http://www.specnext.com/about/:

The Spectrum Next is fully implemented with FPGA technology, ensuring it can be upgraded and enhanced while remaining truly compatible with the original hardware by using special memory chips and clever design. Here's what under the hood of the machine:

- Processor: Z80n normal and turbo modes
- Memory: 1024Kb RAM (expandable to 2048Kb on board)
- Video: Multilayer video implementing classic ZX Spectrum, Timex Hi-Resolution, Timex Hi-Colour, LoRes, Layer 2, and Tilemap video modes with Hardware sprites
- Video Output: RGB, VGA, HDMI
- Storage: SD Card slot, with DivMMC-compatible protocol
- Audio: ZX Spectrum 1-bit audio, Turbo Sound Next (3x AY-3-8912 audio chips with stereo output), stereo PCM audio, and ability to use Pi

accelerator as a sound source

- Joystick: DB9 compatible with Cursor, Kempston and Interface 2 protocols (selectable)
- \bullet PS/2 port: Mouse with Kempston mode emulation and an external keyboard
- \bullet Special: Multiface functionality for memory access, savegames, cheats etc.
- Tape support: Mic and Ear ports for tape loading and saving
- Expansion: Original external bus expansion port and accelerator expansion port
- Network (optional): Wi Fi module
- Extras: Real Time Clock (optional), internal speaker (optional)

Chapter 2

Video

ZX Spectrum Next video splits the display types into four categories (layer 1 (ULA/Timex/LoRes), layer 2, layer 3 (tilemap) and sprites) which have their own sets of controls for colour palettes, clipping, and scrolling. Some aspects of ULA and tilemap are tied together, but all the rest operate in a largely independent manner using a layering system. The ULA category has a number of separate video modes that it can use. One of these (LoRes) is incompatible with using tilemaps (This may have change in the most recent cores).

2.1 General Features

There are a number of control features for the various video modes that are done in a unified fashion. These features are layering and transparency, palettes, scrolling, and clipping. For the sake of convenience we will occasionally talk about a global coordinate system for graphics on the ZX Next. This coordinate system has (0, 0) at the upper left corner of the usable display area and (319, 255) at the lower right corner. Individual pixels generally correspond to integer locations in this grid, but some modes may either double or halve this grid. This will be discussed in the sections for each of the video layers.

2.1.1 Video Layering and Transparency

Video for the ZX Next is composed of a number of features and layers each of which may have its own set of video modes. Not all of these features are mandatory.

By composing together the border colour and transparency fallback color, layer 1 (ULA, Timex modes, or LoRes), layer 2 ($256 \times 192 \times 256$, $320 \times 256 \times 256$, or

 $640 \times 256 \times 16$), layer 3 (16 or 2 colour tiles), and sprites; we generate the full video display.

The border/transparency fallback is the bottom with the ordering of the layers controlled by a combination of the video layering register (Next register \$15 (21) bits 4-2), the interaction of layers 1 and 3 (Next register \$6B (107) bit 0), and whether or not a pixel in layer 2 is set as a priority colour.

Register (R/W) \$15 (21) \Rightarrow Sprite and Layer System Setup

- bit 7 = LoRes mode (0 on reset)
- bit 6 = Sprite priority (1 = sprite 0 on top, 0 = sprite 127 on top) (0 on reset)
- bit 5 = Enable sprite clipping in over border mode (0 on reset)
- bits 4-2 = set layers priorities (000 on reset)
 - 000 S L U
 - 001 L S U
 - 010 S U L
 - 011 L U S
 - 100 U S L
 - 101 U L S
 - 110 S(U+L) ULA and Layer 2 combined, colours clamped to 7
 - 111 S(U+L-5) ULA and Layer 2 combined, colours clamped to [0,7]
- bit 1 = Enable Sprites Over border (0 on reset)
- bit 0 = Enable Sprites (0 on reset)

Transparency for Layer 2, Layer 1, and 1-bit Tilemaps are controlled by Next register \$14 (20) and defaults to \$E3. Sprites and 4-bit Tilemaps have their own registers (\$4B and \$4C respectively) for setting their transparency index (not colour). This colour ignores the state of the least significant blue bit, so \$E3 equates to both \$1C6 and \$1C7. For Sprites and Tilemaps transparency is determined by colour index. For Sprites this is controlled by register \$4B (with only the least significant 4-bits being relevant for 16-colour Sprites). For Tilemaps, the transparency index is set by register \$4C. If all layers are transparent, the transparency fallback colour is displayed. This is set by register \$4A.

Register (R/W) \$14 (20) \Rightarrow Global transparency color

• bits 7-0 = Transparency color value (\$E3 after a reset)

(Note: this value is 8-bit, so the transparency is compared against only by the MSB bits of the final 9-bit colour)

(Note2: this only affects Layer 2, ULA and LoRes. Sprites use register \$4B for transparency and tilemap uses nextreg \$4C)

Register (R/W) 4A (74) \Rightarrow Fallback Colour Value

• bits 7-0 = 8-bit colour if all layers are transparent (\$E3 on reset)

(black on reset = 0)

Register (R/W) \$4B (75) \Rightarrow Sprite Transparency Index

• bits 7-0 = Index value (\$E3 if reset)

For 4-bit sprites only the bottom 4-bits are relevant.

Register (R/W) \$4C (76) \Rightarrow Level 3 Transparency Index

- bits 7-4 = Reserved, must be 0
- bits 3-0 = Index value (\$0F on reset)

2.1.2 Palette

Next Colour Palettes Each video mode group has a pair of palettes assigned to it a primary and an alternate palette. Each palette entry is actually a 9-bit value (RRRGGGBBB) and can be set by selecting a palette using nextreg \$43 (palette control), the entry using nextreg \$40 (palette index), then writing the value into nextreg \$44 (palette value, 9-bit) using pairs of consecutive writes for each palette value or nextreg \$41 (palette value, 8-bit). Once a palette index has been selected writes automatically increment the palette index number so it is possible to efficiently write the values for a collection of palette entries.

Register (R/W) \$40 (64) \Rightarrow Palette Index Select

• bits 7-0 = Palette Index Number

Selects the palette index to change the associated colour

For ULA only, INKs are mapped to indices 0 through 7, BRIGHT INKs to indices 8 through 15, PAPERs to indices 16 through 23 and BRIGHT PAPERs to indices 24 through 31. In EnhancedULA mode, INKs come from a subset of indices from 0 through 127 and PAPERs from a subset of indices from 128 through 255.

The number of active indices depends on the number of attribute bits assigned to INK and PAPER out of the attribute byte.

In ULAplus mode, the last 64 entries (indices 192 to 255) hold the ULAplus palette. The ULA always takes border colour from PAPER for standard ULA and Enhanced ULA

Register (R/W) \$41 (65) \Rightarrow 8-bit Palette Data

• bits 7-0 = Colour Entry in RRRGGGBB format

The lower blue bit of the 9-bit internal colour will be the logical or of bits 0 and 1 of the 8-bit entry. After each write, the palette index auto-increments if autincrement has been enabled (NextReg \$43 bit 7), Reads do not auto-increment.

Register (R/W) \$43 (67) \Rightarrow Palette Control

• bit 7 = Disable palette write auto-increment.

- bits 6-4 = Select palette for reading or writing:
 - 000 = ULA first palette
 - 100 = ULA second palette
 - -001 = Laver 2 first palette
 - -101 = Layer 2 second palette
 - 010 = Sprite first palette
 - -110 = Sprite second palette
 - -011 = Layer 3 first palette
 - 111 = Layer 3 second palette
- bit 3 = Select Sprite palette (0 = first palette, 1 = second palette)
- bit 2 =Select Layer 2 palette (0 =first palette, 1 =second palette)
- bit 1 = Select ULA palette (0 = first palette, 1 = second palette)
- bit 0 = Enable EnhancedULA mode if 1. (0 after a reset)

Register (R/W) \$44 (68) \Rightarrow 9-bit Palette Data Non Level 2

1st write

- bits 7-0 = MSB (RRRGGGBB) 2nd write
- bits 7-1 = Reserved, must be 0
- bit 0 = LSB(B)

Level 2

1st write

- bits 7-0 = MSB (RRRGGGBB)2nd write
- bit 7 = Priority
- bits 6-1 = Reserved, must be 0
- bit 0 = LSB(B)

9-bit Palette Data is entered in two consecutive writes; the second write autoincrements the palette index if auto-increment is enabled in NextREG \$43 bit 7

If writing an L2 palette, the second write's D7 holds the L2 priority bit which if set (1) brings the colour defined at that index on top of all other layers. If you also need the same colour in regular priority (for example: for environmental masking) you will have to set it up again, this time with no priority.

Reads return the second byte and do not autoincrement. Writes to nextreg \$40, \$41, \$41, or \$43 reset to the first write.

2.1.3 Scrolling

The ZX Spectrum Next has four sets of scrolling registers to independently contol the display offsets of various video modes (Layer2, ULA, Tilemap, and

2.2. LAYER 1 7

LoRes). When the video is offset, the portion that is pushed off the screen (to the left and or top) then becomes visible on the opposite side of the screen so that the video offset values are effectively the coordinates of the origin in a toroidal universe.

2.1.4 Clipping

The ZX Spectrum Next has four clipping registers create a window of the layer that is visible. Clipping is managed by a set of four successive writes to the clipping register applicable for the video mode. If a section is masked off by clipping, it is as if the area were the transparency colour and the video lyers behind it become visible.

2.2 Layer 1

Table	$2.1\cdot$	Laver	1	Mode	summary

rabic 2:1. Eayer 1 mode sammary						
Mode	Resolution	Colour				
ULA	256×192	ULA 8×8				
Timex Alt	256×192	ULA 8×8				
HiCol	256×192	ULA 8×1				
HiRes	512×192	2 colours				
128 Alt	256×192	ULA 8×8				
LoRes	128×96	256 colours				
Rad	128×96	16 colours				

The Layer 1 consists of ZX Spectrum ULA video, Timex video modes, and the Spectrum Next's lores video modes all use 16k memory bank 5 or 7 with the data coming from some combination of addresses \$0000-\$17FF (bitmap 1), \$1800-\$1AFF (attribute 1), \$2000-\$37FF (bitmap 2), and \$3800-\$3AFF (attribute 2) within the selected bank. Assuming default memory mapping and the use of bank 5 this will be mapped as some combination of memory \$4000-\$57FF, \$5800-\$5AFF, \$6000-\$77FF, \$780-\$7AFF. All of the modes other than the lores mode can either use the default ZX Spectrum colours, ULANext mode, or an emulation of ULAplus. In the Spectrum and Timex modes all colours are either Paper (foreground), paper (background), or border colours.

2.2.1 Colour Attributes

The ZX Spectrum Next has three major modes for colour attributes: the ZX Spectrum attribute mapping, which is augmented by using the ZX Spectrum Next's palette; ULANext, which allows the user to how many foreground and

Table 2.2: Layer 1 Memory Map

	BM 1	Attr 1	BM 2	Attr 2	BM a	Attr a
Bank	5	5	5	5	7	7
start	\$0000	\$1800	\$2000	\$3800	\$0000	\$1800
end	\$17FF	\$1AFF	\$37FF	\$3AFF	\$17FF	\$1AFF
ULA	*	*				
Timex Alt			*	*		
HiCol	*		*			
HiRes	*		*			
128 Alt					*	*
LoRes	*		*			
Rad	1		2			

how many background colous are to be selected by the attribute bytes; and an emulation of ULAplus.

ULA Colour In ULA colour INKs are mapped to indices 0-7, Bright INKS to indices 8-15, PAPERs to indices 16-23 and Bright PAPERs to indices 24-31. This is the default state for interpreting ULA palettes.

Table 2.3: ULA Colour								
Bit	7	6	5	4	3	2	1	0
Function	F	В	P_2	P_1	P_0	I_2	I_1	I_0

ULANext The ULANext modes use a varying number of bits from the attribute byte to determine the ink colours as the palette index from the appropriate bits (all others being zero) and the paper colours coming from the indicated value+128 with palette format 255 being a special case where all the bits determine the ink colour while the paper is always palette index 128. The ULA always takes border colour from paper. ULANext is enabled using bit 0 of nextreg \$43 (palette control) and controlled with nextreg \$42 (ULA Next attribute byte format)

ULAplus The ZX Next emulates ULAPlus using the last 64 (192-255) entries of the ULA palette. ULAplus is controlled using two ports: \$BF3B (register port) and \$FF3B (data port)

I/O ports ULAplus is controlled by two ports.

\$BF3B is the register port (write only)

2.2. LAYER 1 9

Table 2.4: ULANext								
Bit	7	6	5	4	3	2	1	0
format 1	P_6	P_5	P_4	P_3	P_2	P_1	P_0	I_0
format 3	P_5	P_4	P_3	P_2	P_1	P_0	I_1	I_0
format 7	P_4	P_3	P_2	P_1	P_0	I_2	I_1	I_0
format 15	P_3	P_2	P_1	P_0	I_3	I_2	I_1	I_0
format 31	P_2	P_1	P_0	I_4	I_3	I_2	I_1	I_0
format 63	P_1	P_0	I_5	I_4	I_3	I_2	I_1	I_0
format 127	P_0	I_6	I_5	I_4	I_3	I_2	I_1	I_0
format 255	I_7	I_6	I_5	I_4	I_3	I_2	I_1	I_0

The byte output will be interpreted as follows:

- Bits 7-6: Select the register group. Two groups are currently available:
 - 00=palette group
 - When this group is selected, the sub-group determines the entry in the palette table (0-63).
 - 01=mode group
 - The sub-group is (optionally) used to mirror the video functionality of Timex port \$FF as follows:
- Bits 5-0: Select the register sub-group Mode group
- Bits 5-3: Sets the screen colour in hi-res mode.
 - 000=Black on White
 - 001=Blue on Yellow
 - 010=Red on Cyan
 - 011=Magenta on Green
 - 100=Green on Magenta
 - 101=Cyan on Red
 - 110=Yellow on Blue
 - 111=White on Black
- Bits 2-0: Screen mode.
 - 000=screen 0 (bank 5)
 - 001=screen 1 (bank 5)
 - -010=hi-colour (bank 5)
 - 100=screen 0 (bank 7)
 - 101=screen 1 (bank 7)
 - 110=hi-colour (bank 7)
 - 110=hi-res (bank 5)
 - 111=hi-res (bank 7)

\$FF3B is the data port (read/write)

When the palette group is selected, the byte written will describe the color.

When the mode group is selected, the byte output will be interpreted as follows:

- Bit 0: ULAplus palette on (1) / off (0)
- Bit 1: (optional) grayscale: on (1) / off (0) (same as turing the color off on the television)

Implementations that support the Timex video modes use the \$FF register as the primary means to set the video mode, as per the Timex machines. It is left to the individual implementations to determine if reading the port returns the previous write or the floating bus.

GRB palette entries G3R3B2 encoding

For a device using the GRB colour space the palette entry is interpreted as follows

- Bits 7-5: Green intensity.
- Bits 4-2: Red intensity.
- Bits 1-0: Blue intensity.

This colour space uses a sub-set of 9-bit GRB. The missing lowest blue bit is set to OR of the other two blue bits (Bb becomes 000 for 00, and Bb1 for anything else). This gives access to a fixed half the potential 512 colour palette. The reduces the jump in intensity in the lower range in the earlier version of the specification. It also means the standard palette can now be represented by the ULAplus palette.

Grayscale palette entries This is an optional ULAPlus feature that is not supported on the Next.

In grayscale mode, each palette entry describes an intensity from zero to 255. This can be achieved by simply removing the colour from the output signal.

Limitations Although in theory 64 colours can be displayed at once, in practice this is usually not possible except when displaying colour bars, because the four CLUTs are mutually exclusive; it is not possible to mix colours from two CLUTs in the same cell. However, with software palette cycling it is possible to display all 256 colours on screen at once.

Emulation The 64 colour mode lookup table is organized as 4 palettes of 16 colours.

Bits 7 and 6 of each Spectrum attribute byte (normally used for FLASH and BRIGHT) will be used as an index value (0-3) to select one of the four colour palettes.

Each colour palette has 16 entries (8 for INK, 8 for PAPER). Bits 0 to 2 (INK) and 3 to 5 (PAPER) of the attribute byte will be used as indexes to retrieve colour data from the selected palette.

2.2. LAYER 1 11

With the standard Spectrum display, the BORDER colour is the same as the PAPER colour in the first CLUT. For example BORDER 0 would set the border to the same colour as PAPER 0 (with the BRIGHT and FLASH bits not set).

The complete index can be calculated as ink_colour = (FLASH * 2 + BRIGHT) * 16 + INK paper_colour = (FLASH * 2 + BRIGHT) * 16 + PAPER + 8

Palette file format The palette format doubles as the BASIC patch loader. This enables you to edit patches produced by other people.

```
;;; 64 colour palette file format (internal) - version 1.0
;;; copyright (c) 2009 Andrew Owen
;;; The palette file is stored as a BASIC program with embedded
;;; machine code
header:
    db 0x00 ; program file
    db 0x14, 0x01, "64colour"; file name
    dw 0x0097; data length
    dw 0x0000; autostart line
    \mbox{dw} \mbox{0x0097} ; program length
basic:
    ;; O RANDOMIZE USR ((PEEK VAL "2
    ;; 3635"+VAL "256"*PEEK VAL "23636"
    ;; )+VAL "48"): LOAD "": REM
    db 0x00, 0x00, 0x93, 0x00, 0xf9, 0xc0, 0x28, 0x28
    db 0xbe, 0xb0, 0x22, 0x32, 0x33, 0x36, 0x33, 0x35
    db 0x22, 0x2b, 0xb0, 0x22, 0x32, 0x35, 0x36, 0x22
    db 0x2a, 0xbe, 0xb0, 0x22, 0x32, 0x33, 0x36, 0x33
db 0x36, 0x22, 0x29, 0x2b, 0xb0, 0x22, 0x34, 0x38
db 0x22, 0x29, 0x3a, 0xef, 0x22, 0x22, 0x3a, 0xea
start:
    di ; disable interrupts
    ld hl, 38 ; HL = length of code
    add hl, bc; BC = entry point (start) from BASIC
    {\tt ld} bc, {\tt 0xbf3b} ; register select
    ld a, 64; mode group
    out (c), a;
    ld a, 1 ;
    ld b, Oxff; choose register port
    out (c), a ; turn palette mode on
    xor a ; first register
setreg:
    1d b, 0xbf ; choose register port
    out (c), a ; select register
    ex af, af'; save current register select
```

```
ld a, (hl); get data
    ld b, Oxff; choose data port
    out (c), a ; set it
    ex af, af'; restore current register
    inc hl ; advance pointer
    inc a ; increase register
    cp 64; are we nearly there yet?
    jr nz, setreg ; repeat until all 64 have been done
    ei ; enable interrupts
    ret ; return
;;; this is where the actual data is stored. The following is an
;;; example palette.
registers:
    db 0x00, 0x02, 0x18, 0x1b, 0xc0, 0xc3, 0xd8, 0xdb ; INK
    db 0x00, 0x02, 0x18, 0x1b, 0xc0, 0xc3, 0xd8, 0xdb; PAPER
   db 0x00, 0x03, 0x1c, 0x1f, 0xe0, 0xe3, 0xfc, 0xff; +BRIGHT db 0x00, 0x03, 0x1c, 0x1f, 0xe0, 0xe3, 0xfc, 0xff;
    db 0xdb, 0xd8, 0xc3, 0xc0, 0x1b, 0x18, 0x02, 0x00;
    db 0xdb, 0xd8, 0xc3, 0xc0, 0x1b, 0x18, 0x02, 0x00 ;
    db 0xff, 0xfc, 0xe3, 0xe0, 0x1f, 0x1c, 0x03, 0x00 ; +BRIGHT/
    db 0xff, 0xfc, 0xe3, 0xe0, 0x1f, 0x1c, 0x03, 0x00; +FLASH
terminating_byte:
    db 0x0d
```

2.2.2 Layer 1 Scrolling

Layer 1 has two sets of scrolling registers. One for the the legacy modes (ZX Spectrum, Alternate Page, Timex Hi-Resoulution, and Timex Hi-colour) and a second set for the two ZX Spextrum Next specific LoRes modes. All modes scroll as if they were 256×192 screens located at global coordinates (32, 32) to (287, 223), The registers for the legacy modes are \$26 and \$27 and the registers for the LoRes modes are \$32 and \$33.

Register (R/W) \$26 (38) \Rightarrow ULA Horizontal Scroll Control

• bits 7-0 = ULA X Offset (0-255) (0 on reset)

Register (R/W) \$27 (39) \Rightarrow ULA Vertical Scroll Control

• bits 7-0 = ULA Y Offset (0-191) (0 on reset)

Register (R/W) \$32 (50) \Rightarrow Layer 1,0 (LoRes) Horizontal Scroll Control)

• bits 7-0 = X Offset (0-255) (\$00 on reset)

Layer 1,0 (LoRes) scrolls in "half-pixels" at the same resolution and smoothness as Layer 2.

Register (R/W) \$33 (51) \Rightarrow Layer 1,0 (LoRes) Vertical Scroll Control)

2.2. LAYER 1 13

• bits 7-0 = Y Offset (0-191) (\$00 on reset)

Layer 1,0 (LoRes) scrolls in "half-pixels" at the same resolution and smoothness as Layer 2.

2.2.3 Layer 1 Clipping

All of the modes in the Layer 1 share a single clipping register, \$1A. The clip index may alternately be set using register \$1C. This is expecially useful for reading the current clipping coordinates as reads on the clipping register do not change the index. Note that clipping coordinates are based on a full display area for the mode of 256×192 resolution even though not all modes have that resolution.

Register (R/W) \$1A (26) \Rightarrow Layer 0 (ULA/LoRes) Clip Window Definition

• bits 7-0 = Coord. of the clip window

1st write = X1 position

2nd write = X2 position

3rd write = Y1 position

4rd write = Y2 position

The values are 0,255,0,191 after a Reset Reads do not advance the clip position

Register (R/W) \$1C (28) \Rightarrow Clip Window Control Read

- bits 7-6 = Layer 3 Clip Index
- bits 5-4 = Layer 0/1 Clip Index
- bits 3-2 =Sprite clip index
- bits 1-0 = Layer 2 Clip Index

Write

- bits 7-4 = Reserved, must be 0
- bit 3 reset Layer 3 clip index
- \bullet bit 2 reset Layer 0/1 clip index
- $\bullet\,$ bit 1 reset sprite clip index.
- bit 0 reset Layer 2 clip index.

2.2.4 ZX Spectrum Mode

 ${\bf Timex\ mode\ 0}$

This is the default ULA mode and has its origins in the original ZX Spectrum. It uses 256×192 pixels located at global coordinates (32, 32) to (287, 223) with 8×8 colour attribute areas mapped into a 32×24 grid. If Timex modes

are not enabled, this and the LoRes mode are the only ones available, so you would switch back to this mode by writing 000xxxxx to Next register \$15 (21, the sprites and layers register). If another Timex mode is enabled, then this is mode 0 so you would write 0 to port \$ff to enable it. This is a 256×192 video mode. The bitmap 1 area is used for selection between ink and paper colours with one bit per pixel and the attribute 1 area for colour attributes.

The easiest way to visualize the mapping of this mode is to think of the 256×192 area as being divided into a 32×24 grid of 8×8 characters. IF we consider X and Y as the position in the grid and R to the the row within the character. For ink/paper selection, 0=paper, 1=ink and the entries are stored left to right as lsb to msb within the bye. The address for a pixel value is: $0R_4R_3Y_2Y_1Y_0R_2R_1R_0C_4C_3C_2C_1C_0$. Each 8×8 cell has its own colour attribute where the address for an attribute cell is $0110R_4R_3R_2R_1R_0C_4C_3C_2C_1C_0$ in other words mapped lineally column-wise starting at the beginning of the attribute 1 area.

Code:

```
;; from any other Timex mode:
ld a,$00
ld c,$ff
out (c),a

;; from LoRes mode:
ld bc,$243B; next register select port
ld a,$15
out (c),a
ld bc,$253B; next register r/w port
in a,(c)
and $7f
out (c),a
```

2.2.5 Alternate Page Mode

Timex mode 1

This mode is the same as ZX Spectrum mode except it is at an alternate addresses. Alternate page mode is selected by enabling Timex modes by writing 00xxxx1xx to Next register \$08 (8, Peripheral 3 setting) then writing 1 to the Timex ULA port (\$ff). It is identical to ZX Spectrum mode except the pixel are mapped to the bitmap 2 area giving use pixel addresses of $1R_4R_3Y_2Y_1Y_0R_2R_1R_0C_4C_3C_2C_1C_0$ and the attributes to the attribute 2 area with addresses of $1110R_4R_3R_2R_1R_0C_4C_3C_2C_1C_0$.

Code:

```
;; disable LoRes mode:
ld bc,$243B ; next register select port
ld a,$15
out (c),a
ld bc,$253B ; next register r/w port
```

2.2. LAYER 1 15

```
in a,(c)
and $7f
out (c),a
;; set Timex mode
1d bc,$243B; next register select port
1d a,$08
out (c),a
1d bc,$253B; next register r/w port
in a,(c)
or $04
out (c),a
;; set alternate page mode
1d c,$ff
1d a,$01
out (c),a
```

2.2.6 Timex Hi-Colour Mode

Timex mode 2

This mode is a 256×192 video mode located at global coordinates (32, 32) to (287, 223) with 8×1 colour attribute mapping on a 32×192 grid. It is selected by writing 2 to the Timex ULA port (\$ff). Pixel mapping in this mode is the same as in ZX Spectrum mode using the bitmap 1 area based on $0R_4R_3Y_2Y_1Y_0R_2R_1R_0C_4C_3C_2C_1C_0$. The colour attributes use the bitmap 2 area with 8×1 colour attribute areas corresponding to the addresses $1R_4R_3Y_2Y_1Y_0R_2R_1R_0C_4C_3C_2C_1C_0$.

Code:

```
;; disable LoRes mode:
ld bc, $243B; next register select port
ld a,$15
out (c),a
ld bc,$253B ; next register r/w port
in a,(c)
and $7f
out (c),a
;; set Timex mode
ld bc,$243B ; next register select port
1d a,$08
out (c),a
ld bc,$253B ; next register r/w port
in a,(c)
or $04
out (c),a
;; set hi-colour mode
ld c,$ff
1d a, $02
out (c),a
```

2.2.7 Timex Hi-Resolution Mode

Timex mode 6

This is a monochrome 512×192 video mode located at global coordinates (32, 32) to (287, 223) with each pixel being half width. It is selected by writing to the Timex ULA port (\$ff with values that also select which two colours (or colour entries in ULANext mode) you use.

OD 11	O =	TT. T	1	α 1
- Table	ソム・	Hi-Reso	dution	('Olourg

Table 2.9. In Resolution Colours							
Port 0xff bits 5-3	Attribute	Ink	Paper				
000	01111000	black	white				
001	01110001	blue	yellow				
010	01101010	red	cyan				
011	01100011	magenta	green				
100	01011100	green	magenta				
101	01010101	cyan	red				
110	01001110	yellow	blue				
111	01000111	white	black				

Pixels are mapped into both the bitmap 1 and bitmap 2 areas where 8-pixel wide character columns alternate between the two bitmap areas. The pixels within a byte being rendered left to right lsb to msb as in other Spectrum video modes. The addresses for each row within a character are based on a 64×32 grid of 8×8 characters which using a 64×24 R, C, and Y scheme gives us addresses of the form $C_0R_4R_3Y_2Y_1Y_0R_2R_1R_0C_5C_4C_3C_2C_1$.

Code:

```
;; disable LoRes mode:
ld bc,$243B ; next register select port
ld a,$15
out (c),a
ld bc,$253B ; next register r/w port
in a,(c)
and $7f
out (c),a
;; set Timex mode
ld bc,$243B ; next register select port
ld a,$08
out (c),a
ld bc,$253B ; next register r/w port
in a,(c)
or $04
out (c),a
;; set hi-res mode, black on white
ld c,$ff
ld a,$06
out (c),a
```

2.2. LAYER 1 17

2.2.8 Lo-Resolution Mode

This is a Spectrum Next specific video mode with a resolution of 128×96 located at global coordinates (32, 32) to (287, 223) with each pixel being double height and double width replacing the old Radistan mode. It can either allow for 16 colours, in which case it uses either the bitmap 1 area or the bitmap 2 area, or 256 colours using both bitmap 1 and bitmap 2. The colour of each pixel can be selected independently with data ordered linearly in a row major fashion. In the case of 16 colour mode, the nybbles describing the colours are X major (MSN LSN). Scrolling is by half pixels and uses different registers (\$32 and \$33) from the rest of the ULA group modes. LoRes mode is enabled by writing 100xxxxxx to Next register \$15 (the sprites and layers register) with Next register \$6A used to decide whether it is 16 or 256 colours.

Register (R/W) \$15 (21) \Rightarrow Sprite and Layer System Setup

```
• bit 7 = LoRes mode (0 on reset)
```

- bit 6 = Sprite priority (1 = sprite 0 on top, 0 = sprite 127 on top) (0 on reset)
- bit 5 = Enable sprite clipping in over border mode (0 on reset)
- bits 4-2 = set layers priorities (000 on reset)
 - 000 S L U
 - 001 L S U
 - 010 S U L
 - 011 L U S
 - 100 U S L
 - 101 U L S
 - 110 S(U+L) ULA and Layer 2 combined, colours clamped to 7
 - 111 S(U+L-5) ULA and Layer 2 combined, colours clamped to [0,7]
- bit 1 = Enable Sprites Over border (0 on reset)
- bit 0 = Enable Sprites (0 on reset)

Register (R/W) \$32 (50) \Rightarrow Layer 1,0 (LoRes) Horizontal Scroll Control)

• bits 7-0 = X Offset (0-255) (\$00 on reset)

Layer 1,0 (LoRes) scrolls in "half-pixels" at the same resolution and smoothness as Layer 2.

Register (R/W) \$33 (51) \Rightarrow Layer 1,0 (LoRes) Vertical Scroll Control)

• bits 7-0 = Y Offset (0-191) (\$00 on reset)

Layer 1,0 (LoRes) scrolls in "half-pixels" at the same resolution and smoothness as Layer 2.

Register (R/W) 6A (106) \Rightarrow Layer 1,0 (LoRes) Control

- bits 7-6 = reserved, must be 0
- bit 5 = Enable Radistan (16-colour) (0 on reset)

- bit 4 = Radistan DFILE switch (xor with bit 0 of port \$ff) (0 on reset)
- bits 3-0 = Radistsan palette offset (0 on reset)
- bits 1-0 = ULAplus palette offset (0 on reset)

Code: 256 colour

```
;; enable LoRes mode:
nextreg $15,$80
;; 256-colour mode
ld bc,$243B; next register select port
ld a,$6A
out (c),a
ld bc,$253B; next register r/w port
in a,(c)
and $EF; lores radistan control
out (c),a
```

Code: 16 colour

```
;; enable LoRes mode:

nextreg $15,$80

;; 16-colour mode

nextreg $6A,$10
```

2.3 Layer 2

Layer 2 is a for bitmapped graphics. It supports modes with $256 \times 192 \times 256$ resolution at global coordinates (32, 32) to (287, 223) mapped linearly left to right/top to bottom, $320 \times 256 \times 256$ resolution at global coordinates (0, 0) to (318, 255) mapped top to bottom/left to right, and $640 \times 256 \times 16$ resolution at global coordinates (0, 0) to (319, 255) with half width pixels mapped so that the nybbles in a byte are adjacent columns (MSN on the left) and bytes running top to bottom/left to right. It can be mapped starting at any 16k memory blocks. The $256 \times 192 \times 256$ mode requires 3 consecutive blocks (48k) while the others use 5 consecutive blocks (80k).

2.3.1 Configuration

Layer 2 is enabled using port \$123B or register \$69. The mode is selected using register \$70. How layer 2 memory is overlaid on main memory is controlled by port \$123B and register \$70. The location in memory is controlled by register \$12 with a shadow area pointed to by register \$13 for double buffering. Finally port \$123B is used to select either the main RAM area or the shadow RAM area for rendering the layer.

```
Port $123B (4667) Layer 2
Bit 4 = 0
```

2.3. LAYER 2 19

```
bits 7-6 = Video RAM bank select
           00 = first 16k
           01 = second 16k
           10 = third 16k
           11 = first 48k
      bit 5 = \text{Reserved}, must be 0
      bit 4 = 0
      bit 3 = Shadow layer 2 select
      bit 2 = \text{Enable layer } 2 \text{ read paging}
      bit 1 = \text{Layer 2} visible (mirrored in register $69)
      bit 0 = \text{Enable layer } 2 \text{ write paging}
Bit 4 = 1
      bits 7-5 = \text{Reserved}, must be 0
      bit 4 = 1
      bit 3 = \text{Reserved}, must be 0
      bit 2-0 = 16k bank relative offset
Register (R/W) $12 (18) \Rightarrow Layer 2 Active RAM bank
   • bits 7-6 = \text{Reserved}, must be 0
   • bits 5-0 = RAM bank (point to bank 8 after a Reset, NextZXOS modifies
      to 9)
Register (R/W) $13 (19) \Rightarrow Layer 2 Shadow RAM bank
   • bits 7-6 = \text{Reserved}, must be 0
   • bits 5-0 = RAM bank (point to bank 11 after a Reset, NextZXOS modifies
      to 12)
Register (R/W) $69 (105) \Rightarrow Display Control 1
   • bit 7 = Layer 2 Enable (Port $123B bit 1 alias)
   • bit 6 = ULA Shadow display enable (Port $7FFD bit 3 alias)
   • bits 5-0 = Timex alias (Port $FF alias)
Register (R/W) $70 (112) \Rightarrow Layer 2 Control
   • bits 7-6 = \text{Reserved}, must be 0
   • bits 5-4 = Resolution (00 on soft reset)
         -00 = 256 \times 192 \times 256
         -01 = 320 \times 256 \times 256
         -10 = 640 \times 256 \times 16
         -11 = Do not use
   • bits 3-0 = Palette offset ($0 on soft reset)
```

Layer 2 256×192 , Write only overlaid on ROM Code:

p_layer2: defl \$123b
start:

```
ld bc,p_layer2
               ; enable, wo, 1st 16k
   ld a,$03
    out (c),a
    call wrtpage
    ld bc,p_layer2
   ld a,$43
                 ; enable, wo, 2nd 16k
   out (c),a
    call wrtpage
   ld bc,p_layer2
                 ; enable, wo, 3rd 16k
   ld a,$83
   out (c),a
   call wrtpage
   ret
wrtpage:
   ld h1,$0000
   ld bc,$0040
                 ; 40*256 writes
loop:
   ld (h1),b
   inc hl
    djnz loop
   dec c
   jr nz,loop
```

Layer 2 256×192 **resolution** Code:

```
r_mmu_7: defl $57
r_disp1: defl $69
r_layer2: defl $70
start:
    nextreg r_disp1,$80 ; enable layer 2
    nextreg r_layer2,$00 ; 256x192x256
    ld a,$12
                            ; page 18=bank 9
loop1:
    nextreg r_mmu_7,a
                         ; map page into slot 7
                           ; 20*256 = 8k
    ld bc,$0020
    ld hl, $E000
                           ; address of slot 7
loop2:
    ld (h1),b
    inc hl
    djnz loop2
    dec c
    jp NZ,loop2
    inc a
    cp $18
                            ; stop at page 24
    jp NZ,loop1
```

Layer 2 320×256 **resolution** Code:

```
r_mmu_7: defl $57
r_disp1: defl $69
r_layer2: defl $70
start:
    nextreg r_disp1,$80 ; enable layer 2
    nextreg r_layer2,$10 ; 320x256x256
```

2.3. LAYER 2 21

```
1d a,$12
                        ; page 18=bank 9
loop1:
    nextreg r_mmu_7,a
                      ; map page into slot 7
                       ; 20*256 = 8k
    ld bc,$0020
                        ; start of slot 7
    ld h1,$E000
loop2:
   ld (h1),b
    inc hl
    djnz loop2
    dec c
    jp NZ,loop2
    inc a
    cp $1C
                         ; stop at page 28
    jp NZ,loop1
```

Layer 2 640×256 **resolution** Code:

```
r_mmu_7: defl $57
r_disp1: defl $69
r_layer2: defl $70
start:
   nextreg r_disp1, $80 ; enable layer 2
   nextreg r_layer2, $20 ; 640x256x16
   ld a, $12
            ; page 18=bank 9
loop1:
   nextreg r_mmu_7, a ; map page into slot 7
   loop2:
   ld (hl), b
   inc hl
   djnz loop2
   dec c
   jp NZ, loop2
   inc a
   cp $1C
             ; stop at page 28
   jp NZ, loop1
```

2.3.2 Scrolling

Scrolling Layer 2 is controlled by registers \$16 and \$17. (Is there a third scrolling register for layer 2?)

Register (R/W) \$16 (22) \Rightarrow Layer 2 Horizontal Scroll Control

• bits 7-0 = X Offset (0-255)(0 on reset)

Register (R/W) \$17 (23) \Rightarrow Layer 2 Vertical Scroll Control

 \bullet bits 7-0 = Y Offset (0-191)(0 on reset)

2.3.3 Clipping

The Clip area for is based on the local coordinate system for the mode in question and is set using register \$18 with the option of selection which write in active using register \$1C.

Register (R/W) \$18 (24) \Rightarrow Layer 2 Clip Window Definition

• bits 7-0 = Coords of the clip window

1st write - X1 position

2nd write - X2 position

3rd write - Y1 position

4rd write - Y2 position

Reads do not advance the clip position The values are 0,255,0,191 after a Reset

Register (R/W) \$1C (28) \Rightarrow Clip Window Control Read

- bits 7-6 = Layer 3 Clip Index
- bits 5-4 = Layer 0/1 Clip Index
- bits 3-2 = Sprite clip index
- bits 1-0 = Layer 2 Clip Index

Write

- bits 7-4 = Reserved, must be 0
- bit 3 reset Layer 3 clip index
- bit 2 reset Layer 0/1 clip index
- bit 1 reset sprite clip index.
- bit 0 reset Layer 2 clip index.

2.4 Layer 3 (Tilemap) Mode

Started with documentation by Phoebus Dokos, February 25, 2019. Partially rewritten for clarity and to add core 3.00.00 features.

2.4.1 General Description

The tilemap is a hardware character oriented display. It uses a set of user defined 4-bit, 16-colour, or 1-bit, 2-colour 8×8 tiles. The tiles can be dispplayed in two resolutions: 40×32 tiles (320×256 pixels) and 80×32 tiles (640×256 pixels).

The display area on screen is the same as the sprite layer, meaning it overlaps the standard 256×192 area by 32 pixels on all sides. Vertically this is larger than the physical HDMI display, which will cut off the top and bottom character

rows making the visible area 40×30 or 80×30 , but the full area is visible on VGA.

The obvious application for the tilemap is for a fast, clearly readable and wide multicoloured character display. Less obvious perhaps is that it can also be used to make fast and wide resolution full colour backgrounds with easily animated components such as have historically been used in many games.

The tilemap is defined by two data structures and configured using four NextRegs. The NextRegs are \$6b (107), Tilemap Control; \$6c (108), Default Tilemap Attribute, \$6c (110); Tilemap Base Address; and \$6d (111) Tile Definitions Base Address.

2.4.2 Data Structures

Tilemap The first data structure is the tilemap itself which indicates what characters occupy each cell on screen. Each tilemap entry is either one or two bytes.

If entries are two bytes each, the first byte for each entry is bits 0-7 of the tile number, while the second byte is an attribute byte which is interpreted acctording to the mode set in the tilemap control register (\$6b). For 40×32 resolution, a full size tilemap will occupy 2560 bytes, and for 80×32 resolution the space taken is twice that at 5120 bytes. The tilemap entries are stored in X-major order and each two-byte tilemap entry consists of a tile number byte (bits 0-7 of the tile number) followed an attribute byte:

Tilemap Attribute Byte 4-bit

bits 7-4: most significant 4-bits of palette entry

bit 3: x mirror bit 2: y mirror bit 1: rotate

bit 0: ULA over tilemap (in 512 tile mode, bit 8 of the tile number)

Tilemap Attribute Byte 1-bit

bits 7-1: most significan 7-bits of palette entry

bit 0: ULA over tilemap (in 512 tile mode, bit 8 of the tile number)

The character displayed is indicated by the "tile number" which can be thought of as an ASCII code. The tile number is normally eight bits allowing up to 256 unique tiles to be displayed but this can be extended to nine bits for 512 unique tiles if 512 tile mode is enabled via the Tilemap Control register (\$6b).

The other bits are tile attributes that modify how the tile image is drawn. Their function is the same as the equivalent sprite attributes for sprites. Bits apply rotation then mirroring, and colour can be shifted with a palette offset. If 512 tile mode is not enabled, bit 8 will determine if the tile is above or below the

ULA display on a per tile basis.

When using 1-byte tilemap entries, the map consists of the tile numbers for tile in the map with the tilemap attribute byte for every tile coming from the default tilemap attribute register (\$6c).

Tile Definitions The second data structure is the tile definitions themselves. To find the difinition for a specific tile you would look at (base address) + (tile number) * (definition size).

For 4-bit, 16-colour, tiles, each 8×8 tile takes up 32 bytes. Each pixel uses four bits to select one of 16 colours. A tile is defined in X major order with packing in the X direction in the same way that 4-bit sprites are defined. The 4-bit colour of each pixel is augmented by the 4-bit palette offset from the tilemap in the most significant bits to form an 8-bit colour index that is looked up in the tilemap palette to determine the final 9-bit colour sent to the display. Ane of the 16 colours for each tile is the transparency color.

For 1-bit, 2-colour, tiles, each 8×8 tile takes up 8 bytes. Each pixel uses one bit to select one of two colours. A tile is defined in X major order with packing in the X direction. The 1-bit colour of each pixel is augmented by the 7-bit palette offset from the tilemap in the most significant bits to form an 8-bit colour index that is looked up in the tilemap palette to determine the final 9-bit colour sent to the display. Transparency for each tile is according to the global transparency colour.

The tilemap display surface extends 32 pixels around the central 256×192 display. The origin of the clip window is the top left corner of this area 32 pixels to the left and 32 pixels above the central 256×192 display. The X coordinates are internally doubled to cover the full 320 pixel width of the surface. The clip window indicates the portion of the tilemap display that is non-transparent and its indicated extent is inclusive; it will extend from X1*2 to X2*2+1 horizontally and from Y1 to Y2 vertically.

Bit 0 can be set to choose stencil mode for the combined output of the ULA and tilemap. Bit 6 determines what colour is used in SLU modes 6 & 7 where the ULA is combined with Layer 2 to generate highlighting effects.

2.4.3 Memory Organization & Display Layer

The tilemap is a logical extension of the ULA and its data structures are contained in 16k banks 5 and 7 (first half only). If both the ULA and tilemap are enabled, this means that the tilemap's map and tile definitions should be arranged within the 24k to avoid overlap with the display ram used by the ULA.

The tilemap exists on the same display layer as the ULA. The graphics generated by the ULA and tilemap are combined before being forwarded to the SLU layer

system as layer U.

2.4.4 Combining ULA & Tilemap

The combination of the ULA and tilemap is done in one of two modes: the standard mode or the stencil mode.

The standard mode uses bit 8 of a tile's tilemap entry to determine if a tile is above or below the ULA. The source of the final pixel generated is then the topmost non-transparent pixel. If the ULA or tilemap is disabled then they are treated as transparent.

The stencil mode will only be applied if both the ULA and tilemap are enabled. In the stencil mode, the final pixel will be transparent if either the ULA or tilemap are transparent. Otherwise the final pixel is a logical AND of the corresponding colour bits. The stencil mode allows one layer to act as a cut-out for the other.

2.4.5 Configuration

Register (R/W) \$68 (104) \Rightarrow ULA Control

- bit 7 = Disable ULA output (0 on reset)
- bit 6-5 = Color blending control for layering modes 6 & 7 (3.01.01)
 - -00 = ULA as blend colour
 - -01 = No blending
 - -10 = ULA/Tilemap mix result as blend colour
 - -11 = Tilemap as blend colour
- bit 4 = Cancel entries in 8x5 matrix for extended keys (3.01.04)
- bit 3 = Enable ULAplus (0 on reset)
- bit 2 = Enable ULA half pixel scroll (0 on reset) may change
- bit 1 = Reserved (must be 0)
- bit 0 = Enable stencil mode (0 on reset)
 When ULA and Layer 3 are enabled, if either are transparent, the result is transparent, otherwise the result is the logical AND of both colours.

Bit 0 controls how Layer 1 (ULA) and Layer 3 are combined. If cleared they are combined in the normal manner. Priority and transparency determine which of the two is shown. Setting enables stencil mode.

Register (R/W) $$6B (107) \Rightarrow Layer 3 (Tilemap) Control$

- bit 7 = Layer 3 Enable (0 on reset)
- bit 6 = Layer 3 Size control (0 on reset)
 - -0 = 40x32
 - -1 = 80x32

- bit 5 = Disable Arribute Entry (0 on reset)
- bit 4 = palette select (0 on reset)
- bit 3 = Enable Text mode (1-bit tilemap) (0 on reset)
- bit 2 =Reserved, must be 0
- bit 1 = Activate 512 tile mode (0 on reset)
- bit 0 = Enable Layer 3 on top of ULA (0 on reset)

Bits 7 & 6 enable the tilemap and select resolution. Bit 4 selects one of two tilemap palettes used for final colour lookup. Bit 5 changes the structure of the tilemap so that it contains only 8-bit tilemap entries instead of 16-bit tilemap entries. If 8-bit, the tilemap only contains tile numbers and the attributes are instead taken from nextreg \$6C.

Bit 5 determines whether the attribute byte for each tile come from the tilemap (0) or from the default tile attribute register (1).

Bit 4 selects either the primary tilemap palette (0) or the secondary tilemap palette (1).

Bit 3 selects whether to use 4-bit, 16-colour, or 1-bit 2-colour tiles.

Bit 1 activates 512 tile mode. In this mode, the "ULA over tilemap" bit in a tile's attribute is re-purposed as the ninth bit of the tile number, allowing up to 512 unique tiles to be displayed. In this mode, the ULA is always on top of the tilemap.

Bit 0 forces the tilemap to be on top of the ULA. It can be useful in 512 tile mode to change the relative display order of the ULA and tilemap.

Register (R/W) 6C (108) \Rightarrow Default Layer 3 Attribute*

- bits 7-4 = Palette Offset (\$00 on reset)
- bit 3 = X mirror (0 on reset)
- bit 2 = Y mirror (0 on reset)
- bit 1 = Rotate (0 on reset)
- bit 0 = Bit 8 of the tile number (512 tile mode) (0 on reset)
- bit 0 = ULA over tilemap (256 tile mode) (0 on reset)

If bit 5 of nextreg \$6B is set, the tilemap structure is modified to contain only 8-bit tile numbers instead of the usual 16-bit tilemap entries. In this case, the tile attributes used are taken from this register instead.

Register (R/W) 6E (110) \Rightarrow Layer 3 Tilemap Base Address

- bit 7 = Bank Select (3.01.08)
 - $0={\rm Bank}\; 5$
 - $1={\rm Bank}\ 7$
- bit 6 = Reserved, must be 0
- bits 5-0 = MSB of address of the tile map in Bank 5 (16k) or 7 (8k) (\$2C on reset)

^{*}Active tile attribute if bit 5 of nextreg \$6B is set.

Soft Reset default \$2C - This is because the address is \$6C00 so the MSB is \$6C. But the stored value is only the lower 6 bits so it's an offset into the 16k Bank 5. To calculate therefore subtract \$40 leaving you with \$2C.

The value written is an offset into the 16k Bank 5 or the 8k lower half of Bank 7 allowing the tilemap to be placed at any multiple of 256 bytes.

This register determines the tile mapis base address in bank 5. The base address is the MSB of an offset into the 16k bank, allowing the tile map to begin at any multiple of 256 bytes in the bank. Writing a physical MSB address in \$40-\$7f or \$c0-\$ff, corresponding to traditional ULA physical addresses, is permitted. The value read back should be treated as a fully significant 8-bit value.

The tilemap will be 40×32 or 80×32 in size depending on the resolution selected in nextreg \$6B. Each entry in the tilemap is normally two bytes but can be one byte if attributes are eliminated by setting bit 5 of nextreg \$6B.

Register (R/W) f (111) \Rightarrow Layer 3 Tile Definitions Base Address

- bit 7 = Select bank (3.01.08)
 - 0 = Bank 5
 - 1 = Bank 7
- bit 6 = Reserved, must be 0
- bits 5-0 = MSB of address of the tile definitions in Bank 5 (16k) or 7 (8k) (\$0C on reset)

Soft Reset default \$0C - This is because the address is \$4C00 so the MSB is \$4C. But the stored value is only the lower 6 bits so it's an offset into the 16k Bank 5. To calculate therefore subtract \$40 leaving you with \$0C.

The value written is an offset into the 16k Bank 5 or the 8k lower half of Bank 7 allowing the tilemap to be placed at any multiple of 256 bytes.

This register determines the base address of tile definitions in bank 5. As with nextreg \$6E, the base address is the MSB of the an offset into the 16k bank, allowing tile definitions to begin at any multiple of 256 bytes in the bank. Writing a physical MSB address in \$40-\$7f or \$c0-\$ff, corresponding to traditional ULA physical addresses, is permitted. The value read back should be treated as a fully significant 8-bit value.

Each tile definition is 32 bytes in size and is located at address: Tile Def Base Addr + 32 * (Tile Number)

Register (R/W) \$4C (76) \Rightarrow Level 3 Transparency Index

- bits 7-4 = Reserved, must be 0
- bits 3-0 = Index value (\$0F on reset)

Defines the transparent colour index for 4-bit tiles. The 4-bit pixels of a tile definition are compared to this value to determine if they are transparent. In the case of 1-bit tiles transparency is determined by comparing the final pixel colour against the global transparency colour.

For palette information see palette section.

```
40x32 Tilemap, no attributes
            defl $4000
screen:
ulaattr:
            defl $5800
tilemap:
            defl $5b00
   org $8000
start:
    дi
    ;; load tile descriptions
    ld hl,tilemap
    ld bc,$0005
    xor a
.loop:
    ld (h1),a
    inc hl
    djnz .loop
    dec c
    jp NZ,.loop
    ld de,tilemap+$0500
    ld hl,tiles
    \begin{array}{c} \textbf{1d} & \textbf{bc,tiles\_end-tiles} \end{array}
    ldir
    ;; setup tilemap mode
                       ; tile transparency index \mathbf{0}
    nextreg $4c,$00
    nextreg $6b,$a0
                         ; enable tilemap 40x32, no attributes, \hookleftarrow
        palette 0
    nextreg $6c,$00
                        ; default attr, tilemap over ula
                        ; tilemap starts at $5b00
    nextreg $6e,$1b
                        ; tile definition start at $6000
    nextreg $6f,$20
    nextreg $43,$30
                          ; set select tilemap palette and primary \hookleftarrow
       palette
    nextreg $40,$00
                          ; palette index 0
    ;; write palette
    ld hl,palette
    1d b,$20
.loop:
    ld a,(h1)
    inc hl
    nextreg $44,a
    djnz .loop
    ;; write tiles
    ld bc,$1010
    ld hl,tilemap+12+8*40
    xor a
.loop:
    ld (hl),a
    inc hl
    inc a
    djnz .loop
    add hl, 40-16
    ld b,$10
    dec c
```

```
jp NZ,.loop
    ;; setup background (ULA attributes)
    ld hl,ulaattr+11+6*32
    1d a,$78
    ld bc,$0a09
.loop:
    ld (hl),a
    inc hl
    djnz .loop
    ld b,$0a
    add hl,32-10
    dec c
    jp NZ,.loop
    ;; infinite loop
.loop:
    jp .loop
    ;; Tile patterns
    include "tiles.asm"
tiles_end:
    ;; Palette data
palette:
    include "palette.asm"
```

2.4.6 Scrolling

Scrolling Layer 3 is controlled by registers \$2F, \$30, and \$31.

Register (R/W) \$2F (47) \Rightarrow Layer 3 (Tilemap) Horizontal Scroll Control MSB

- bits 7-2 = Reserved, must be 0
- bits 1-0 = X Offset MSB (\$00 on reset)

Meaningful Range is 0-319 in 40 char mode, 0-639 in 80 char mode

Register (R/W) \$30 (48) \Rightarrow Layer 3 (Tilemap) Horizontal Scroll Control LSB

• bits 7-0 = X Offset LSB (\$00 on reset)

Meaningful range is 0-319 in 40 char mode, 0-639 in 80 char mode

Register (R/W) \$31 (49) \Rightarrow Layer 3 (Tilemap) Vertical Scroll Control

• bits 7-0 = Y Offset (0-255) (\$00 on reset)

2.4.7 Clipping

The Clip area for is based on the local coordinate system for the mode in question and is set using register \$18 with the option of selection which write in active using register \$1C.

Register (R/W) \$1B (27) \Rightarrow Layer 3 (Tilemap) Clip Window Definition

• bits 7-0 = Coord. of the clip window

1st write = X1 position 2nd write = X2 position 3rd write = Y1 position 4rd write = Y2 position

The values are 0,159,0,255 after a Reset Reads do not advance the clip position The X coords are internally doubled.

Register (R/W) \$1C (28) \Rightarrow Clip Window Control Read

- bits 7-6 = Layer 3 Clip Index
- bits 5-4 = Layer 0/1 Clip Index
- bits 3-2 =Sprite clip index
- bits 1-0 = Layer 2 Clip Index

Write

- bits 7-4 = Reserved, must be 0
- bit 3 reset Layer 3 clip index
- bit 2 reset Layer 0/1 clip index
- bit 1 reset sprite clip index.
- bit 0 reset Layer 2 clip index.

Changes Since 2.00.26

- 1. 512 Tile Mode. In 2.00.26, the 512 tile mode was automatically selected when the ULA was disabled. With the ULA disabled, the tilemap attribute bit "ULA on top" was re-purposed to be bit 8 of the tile number. In 2.00.27, selection of the 512 tile mode is moved to bit 1 of Tilemap Control nextreg \$6B. This way 512 tile mode can be independently chosen without disabling the ULA. The "ULA on top" bit is still taken as bit 8 of the tile number and in the 512 mode, the tilemap is always displayed underneath the ULA.
- 2. Tilemap Always On Top of ULA. In 2.00.27, bit 0 of Tilemap Control nextreg \$6B is used to indicate that the tilemap should always be displayed on top of the ULA. This allows the tilemap to display over the ULA when in 512 mode.
- 3. 1-bit tile maps. In 3.00.00, a number of modifications were made to accomidate 1-bit tile maps.
- 4. Bank select. In 3.01.08 bit 7 of both Tilemap Base Address nextreg \$6E and Tile Definitions Base Address nextreg \$6F enabled selecting bewteen bank 5 (16k) and bank 7 (8k). Before this Layer 3 exclusively used bank 5.

Future Direction The following compatible changes may be applied at a later date:

1. Addition of a bit to Tilemap Control to select a reduced tilemap area of size 32×24 or 64×24 that covers the ULA screen.

2.5 Sprites

February 25, 2019 Victor Trucco

The Spectrum Next has a hardware sprite system with the following characteristics:

- Total of 128 sprites
- \bullet Display surface is 320×256 overlapping the ULA screen by 32 pixels on each side
- Minimum of 100 sprites per scanline*
- Choice of 512 colours for each pixel
- Site of each sprite is 16×16 pixels but sprites can be magnified $2 \times$, $4 \times$ or $8 \times$ horizontally and vertically
- Sprites can be mirrored and rotated
- Sprites can be grouped together to form larger sprites under the control of a single anchor
- A 16K pattern memory can contain 64 8-bit sprite images or 128 4-bit sprite images and combinations in-between
- A per sprite palette offset allows sprites to share images but colour them differently
- A nextreg interface allows the copper to move sprites during the video frame

The actual limit is determined by how many 28MHz clock cycles there are in a scanline. The sprite hardware is able to plot one pixel cycle and uses one cycle to qualify each sprite. Since the number of cycles there are in a scanline varies with video timing (HDMI, VGA), the number of pixels that can be plotted also varies but the minimum will be 1600 pixels per line including overhead cycles needed to qualify 100 sprites. Since sprites magified horizontally involve plotting more pixels, $2\times$, $4\times$, and $8\times$ sprites will take more cycles to plot and the presence of these sprites in a line will reduce the total number of sprites that can be plotted.

^{*}A minimum of $100\ 16 \times 16$ sprites is guaranteed to be displayed in any scanline. Any additional sprites will not be displayed with the hardware ensuring sprites are not partially plotted.

2.5.1 Sprite Patterns

Sprite patterns are the images that each sprite can take on. The images are stored in a 16K memory internal to the FPGA and are identified by pattern number. A particular sprite chooses a pattern by storing a pattern number in its attributes.

All sprites are 16×16 pixels in size but the come in two flavours: 4-bit and 8-bit. The bit width describes how many bits are used to code the colour of each pixel.

An 8-bit sprite uses a full byte to colour each of its pixels so that each pixel can be one of 256 colours. In this case, a 16×16 sprite requires 256 bytes of pattern memory to store its image.

A 4-bit sprite uses a nibble to colour each of its pixels so that each pixel can be one of 16 colours. In this case, a 16×16 sprite requires just 128 bytes of pattern memory to store its image.

The 16K pattern memory can contain any combination of these images, whether they are 128 bytes or 256 bytes and their locations in the pattern memory are described by a pattern number. This pattern number is 7 bits with bits named as follows:

Pattern Number

N5 N4 N3 N2 N1 N0 N6

N6, despite the name, is the least significant bit.

This 7-bit pattern number can identify 128 patterns in the 16k pattern memory, each of which are 128 bytes in size. The full 7-bits are therefore used for 4-bit sprites.

For 8-bit sprites, N6=0 always. The remaining 6 bits can identify 64 patterns, each of which is 256 bytes in size.

The N5:N0,N6 bits are stored in a particular sprite's attributes to identify which image a sprite uses.

8-Bit Sprite Patterns The 16×16 pixel image uses 8-bits for each pixel so that each pixel can be one of 256 colours. One colour indicates transparency and this is programmed into the Sprite Transparency Index register (nextreg \$4B). By default the transparent value is \$E3.

As an example of an 8-bit sprite, let's have a look at figure 1.1.

Using the default palette, which is initialised with RGB332 colours from 0-255, the hexadecimal values for this pattern arranged in a 16×16 array are shown



Figure 2.1: Pattern Example

below:

04040404040404E3E3E3E3E3E3E3E3E3 04FFFFFFFFF04E3E3E3E3E3E3E3E3 04FFFBFBFBFF04E3E3E3E3E3E3E3E3E3 04FFFBF5F5FBFF04E3E3E3E3E3E3E3E3 04FFFBF5A8A8FBFF04E3E3E3E3E3E3E3 04FFFFBA844A8FBFF04E3E3E3E3E3 040404FFFBA844A8FBFF04E3E3E3E3 E3E3E304FFFBA84444FBFF04E304E3E3 E3E3E3E304FFFB444444FBFF044D04E3 E3E3E3E3O4FFFB4444444FA4D04E3 E3E3E3E3E3E304FFFB44FFF54404E3E3 E3E3E3E3E3E3E3O4FF44F5A8O4E3E3E3 E3E3E3E3E3E3E3E3O4FA44O4A8O4E3E3 E3E3E3E3E3E3E3O44D4D04E304F504E3 E3E3E3E3E3E3E3E30404E3E3E304FA04 E3E3E3E3E3E3E3E3E3E3E3E3E30404

Here \$E3 is used as the transparent index.

These 256 bytes would be stored in pattern memory in left to right, top to bottom order.

4-Bit Sprite Patterns The 16×16 pixel image uses 4-bits for each pixel so that each pixel can be one of 16 colours. One colour indicates transparency and this is programmed into the lower 4-bits of the Sprite Transparency Index register (nextreg \$4B). By default the transparency value is \$3. Note that the same register is shared with 8-bit patterns to identify the transparent index.

Since each pixel only occupies 4-bits, two pixels are stored in each byte. The leftmost pixel is stored in the upper 4-bits and the rightmost pixel is stored in the lower 4-bits.

As an example we will use the same sprite image as was given in the 8-bit pattern example. Here only the lower 4 bits of each pixel is retained to confine each pixel's color to 4-bits:

4444443333333333

```
4FFFF433333333
4FBBBF433333333
4FB58BF43333333
4FFB848BF4333333
44FB848BF433333
344FB844BF43433
33334FB44444AD43
333334FB4444AD43
3333334FB44444AD43
3333334FB44444AD43
3333334FB44444AD43
33333334FB458433
3333334FB458433
```

\$3 is used as the transparent index.

These 128 bytes would be stored in pattern memory in left to right, top to bottom order.

The actual colour that will appear on screen will depend on the palette, described below. The default palette will not likely generate suitable colours for 4-bit sprites.

2.5.2 Sprite Palette

Each pixel of a sprite image is 8-bit for 8-bit patterns or 4-bit for 4-bit patterns. The pixel value is known as a pixel colour index. This colour index is combined with the sprite's palette offset. The palette offset is a 4-bit value added to the top 4-bits of the pixel colour index. The purpose of the palette offset is to allow a sprite to change the colour of an image.

The final sprite colour index generated by the sprite hardware is then the sum of the pixel index and the 4-bit palette offset. In pictures using binary math:

```
8-bit Sprite
PPPP0000
+ IIIIIIII
-----
SSSSSSS
4-bit Sprite
PPPP0000
+ 0000III
------
SSSSSSS = PPPPIIII
```

Where "PPPP" is the 4-bit palette offset from the sprite's attributes and the "I's represent the pixel value from the sprite pattern. The final sprite index is represented by the 8-bit value "SSSSSSSS".

For 4-bit sprites the palette offset can be thought of as selecting one of 16 different 16-colour palettes.

This final 8-bit sprite index is then passed through the sprite palette which acts like a lookup table that returns the 9-bit RGB333 colour associated with the sprite index.

At power up, the sprite palette is initialized such that the sprite index passes through unchanged and is therefore interpretted as an RGB332 colour. The missing third blue bit is generated as the logical OR of the two other blue bits. In short, for 8-bit sprites, the sprite index also acts like the colour when using the default palette.

2.5.3 Sprite Attributes

A sprite's attributes is a list of properties that determine how and where the sprite is drawn.

Each sprite is described by either 4 or 5 attribute bytes listed below:

Sprite Attribute 0

x x x x x x x x

The least significant eight bits of the sprite's X coordinate. The ninth bit is found in sprite attribute 2.

Sprite Attribute 1

Y Y Y Y Y Y Y

The least significant eight bits of the sprite's Y coordinate. The ninth bit is optional and is found in attribute 4.

Sprite Attribute 2

P P P P XM YM R X8/PR

P = 4-bit Palette Offset

XM = 1 to mirror the sprite image horizontally

YM = 1 to mirror the sprite image vertically

R = 1 to rotate the sprite image 90 degrees clockwise

X8 = Ninth bit of the sprite's X coordinate

PR = 1 to indicate P is relative to the anchor's palette offset (relative sprites only)

Rotation is applied before mirroring.

Relative sprites, described below, replace X8 with PR.

Sprite Attribute 3

V E N5 N4 N3 N2 N1 N0




Figure 2.2: All Rotate and Mirror Flags

V = 1 to make the sprite visible

E = 1 to enable attribute byte 4

N = Sprite pattern to use 0-63

If E=0, the sprite is fully described by sprite attributes 0-3. The sprite pattern is an 8-bit one identified by pattern N=0-63. The sprite is an anchor and cannot be made relative. The sprite is displayed as if sprite attribute 4 is zero.

If E=1, the sprite is further described by sprite attribute 4.

Sprite Attribute 4

A. Extended Anchor Sprite

H N6 T X X Y Y Y8

H = 1 if the sprite pattern is 4-bit

N6 = 7th pattern bit if the sprite pattern is 4-bit

T = 0 if relative sprites are composite type else 1 for unified type

XX = Magnification in the X direction (00 = 1×, 01 = 2×, 10 = 4 × 4, 11 = 8×)

YY = Magnification in the Y direction (00 = 1×, 01 = 2×, 10 = 4×, 11 = 8×)

Y8 = Ninth bit of the sprite's Y coordinate

H,N6 must not equal 0,1 as this combination is used to indicate a relative sprite.

B. Relative Sprite, Composite Type

0 1 N6 X X Y Y PO

N6 = 7th pattern bit if the sprite pattern is 4-bit

XX = Magnification in the X direction ($00 = 1 \times$, $01 = 2 \times$, $10 = 4 \times$, $11 = 8 \times$)

YY = Magnification in the Y direction (00 = 1×, 01 = 2×, 10 = 4×, 11 = 8×)

PO = 1 to indicate the sprite pattern number is relative to the anchor's

C. Relative Sprite, Unified Type

0 1 N6 0 0 0 0 PO

N6 = 7th pattern bit if the sprite pattern is 4-bit

PO = 1 to indicate the sprite pattern number is relative to the anchor's

The display surface for sprites is 320×256 . The X coordinate of the sprite is nine bits, ranging over 0-511, and the Y coordinate is optionally nine bits again ranging over 0-511 or is eight bits ranging over 0-255. The full extent 0-511 wraps on both axes, meaning a sprite 16 pixels wide plotted at X coordinate 511 would see its first pixel not displayed (coordinate 511) and the following pixels displayed in coordinates 0-14.

The full display area is visible in VGA. However, the HDMI display is vertically shorter so the top eight pixel rows (Y = 0-7) and the bottom eight pixel rows (Y = 248-255) will not be visible on an HDMI display.

Sprites can be fully described by sprite attributes 0-3 if the E bit in sprite attribute 3 is zero. These sprites are compatible with the original sprite module from core versions prior to 2.00.26.

If the E bit is set then a fifth sprite attribute, sprite attribute 4, becomes active. This attribute introduces scaling, 4-bit patterns, and relative sprites. Scaling is self-explanatory and 4-bit patterns were described in the last section. Relative sprites are described in the next section.

2.5.4 Relative Sprites

Normal sprites (sprites that are not relative) are known as anchor sprites. As the sprite module draws sprites in the order 0-127 (there are 128 sprites), it internally stores characteristics of the last anchor sprite seen. If following sprites are relative, they inherit some of these characteristics, which allows relative sprites to have, among other things, coordinates relative to the anchor. This means moving the anchor sprite also causes its relatives to move with it.

There are two types of relative sprites supported known as "Composite Sprites" and "Unified Sprites". The type is determined by the anchor in the T bit of sprite attribute 4.

A. Composite Sprites

The sprite module records the following information from the anchor:

- Anchor.visible
- Anchor.Y
- Anchor.palette offset
- Anchor.N (pattern number)
- Anchor.H (indicates if the sprite uses 4-bit patterns)

These recorded items are not used by composite sprites:

- Anchor.rotate
- Anchor.xmirror
- Anchor.ymirror
- Anchor.xscale
- Anchor.yscale

The anchor determines if all its relative sprites use 4-bit patterns or not.

The visibility of a particular relative sprite is the result of ANDing the anchor's visibility with the relative sprite's visibility. In other words, if the anchor is invisible then so are all its relatives.

Relative sprites only have 8-bit X and Y coordinates (the ninth bits are taken for other purposes). These are signed offsets from the anchor's X,Y coordinate. Moving the anchor moves all its relatives along with it.

If the relative sprite has its PR bit set in sprite attribute 2, then the anchor's palette offset is added to the relative sprite's to determine the active palette offset for the relative sprite. Otherwise the relative sprite uses its own palette offset as usual.

If the relative sprite has its PO bit set in sprite attribute 4, then the anchor's pattern number is added to the relative sprite's to determine the pattern used for display. Otherwise the relative sprite uses its own pattern number as usual. The intention is to supply a method to easily animate a large sprite by manipulating the pattern number in the anchor.

A composite sprite is like a collection of independent sprites tied to an anchor.

B. Unified Sprites

Unified sprites are a further extension of the composite type. The same information is recorded from the anchor and the same behaviour as described under composite sprites applies.

The difference is the collection of anchor and relatives is treated as if it were a single 16×16 sprite. The anchor's rotation, mirror, and scaling bits apply to all its relatives. Rotating the anchor causes all the relatives to rotate around the anchor. Mirroring the anchor causes the relatives to mirror around the anchor. The sprite hardware will automatically adjust X,Y coords and rotation, scaling and mirror bits of all relatives according to settings in the anchor.

Unified sprites should be defined as if all its parts are 16×16 in size with the anchor controlling the look of the whole.

A unified sprite is like a big version of an individual 16×16 sprite controlled by the anchor.

2.5.5 Programming Sprites

Sprites are created via three io registers and a nextreg interface.

Port \$303B (12347) Sprite Slot/Flags

Write: Sprite Slot Select

select sprite slot for Sprite Attribute and Sprite Pattern ports which independently auto-increment

Read: Sprite status

bits 7-2 = reserved

bit 1 = Max sprites per line

bit 0 = Collision flag

```
X S S S S S S S N6 X N N N N N N N
```

A write to this port has two effects.

One is it selects one of 128 sprites for writing sprite attributes via port \$57.

The other is it selects one of 128 4-bit patterns in pattern memory for writing sprite patterns via port \$5B. The N6 bit shown is the least significant in the 7-bit pattern number and should always be zero when selecting one of 64 8-bit patterns indicated by N.

```
Port $57 (87) Sprite Attributes
Byte 1
      bits 7-0 = LSB of X coordinate (bit 8 is in byte 3)
Byte 2
      bits 7-0 = LSB of Y coordinate (bit 8 is in byte 5)
Byte 3
      bits 7-4 = Palette Offset
      bit 3 = \text{Enable X Mirror}
      bit 2 = \text{Enable Y Mirror}
      bit 1 = \text{Enable Roration}
      bit 0 = By Sprite Type
           Anchor = MSB of X coordinate
           Relative = Enable relative palette offset
Byte 4
      bit 7 = \text{Enable visibility}
      bit 6 = \text{Enable Byte } 5
      bit 5-0 = Pattern Index ("name")
Byte 5 (optional)
Anchor
      bit 7-6 = type and pattern
           00 = 8-bit color
           01 = \text{relative}
           10 = 4-bit color, lower half of pattern (bytes 0-127)
           11 = 4-bit color, upper half of pattern (byets 128-255)
      bit 5 = \text{Attached relative sprite type}
           0 = composite
           1 = \text{big sprite}
      bit 4-3 = X-axis scale factor
           00 = 1 \times
           01 = 2 \times
           10 = 4 \times
```

```
11 = 8 \times
      bit 2-1 = Y-axis scale factor
      bit 0 = MSB of Y coordinate
Composite Relative
      bits 7-6 = 01
      bit 5 = N6
      8-bit
            Reserved, must be 0
      4-bit
           0 = \text{lower half of pattern (bytes 0-127)}
            1 = \text{upper half of pattern (bytes } 128-255)
      bit 4-3 = X-axis scale factor
      bit 2-1 = Y-axis scale factor
      bit 0 = \text{Enable relative pattern offset}
Big-sprite Relative
      bits 7-6 = 01
      bit 5 = N6
      8-bit
            Reserved, must be 0
      4-bit
           0 = \text{lower half of pattern (bytes 0-127)}
            1 = \text{upper half of pattern (bytes } 128-255)
      bit 4-1 = \text{Reserved}, must be 0
      bit 0 = \text{Enable relative pattern offset}
```

Once a sprite is selected via port \$303B, its attributes can be written to this port one byte after another. Sprites can have either four or five attribute bytes and the internal attribute pointer will move onto the next sprite after those four or five attribute bytes are written. This means you can select a sprite via port \$303B and write attributes for as many sequential sprites as desired. The attribute pointer will roll over from sprite 127 to sprite 0.

Port \$5B (91) Sprite Pattern

Load data into sprite pattern memory auto-incrementing. Port \$303B can be used to set the starting sprite pattern number.

Once a pattern number is selected via port \$303B, the 256-byte or 128-byte pattern can be written to this port. The internal pattern pointer auto-increments after each write so as many sequential patterns as desired can be written. The internal pattern pointer will roll over from pattern 127 to pattern 0 (4-bit patterns) or from pattern 63 to pattern 0 (8-bit patterns) automatically.

Port \$303B (R)

M = 1 if the maximum number of sprites per line was exceeded

C = 1 if any two displayed sprites collide on screen

Reading this port automatically resets the M and C bits.

Besides the i/o interface, there is a nextreg interface to sprite attributes. The nextreg interface allows the copper to manipulate sprites and grants the program random access to a sprite's individual attribute bytes.

Register (R/W) \$34 (52) \Rightarrow Sprite Number Lockstep (NextReg \$09 bit 4 set)

- bit 7 = Pattern address offset (Add 128 to pattern address)
- bits 6-0 = Sprite number 0-127, Pattern number 0-63 effectively performs an out to port \$303B

No Lockstep (NextReg \$09 bit 4 clear)

- bit 7 =Reserved, must be 0
- bits 6-0 = Sprite number 0-127

This register selects which sprite has its attributes connected to the sprite attribute registers

Register (W) \$35 (53) \Rightarrow Sprite Attribute 0

• bits 7-0 = Sprite X coordinate LSB (MSB in NextReg \$37)

Register (W) \$75 (117) \Rightarrow Sprite Attribute 0 (Auto-incrementing) See nextreg \$35

Register (W) \$36 (54) \Rightarrow Sprite Attribute 1

• bits 7-0 = Sprite Y coordinate LSB (MSB in NextReg \$39)

Register (W) \$76 (118) \Rightarrow Sprite Attribute 1 (Auto-incrementing) See nextreg \$36

Register (W) \$37 (55) \Rightarrow Sprite Attribute 2

- bits 7-4 = 4-bit Palette offset
- bit 3 = Enable horizontal mirror (reverse)
- bit 2 = Enable vertical mirror (reverse)
- bit $1 = \text{Enable } 90^{O} \text{ Clockwise Rotation}$

Normal Sprites

• bit 0 = X coordinate MSB

Relative Sprites

• bit 0 = Palette offset is relative to anchor sprite

Rotation is applied before mirroring

Register (W) \$77 (119) \Rightarrow Sprite Attribute 2 (Auto-incrementing) See nextreg \$37

Register (W) \$38 (56) \Rightarrow Sprite Attribute 3

- bit 7 = Enable Visiblity
- bit 6 = Enable Attribute 4 (0 = Attribute 4 effectively \$00)
- bits 5-0 = Sprite Pattern Number

Register (W) \$78 (120) \Rightarrow Sprite Attribute 3 (Auto-incrementing) See nextreg \$38

Register (W) \$39 (57) \Rightarrow Sprite Attribute 4 Normal Sprites

- bit 7 = 4-bit pattern switch (0 = 8-bit sprite, 1 = 4-bit sprite)
- bit 6 = Pattern number bit-7 for 4-bit, 0 for 8-bit
- bit 5 = Type of attached relative sprites (0 = Composite, 1 = Unified)
- bits 4-3 = X scaling (00 = 1x, 01 = 2x, 10 = 4x, 11 = 8x)
- bits 2-1 = Y scaling (00 = 1x, 01 = 2x, 10 = 4x, 11 = 8x)
- bit 0 = MSB of Y coordinate

Relative, Composite Sprites

- bit 7-6 = 01
- bit 5 = Pattern number bit-7 for 4-bit, 0 for 8-bit
- bits 4-3 = X scaling (00 = 1x, 01 = 2x, 10 = 4x, 11 = 8x)
- bits 2-1 = Y scaling (00 = 1x, 01 = 2x, 10 = 4x, 11 = 8x)
- bit 0 = Pattern number is relative to anchor

Relative, Unified Sprites

- bit 7-6 = 01
- bit 5 = Pattern number bit-7 for 4-bit, 0 for 8-bit
- bits 4-1 = 0000
- bit 0 = Pattern number is relative to anchor

Register (W) \$79 (121) \Rightarrow Sprite Attribute 4 (Auto-incrementing) See nextreg \$39

2.5.6 Global Control of Sprites

The following nextreg are also of interest for sprites.

Register (R/W) \$09 (9) \Rightarrow Peripheral 4 setting:

- bit 7 = PSG 2 Mono Enable (0 on hard reset)
- bit 6 = PSG 1 Mono Enable (0 on hard reset)
- bit 5 = PSG 0 Mono Enable (0 on hard reset)
- bit 4 = Sprite ID lockstep enable (1 = Nextreg \$34 and IO Port \$303B are in lockstep, 0 on reset)
- bit 3 = divMMC mapRAM bit Control (reset bit 7 of port \$E3)
- bit 2 = HDMI audio mute (0 on hard reset)

```
• bits 1-0 = scanlines

-00 = scanlines off

-01 = scanlines 12.5\%

-10 = scanlines 25\%

-11 = scanlines 50\%
```

In Sprite lockstep, NextREG \$34 and Port \$303B are in lockstep

Register (R/W) \$15 (21) \Rightarrow Sprite and Layer System Setup

```
• bit 7 = LoRes mode (0 on reset)
```

- bit 6 = Sprite priority (1 = sprite 0 on top, 0 = sprite 127 on top) (0 on reset)
- bit 5 = Enable sprite clipping in over border mode (0 on reset)
- bits 4-2 = set layers priorities (000 on reset)

```
- 000 - S L U
- 001 - L S U
- 010 - S U L
```

– 011 - L U S

- 100 - U S L - 101 - U L S

- 110 - S(U+L) ULA and Layer 2 combined, colours clamped to 7

- 111 - S(U+L-5) ULA and Layer 2 combined, colours clamped to $[0,\!7]$

- bit 1 = Enable Sprites Over border (0 on reset)
- bit 0 = Enable Sprites (0 on reset)

The sprite module draws sprites in the order 0-127 in each scanline. Bit 6 determines whether sprite 0 is topmost or sprite 127 is topmost.

Bits 4:2 determine layer priority and how sprites overlay or are obscured by other layers.

Register (R/W) \$19 (25) \Rightarrow Sprite Clip Window Definition

```
bits 7-0 = Cood. of the clip window
1st write - X1 position
2nd write - X2 position
3rd write - Y1 position
4rd write - Y2 position
```

The values are 0,255,0,191 after a Reset Reads do not advance the clip position

When the clip window is enabled for sprites in "over border" mode, the X coords are internally doubled and the clip window origin is moved to the sprite origin inside the border.

When the clip window is enabled for sprites in "over border" mode, the X coords are internally doubled and the clip window origin is moved to the sprite origin inside the border.

Sprites will only be visible inside the clipping window. When not in over-

border mode (bit 1 of nextreg \$15) the clipping window is given in ULA screen coordinates with 0,0 correspoding to the top left corner of the ULA screen. In over-border mode, the clipping window's origin is moved to the sprite coordinate origin 32 pixels to the left and 32 pixels above the ULA screen origin.

Regardless, sprite position is always in sprite coordinates with 32,32 corresponding to the top left corner of the ULA screen.

Register (R/W) \$1C (28) \Rightarrow Clip Window Control Read

- bits 7-6 = Layer 3 Clip Index
- bits 5-4 = Layer 0/1 Clip Index
- bits 3-2 = Sprite clip index
- bits 1-0 = Layer 2 Clip Index

Write

- bits 7-4 = Reserved, must be 0
- bit 3 reset Layer 3 clip index
- bit 2 reset Layer 0/1 clip index
- bit 1 reset sprite clip index.
- bit 0 reset Layer 2 clip index.

Register (R/W) \$4B (75) \Rightarrow Sprite Transparency Index

• bits 7-0 = Index value (\$E3 if reset)

For 4-bit sprites only the bottom 4-bits are relevant.

Chapter 3

Audio

3.1 ZX Spectrum 1-bit

The baseline sound of the ZX Spectrum was produced by toggling the Ear bit (bit 4) of \$fe (254) The ULA port to produce 1-bit audio. It is enabled by bit 4 of Next register \$08 (8). While this does work on the ZX Spectrum Next, there are other much better methods and this is only supported for backward compatibility.

Code:

```
;; enable internal speaker
ld bc,$243B
ld a,$08
out (c),a
ld bc,$253B
in a,(c)
or $10
out (c),a
```

3.2 Sampled 8-bit

The ZX Next has four 8-bit D/A audio channels connected to provide sampled stereo sound. Channels A and B are the left channels, while C and D are the right channels. In order use 8-bit sound, it must first be enabled by setting bit 3 on nextreg \$08. In order to emulate legacy hardware there are a number of ports that can be used to control the four channels additionally these are mirrored to three nextregs to enable driving audio using the copper. Channel A is mapped to ports \$0f, \$3f, and \$f1; channel B to ports \$1f and \$f3 and nextreg \$2C; channel C to ports \$4f, and \$f9 and nextreg \$2E; and channel D to: \$5f

and \$fb; with port \$df connected to both channel A and C and nextreg \$2D connected to both channel A and D.

Code:

```
;; enable SpecDrum/Convox audio
ld bc,$243B
ld a,$08
out (c),a
ld bc,$253B
in a,(c)
or $08
out (c),a
```

3.3 Turbosound

TurboSound consists of the implementation of three AY-3-8912 chips. To enable TurboSound set bit 1 of Next Register \$08 (8). Once enabled the sound chips and registers of the sound chips are selected using port \$fffd (65533) TurboSound Next Control while the registers are accessed using \$bffd () Sound Chip Register Access. To enable access to a particular chip write 1111111xx to the control register where 01=AY1, 10=AY2, and 11=AY3. Access to particular registers of the selected chip is selected by writing the register number to the control register. You can then access a chip register using the access port.

Code:

```
;; enable TurboSound audio
ld bc,$243B
ld a,$08
out (c),a
ld bc,$253B
in a,(c)
or $02
out (c),a
```

Each of the three AY chips has three channels, A, B, and C whose mapping is controlled by bit 5 of Next register 0x08 (8).

```
Register (R/W) $00 (0) \Rightarrow Channel A fine tune
Register (R/W) $01 (1) \Rightarrow Channel A coarse tune (4 bits)
Register (R/W) $02 (2) \Rightarrow Channel B fine tune
Register (R/W) $03 (3) \Rightarrow Channel B coarse tune (4 bits)
Register (R/W) $04 (4) \Rightarrow Channel C fine tune
Register (R/W) $05 (5) \Rightarrow Channel C coarse tune (4 bits)
Register (R/W) $06 (6) \Rightarrow Noise period (5 bits)
```

Register (R/W) $$07 (7) \Rightarrow$ Tone Enable

- bit 5 = Channel C tone enable (0=enable, 1=disable)
- bit 4 = Channel B tone enable (0=enable, 1=disable)
- bit 3 = Channel A tone enable (0=enable, 1=disable)
- bit 2 = Channel C noise enable (0=enable, 1=disable)
- bit 1 = Channel B noise enable (0=enable, 1=disable)
- bit 0 = Channel A noise enable (0=enable, 1=disable)

Register (R/W) $$08 (8) \Rightarrow$ Channel A amplitude

- bit 4 = enable fixed amplitude
 - -0 =fixed amplitude
 - -1 = use envelope generator (bits 0-3 ignored)
- bits 3-0 = value of fixed amplitude

Register (R/W) \$09 (9) \Rightarrow Channel B amplitude

- bit 4 = enable fixed amplitude
 - -0 = fixed amplitude
 - -1 = use envelope generator (bits 0-3 ignored)
- bits 3-0 = value of fixed amplitude

Register (R/W) $$0A\ (10) \Rightarrow Channel C amplitude$

- bit 4 = enable fixed amplitude
 - -0 =fixed amplitude
 - -1 =use envelope generator (bits 0-3 ignored)
- bits 3-0 = value of fixed amplitude

Register (R/W) 0B (11) \Rightarrow Envelope period fine

Register (R/W) $OC(12) \Rightarrow Envelope period coarse$

Register (R/W) 0D (13) \Rightarrow Envelope shape

- bit 3 = Continue
 - -0 = drop to amplitude 0 after 1 cycle
 - -1 = use 'Hold' value
- bit 2 = Attack
 - -0 = generator counts down
 - -1 = generator counts up
- bit 1 = Alternate

hold = 0

- -0 = generator resets after each cycle
- 1=generator reverses direction each cycle

hold=1

- -0 = hold final value
- -1 = hold initial value
- bit 0 = Hold
 - -0 =cycle continuously

-1 = perform one cycle and hold

3.3.1 Pi Audio

If connected the Pi Zero is configured to use the ZX Next as a sound card over an $\rm\,I^2S$ interface making the Raspberry Pi a fully configurable audio source for the ZX Spectrum Next.

Chapter 4

Basic Input/Output

The basic I/O (human interface) system of the ZX Spectrum Next supports keyboard, mouse and game controllers. These all extend the functionality found on common ZX Spectrum peripherals. game controllers and PS/2 keyboards can be customized to simulate responses on the stock keyboard.

4.1 Keyboard

The ZX Spectrum Next can use a classic ZX Spectrum keyboard with a 8×5 matrix, an extended ZX Spectrum Next keyboard with a 8×7 matrix (the one used in a cased Next or the custom cases for the N-Go), or a PS/2 keyboard. In all of these cases the system translates the physical signals to look like a classic Spectrum keyboard with access to the additional lines of the ZX Spectrum Next keyboard as well.

The classic Spectrum part of the matrix is accessed using port \$xxFE where there is a single unset bit in "xx" to select the row being read. Next extensions are read using Nextregs \$B0 and \$B1 to read columns 5 and 6.

Bit	0	1	2	3	4	\$B0	\$B1	b
\$FEFE	Cap Sh	Z	X	С	V	\Rightarrow	Extend	0
\$FDFE	A	S	D	\mathbf{F}	G	←	Cap Lk	1
\$FBFE	Q	W	\mathbf{E}	R	Т	₩	Graph	2
\$F7FE	1	2	3	4	5	1	True Vid	3
\$FBFE	0	9	8	7	6		Inv Vid	4
\$EFFE	P	О	I	U	Y	,	Break	5
\$DFFE	Enter	L	K	J	Н	"	Edit	6
\$BFFE	Space	Sym Sh	Μ	Ν	В	;	Del	7

```
Port $7FFE (32766) Keyboard 8 (read only)
     bit 0: 'B'
     bit 1: 'N'
     bit 2: 'M'
     bit 3: Symbol Shift
     bit 4: Space
Port $BFFE (49150) Keyboard 7 (read only)
     bit 0 = 'H'
     bit 1 = 'J'
     bit 2 = K'
     bit 3 = L'
     bit 4 = Enter
Port $DFFE (57342) Keyboard 6 (read only)
     bit 0 = Y'
     bit 1 = 'U'
     bit 2 = I'
     bit 3 = 'O'
     bit 4 = P'
Port $EFFE (61438) Keyboard 5 (read only)
     bit 0 = 6'
     bit 1 = '7'
     bit 2 = '8'
     bit 3 = '9'
     bit 4 = 0
Port $F7FE (63486) Keyboard 4 (read only)
     bit 0 = 5
     bit 1 = '4'
     bit 2 = '3'
     bit 3 = '2'
     bit 4 = '1'
Port $FBFE (64510) Keyboard 3 (read only)
     bit 0 = T
     bit 1 = R'
     bit 2 = E'
     bit 3 = \text{'W'}
     bit 4 = 'Q'
Port $FDFE (65022) Keyboard 2 (read only)
     bit 0 = G'
     bit 1 = F'
```

```
bit 2 = \text{`D'}

bit 3 = \text{`S'}

bit 4 = \text{`A'}

Port $FEFE (65278) Keyboard 1 (read only)

bit 0 = \text{`V'}

bit 1 = \text{`C'}

bit 2 = \text{`X'}

bit 3 = \text{`Z'}

bit 4 = \text{Caps Shift}

Register (R) $B0 (176) \Rightarrow Extended Keys 0 (3.01.04)

• bit 7 = 1 if; pressed

• bit 6 = 1 if pressed

• bit 5 = 1 if, pressed

• bit 4 = 1 if, pressed
```

- bit 3 = 1 if UP pressed
- bit 2 = 1 if DOWN pressed
- bit 1 = 1 if LEFT pressed
- bit 0 = 1 if RIGHT pressed

Register (R) \$B1 (177) \Rightarrow Extended Keys 1 (3.01.04)

- bit 7 = 1 if DELETE pressed
- bit 6 = 1 if EDIT pressed
- bit 5 = 1 if BREAK pressed
- bit 4 = 1 if INV VIDEO pressed
- bit 3 = 1 if TRUE VIDEO pressed
- bit 2 = 1 if GRAPH pressed
- bit 1 = 1 if CAPS LOCK pressed
- bit 0 = 1 if EXTEND pressed

4.2 Game Controllers

The ZX Spectrum used a number of joystick standards and the ZX Spectrum Next can make Atari controllers or Mega Drive controllers look like many of these standards. Atari joystick and driving (not the similar looking paddle) controllers are supported by the interface. The interface supports Mega Drive controllers with up to 11 buttons (start, a, b, c, x, y, z, up, down, left, right). It is possible to map unused buttons to keys and simulate unavailable buttons with keys.

Nextreg \$05 selects the interface mode for each of the two joysticks. If in Kempston or Megadrive mode the joystick 1 can be read using port \$1F and joystick 2 using port \$37. When using these ports in Megadrive mode, some

buttons will be paired A/X, B/Y, C/Z with B/Y also corresponding to the single fire button on Atari joysticks. In order to disambiguate presses of A/X, B/Y, and C/Z it is necessary to also read nextreg B2.

Port \$1F (31) Kempston/Mega Drive Joystick 1/DAC A Read

```
bit 7 = "start" button
bit 6 = A/X button
bit 5 = C/Z button
bit 4 = Fire/C/Y button
bit 3 = Up
bit 2 = Down
bit 1 = Left
bit 0 = Right
```

Disable with Nextreg \$05 Write

bits 7-0 = DAC Value

The XYZ buttons on md pads can be read through nextreg 0xB2.

The joysticks can also be placed in i/o mode see nextreg 0x0B.

All eleven md pad buttons can be assigned to the keyboard see nextreg 0x05. Port \$37 (55) Kempston/Mega Drive Joystick 2

Read

```
bit 7 = "start" button
bit 6 = A/X button
bit 5 = C/Z button
bit 4 = Fire/C/Y button
bit 3 = Up
bit 2 = Down
bit 1 = Left
bit 0 = Right
```

The XYZ buttons on md pads can be read through nextreg 0xB2.

The joysticks can also be placed in i/o mode see nextreg 0x0B.

All eleven md pad buttons can be assigned to the keyboard see nextreg 0x05.

Register (R/W) 05 (5) \Rightarrow Peripheral 1 Settings

```
bits 7-6 = joystick 1 mode (MSB)
bits 5-4 = joystick 2 mode (MSB)
bit 3 = joystick 1 mode (LSB)
bit 2 = 50/60 Hz mode (0 = 50Hz, 1 = 60Hz)
bit 1 = joystick 2 mode (LSB)
bit 0 = Enable Scandoubler
```

Joystick modes

4.3. MOUSE 53

- 000 = Sinclair 2 (67890)
- 001 = Kempston 2 (port \$37)
- 010 = Kempston 1 (port \$1F)
- 011 = Megadrive 1 (port \$1F)
- 100 = Cursor
- 101 = Megadrive 2 (port \$37)
- 110 = Sinclair 1 (12345)
- 111 = User Defined Keys Joystick
- * Joysticks can be placed in i/o mode via nextreg 0x0B.
- * Programming the user defined keys joystick is done through the ps2 keymap interface on nextreg 0x28, 0x29 and 0x2B:
- 1. Write 128 to nextreg 0x28
- 2. Write 0 (left joystick) or 16 (right joystick) to nextreg 0x29
- 3. Write eleven bytes to nextreg 0x2B. The bytes correspond to the eleven buttons on an md pad (X=11~Z~Y~START~A~C~B~U~D~L~R=1)
- 4. Each byte written identifies a key in the 8x7 membrane; bits 5:3 select the row and bits 2:0 select the column with 111 meaning no action.

 In all joystick modes, excess buttons on an md pad not read via ports will generate key input if so programmed.

Register (R) $B2 (178) \Rightarrow Extended MD Pad Buttons (3.01.10)$

- bit 7 = 1 if Right Pad X Pressed
- bit 6 = 1 if Right Pad Z Pressed
- bit 5 = 1 if Right Pad Y Pressed
- bit 4 = 1 if Right Pad START Pressed
- bit 3 = 1 if Left Pad X Pressed
- bit 2 = 1 if Left Pad Z Pressed
- bit 1 = 1 if Left Pad Y Pressed
- bit 0 = 1 if Left Pad START Pressed

4.3 Mouse

A mouse attached to the PS/2 port looks like a kempston mouse to the system. Port \$FADF is used to read the state of the mouse wheel and buttons while ports \$FBDF and \$FBDF are used to read the X and Y positions.

Port \$FADF (64223) Kempston Mouse Buttons

bits 7-4 = Wheel delta since last read

bit 3 =fourth button

bit 2 = middle button

bit 1 = left button

bit 0 = right button

```
Port $FBDF (64479) Kempston Mouse X
```

bits 7-0 = X coordinate of mouse

Port \$FFDF (65503) Kempston Mouse Y

bits 7-0 = Y coordinate of mouse (0-192)

4.4 Keymapping

Both a PS/2 keyboard and the contoller buttons can be given custom keyboard mappings. These mappings are accomplished using nextregs \$28 (keymap address MSB), \$29 (keymap address LSB), \$2A (keymap data MSB) and \$2B (keymap data LSB).

Keymap data format:

- bit 8 = reserved, must be 0
- bits 7-6 = modifier
 - 00 = No modifier
 - 01 = Caps Shift
 - 10 = Symbol Shift
 - 11 = Special Function
- bits 5-3 = row
- bits 2-0 = column (111 = no action)

If data is special function, the row will 0 and the column will be as follows:

- 0 = F1, hard reset
- \bullet 0 = F2, toggle scandoubler/hdmi reset
- 0 = F3, toggle 50/60 Hz
- 0 = F4, soft reset
- 0 = F5, (temporary) expansion bus on
- 0 = F6, (temporary) expansion bus off
- 0 = F7, change scanline weight
- 0 = F8, change CPU speed

Register (R/W) \$28 (40) \Rightarrow Stored Palette Value and PS/2 Keymap Address MSB

Read

• bits 7-0 = Stored palette value (see NextREG \$44)

Write

- bit 7 = PS/2 or Joystick
 - -0 = PS/2 keymap
 - -1 = Key joystick
- bits 6-1 = Reserved, must be 0

• bit 0 = PS/2 Keymap Address MSB

Register (W) \$29 (41) \Rightarrow PS/2 Keymap Address LSB

• bits 7-0 = PS/2 Keymap Address LSB

Register (W) 2A (42) $\Rightarrow PS/2$ Keymap Data MSB

- bits 7-1 = Reserved, must be 0
- bit 0 = PS/2 Keymap Data MSB

Register (W) \$2B (43) \Rightarrow PS/2 Keymap Data LSB

• bits 7-0 = PS/2 Keymap Data LSB

(writing this register auto-increments the address)

4.4.1 Keyboard

To remap PS/2 keyboard keys, the starting address for the keymap data is written to nextregs \$28 and \$29 keyboard data address followed by writing the data to nextregs \$2A and \$2B with the write to \$2B autoincrementing the address for the data.

 $\mathrm{PS}/2$ keyboard function keys F9-F12 cannot be remapped and have a fixed function.

- F9 = Multiface NMI/Function key modifier (with 1-8 sends special function F1-F8)
- F10 = divMMC NMI
- F11 = expansion bus on
- F12 = expansion bus off

4.4.2 Joystick

To map joystick buttons an \$80 is written to nextreg followed by a \$00 (left) or \$10 (right) to nextreg \$29 to select which joystick is being mapped to the keyboard 11 writes to nextgreg \$2B to indicate the key(s) for each button. Each byte to addresses the row and column of the ZX Next keyboard with bits 5-3 being the row and bits 2-0 being the column (column 7, 111 is no action).

Chapter 5

Memory

The ZX Spectrum Next commonly has with either 1MB or 2MB SRAM memory. This is more the 64kB directly addressable by its Z80N CPU. It is therefore necessary to use some form of memory paging to address all of the memory. This is accomplished using 8k pages or 16k banks. 256k of the total memory is used by the ROM images and device specific RAM leaving either 768k (pages 0-95/banks 0-47) or 1792k (pages 0-223/banks 0-111) that can be paged in as RAM. Pages 10, 11, and 14 are a little odd in that rather than coming from the normal SRAM, they come from BRAM internal to the FPGA.

5.1 Memory Management

There are a number of different systems for controling memory papping into the 64k memory space of the Z80N CPU in the ZX Next: ZX Next native memory paging, ZX Spectrum 128, ZX Spectrum +3, divMMC, and Multiface.

5.1.1 Default Layout

The default mapping of memory banks is the same as on 128k Spectrum models with a ROM0 (128k editor and menu system) mapped in at \$0000-\$3FFF, bank 5 at \$4000-\$7FFF, bank 2 at \$8000-\$8FFF, and bank 0 at \$C000-\$FFFF.

5.1.2 RAM

ZX Spectrum Next Native Registers \$50 to \$57 control the which SRAM pages are in each of the eight memory slots. Registers \$50 and \$51 support

the special value FF which indicates that the currently selected ROM is to be mapped into slots 0 and/or 1 (0000-3FFF).

Register (R/W) \$50 (80) \Rightarrow MMU Slot 0 Control

• bits 7-0 = 8k RAM page at position \$0000 to \$1FFF (\$ff on reset)

Pages can be from 0 to 223 on a fully expanded Next.

A 255 value causes the ROM to become visible.

Register (R/W) \$51 (81) \Rightarrow MMU Slot 1 Control

• bits 7-0 = 8k RAM page at position \$2000 to \$3FFF (\$ff on reset)

Pages can be from 0 to 223 on a fully expanded Next.

A 255 value causes the ROM to become visible.

Register (R/W) $$52 (82) \Rightarrow MMU Slot 2 Control$

• bits 7-0 = 8k RAM page at position \$4000 to \$5FFF (\$0A on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Register (R/W) \$53 (83) \Rightarrow MMU Slot 3 Control

• bits 7-0 = 8k RAM page at position \$6000 to \$7FFF (\$0B on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Register (R/W) \$54 (84) \Rightarrow MMU Slot 4 Control

• bits 7-0 = 8k RAM page at position \$8000 to \$9FFF (\$04 on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Register (R/W) \$55 (85) \Rightarrow MMU Slot 5 Control

• bits 7-0 = 8k RAM page at position \$A000 to \$BFFF (\$05 on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Register (R/W) \$56 (86) \Rightarrow MMU Slot 6 Control

• bits 7-0 = 8k RAM page at position \$C000 to \$DFFF (\$00 on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Register (R/W) $$57 (87) \Rightarrow MMU Slot 7 Control$

• bits 7-0 = 8k RAM page at position \$E000 to \$FFFF (\$01 on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Writing to ports \$1FFD, \$7FFD and \$DFFD writes \$FF to MMU0 and MMU1 and writes appropriate values to MMU6 and MMU7 to map in the selected 16k bank.

+3 special modes override the MMUs if used.

In addition the ZX Next has special controls which allow the data area for Layer 2 to be overlaied on memory in a fashion that permits selective read or write access. For details see the section on Layer 2 video.

ZX Spectrum 128 In addition to the native memory management, the ZX Next supports a memory management system that is an expanded, and backward compatible, version of the the system used on earlier ZX Spectrum models. This system uses registers \$1FFD, \$7FFD, and \$DFFD.

Port \$1FFD (8189) Plus 3 Memory Paging Control

```
bits 7-3 = \text{Unused}, nust be 0
     bit 2 = High bit of ROM selection (low bit is in Port $7FFD)
          00 = ROM0 = 128k editor and menu system
          01 = ROM1 = 128k \text{ syntax checker}
          10 = ROM2 = +3DOS
          11 = ROM3 = 48k BASIC
     bit 1 = Special mode: Low bit of memory configuration number
     bit 0 = Paging mode
          0 = Normal
          1 = Special
You should echo writes to $5B67
Port $7FFD (32765) Memory Paging Control
     bits 7-6 = Extra two bits for 16k RAM bank if in Pentagon 512k/1024k
     mapping mode (nextreg $8f)
     bit 5 = \text{Lock memory paging}
     bit 4 = \text{low bit of ROM Select (high bit is in Port $1FFD)}
          00 = ROM0 = 128k editor and menu system
          01 = ROM1 = 128k syntax checker
          10 = ROM2 = +3DOS
          11 = ROM3 = 48k BASIC
     bit 3 = \text{Shadow screen toggle}
     bits 2-0 = LSB of Bank number for slot 4 (MSB is in Port $DFFD)
Disable with bit 5 port $7FFD
Port $DFFD (57341) Next Memory Bank Select
     bits 7-4 = \text{Reserved}, must be 0
```

Spectrum 128 Standard Paging 128-style memory management can only alter the bank addressed at \$c000 (16k-slot 4, or 8k-slots 7-8). The active 16k-bank at \$c000 is selected by writing the 3 LSBs of the 16k-bank number to the bottom 3 bits of Memory Paging Control (\$7FFD), and the 4 MSBs to

bits 3-0 = MSB of bank number for slot 4 (LSB is in Port \$7FFD)

the bottom 4 bits of Next Memory Bank Select (\$DFFD). (The reason for the division is that the original Spectrum 128, having only 128k of memory, only needed 3 bits.)

If you are using the standard interrupt handler or OS routines, then any time you write to Memory Paging Control (\$7FFD) you should also store the value at \$5B5C. Any time you write to Plus 3 Memory Paging Control (\$1FFD) you should also store the value at \$5B67. There is no corresponding system variable for the Next-only Next Memory Bank Select (\$DFFD) and standard OS routines may not support the extended banks properly.

Paging out ROM ROM can be paged out by enabling AllRam mode, or by using Next memory management. Beware that some programs may assume that they can find ROM service routines at fixed addresses between \$0000-\$3fff. More importantly, if the default interrupt mode (IM 1) is set, the Z80 will jump the program counter to \$0038 every frame expecting to find an interrupt handler there. If it does not, pain and suffering will likely result. DI is your friend. On the plus side, this does allow you to write your own interrupt handler without the nuisance of using IM 2.

Spectrum 128 Special Paging "Special paging mode" (also called "AllRam mode" or "CP/M mode") is enabled by writing a value with the LSB set to Plus 3 Memory Paging Control (\$1FFD). Depending on the 3 low bits of this value a memory configuration is selected as follows:

rable 5:1: Special raging modes					
Bits 2-0	Slot 1	Slot 2	Slot 3	Slot 4	
1	0	1	2	3	
3	4	5	6	7	
5	4	5	6	3	
7	4	7	6	3	

Table 5.1: Special Paging Modes

5.1.3 ROM

The ZX Spectrum Next had several ROMS: ROM0 (16k) - 128k editor and menu system, ROM1 (16k) - 128k syntax checker, ROM2 (16k) - +3DOS, ROM3 (16k) - 48k BASIC, divMMC/esxDOS ROM (8k), divMMC RAM (128k), Multiface ROM (8k) and Alternate ROM (16k).

ZX Next native Slots 0 and 1 select use by ROM by selecting page \$FF. Which what ROM is mapped in is determined by the other memory management system. If the rest of the system selected the 48k ROM, Nextreg \$8C determines

whether the actual 48k ROM, or the ZX Next Alternate ROM is in use. In addition, it is possible to enable writing to the Alternate ROM.

Register (R/W) \$8C (140) \Rightarrow Alternate ROM Immediate

- bit 7 = Alt ROM Enable (0 on hard reset)
- bit 6 = Alt ROM visible ONLY during writes (0 on hard reset)
- bit 5 = Reserved, must be 0
- bit 4 = 48k ROM Lock (0 on hard reset)

After Soft Reset (copied into bits 7-4)

- bit 3 = Alt ROM Enable (0 on hard reset)
- bit 2 = Alt ROM visible ONLY during writes (0 on hard reset)
- bit 1 = Reserved, must be 0
- bit 0 = 48k ROM Lock (0 on hard reset)

ZX Spectrum 128k

ROM paging and selection \$0000-\$3fff is usually mapped to ROM. This area can only be fully remapped using Next memory management. ROM is not considered one of the numbered banks; it is mapped to the two 8k-banks by default, or by setting their 8k-bank numbers to 255.

The 128k Spectrum has 2 ROM pages. Which of these is mapped is selected by altering Bit 4 of Memory Paging Control (\$7FFD). The +2a/+3 has 4 ROM pages; the extra bit needed to select between these is bit 2 of Plus 3 Memory Paging Control (\$1FFD). This maintains compatibility with the original machines' ROM paging as long as the ROM is not paged out.

divMMC The divMMC ROM mapping can take priority when it is enabled by port \$E3 or, when automapping has been enabled by nextreg \$06, when it has been automapped due to reading one of the appropriate addresses. Port \$E3 also controls whether the divMMC maps the esxDOS ROM or divMMC RAM page 3 into slot 0 and which divMMC RAM page is mapped into slot 1.

Port \$E3 (227) divMMC Control Disable with bit 2 of Nextreg \$09

bit 7 = conmem, enable divMMC memory

bit 6 = mapram, enable divMMC allRAM mode

bits 3-0 = bank, selected divMMC ram bank for \$2000-\$3FFF region

• conmem can be used to manually control divMMC mapping. When enabled

0000-1FFF contains exxDOS ROM or exxDOS page 3 2000-3FFF contains exxDOS RAM page selected by bits 3-0

- divMMC automatically maps itself in when instruction fetches hit specific addresses in the ROM. When this happens, the esxDOS ROM (or divMMC bank 3 if mapram is set) appears in \$0000-\$1FFF and the selected divMMC bank appears as RAM in \$2000-\$3FFF
- bit 6 can only be set, once set only a power cycle can reset it. nextreg \$09 bit 3 can be set to reset this bit.

div
MMC automapping is normally disabled by NextZXOS see nextreg
 \$06 bit 4

Register (R/W) \$06 (6) \Rightarrow Peripheral 2 Settings

```
• bit 7 = Enable F8 cpu speed hotkey (soft reset = 1)
```

- bit 6 = Divert BEEP only to internal speaker (hard reset = 0)
- bit 5 = Enable F3 50/60 Hz hotkey (soft reset = 1)
- bit 4 = Enable divmmc nmi by DRIVE button (hard reset = 0)
- bit 3 = Enable multiface nmi by M1 button (hard reset = 0)
- bit 2 = PS/2 mode (config mode only)
 - -0 = keyboard primary
 - -1 =mouse primary
- bits 1-0 = Audio chip mode
 - -00 = YM
 - -01 = AY
 - -11 = Hold all AY in reset

Multiface Need to find useful docs on the Multiface memory.

9f 1-In, 128-In2 1f 1-Out bf 128-In, 3-Out 3f 128-Out, 3-In, 3-button 7f3f 3-7ffd 1f3f 3-1ffd

5.2 Interactions between paging methods

Changes made in 128 style and Next style memory management are synchronized. The most recent change always has priority. This means that

using 128-style memory management to select a new 16k-bank in 16k-slot 4 will update the MMU registers for the two 8k-slots with the corresponding 8k-bank numbers. enabling AllRam mode will update all of the 8k-bank values with the appropriate 8k-slot numbers. These may then be overwritten using Next memory management without needing to alter the value at port \$1FFD. Since the 128-style memory management ports are not readable, there is no synchronization applicable in the other direction.

5.3 Memory Map

5.3.1 Global Memory Map

Physical Address	Size	Description
\$000000-\$00FFFF	64k	ZX Spectrum ROM (ROM0-3)
\$010000-\$011FFF	8k	EsxDOS ROM
\$012000-\$013FFF	8k	Multiface ROM
\$014000-\$017FFF	16k	EsxDOS Extra ROM
\$018000-\$01BFFF	16k	Alternate ROM
\$01C000-\$01FFFF	16k	Multiface RAM
\$020000-\$03FFFF	128k	DivMMC RAM
\$040000-\$0FFFFF	768k	Standard RAM
\$100000-\$1FFFFF	1024k	Expanded RAM

Normal RAM is divided into 8k pages or 16k banks which may be mapped into the 64k memory space by the memory management hardware of the Next. Some of these pages have special properties.

Pages 10, 11 and 14 are used by Layer 1/0 (ULA) video modes with 10 used by standard Spectrum ULA video, 10 and 11 used by Timex Hi-res and Hi-colour modes, 11 used by Timex alternate video and page 14 used by the ULA shadow mode. Pages 10 an 11 are usable by Layer 3 (Tilemap) video.

5.3.2 Z80 Visible Memory Map

5.4 Memory Decoding

The ZX Next uses a heirarchical memory decoding scheme. Looking at the virtual memory address, the decode order is:

ROM area \$0000-\$1000

- 1. bootrom
- 2. multiface
- 3. divmmc
- 4. layer 2 mapping
- 5. mmu
- 6. config
- 7. romcs expansion bus
- 8. rom

Mid memory \$2000-\$DFFF

- layer 2 mapping
 mmu

High memory \$E000-\$FFFF

1. mmu

Chapter 6

zxnDMA

February 25, 2019 Phoebus Dokos Off Hardware, Resources, The ZX Spectrum Next DMA (zxnDMA)

6.1 Overview

The ZX Spectrum Next DMA (zxnDMA) is a single channel dma device that implements a subset of the Z80 DMA functionality. The subset is large enough to be compatible with common uses of the similar Datagear interface available for standard ZX Spectrum computers and compatibles. It also adds a burst mode capability that can deliver audio at programmable sample rates to the DAC device.

6.2 Accessing the zxnDMA

The zxnDMA is mapped to a single Read/Write IO Port 0x6B which is the same one used by the Datagear but unlike the Datagear it doesn't also map itself to a second port 0x0B similar to the MB-02 interface.

PORT \$6b: zxnDMA

6.3 Description

The normal Z80 DMA (Z8410) chip is a pipelined device and because of that it has numerous off-by-one idiosyncrasies and requirements on the order that

certain commands should be carried out. These issues are not duplicated in the zxnDMA. You can continue to program the zxnDMA as if it is were a Z8410 DMA device but it can also be programmed in a simpler manner.

The single channel of the zxnDMA chip consists of two ports named A and B. Transfers can occur in either direction between ports A and B, each port can describe a target in memory or IO, and each can be configured to autoincrement, autodecrement or stay fixed after a byte is transferred.

A special feature of the zxnDMA can force each byte transfer to take a fixed amount of time so that the zxnDMA can be used to deliver sampled audio.

6.4 Modes of Operation

The zxnDMA can operate in a z80-dma compatibility mode.

The z80-dma compatibility mode is selected by setting bit 6 of nextreg \$06. In this mode, all transfers involve length+1 bytes which is the same behaviour as the z80-dma chip. In zxn-dma mode, the transfer length is exactly the number of bytes programmed. This mode is mainly present to accommodate existing spectrum software that uses the z80-dma and for cp/m programs that may have a z80-dma option.

The zxnDMA can also operate in either burst or continuous modes.

Continuous mode means the DMA chip runs to completion without allowing the CPU to run. When the CPU starts the DMA, the DMA operation will complete before the CPU executes its next instruction.

Burst mode nominally means the DMA lets the CPU run if either port is not ready. This condition can't happen in the zxnDMA chip except when operated in the special fixed time transfer mode. In this mode, the zxnDMA will let the CPU run while it waits for the fixed time to expire between bytes transferred.

Note that there is no byte transfer mode as in the Z80 DMA.

6.5 Programming the zxnDMA

Like the Z80 DMA chip, the zxnDMA has seven write registers named WR0-WR6 that control the device. Each register WR0-WR6 can have zero or more parameters associated with it.

In a first write to the zxnDMA port, the write value is compared against a bitmask to determine which of the WR0-WR6 is the target. Remaining bits in the written value can contain data as well as a list of associated parameter bits. The parameter bits determine if further writes are expected to deliver parameter

values. If there are multiple parameter bits set, the expected order of parameter values written is determined by parameter bit position from right to left (bit 0 through bit 7). Once all parameters are written, the zxnDMA again expects a regular register write selecting WR0-WR6.

The table X.Y describes the registers and the bitmask required to select them on the zxnDMA.

	Table 0.1. Zalibita Registers		
Group	Register Function Description	Bitmask	Notes
WR0	Direction Operation and Port A configuration	0XXXXXAA	AA must NOT be 00
WR1	Port A configuration	0XXXX100	
WR2	Port B configuration	0XXXX000	
WR3	Activation	1XXXXX00	It's best to use WR6
WR5	Ready and Stop configuration	10XXX010	
WR6	Command Register	1XXXXXX11	

Table 6.1: zxnDMA Registers

6.6 zxnDMA Registers

These are described below following the same convention used by Zilog for its DMA chip:

WR0 - Write Register Group 0

```
D7
       D5
               D3 D2
                          DO BASE REGISTER BYTE
           D4
                      D1
                       0
                           O Do not use
                              Transfer (Prefer this for Z80 DMA compatibility)
                       0
                           O Do not use (Behaves like Transfer, Search on Z80
                                          DMA)
                           1 Do not use (Behaves like Transfer, Search/Trans-
                                         fer on Z80 DMA)
                   0 = Port B -> Port A (Byte transfer direction)
                    1 = Port A -> Port B
                     D1 DO PORT A STARTING ADDRESS (LOW BYTE)
D7
   D6
      D5
          D4
               D3
                  D2
D7
   D6
      D5
          D4
               D3 D2 D1 D0 PORT A STARTING ADDRESS (HIGH BYTE)
                             BLOCK LENGTH (LOW BYTE)
D7
   D6 D5
          D4 D3 D2 D1 D0
D7 D6 D5 D4 D3 D2 D1 D0 BLOCK LENGTH (HIGH BYTE)
```

Several registers are accessible from WR0. The first write to WR0 is to the base register byte. Bits D6:D3 are optionally set to indicate that associated registers in this group will be written next. The order the writes come in are from D3 to D6 (right to left). For example, if bits D6 and D3 are set, the next two writes will be directed to PORT A STARTING ADDRESS LOW followed by BLOCK LENGTH HIGH.

WR1 - Write Register Group 1

```
D7
   D6 D5 D4 D3 D2 D1 D0 BASE REGISTER BYTE
               1
                      0
                          0
               0 = Port A is memory
               1 = Port A is IO
        П
           - 1
           0 = Port A address decrements
        0
           1 = Port A address increments
        0
        1
           0 = Port A address is fixed
           1 = Port A address is fixed
    V
D7 D6 D5 D4 D3 D2 D1 D0 PORT A VARIABLE TIMING BYTE
0
    0
       0
           0
               0
                   0
                      - 1
                       Ω
                         0 = Cycle Length = 4
                       0
                          1 = Cycle Length = 3
                          0 = Cycle Length = 2
                       1
                          1 = Do not use
```

The cycle length is the number of cycles used in a read or write operation. The first cycle asserts signals and the last cycle releases them. There is no half cycle timing for the control signals.

WR2 – Write Register Group 2

```
D6 D5 D4 D3 D2 D1 D0 BASE REGISTER BYTE
0
                      0 0
    - 1
        - 1
               - 1
                   0
               0 = Port B is memory
           - 1
               1 = Port B is IO
        0
           0 = Port B address decrements
           1 = Port B address increments
        0
           0 = Port B address is fixed
        1
        1
           1 = Port B address is fixed
D7 D6 D5 D4 D3 D2 D1 D0 PORT B VARIABLE TIMING BYTE
0
    0
        0 0 0
                      0
                          0 = Cycle Length = 4
                         1 = Cycle Length = 3
                       0
                       1
                         0 = Cycle Length = 2
                          1 = Do not use
D7 D6 D5 D4 D3 D2 D1 D0 ZXN PRESCALAR (FIXED TIME TRANSFER)
```

The ZXN PRESCALAR is a feature of the zxnDMA implementation. If non-zero, a delay will be inserted after each byte is transferred such that the total time needed for each transfer is determined by the prescalar. This works in both the continuous mode and the burst mode. If the DMA is operated in burst mode, the DMA will give up any waiting time to the CPU so that the CPU can run while the DMA is idle.

The rate of transfer is given by the formula "Frate $= 875 \mathrm{kHz}$ / prescalar" or, rearranged, "prescalar $= 875 \mathrm{kHz}$ / Frate". The formula is framed in terms of

a sample rate (Frate) but Frate can be inverted to set a transfer time for each byte instead. The 875kHz constant is a nominal value assuming a 28MHz system clock; the system clock actually varies from this depending on the video timing selected by the user (HDMI, VGA0-6) so for complete accuracy the constant should be prorated according to documentation for nextreg \$11.

In a DMA audio setting, selecting a sample rate of 16kHz would mean setting the prescalar value to 55. This sample period is constant across changes in CPU speed.

WR3 - Write Register Group 3

The Z80 DMA defines more fields but they are ignored by the zxnDMA.

The two other registers defined by the Z80 DMA in this group on D4 and D3 are implemented by the zxnDMA but they do nothing.

It is preferred to start the DMA by writing an Enable DMA command to WR6.

WR4 – Write Register Group 4

The Z80 DMA defines three more registers in this group through D4 that define interrupt behaviour. Interrups and pulse generation are not implemented in the zxnDMA nor are these registers available for writing.

WR5 – Write Register Group 5

```
D7 D6 D5 D4 D3 D2 D1 D0 BASE REGISTER BYTE

1 0 | | 0 0 1 0

| 0 = /ce only
| 1 = /ce & /wait multiplexed
|
0 = Stop on end of block
1 = Auto restart on end of block
```

The /ce & /wait mode is implemented in the zxnDMA but is not currently used. This mode has an external device using the DMA's /ce pin to insert wait states during the DMA's transfer.

The auto restart feature causes the DMA to automatically reload its source and destination addresses and reset its byte counter to zero to repeat the last transfer when a previous one is finished.

WR6 - Command Register

```
DЗ
                  D2
                      D1 DO BASE REGISTER BYTE
                       1
                           1
                0
                    0 = \SC3 = Reset
                0
                      = \$C7 = Reset Port A Timing
                    1
                      = \$CB = Reset Port B Timing
                1
                      = \$BF = Read Status Byte
                1
                    1
                    0 = \$8B = Reinitialize Status Byte
                1
                0
                        \$A7 = Initialize Read Sequence
                        \SCF = Load
                1
                0
                        \$D3 = Continue
                    0
     0
                    1 = \$87 = Enable DMA
            0
                0
     0
        0
            0
                0
                    0 =
                        \$83 = Disable DMA
                    0 = \$BB = Read Mask Follows
D7
       D5
           D4
               D3
                          DO
                              READ MASK
   D6
                  D2
                       D1
0
D7
   D6
               D3
                  D2
                      D1
                          D0
                              Status Byte
       D5
           D4
                      D1 D0 Byte Counter Low
D7
   D6
       D5
           D4
               D3
                  D2
D7
       D5
               D.3
                  D2 D1 D0 Byte Counter High
   D6
           D4
D7
       D5 D4
               D3 D2 D1 D0 Port A Address Low
   D6
D7
               D3 D2
                      D1 D0 Port A Address High
   D6
       D5
D7
   D6
       D5
           D4
              D3 D2
                      D1
                          DO
                              Port B Address Low
D7 D6 D5 D4 D3 D2 D1 D0 Port B Address High
```

Unimplemented Z80 DMA commands are ignored.

Prior to starting the DMA, a LOAD command must be issued to copy the Port A and Port B addresses into the DMA's internal pointers. Then an ``Enable DMA' command is issued to start the DMA.

The iContinue command resets the DMA's byte counter so that a following iEnable DMA allows the DMA to repeat the last transfer but using the current internal address pointers. I.e. it continues from where the last copy operation left off.

Registers can be read via an IO read from the DMA port after setting the read mask. (At power up the read mask is set to \$7f). Register values are the current internal dma counter values. So `iPort Address A Lowi` is the lower 8-bits of Port A's next transfer address. Once the end of the read mask is reached, further reads loop around to the first one.

The format of the DMA status byte is as follows:

00E1101T

E is set to 0 if the total block length has been transferred at least once.

T is set to 1 if at least one byte has been transferred.

Operating speed The zxnDMA operates at the same speed as the CPU, that is 3.5MHz, 7MHz or 14MHz. This is a contended clock that is modified by the ULA and the auto-slowdown by Layer2.

Auto-slowdown occurs without user intervention if speed exceeds 7Mhz and the active Layer2 display is being generated (higher speed operation resumes when the active Layer2 display is not generated). Programmers do NOT need to account for speed differences regarding DMA transfers as this happens automatically.

Because of this, the cycle lengths for Ports A and B can be set to their minimum values without ill effects. The cycle lengths specified for Ports A and B are intended to selectively slow down read or write cycles for hardware that cannot operate at the DMA's full speed.

The DMA and Interrupts The zxnDMA cannot currently generate interrupts.

The other side of this is that while the DMA controls the bus, the Z80 cannot respond to interrupts. On the Z80, the nmi interrupt is edge triggered so if an nmi occurs the fact that it occurred is stored internally in the Z80 so that it will respond when it is woken up. On the other hand, maskable interrupts are level triggered. That is, the Z80 must be active to regularly sample the /INT line to determine if a maskable interrupt is occurring. On the Spectrum and the ZX Next, the ULA (and line interrupt) are only asserted for a fixed amount of time 30 cycles at 3.5MHz. If the DMA is executing a transfer while the interrupt is asserted, the CPU will not be able to see this and it will most likely miss the interrupt. In burst mode, the CPU will never miss these interrupts, although this may change if multiple channels are implemented.

6.7 Programming examples

A simple way to program the DMA is to walk down the list of registers WR0-WR5, sending desired settings to each. Then start the DMA by sending a LOAD command followed by an ENABLE_DMA command to WR6. Once more familiar with the DMA, you will discover that the amount of information sent can be reduced to what changes between transfers.

1. Assembly

ENDIF

Short example program to DMA memory to the screen then DMA a sprite image from memory to sprite RAM, and then showing said sprite scroll across the screen.

```
device zxspectrum48
;;;-----
;;; DEFINE testing
                   _____
;;; DMA (Register 6)
:::
;;; zxnDMA programming example
-
;;;(c) Jim Bagley
;;;-----
DMA_RESET equ $c3
DMA_RESET_PORT_A_TIMING equ $c7
DMA_RESET_PORT_B_TIMING equ $cb
\texttt{DMA\_LOAD} equ $cf ; %11001111
DMA_CONTINUE equ $d3
DMA_DISABLE_INTERUPTS equ $af
DMA_ENABLE_INTERUPTS equ $ab
DMA_RESET_DISABLE_INTERUPTS equ $a3
DMA_ENABLE_AFTER_RETI equ $b7
DMA_READ_STATUS_BYTE equ $bf
DMA_REINIT_STATUS_BYTE equ $8b
DMA_START_READ_SEQUENCE equ $a7
DMA_FORCE_READY equ $b3
DMA_DISABLE equ $83
DMA_ENABLE equ $87
DMA_WRITE_REGISTER_COMMAND equ $bb
DMA_BURST equ %11001101
DMA_CONTINUOUS equ %10101101
ZXN_DMA_PORT equ $6b
SPRITE_STATUS_SLOT_SELECT equ $303B
SPRITE_IMAGE_PORT equ $5b
SPRITE_INFO_PORT equ $57
   IFDEF testing
   org $6000
   ELSE
   org $2000
```

```
start
   ld hl, $0000
    ld de,$4000
   ld bc,$800
    call TransferDMA; copy some random data to the screen
    ;; pointing to ROM for now, for the purpose of showing
    ;; how to do a DMA copy.
    ld a,0 ; sprite image number we want to update
    ld bc,SPRITE_STATUS_SLOT_SELECT
    out (c),a ; set the sprite image number
    ld bc,1*256 ; number to transfer (1)
    ld hl,testsprite ; from
    {\tt call \ TransferDMASprite} \ ; \ {\tt transfer} \ {\tt to} \ {\tt sprite} \ {\tt ram}
    nextreg 21,1; turn sprite on. for more info on this
    ;; check out
    ;; https://www.specnext.com/tbblue-io-port-system/
    1d de,0
    ld (xpos), de ; set initial X position ( doesn't need it
    ;; for this demo, but if you run the .loop again it will
    ;; continue from where it was
    1d a,$20
    ld (ypos), a ; set initial Y position
.loop
    ld a,0; sprite number we want to position
    ld bc,SPRITE_STATUS_SLOT_SELECT
    out (c),a
    ld de,(xpos)
    ld hl,(ypos); ignores H so doing this rather than
    ;; ld a,(ypos):ld l,a
    ld bc,(image) ; not flipped or palette shifted
    call SetSprite
    halt
    ld de,(xpos)
    inc de
    ld (xpos),de
   ld a,d
    cp $01
    jr nz,.loop ; if high byte of xpos is not 1 (right of
    ;; screen )
   ld a,e
   cp $20+1
    {\tt jr} nz,.loop; if low byte is not $21 just off the right
    ;; of the screen, $20 is off screen but as the INC DE is
    ;; just above and not updated sprite after it, it needs
    ;; to be $21
    xor a
    ret; return back to basic with OK
xpos dw 0 ; x position
ypos db 0 ; y position
;;; these next two BITS and IMAGE are swapped as bits needs
;;; to go into B register image db 0+$80; use image 0 (for
```

```
;;; the image we transfered)+$80 to set the sprite to active
bits db 0 ; not flipped or palette shifted
   c1 = %11100000
   c2 = %11000000
   c3 = %10100000
   c4 = %10000000
   c5 = %01100000
   c6 = %01000000
   c7 = %00100000
   c8 = %00000000
testsprite
   db c1,c2,c3,c3,c3,c3,c3,c3,c3,c3,c3,c3,c3,c2,c1
   db c1,c2,c3,c4,c4,c4,c4,c4,c4,c4,c4,c4,c4,c3,c2,c1
   db c1,c2,c3,c4,c5,c5,c5,c5,c5,c5,c5,c5,c4,c3,c2,c1
   db c1,c2,c3,c4,c5,c6,c6,c6,c6,c6,c6,c5,c4,c3,c2,c1
   db c1,c2,c3,c4,c5,c6,c7,c7,c7,c6,c5,c4,c3,c2,c1
   db c1,c2,c3,c4,c5,c6,c7,c8,c8,c7,c6,c5,c4,c3,c2,c1
   db c1,c2,c3,c4,c5,c6,c7,c8,c8,c7,c6,c5,c4,c3,c2,c1
   \verb"db" c1,c2,c3,c4,c5,c6,c7,c7,c7,c7,c6,c5,c4,c3,c2,c1"
   db c1,c2,c3,c4,c5,c6,c6,c6,c6,c6,c6,c5,c4,c3,c2,c1
   db c1,c2,c3,c4,c5,c5,c5,c5,c5,c5,c5,c5,c4,c3,c2,c1
   \verb"db" c1,c2,c3,c4,c4,c4,c4,c4,c4,c4,c4,c4,c4,c3,c2,c1"
   db c1,c2,c3,c3,c3,c3,c3,c3,c3,c3,c3,c3,c3,c1
   ;;;-----
;;; de = X
;;; 1 = Y
;;; b = bits
;;; c = sprite image
SetSprite
  push bc
   ld bc,SPRITE_INFO_PORT
   out (c),e ; Xpos
   out (c),1 ; Ypos
   pop hl
   ld a,d
   and 1
   or h
   out (c),a
   ld a,1:or $80
   out (c),a ; image
   ret
;;;-----
;;; h1 = source
;;; de = destination
;;; bc = length
;;;-----
TransferDMA
   ld (DMASource),hl
```

```
ld (DMADest),de
   ld (DMALength),bc
   ld hl,DMACode
   ld b,DMACode_Len
   ld c,ZXN_DMA_PORT
   otir
   еi
   ret
DMACode db DMA_DISABLE
    db \%01111101 ; RO-Transfer mode, A -> B, write adress
    ;; + block length
DMASource dw 0 ; RO-Port A, Start address
    ;; (source address)
DMALength dw 0 ; RO-Block length (length in bytes)
   db \%01010100; R1-write A time byte, increment, to
    ;; memory, bitmask
    db %0000010 ; 2t
   db \%01010000; R2-write B time byte, increment, to
    ;; memory, bitmask
   db %00000010 ; R2-Cycle length port B
    db DMA_CONTINUOUS ; R4-Continuous mode (use this for
    ;; block transfer), write dest adress
{\tt DMADest\ dw\ O\ ;\ R4-Dest\ address\ (destination\ address)}
   db %10000010; R5-Restart on end of block, RDY active
    ;; LOW
    db DMA_LOAD ; R6-Load
    db DMA_ENABLE ; R6-Enable DMA
DMACode_Len equ $-DMACode
;;; h1 = source
;;; bc = length
;;; set port to write to with {\tt TBBLUE\_REGISTER\_SELECT}
;;; prior to call
;;;-----
{\tt TransferDMAPort}
   di
   ld (DMASourceP),hl
   ld (DMALengthP),bc
   ld hl,DMACodeP
   ld b,DMACode_LenP
   ld c,ZXN_DMA_PORT
   otir
   еi
   ret
DMACodeP db DMA_DISABLE
    db \%01111101 ; RO-Transfer mode, A -> B, write adress
    ;; + block length
{\tt DMASourceP\ dw\ O\ ;\ RO-Port\ A\, ,\ Start\ address\ (source\ address)}
DMALengthP dw 0 ; R0-Block length (length in bytes)
    db \%01010100; R1-read A time byte, increment, to
    ;; memory, bitmask
    db %00000010; R1-Cycle length port A
    db %01101000; R2-write B time byte, increment, to
```

```
;; memory, bitmask
   db %00000010 ; R2-Cycle length port B
   db %10101101; R4-Continuous mode (use this for block
   ;; transfer), write dest adress
   dw $253b; R4-Dest address (destination address)
   db %10000010; R5-Restart on end of block, RDY active
   ;; LOW
   db DMA_LOAD ; R6-Load
   db DMA_ENABLE ; R6-Enable DMA
DMACode_LenP equ $-DMACodeP
;;;-------
;;; h1 = source
;;; bc = length
;;;-----
{\tt TransferDMASprite}
   di
   ld (DMASourceS),hl
   ld (DMALengthS),bc
   ld hl,DMACodeS
   ld b,DMACode_LenS
   ld c,ZXN_DMA_PORT
   otir
   еi
   ret
DMACodeS db DMA_DISABLE
   db %01111101 ; RO-Transfer mode, A -> B, write adress
   ;; + block length
DMASourceS dw 0 ; RO-Port A, Start address (source address)
DMALengthS dw 0 ; RO-Block length (length in bytes)
   db \%01010100; R1-read A time byte, increment, to
   ;; memory, bitmask
   db \%0000010; R1-Cycle length port A
   db %01101000; R2-write B time byte, increment, to
   ;; memory, bitmask
   db %00000010 ; R2-Cycle length port B
   db \%10101101 ; R4-Continuous mode (use this for block
   ;; transfer), write dest adress
   dw SPRITE_IMAGE_PORT ; R4-Dest address (destination \hookleftarrow
       address)
   db %10000010 ; R5-Restart on end of block, RDY active
   ;; LOW
   db DMA_LOAD ; R6-Load
   db DMA_ENABLE ; R6-Enable DMA
DMACode_LenS equ $-DMACodeS
;;; de = dest, a = fill value, bc = lenth
;;;-----
   DMAFill
   di
   ld (FillValue),a
   ld (DMACDest),de
   ld (DMACLength),bc
   ld hl,DMACCode
   ld b,DMACCode_Len
   ld c,ZXN_DMA_PORT
```

```
otir
   еi
   ret
FillValue db 22
DMACCode db DMA_DISABLE
   db %01111101
DMACSource dw FillValue
DMACLength dw 0
   db %00100100,%00010000,%10101101
{\tt DMACDest} \  \, {\tt dw} \  \, {\tt 0}
   db DMA_LOAD, DMA_ENABLE
DMACCode_Len equ $-DMACCode
;;; End of file
;;;-----
   IFDEF testing
   savesna "dmatest.sna", start
   ELSE
   fin
   savebin "DMATEST", start, fin-start
```

Chapter 7

Copper and Display Timing

From: KevB (aka 9bitcolour)

Introduction The ZX Spectrum Next includes a co-processor named "COP-PER". It functions in a similar way to the Copper found in the Commodore Amiga Agnus custom chip. It's role is to free the Z80 of tasks that require the writing of hardware registers at precise pixel co-ordinates.

Overview The ZX Spectrum Next COPPER has three instructions: NOOP, MOVE, WAIT.

NOOP is used to fine tune timing. MOVE writes data to a specific range of hardware registers. WAIT waits for a pixel position on the video display.

These instructions are stored in 2k (2048 BYTES) of dedicated write-only program RAM also known as a "Copper list".

Each instruction is 16 bits (WORD) in size allowing for a maximum of 1024 instructions to be stored in the program RAM. The COPPER uses an internal 10 bit program counter (PC) which wraps to zero at the end of the list. The PC can be reset to zero, this is the default value after a hard/soft reset.

The instructions are stored in big endian format and transferred to the 2k program RAM using the Z80 or DMA (bits 15..8 followed by bits 7..0).

Three write-only hardware registers control access to the program RAM as well as the operating modes.

System performance is not affected when the COPPER is executing instructions.

The hardware registers and COPPER program RAM are not connected to the main memory BUS. The overall design of this system together with the use of alternate clock edges means that contention between the COPPER, Z80 and DMA has been eliminated.

The COPPER has a base clock speed of $13.5 \mathrm{Mhz}$ for HDMI and $14 \mathrm{Mhz}$ for VGA.

The bandwidth is around 14 million single cycle NOOP/WAIT instructions and 7 million two cycle MOVE instructions per second.

7.1 Timing

To fully understand the COPPER, you must first understand the display timing for each of the machines and video modes found in the ZX Spectrum Next.

There are several display timing configurations due to the four machine types, two refresh rates, two video systems (VGA/HDMI) and Timex HIRES mode.

Details of these timings are outlined in this chapter.

Machines The ZX Spectrum Next has four machine types (48k, 128k, Pentagon, and HDMI). The machine timing and HDMI determine the number of T-states per line which determines the base dot clock frequency and Z80/DMA clock speed.

This guide groups machine types by their timing for convenience. The HDMI video mode overrides the default machine timing so it is included as an extra machine type which does not exist in the official documentation.

Display The ZX Spectrum Next doesn't have video modes based on resolution that you would expect to find on graphics card based hardware. There is one fixed resolution of 256×192 which can be doubled to 512×192 in Timex HIRES mode. What it does have is the ability to set the refresh rate from 50Hz to 60Hz and horizontal dot clock. This in turn together with the VGA and HDMI timing affects the vertical line count giving several combinations in total.

VGA modes 0..6 are included as one single VGA mode as the internal machine timing is constant across those seven refresh rate steps.

More details can be found in Video modes.

Resolution There are two main horizontal resolutions: standard 256×192 and Timex HIRES 512×192 . Details of LORES 128×96 are not included to simplify this guide.

The frame buffer height is fixed at 192 pixels and surrounded by a large border and overscan as well as horizontal and vertical blanking periods.

7.1. TIMING 81

There are five vertical line counts: 261, 262, 311, 312, 320. Several pixels are hidden in the overscan and blanking periods beyond the visible border.

The result is 256×192 and 512×192 pixel resolutions with a large border.

The colour of the visible border beyond the frame buffer can be manipulated. Visual changes will not show during the overscan and blanking periods.

Dot Clock The dot clock on the ZX Spectrum Next runs at 13.5Mhz for HDMI and around 14Mhz for VGA. The COPPER clock runs at the same frequency as the dot clock. For v3.00 the copper runs at twice the frequency of the dot clock.

The number of dot clocks per line is calculated by multiplying the number of 3.5 Mhz Z80 T-states per line by four. Example: 228 Ts * 4 = 912 dot clocks.

The number of dot clocks per second is calculated by the following:

T-states per line * 4 * line count * refresh rate

In standard 256×192 resolution the duration of one pixel is two dot clocks. In Timex HIRES 512×192 resolution the duration of one pixel is one dot clock.

Details of the dot clock counts can be found in tables 5.1 and 5.2.

Table 7.1: Vertical Line Counts and Dot Clock Combinations

System	Lines	Clocks
48K VGA 50Hz	312	224.0*4 = 896
128K VGA 50Hz	311	228.0*4 = 912
PENTAGON VGA 50Hz	320	224.0*4 = 896
48K VGA 60Hz	262	224.0*4 = 896
128K VGA 60Hz	261	228.0*4 = 912
HDMI 50Hz	312	216.0*4 = 864
HDMI 60Hz	262	214.5*4 = 858

Table 7.2: Dot Clocks per Second

System	Lines	Clocks	Freq
48K VGA 50Hz	312	13 977 600	14.0Mhz (28Mhz)
128K VGA 50Hz	311	14 181 600	14.2Mhz (28Mhz)
PENTAGON VGA 50Hz	320	14 336 000	14.3Mhz (28Mhz)
48K VGA 60Hz	262	14 085 120	14.1Mhz (28Mhz)
128K VGA 60Hz	261	14 281 920	14.3Mhz (28Mhz)
HDMI 50Hz	312	13 478 400	13.5Mhz (27Mhz)
HDMI 60Hz	262	13 487 760	13.5Mhz (27Mhz)

Coordinates The top left pixel of the frame buffer is line 0 and horizontal dot clock 0. This is also known as "0,0".

The bottom right pixel of the frame buffer in standard 256×192 resolution is line 191 and horizontal dot clocks 510+511.

The bottom right pixel of the frame buffer in Timex HIRES 512×192 resolution is line 191 and horizontal dot clock 511.

The line one pixel above the frame buffer is the last line of the video frame and equal to the total line count minus one (312-1 for example).

The line one pixel below the frame buffer is line 192.

The COPPER horizontal dot clock compare is locked to every eight pixels in standard 256×192 resolution and every sixteen pixels in Timex HIRES 512×192 resolution. The NOOP instruction can be used to fine tune timing in single dot clock steps.

Compare The COPPER uses a 9 bit vertical line compare allowing it to handle the various line counts.

The COPPER horizontal compare is 6 bits meaning that it can wait for 64 positions across each line. The range of this value is limited by the machine timing as that determines the number of dot clocks per line.

Table 7.3: Maximum Horizontal COPPER Compare

System	Max
HDMI	52
Pentagon	54
48k	54
128k	55

Each horizontal compare is in steps of 16 dot clocks to cover the full range across a raster line.

 $16 \text{ dot clocks} = 4 \text{ pixels in lo } 128 \times 96 \text{ resolution}$

16 dot clocks = 8 pixels in standard 256×192 resolution

 $16 \text{ dot clocks} = 16 \text{ pixels in high } 512 \times 192 \text{ resolution}$

There is some slack to consider after the maximum horizontal compare value. The slack is calculated using the following:

dot clocks per line - maximum horizontal compare * 16

Table 5.5 provides details of the horizontal display, left/right border, blanking and COPPER dot clock/pixel position compare values:

Table 5.6 provides a detailed list of vertical display, top/bottom border and

7.1. TIMING 83

Table 7.4: Slack Dot Clocks After Maximum Compare

clocks/line		slack
858	(52 * 16 = 832)	26 dot clocks
864	(52 * 16 = 832)	32 dot clocks
896	(54 * 16 = 864)	32 dot clocks
912	(55 * 16 = 880)	32 dot clocks

Table 7.5: Horizontal Timing

Compare	Standard	Timex	HDMI	48k	128k	Pentagon
0-31	0-255	0-511	Display	Display	Display	Display
32-36	256-295	512-591	R-Border	R-Border	R-Border	R-Border
37	296-303	592-607	R-Border	R-Border	Blanking	Blanking
38-48	304-391	608-783	Blanking	Blanking	Blanking	Blanking
49	392-399	784-799	L-Border	Blanking	Blanking	L-Border
50-52	400-423	800-847	L-Border	L-Border	L-Border	L-Border
53-54	424-439	848-879	_	L-Border	L-Border	L-Border
55	440-447	880-895	_	_	L-Border	_

⁻ Dot clock compare is out of range.

blanking as well as maximum COPPER line compare. It also provides the ULA VBLANK interrupt line number.

Table 7.6: Vertical Timing

					0		
Line	HDMI 50Hz	HDMI 60Hz	48k 50Hz	48k 60Hz	128k 50Hz	128k 60Hz	Pentagon
0-191	Display	Display	Display	Display	Display	Display	Display
192-211	B-Border	B-Border	B-Border	B-Border	B-Border	B-Border	B-Border
212-224	B-Border	Blanking	B-Border	B-Border	B-Border	B-Border	B-Border
225-231	B-Border	Blanking	B-Border	Blanking	B-Border	Blanking	B-Border
232-238	Blanking	Blanking	B-Border	Blanking	B-Border	Blanking	B-Border
239	Blanking	Blanking	B-Border	T-Border	B-Border	T-Border	B-Border*
240	Blanking	Blanking	B-Border	T-Border	B-Border	T-Border	B-Border
241-244	Blanking	Blanking	B-Border	T-Border	B-Border	T-Border	Blanking
245-247	Blanking	T-Border	B-Border	T-Border	B-Border	T-Border	Blanking
248	Blanking	T-Border	B-Border*	T-Border	B-Border*	T-Border	Blanking
249-255	Blanking	T-Border	Blanking	T-Border	Blanking	T-Border	Blanking
255	Blanking	T-Border	Blanking	T-Border	Blanking	T-Border	T-Border
256	Blanking*	T-Border	Blanking	T-Border	Blanking	T-Border	T-Border
257-260	Blanking	T-Border	Blanking	T-Border	Blanking	T-Border	T-Border
261	Blanking	T-Border	Blanking	T-Border	Blanking	-	T-Border
262	Blanking	-	Blanking	-	Blanking	-	T-Border
263-271	Blanking	-	T-Border	-	T-Border	-	T-Border
272-310	T-Border	-	T-Border	-	T-Border	-	T-Border
311	T-Border	-	T-Border	-	-	-	T-Border
312-319	_	-	_	-	-	-	T-Border

⁻ Line compare is out of range

Note: The HDMI overscan and blanking period is larger than that of a VGA monitor which can auto-adjust alignment. The following data is based on visible results from various monitors thus subject to refinement.

Pixels are visible during DISPLAY/BORDER and hidden during BLANKING.

Overscan The visible area of the display can extend to resolutions exceeding 256×192 .

The 50/60 Hz refresh rate mode dictates the vertical limit.

VGA and HDMI differ with VGA providing more visible pixels beyond the range of HDMI. Table 5.7 provides ideal extended pixel resolutions:

Maximum Extended VGA Resolutions

 $50 \text{Hz} = 352 \times 288 \text{ (standard 256 resolution)}$

 $60 \text{Hz} = 352 \times 240 \text{ (standard 256 resolution)}$

Table 7.7: Ideal Extended Resolutions for Both VGA and HDMI

Freq	Resolution	Top	Bottom	Left	Right
50Hz	336x288	32	32	40	40
60Hz	336x240	24	24	40	40

Table 5.8 provides COPPER horizontal position and vertical line compare parameters for ideal extended resolutions:

Table 7.8: Ideal Extended Resolution Display Parameters

						1 0			
Timing	Video	Ref	Lines	Top	Bot	Left	Right	Ext	Res
$0/1 \ 48k$	VGA	50Hz	312	280	223	51.1	36.15	80x64	336x256
$0/1 \ 48k$	VGA	60Hz	262	246	207	51.1	36.15	80x48	336x240
2/3 128k	VGA	50Hz	311	279	223	52.1	36.15	80x64	336x256
2/3 128k	VGA	60Hz	261	245	207	52.1	36.15	80x48	336x240
4 Pentagon	VGA	50Hz	320	288	223	51.1	36.15	80x64	336x256
$0/1 \ 48k$	HDMI	50Hz	312	280	223	49.1	36.15	80x64	336x256
$0/1 \ 48k$	HDMI	60Hz	262	246	207	48.11	36.15	80x48	336x240
2/3 128k	HDMI	50Hz	312	280	223	49.1	36.15	80x64	336x256
2/3 128k	HDMI	60Hz	262	246	207	48.11	36.15	80x48	336x240
4 Pentagon	HDMI	50Hz	312	280	223	49.1	36.15	80x64	336x256
4 Pentagon	HDMI	60Hz	262	246	207	48.11	36.15	80x48	336x240

TOP: Initial line of the extended top border area - see notes below*

BOT: Last line of the extended bottom border area - see notes below*

LEFT: First pixel of the extended left border area - see notes below**

RIGHT: Last pixel of the extended right border area - see notes below**

7.2 Instructions

This section describes the behaviour of the COPPER instructions as well as the bit definitions and execution time.

The three 16 bit COPPER instructions are comprised of the following bit definitions:

^{*} Line compare value for MOVE (bits 8..0).

^{**} The integer part is the horizontal value for MOVE (bits 14..9).

^{**} The fractional part is specified in dot clocks (NOOP instructions).

Table 7.9: Instruction Bit Definition

Name	15-8	7-0	Clocks
NOOP	00000000	00000000	1
MOVE	0RRRRRR	DDDDDDDD	2
WAIT	1НННННН	VVVVVVV	1

H 6 bit horizontal dot clock compare

V 9 bit vertical line compare

R 7 bit Next register 0x00..0x7F

D 8 bit data

NOOP NOOP (no-operation) executes in one dot clock. It is useful for fine tuning timing, initialising COPPER RAM and 'NOP' out COPPER program instructions.

It can be used to align colour and display changes to half pixel positions in standard 256×192 resolution. Its duration is equal to one Timex HIRES pixel.

This guide uses the name 'NOOP' to avoid confusion with the Z80 opcode NOP.

MOVE MOVE executes in two dot clocks. It moves 8 bits of data into any of the Next hardware registers in the range \$00 (0) .. \$7F (127).

The WORD value \$0000 is reserved for the NOOP instruction so no register access is carried out for that special case. Register \$00 is read-only so not affected by the restriction of not being able to write zero to it.

This instruction can perform 7 million register writes per second for VGA and 6.75 million register writes per second for HDMI.

WAIT WAIT executes in one dot clock. It performs a compare with the current vertical line number and the current horizontal dot clock.

WAIT will hold until the current raster line matches the 9 bit value stored in bits 8..0. When the line compare matches, WAIT will still hold if the current horizontal dot clock is less than the value in bits 14..9.

This compare logic means that out of order vertical line compares will cause the COPPER to wait until the next video frame as the test is for an exact match of the line number. The COPPER will continue to the next instruction after an out of order horizontal pixel position compare as the test checks for the current dot clock being greater than or equal to the compare value.

WAIT will stop the COPPER when a compare is made against an out of range vertical line or horizontal dot clock position as they will never occur

A standard way to terminate a COPPER program is to wait for line 511 and horizontal position 63. This encodes into the instruction WORD \$FFFF.

The horizontal dot clock position compare includes an adjustment meaning that the compare completes three dot clocks early in standard 256×192 resolution and two dot clocks early in Timex HIRES 512×192 resolution. In practice, a pixel position can be specified with clocks to spare to write a register value before the pixel is displayed. This saves software having to auto-adjust positions to arrive early. It also means that a wait for 0.0 can affect the first pixel of the frame buffer before it is displayed and set the scroll registers without visual artefacts.

Example The following example provides a simple COPPER program to move data to a hardware register at two specific pixel positions. The BYTES for the program are listed in the left column:

```
PAL8 equ
                    0x41
                                   ; 8 bit palette hardware register
$80,$00
              WAIT 0.0
                                   ; wait for pixel position 0.0 (H.V)
$00,$00
              NOOP
                                   ; fine tune timing by one dot clock
              MOVE PAL8,11100000b; write RED to palette register
$41,$E0
              WAIT 32,191
$CO.$BF
                                   ; wait for pixel position 256,191
$00,$00
              NOOP
                                    ; fine tune timing by one dot clock
              MOVE PAL8,00000000b; write BLACK to palette register
$41,$00
$FF.$FF
              WAIT 63,511
                                   : wait for an out of range position
```

7.3 Control

The COPPER is controlled by the following three write-only registers:

```
$60 (96) Copper data
$61 (97) Copper control LO BYTE
$62 (98) Copper control HI BYTE
```

The COPPER instructions are written one BYTE at a time to the program RAM using register \$60 (Copper data).

An index system is used to select the destination write address within the 2K program RAM. Eleven bits are needed to represent the index. Registers \$61 and \$62 hold this 11 bit index.

The index increments each time one BYTE is written to register \$60. The index wraps to zero when the last BYTE of program RAM is written.

The instruction data is normally written in big endian format although there is no rule stating that partial instruction BYTES cannot be written. It is safe to write to the COPPER program RAM while the COPPER is executing as long the instruction data written does not create a mall formed instruction which comprises of one half of the current executing instruction and one half the new instruction - this could result in unexpected behaviour.

7.3. CONTROL 87

The Z80 and DMA can be used to write the instruction data.

Writing to program RAM while the COPPER is running has no impact on system performance as the RAM is contention free. COPPER timing is not affected by the Z80 or DMA writing to the program RAM. Program RAM is write-only.

The contents of the 2k program RAM are preserved during a hard/soft reset.

Register \$61 holds the lower 8 bits of the index. Register \$62 holds the upper 3 bits of the index as well as two control bits which set the COPPER operating mode.

Table 7.10: Register Bit Definitions

Reg	7-0	Description			
0x60	DDDDDDDD	BYTE data to write to COPPER program RAM			
0x61	IIIIIIII	Program RAM index 70			
0x62	CC000III	Program RAM index 108 and control bits			

D 8 bit data

I 11 bit index

C 2 bit control

The COPPER has an internal 10 bit program counter (PC). Each instruction advances the program counter by one after completion. The program counter wraps to zero after the last instruction at location 1023. This causes the copper list to loop.

The program counter defaults to zero during a hard/soft reset.

The control bits require a change to update the operating mode. This feature preserves COPPER operation when setting the program RAM index address.

The program counter is preserved when stopping the COPPER. Two of the four control settings reset the internal PC to zero.

Table 5.11 describes the control bits:

Table 7.11: Control Mode Definitions

Name	CC	Description
STOP	00	STOP COPPER
RESET	01	RESET PC and start COPPER
START	10	START COPPER

^{*} The control mode names used in this guide differ from the official names.

Here is a detailed description of the control bits:

STOP This is the default operating mode set during a hard/soft reset. The COPPER is idle in this state and will STOP if currently executing when entering

this mode. It is safe to write to any location within the 2K program RAM when the COPPER is stopped.

Entering STOP mode preserves the internal program counter so that the COP-PER may continue when restarted.

RESET The program counter is RESET to zero when entering this mode. The COPPER is started if idle otherwise entering this mode acts as a jump to location zero when the COPPER is running.

START Entering this mode causes an idle COPPER to start executing instructions from the current program counter. Entering this mode while the COPPER is running has no effect other than to disable FRAME mode if active.

FRAME The program counter is RESET to zero when entering this mode. The COPPER is started if idle otherwise entering this mode acts as a jump to location zero when the COPPER is running.

Entering this state enables FRAME mode. The program counter will be reset to zero each frame at 0,0.

7.4 Configuration

Hardware registers provide timing and configuration data allowing software to build and configure COPPER programs that function correctly across the various video modes and machine types. It is not essential to detect the machine type but it should be noted that software should not assume that it is running on a specific machine as the COPPER hardware is available across all four machine types.

Three registers can be read to determine the machine configuration for Ts per line, dot clocks, refresh rate, line count and maximum horizontal dot clock/pixel position compare.

Refresh Rate The refresh rate must be taken into account and can change real-time so should be monitored and auto-configured when the COPPER is active as the line count will change with the refresh rate. This could lead to the COPPER waiting for lines that never occur.

Register (R/W) 05 (5) \Rightarrow Peripheral 1 Settings

- bits 7-6 = joystick 1 mode (MSB)
- bits 5-4 = joystick 2 mode (MSB)
- bit 3 = joystick 1 mode (LSB)

- bit 2 = 50/60 Hz mode (0 = 50Hz, 1 = 60Hz)
- bit $1 = \text{joystick } 2 \mod \text{(LSB)}$
- bit 0 = Enable Scandoubler

Joystick modes

- 000 = Sinclair 2 (67890)
- 001 = Kempston 2 (port \$37)
- 010 = Kempston 1 (port \$1F)
- 011 = Megadrive 1 (port \$1F)
- 100 = Cursor
- 101 = Megadrive 2 (port \$37)
- 110 = Sinclair 1 (12345)
- 111 = User Defined Keys Joystick
- * Joysticks can be placed in i/o mode via nextreg 0x0B.
- * Programming the user defined keys joystick is done through the ps2 keymap interface on nextreg 0x28, 0x29 and 0x2B:
- 1. Write 128 to nextreg 0x28
- 2. Write 0 (left joystick) or 16 (right joystick) to nextreg 0x29
- 3. Write eleven bytes to nextreg 0x2B. The bytes correspond to the eleven buttons on an md pad (X=11 Z Y START A C B U D L R=1)
- 4. Each byte written identifies a key in the 8x7 membrane; bits 5:3 select the row and bits 2:0 select the column with 111 meaning no action.

 In all joystick modes, excess buttons on an md pad not read via ports will generate key input if so programmed.

Video Modes The video mode can only be changed during the boot process so one initial read is required of this register during software start up phase.

The machine timing is identical for the seven VGA modes although the physical refresh rate of the video output speeds up for each mode in turn by roughly 1Hz. The internal timing of the machine remains constant and as close to the original hardware as possible. VGA is a perfect Amstrad ZX Spectrum 128k +3 for example as far as timing is concerned across the seven VGA modes.

The effect of this speed up means that mode 0 will execute in one second of time whereas mode 6 will execute in a shorter time period. Mode 0 is as close to 50/60 Hz as possible where mode 6 is closer to 60/70 Hz. That would mean that one second of machine time for mode 6 will execute in 0.83 seconds of human time when running 50 frames per second at 60Hz.

The eighth mode (mode 7) is used for HDMI timing. Machine configuration is forced for this mode. Line counts, Ts and various other settings are set to meet the rigid HDMI timing specification. For mode 7, 50/60 Hz are rock solid but the original hardware timing loses Ts across all machines to meet HDMI display requirements.

Software that was previously written for specific hardware with hard-coded software timing loops may fail. This is one of the risks of coding timing loops counting Ts. We saw evidence of this with the release of the 1985 Sinclair ZX Spectrum 128k+ and the later Amstrad models as previous software written for the ZX Spectrum 48k/48k+ would fail when trying to display colour attribute and border effects as the number of Ts per line was changed from 224Ts (1982 original 48k) to 228Ts (128k models). The ZX Spectrum Next runs slower in HDMI mode. Demos may fail to display correctly and games may slow down although setting the Z80 to 7Mhz can solve the game slow down, demos should be run in VGA mode for maximum compatibility.

Video timing also affects audio output as the sample rate can vary depending on the output timing method.

The following register allows software to read the video timing mode:

Register (R/W) \$11 (17) \Rightarrow Video Timing (writable in config mode only)

```
bits 7-3 = Reserved, must be 0
bits 2-0 = Mode (VGA = 0..6, HDMI = 7)

000 = Base VGA timing, clk28 = 28000000
001 = VGA setting 1, clk28 = 28571429
010 = VGA setting 2, clk28 = 29464286
011 = VGA setting 3, clk28 = 30000000
100 = VGA setting 4, clk28 = 31000000
101 = VGA setting 5, clk28 = 32000000
```

- 110 = VGA setting 6, clk28 = 33000000

-111 = HDMI, clk28 = 27000000

50/60Hz selection depends on bit 2 of register \$05 Only writable in config mode

Machine Type The machine type register can be used to provide the number of Ts per line, line count, dot clock and maximum horizontal COPPER wait.

The dot clock (DC) is the number of Ts per line * 4.

The maximum horizontal COPPER wait (H) is in multiples of 16 clocks.

Video mode 7 (HMDI) overrides the timing.

The following list shows the various parameters that can be gained from reading the machine register combined with the refresh register and video mode bits:

```
Register (R/W) 03 (3) \Rightarrow Machine Type A write to this register disables the boot rom bits 2-0 select machine type when in config mode
```

- bit 7 = (W) Display Timing change enable (allow changes to bits 6-4) (0 on hard reset)
- bits 6-4 = Display Timing

- bit 3 = Display Timing user lock control Read
 - -0 = No user lock on display timing
 - -1 =User lock on display timing

Write

- -1 = Apply user lock on display timing (0 on hard reset)
- bits 2-0 = Machine Type (config mode only)

determines roms loaded

Machine Types/Display Timings

- 000 or 001 = ZX 48K
- -010 = ZX 128K/+2 (Grey)
- 011 = ZX +2A-B/+3e/Next Native
- -100 = Pentagon 128K

Summary Table 5.13 provides a full list of video timing configuration data:

Table 7.12: Summary of Video Modes

Timing	Video	Refresh	T-States	Clocks	Lines	Width	HRZ	Max	Slack	Adjust
$0/1 \ 48k$	VGA	50Hz	224	896	312	256	448	54	32	-3
$0/1 \ 48k$	VGA	50Hz	224	896	312	512	448	54	32	-2
$0/1 \ 48k$	VGA	60Hz	224	896	262	256	448	54	32	-3
$0/1 \ 48k$	VGA	60Hz	224	896	262	512	448	54	32	-2
2/3 128k	VGA	50Hz	228	912	311	256	456	55	32	-3
2/3 128k	VGA	50Hz	228	912	311	512	456	55	32	-2
2/3 128k	VGA	60Hz	228	912	261	256	456	55	32	-3
2/3 128k	VGA	60Hz	228	912	261	512	456	55	32	-2
4 Pentagon	VGA	50Hz	224	896	320	256	448	55	32	-3
4 Pentagon	VGA	50Hz	224	896	320	512	448	55	32	-2
$0/1 \ 48k$	HDMI	50Hz	216	864	312	256	432	52	32	-3
$0/1 \ 48k$	HDMI	50Hz	216	864	312	512	432	52	32	-2
$0/1 \ 48k$	HDMI	60Hz	214.5	858	262	256	429	52	26	-3
$0/1 \ 48k$	HDMI	60Hz	214.5	858	262	512	429	52	26	-2
2/3 128k	HDMI	50Hz	216	864	312	256	432	52	32	-3
2/3 128k	HDMI	50Hz	216	864	312	512	432	52	32	-2
2/3 128k	HDMI	60Hz	214.5	858	262	256	439	52	26	-3
2/3 128k	HDMI	60Hz	214.5	858	262	512	439	52	26	-2
4 Pentagon	HDMI	50Hz	216	864	312	256	432	52	32	-3
4 Pentagon	HDMI	50Hz	216	864	312	512	432	52	32	-2
4 Pentagon	HDMI	60Hz	214.5	858	262	256	439	52	26	-3
4 Pentagon	HDMI	60Hz	214.5	858	262	512	439	52	26	-2

Chapter 8

Interrupts

8.1 Interrupt Types

The Z80 has three different hardware interrupt signals: $\overline{\text{RESET}}$, $\overline{\text{NMI}}$, and $\overline{\text{INT}}$.

RESET RESET is used to return the CPU to a known state. When the RESET line is pulled low, a RESET is generated. The CPU then does several things. I, and R are set to \$00. PC is set to \$0000. SP becomes \$FFFF. A and F are set to \$FF. The interrupt mode is set to 0. And (maskable) interrupts are disabled by clearing IFF1 and IFF2.

 $\overline{\text{NMI}}$ $\overline{\text{NMI}}$ is the non-maskable interrupt. Upon receiving a non-maskable interrupt ($\overline{\text{NMI}}$ being pulled low) one of two sequences occur depending on the calue of bit 3 of the interrupt control register (nextreg \$C0).

Register (R/W) \$C0 (192) \Rightarrow Interrupt Control (3.01.09) (\$00 on reset)

- bits 7-5 = Programmable portion of IM2 vector *
- bit 4 =Reserved, must be 0
- bit $3 = \text{Enable stackless } \overline{\text{NMI}} \text{ response**}$
- bits 2-1 = Reserved, must be 0
- bit 0 = Maskable interrupt mode
 - 0 pulse
 - 1 IM2

- bits 7-5 = nextreg \$C0 bits 7-5
- bits 4-1 = Interrupt source

 $^{^{\}ast}$ In IM2 mode vector generated is:

```
0 - line interrupt (highest priority)
1 - UART 0 Rx
2 - UART 1 Rx
3-10 - CTC channels 0-7
11 - ULA
12 - UART 0 Tx
13 - UART 1 Tx (lowest priority)

◆ bit 0 = 0
```

- * In IM2 mode the expansion bus is the lowest priority interrupter and if no vector is supplied externally the \$FF is generated.
- ** The return address pushed during an nmi acknowledge cycle will be written to the appropriate nextreg instead of memory (the stack pointer will be decremented) and the RETN after acknowledge will take its return address from nextreg instead of memory (the stack pointer will be incremented). If bit 3=0 and in other circumstances, RETN functions normally.

If bit 3 is clear (0) PC is pushed on the stack, IFF1 is copied to IFF2, IFF1 is cleared (inhibiting maskable interrupts). The $\overline{\text{NMI}}$ should end with RETN which copies the contents of IFF2 to IFF1 (returning the interrupt state to what it was before the $\overline{\text{NMI}}$) and PC is popped off the stack.

If bit 3 is set (1) PC is stored in the $\overline{\text{NMI}}$ return address registers (nextregs \$C2 and \$C3), IFF1 is copied to IFF2, IFF1 is cleared (inhibiting maskable interrupts). The $\overline{\text{NMI}}$ should end with RETN which copies the contents of IFF2 to IFF1 (returning the interrupt state to what it was before the $\overline{\text{NMI}}$) and PC is compied from the $\overline{\text{NMI}}$ return address registers.

```
Register (R/W) $C2 (194) \Rightarrow \overline{\text{NMI}} Return Address LSB (3.01.09) ($00 on reset)
Register (R/W) $C3 (195) \Rightarrow \overline{\text{NMI}} Return Address MSB (3.01.09) ($00 on reset)
```

INT The interrupt generally of most interest to programmers is INT. So much so that if programmers talk about interrupts on the Z80, they are probably only talking about INT. The processing of INT is controlled by IFF1 and IFF2 which are set using EI to enable interrupts and reset using DI to disable interrupts. Interrupts can happen at any time and should preserve register contents. If none of your code uses the alternate registers the EXX and EX AF,AF' instructions can make this faster and easier. Interrupt routined should end with EI and RETI to reenable interrupts, potentially inform the interrupting device that its interrupt has been serviced, and return from the interrupt routine. In general the Spectrum machines do not make any distingtion between RET and RETI, but future developments in the ZX Spectrum Next may make the distinction important.

The ZX Spectrum Next has 14 internal sources for $\overline{\text{INT}}$ signals. This can be enabled and disabled using nextregs C4 - C6. Which signals have been received can be read/cleared using nexregs C8 - CA.

Interrupt Enable

Register (R/W) \$C4 (196) \Rightarrow Interrupt Enable 0 (3.01.08) (\$81 on reset)

- bit $7 = \text{Expansion bus } \overline{\text{INT}}$
- bits 6-2 = Reserved must be zero
- bit 1 = Line
- bit 0 = ULA

Register (R/W) \$C5 (197) \Rightarrow Interrupt Enable 1 (3.01.08) (\$00 on reset)

- bit 7 = ctc channel 7 zc/to
- bit 6 = ctc channel 6 zc/to
- bit 5 = ctc channel 5 zc/to
- bit 4 = ctc channel 4 zc/to
- $\bullet \;$ bit 3 = ctc channel 3 zc/to
- bit 2 = ctc channel 2 zc/to
- bit 1 = ctc channel 1 zc/to
- bit 0 = ctc channel 0 zc/to

Register (W) $C6 (198) \Rightarrow \text{Interrupt Enable 2 } (3.01.08)$ (\$00 on reset)

- bit 7 =Reserved, must be 0
- bit 6 = UART1 Tx empty
- bit 5 = UART1 Rx half full *
- bit 4 = UART1 Rx available *
- bit 3 = Reserved, must be 0
- bit 2 = UART0 Tx empty
- bit 1 = UART0 Rx half full *
- bit 0 = UART0 Rx available *

Interupt Status

Register (R/W) \$C8 (200) \Rightarrow Interrupt Status 0 (3.01.09) (\$00 on reset)

- bits 7-2 = Reserved, must be zero
- bit 1 = Line
- bit 0 = ULA

^{*} For each UART, Rx half full and Rx available are shared interrupts

^{*} Set bits indicate the device generated an interrupt in the past * Writes clear bits where bits are set except in IM2 mode

Register (R/W) $C9 (201) \Rightarrow Interrupt Status 1 (3.01.09)$

- bit 7 = ctc channel 7 zc/to
- bit 6 = ctc channel 6 zc/to
- bit 5 = ctc channel 5 zc/to
- bit 4 = ctc channel 4 zc/to
- bit 3 = ctc channel 3 zc/to
- bit 2 = ctc channel 2 zc/to
- $\bullet \ \, \mbox{bit} \ 1 = \mbox{ctc} \ \mbox{channel} \ 1 \ \mbox{zc/to}$
- bit 0 = ctc channel 0 zc/to

Register (R/W) CA (202) \Rightarrow Interrupt Status 2 (3.01.09) (\$00 on reset)

- bit 7 = Reserved, must be zero
- bit 6 = UART1 Tx empty
- bit 5 = UART1 Rx almost full *
- bit 4 = UART1 Rx available *
- bit 3 = Reserved must be zero
- bit 2 = UART0 Tx empty
- bit 1 = UART0 Rx almost full *
- bit 0 = UART0 Rx available *

Internal Interrupt Sources

- 0 = Line (highest priority)
- 1 = UART 0 Rx
- 2 = UART 1 Rx
- 3-10 = CTC channels 0-7
- 11 = ULA
- $12=\mathrm{UART}~0~\mathrm{Tx}$
- 13 = UART 1 Tx (lowest priority)

8.2 Interrupt Modes

IMO When an interrupt is received by the CPU it disables interrupts and executes the instruction placed on the bus by the interrupting device and (no known use on the Next) It is enabled with the IMO instruction and enabling interrupts (EI).

^{*} Set bits indicate the device generated an interrupt in the past * Writes clear bits where bits are set except in IM2 mode

^{*} For each UART Rx half full and Rx available are shared interrupts ** Set bits indicate the device generated an interrupt in the past ** Writes clear bits where bits are set except in IM2 mode

IM1 When an interrupt is received, the CPU disables interrupts and jumps to an interrupt handler at \$0038 (normally in ROM). The ROM interrupt handler updates the frame counter and scans the keyboard. This is the default interrupt handling method for the ZX Spectrum and is probably the method to use if you don't need the ROMs for anything. It is enabled using the IM1 instruction and enabling interrupts.

IM2 The ZX Spectrum Next has both a legacy method for handling IM2 and an updated one which makes better use of the capabilities of IM2 which was added in Core 3.01.09.

The ZX Spectrum Next has 14 interrupt devices which can all be given independent interrupt vectors when using IM2. These interrupts are controlled by nextregs \$C0 – \$CF. The address of the vector for a given interrupt is created by composing the I register (bits 15-0), nextreg \$C0 bits 7-5 (bits 7-5) and the interrupt number of the interrupt device (bits 4-1). This means that even if you use all 14 internal interrupt sources, your interrupt vector table is no more than 28 bytes which can be at any 32 byte boundry. It also means that far less processing has to be done on interrupts which are received. External interrupts are a little different. If no vector is supplied by a device the implied LSB will be \$FF.

While in IM2 mode, it is possible for interrupts to interrupt DMA transfers. This capability is controlled by The DMA Interrupt enable registers (nextregs \$CC – \$CE). When DMA is interrupted, one instruction of the main program will be processed, then the interrupt will be taken. On return, DMA will continue.

Register (R/W) $CC(204) \Rightarrow DMA$ Interrupt Enable 0 (3.01.09) (\$00 on reset)

- bits 7-2 = Reserved, must be 0
- bit 1 = Line
- bit 0 = ULA

Register (R/W) \$CD (205) \Rightarrow DMA Interrupt Enable 1 (3.01.09) (\$00 on reset)

- \bullet bit 7 = CTC channel 7 zc/to
- bit 6 = CTC channel 6 zc/to
- bit 5 = CTC channel 5 zc/to
- bit 4 = CTC channel 4 zc/to
- bit 3 = CTC channel 3 zc/to
- bit 2 = CTC channel 2 zc/to
- bit 1 = CTC channel 1 zc/to
- bit 0 = CTC channel 0 zc/to

^{*} Set bits indicate the specified interrupt will interrupt a DMA operation when in IM2 mode

^{*} Set bits indicate the corresponding interrupt will interrupt a DMA operation when in IM2 mode

Register (R/W) $CE (206) \Rightarrow DMA$ Interrupt Enable 2 (3.01.09) (\$00 on reset)

```
bit 7 = Reserved, must be 0
bit 6 = UART1 Tx empty
bit 5 = UART1 Rx half full
bit 4 = UART1 Rx available
bit 3 = Reserved, must be 0
bit 2 = UART0 Tx empty
bit 1 = UART0 Tx half full
bit 0 = UART0 Tx available
```

* Set bits indicate the corresponding interrupt will interrupt a DMA operation when in IM2 mode.

In legacy mode, when the CPU receives an interrupt it disables interrupts and jumps to an interrupt routine starting at the contents of the jump table at I. The start of the interrupt routine is the contents of I*\$100+bus and I*\$100+bus+1. Most devices that can supply interrupts on the ZX Spectrum leave the data bus in a floating state. As a result the interpreted state of the data bus while generally \$FF is not entirely predictable. The solution to place your interrupt routine at an address where the MSB and LSB are the same (\$0101, \$0202, ... \$FFFF) then place 257 copies of that value in a block starting at I*\$100 (you can set the value of the I register).

Code:

```
;; my program
    org $8000
    ;; enable interrupt mode im2
    ld i,$fe
    im2
    еi
    ;; program body
    ;; interrupt routine
handler:
    ;; preserve registers used
    ;; handle interrupt
    ;; restore registers
    еi
    ;; jump to interrupt routine
    org $fdfd
    jp handler
    ;; im2 jump table
    org $fe00; not actually legal
    defs $101,$fd
```

8.3. Z80 CTC 99

8.3 Z80 CTC

(3.01.08) Currently does not work properly, in particular IM2 still acts much like the original spectrum interrupt mode.

Eight (currently four) independent CTC channels are available on ports \$183B through \$1F3B. These perform counter/timer functions that can be used to generate timer interrupts or to generate interrupts on behalf of physical signals.

The CTC is a standard Zilog part. Its datasheet can be found at http://www.zilog.com/docs/z80/ps0181.pdf . The Zilog documentation is ambiguous around how soft resets are treated so the following clarifies some points in the Next's implementation.

- 1. Hard reset requires both a control word and a time constant to be written to a channel even if bit 2 = 0 in the first control word.
- 2. Soft reset with bit 2=0 causes the entire control register to be modified. Soft reset with bit 2=1 does not change the control register contents. In both cases a time constant must follow to resume operation.
- 3. Changing the trigger edge selection in bit 4 while the channel is in operation counts as a clock edge. A pending timer trigger will be fired and, in counter mode, an edge will be received.
- 4. ZC/TO is asserted for one clock cycle and not for the entire duration that the count is at zero.

At the moment, any interrupt generated by the CTC will assert the z80's /INT line for 32 cpu cycles. This is the same way that the ULA and line interrupts operate.

At the moment, the ZC/TO output of each channel is fed into the CLK/TRG input of the succeeding channel so that time and count periods can be cascaded.

Programming Initial values are set by a write of a channel control word followed by a time constant. In timer mode, the counter decrements every time it is triggered. In counter mode it decrements every time the prescaler counter reaches zero.

Channel Control Word

```
bit 7 = Enable Interrupt

bit 6 = Mode

-0 = Timer mode

-1 = Counter mode

bit 5 = Prescalar value (Timer mode only)

-0 = 16

-1 = 256

bit 4 = CLK/TRG edge selection

-0 = Falling Edge

-1 = Rising Edge
```

```
bit 3 = Timer Trigger (Timer mode only)
- 0 = Starts on loading of time constant
- 1 = Starts on CLK/TRG
bit 2 = Time constant follows
bit 1 = Software reset
bit 0 = 0 (Control Word)
```

If we are running at 28MHz (Mode 0) and wish to trigger an interrupt every 1 sec, that is 28 million T-States/cycles we could program CTC 5 as a counter with a prescalar of 16 and a period of 175, CTC 6 as a counter with a prescalar of 16 and a period of 125, and CTC 7 as a timer with a period of 5.

CTC 5 triggers ZC5 every 280 cycles or 10 usec.

CTC 6 triggers ZC6 every 560,000 cycles or 20 msec.

CTC 7 triggers ZC7 and an interrupt every 28,000,000 cycles or 1 sec.

```
;;; set up interrupt routine
   im 2
                  ; CTC 0
   ld bc,$183B
   ld hl,$FFFA
                   ; address pointing to start of interrupt
    ;; routine
   ld de, interrupt; start of interrupt routine
   ld (hl),de
   ld i,$FF
   ld a,l
                    ; Vector to address at on this interrupt
   out (c),a
;;; set up CTC 5
                    ; CTC 5
   ld b,$1D
   ld a,$87
    out (c),a
                   ; Interrupt mode, timer mode, time constant,
    ;; soft, control
   ld a,$05
                    ; once every 5 times
   out (c),a
;;; set up CTC 6
                    ; CTC 6
    inc b
   1d a,$47
   out (c),a
                    ; 16x, counter mode, time constant, soft,
   ;; control
                    ; 125 = once every 2000 times
   1d a,$7D
   out (c),a
;;; set up CTC 7
    inc b
                    ; CTC 7
   ld a,$47
   out (c),a
                    ; 16x, counter mode, time constant, soft,
    ;; control
   ld a,$AF
                    ; 175 = once every 2800 times
    еi
```

Chapter 9

Serial Communication

The Spectrum Next has two independent fully featured UARTs. The UARTS share I/O ports so it is important to select the correct one before communicating with it. Each has its own 64 byte Tx buffer and 512 byte Rx buffer. One UART can be connected to either the ESP of joystick port while the other can be connected to the Raspberry Pi accelerator or joystick port. The UARTS are controlled using ports \$37, \$133B, \$143B, \$153B, and \$163B. The UARTs are connected to the IM2 interrupt system. Nextreg \$c6 allows interrupts to be enabled for the status of each UART. UART interrupts correspond to interrupts 1, 2, 12, and 13 (see Interrupts).

```
Port $37 (55) Kempston/Mega Drive Joystick 2 Read
```

```
bit 7 = "start" button
bit 6 = A/X button
bit 5 = C/Z button
bit 4 = Fire/C/Y button
bit 3 = Up
bit 2 = Down
bit 1 = Left
bit 0 = Right
```

Port \$133B (4923) UART tx

The XYZ buttons on md pads can be read through nextreg 0xB2.

The joysticks can also be placed in i/o mode see nextreg 0x0B.

All eleven md pad buttons can be assigned to the keyboard see nextreg 0x05.

```
bit 2 = UART full
     bit 1 = UART transmit busy
     bit 0 = UART receive has data
Write: UART Transmit
Port $143B (5179) UART rx
Read: UART Receive
Write: UART Prescalar
     bit 7 = select prescalar part
          0 = Bits 6-0 of prescalar
           1 = Bits 13-7 of prescalar
     bits 6-0 = Prescalar bits
Port $153B (5435) UART select
     bit 7 = \text{Reserved}(0)
     bit 6 = \text{UART select (0 on soft reset)} **
          0 = ESP
          1 = Pi *
     bit 5 = Reserved(0)
     bit 4 = \text{Prescalar} valid in this write
     bit 3 = Reserved(0)
     bits 2-0 = Bits 16-14 of prescalar (0 on hard reset)
* Pi GPIO must be configured for UART, see next
reg A0
* Either UART can be redirected to the joystick ports, see port $037
Port $153B (5435) UART frame (upcoming)
($18 on hard reset)
      bit 7 = Immediately reset Rx and Tx to idle and empty FIFOs
     bit 6 = Assert break (Tx=0) when Tx reaches idle
     bit 5 = Enable hardware flow control *
     bits 4-3 = \text{Number of bits in a frame}
          00 = 5 bits
          01 = 6 bits
          10 = 7 bits
          11 = 8 bits
     bit 2 = \text{Enable parity}
     bit 1 = Parity
          0 = \text{Even parity}
           1 = Odd parity
     bit 0 = \text{Number of stop bits}
          0 = 1 stop bit
           1 = 2 stop bits
* The ESP ignores hardware flow control
```

In joystick i/o mode only cts is available

```
Register (R/W) $C0 (192) \Rightarrow Interrupt Control (3.01.09) ($00 on reset)
```

- bits 7-5 = Programmable portion of IM2 vector *
- bit 4 =Reserved, must be 0
- bit $3 = \text{Enable stackless } \overline{\text{NMI}} \text{ response**}$
- bits 2-1 = Reserved, must be 0
- \bullet bit 0 = Maskable interrupt mode
 - 0 pulse
 - 1 IM2
- * In IM2 mode vector generated is:
 - bits 7-5 = nextreg \$C0 bits 7-5
 - bits 4-1 = Interrupt source
 - 0 line interrupt (highest priority)
 - 1 UART 0 Rx
 - 2 UART 1 Rx
 - 3-10 CTC channels 0-7
 - 11 ULA
 - 12 UART $0~\mathrm{Tx}$
 - 13 UART 1 Tx (lowest priority)
 - bit 0 = 0
- * In IM2 mode the expansion bus is the lowest priority interrupter and if no vector is supplied externally the \$FF is generated.
- ** The return address pushed during an nmi acknowledge cycle will be written to the appropriate nextreg instead of memory (the stack pointer will be decremented) and the RETN after acknowledge will take its return address from nextreg instead of memory (the stack pointer will be incremented). If bit 3=0 and in other circumstances, RETN functions normally.

Register (W) \$C6 (198) \Rightarrow Interrupt Enable 2 (3.01.08) (\$00 on reset)

- bit 7 =Reserved, must be 0
- bit 6 = UART1 Tx empty
- bit 5 = UART1 Rx half full *
- bit 4 = UART1 Rx available *
- bit 3 = Reserved, must be 0
- bit 2 = UART0 Tx empty
- bit 1 = UART0 Rx half full *
- bit 0 = UART0 Rx available *
- * For each UART, Rx half full and Rx available are shared interrupts

Chapter 10

Raspberry Pi0 Acceleration

The Spectrum Next has a header (with male pins) which can be attached to a Raspberry Pi Zero. There is a modified version of DietPi called NextPi which is the standard distro for the Raspberry Pi0 accelerator. Software for the general public should be written assuming that it will be interfacing with a Pi0 running this distro.

If you are more adventurous, you may choose to use another distro, or even another accelerator that uses the Raspberry Pi style (40 pin) expansion bus. Chief concers when doing this is that you have a console presented on the UART that defaults to 115,200 bps, you don't need to login, the machine is configured with a driver to treat the I²S interface as a sound card, and the presence of the nextpi scripts.

The Raspberry Pi 0 has a Broadcom BCM2835 SoC with an ARMv6 core, a Videocore 4 GPU, and its own 512 MB memory and HDMI output. It has its own SD card from which it boots. For this application the Pi 0 ships with a 1GB microSD card containing NextPi a customized version of DietPi.

The Pi Zero, if installed, is a smart peripheral for the ZX Spectrum Next. Available interfaces are: low level access to the GPIO pins, higher level access to standardized I/O interfaces, and use of the Pi Zero as a sound card.

When using the low level GPIO interface Pi Zero GPIO pins 2-27 can be configured as either inputs or outputs using nextregs \$90-\$93. If they are outputs, the output state can be set by writing to nextregs \$98-\$9b. The current status of the GPIO pins can be read from nextregs \$98-\$9b whether it is the state driven by the ZX Spectrum Next or the state drive by some other peripherial attached to the bus (normally the Raspberry Pi Zero).

Register (R/W) \$90 (144) \Rightarrow Pi GPIO output enable 1/4

• bit 7 = Enable Pin 7 (0 on reset)

```
• bit 6 = Enable Pin 6 (0 on reset)
```

- bit 5 = Enable Pin 5 (0 on reset)
- bit 4 = Enable Pin 4 (0 on reset)
- bit 3 = Enable Pin 3 (0 on reset)
- bit 2 = Enable Pin 2 (0 on reset)
- bit 1 = Enable Pin 1 (cannot be enabled) (0 on reset)
- bit 0 = Enable Pin 0 (cannot be enabled) (0 on reset)

Register (R/W) \$91 (145) \Rightarrow Pi GPIO output enable 2/4

- bit 7 = Enable Pin 15 (0 on reset)
- bit $6 = \text{Enable Pin } 14 \ (0 \text{ on reset})$
- bit 5 = Enable Pin 13 (0 on reset)
- bit $4 = \text{Enable Pin } 12 \ (0 \text{ on reset})$
- bit 3 = Enable Pin 11 (0 on reset)
- bit $2 = \text{Enable Pin } 10 \ (0 \text{ on reset})$
- bit 1 = Enable Pin 9 (0 on reset)
- bit $0 = \text{Enable Pin } 8 \ (0 \text{ on reset})$

Register (R/W) \$92 (146) \Rightarrow Pi GPIO output enable 3/4

- bit 7 = Enable Pin 23 (0 on reset)
- bit 6 = Enable Pin 22 (0 on reset)
- bit 5 = Enable Pin 21 (0 on reset)
- bit $4 = \text{Enable Pin } 20 \ (0 \text{ on reset})$
- bit $3 = \text{Enable Pin } 19 \ (0 \text{ on reset})$
- bit 2 = Enable Pin 18 (0 on reset)
- bit 1 = Enable Pin 17 (0 on reset)
- bit $0 = \text{Enable Pin } 16 \ (0 \text{ on reset})$

Register (R/W) \$93 (147) \Rightarrow Pi GPIO output enable 4/4

- bits 7-4 = Reserved
- bit 3 = Enable Pin 27 (0 on reset)
- bit $2 = \text{Enable Pin } 26 \ (0 \text{ on reset})$
- bit 1 = Enable Pin 25 (0 on reset)
- bit $0 = \text{Enable Pin } 24 \ (0 \text{ on reset})$

Register (R/W) \$98 (152) \Rightarrow Pi GPIO Pin State 1/4

- bit 7 = Pin 7 Data (1 on reset)
- bit 6 = Pin 6 Data (1 on reset)
- bit 5 = Pin 5 Data (1 on reset)
- bit $4 = Pin \ 4 Data \ (1 \text{ on reset})$
- bit $3 = Pin \ 3 \ Data \ (1 \ on \ reset)$
- bit 2 = Pin 2 Data (1 on reset)
- bit $1 = Pin \ 1 \ Data \ (1 \ on \ reset)$
- bit $0 = Pin \ 0 \ Data \ (1 \ on \ reset)$

Register (R/W) \$99 (153) \Rightarrow Pi GPIO Pin State 2/4

- bit 7 = Pin 15 Data (1 on reset)
- bit 6 = Pin 14 Data (1 on reset)
- bit 5 = Pin 13 Data (1 on reset)
- bit 4 = Pin 12 Data (1 on reset)
- bit 3 = Pin 11 Data (1 on reset)
- bit 2 = Pin 10 Data (1 on reset)
- bit 1 = Pin 9 Data (1 on reset)
- bit $0 = Pin \ 8 \ Data \ (1 \ on \ reset)$

Register (R/W) \$9A (154) \Rightarrow Pi GPIO Pin State 3/4

- bit 7 = Pin 23 Data (1 on reset)
- bit 6 = Pin 22 Data (1 on reset)
- bit 5 = Pin 21 Data (1 on reset)
- bit 4 = Pin 20 Data (1 on reset)
- bit 3 = Pin 19 Data (1 on reset)
- bit 2 = Pin 18 Data (1 on reset)
- bit 1 = Pin 17 Data (1 on reset)
- bit 0 = Pin 16 Data (1 on reset)

Register (R/W) \$9B (155) \Rightarrow Pi GPIO Pin State 4/4

- bits 7-4 = Reserved
- bit 3 = Pin 27 Data (1 on reset)
- bit $2 = Pin \ 26 \ Data \ (1 \ on \ reset)$
- bit 1 = Pin 25 Data (1 on reset)
- bit 0 = Pin 24 Data (1 on reset)

Standardized I/O access with the Pi Zero can use the $\rm I^2C$, SPI, or UART interfaces and is configured using nextreg \$a0. Any enabled port will disable low level (write) access to the corresponding GPIO pins.

Register (R/W) A0 (160) \Rightarrow Pi Peripheral Enable

- bits 7-6 = Reserved, must be 0
- bit $5 = \text{Enable UART on GPIO } 14, 15 (0 \text{ on reset})^*$
- bit 4 = Communication Type (0 on reset)
 - -0 = Rx to GPIO 15, Tx to GPIO 14 (Pi)
 - -1 = Rx to GPIO 14, Tx to GPIO 15 (Pi Hats)
- bit $3 = \text{Enable I}^2\text{C on GPIO } 2, 3 (0 \text{ on reset})^*$
- bits 2-1 = Reserved, must be 0
- bit $0 = \text{Enable SPI on GPIO } 7, 8, 9, 10, 11 (0 \text{ on reset})^*$

*Overrides GPIO Enables

The I²C interface is controlled using ports \$103b (SCL) and \$113b (SDA). This is the same I²C interface that is used for the optional Real Time Clock. Interfacing with the Pi Zero over I²C is complicated by the fact that it is a master/slave interface, but both the ZX Spectrum Next and Pi Zero are configured to be bus masters.

```
Port $103B (4155) I<sup>2</sup>C SCL (rtc, rpi)
Port $113B (4411) I<sup>2</sup>C SDA (rtc, rpi)
```

The SPI interface is controlled using ports \$e7 (/CS) and \$eb (/DATA). The SPI interface is shared between the SD card(s), the flash memory, and the Pi Zero. Interfacing with the Pi Zero over SPI is complicated by the fact it is a master/slave interface and both the ZX Spectrum Next and Pi Zero are configured to be bus masters.

```
Port $E7 (231) SPI \overline{\text{CS}} (SD card, flash, rpi)
Disable with bit 2 of Nextreg $09
Port $EB (235) SPI \overline{\text{DATA}} (SD card, flash, rpi)
Disable with bit 2 of Nextreg $09
```

The default means of communication between the ZX Next and the Pi is through the UART interface (see serial communications chapter). In order to communicate withe the Pi the Pi UART must be connected to the Pi by setting nextreg \$a0 bits 5 and 4 to 1, selecting the Pi UART by setting port \$153b bit 6 to 1 and ensuring that both ends are using matching communication protocols (by default 115,200 bps, 8N1 and no flow control). On the Pi end the UART is connected to the serial console.

```
;;; enable UART connection with Pi Zero
    ld c,$3b
    ld b,$15; UART control
;;; select Pi on UART control
    in a,(c)
    or $40
    out (c),a
    ld b,$24; Next Register Select
    ld a,$a0
    out (c),a
    inc b; Next Register Data
;;; Enable UART on GPIO and select Pi
    in a,(c)
    or $30
    out (c),a
```

The I²S sound interface between the ZX Spectrum Next and the Pi Zero is controlled by nextregs \$a2 and \$a3. Normally, one would control the Pi through some other channel such as the UART recieve audio from the Pi to either use as a fulloy programmable sound card or to allow loading of tape files on the ZX Spectrum Next.

Register (R/W) \$A2 (162) \Rightarrow Pi I²S Audio Control

```
• bits 7-6 = I^2S State ($00 on reset)

- 00 = I^2S Disabled

- 01 = I^2S is mono, source R

- 10 = I^2S is mono, source L

- 11 = I^2S is stereo
```

- bit 5 = Reserved, must be 0
- bit 4 = Audio Flow Direction (0 on reset)
 - -0 = PCM DOUT to Pi, PCM DIN from Pi (Hats)
 - 1 = PCM DOUT from Pi, PCM DIN to Pi (Pi)
- bit 3 = Mute left (0 on reset)
- bit 2 = Mute right (0 on reset)
- bit 1 =Slave mode, Reserved must be 1 (remove in 3.01.05)
- bit $0 = \text{Direct I}^2S$ audio to EAR on port \$FE (0 on reset)

Register (R/W) \$A3 (163) \Rightarrow Pi $\ I^2S$ Clock Divide (Master Mode) (removed in 3.01.05)

• bits 7-0 = Clock divide value (\$0B on reset)

$$Divider = \frac{538461}{Rate} - 1 \text{ or } Rate = \frac{538461}{Divider + 1}$$

Chapter 11

System Software

$11.1 \quad CP/M$

The ZX Spextrum Next has support for CP/M+3.0. CP/M was the most popular microcomputer coperating system prior to the advent of MS-DOS.

11.1.1 Utilities

From the Digital Research: $\mathrm{CP/M}\ 3$ Command Reference Manual 1984

This section documents all standard ${\rm CP/M}+$ 3 commands plus those extras included with the ZX Spectrum Next ${\rm CP/M}$ system.

COLOURS

Syntax: COLOURS [RGB] paper ink

Function: Sets the screen colours

Parameters:

paper Paper (background) colour ink Ink (foreground) colour

Options:

RGB Causes ink and paper colours to be interpreted as 9-bit octal RGB

numbers

Notes: Sets the screen colours using standard ZX colours or octal 9-bit RGB numbers.

Examples:

colours 16

colours rgb 000 750

COPYSYS

Syntax: COPYSYS

Function: Copy CP/M system

Notes: COPYSYS copies the $\mathrm{CP/M}$ Plus system from a $\mathrm{CP/M}$ Plus system diskette to another diskette. The new diskette must have the same format as the original system diskette.

DATE

Syntax: DATE

DATE C

DATE CONTINUOUS DATE time-specification

DATE SET

Function: The DATE command lets you display and set the date and time of day.

Parameters:

time-specification Time/date in the format MM/DD/YY HH:MM:SS

Options:

C Continuously show the date and time until a key is pressed

CONTINUOUS Continuously show the date and time until a key is pressed

SET Prompt the user for the current date and time

Notes: The DATE command is a transient utility that lets you display and set the date and time of day. When you start CP/M 3, the date and time are set to the creation date of your CP/M 3 system. Use DATE to change this initial value to the current date and time.

Examples:

DATE

DATE C

DATE CONTINUOUS

DATE 08/13/82 09:15:37

DATE SET

DEVICE

Syntax:

```
DEVICE
DEVICE NAMES
DEVICE VALUES
DEVICE logical-dev {XON|NOXON|baud-rate},
DEVICE physical-dev {XON|NOXON|baud-rate}
DEVICE logical-dev=physical-dev {option} {,physical-dev {option},...}
DEVICE logical-dev = NULL
DEVICE CONSOLE {PAGE}
DEVICE CONSOLE {COLUMNS=n, LINES=n}
```

DEVICE displays current logical device assignments and physical device names.

```
DIR (built-in)
Syntax:
    DIR
    DIR d:
    DIR filespec
    DIR d: options
    DIR filespec,... filespec options
```

The DIR command displays the names of files catalogued in the directory of an online disk that belong to current user number and have the Directory (DIR) attribute. DIR accepts the * and? wildcards in the file specification.

The DIR command with options displays the names of files and the characteristics associated with the files. DIR is a built-in utility. DIR with options is a transient utility and must be loaded into memory from the disk.

DIRSYS/DIRS (built-in)

```
Syntax:
    DIRSYS
```

DIRSYS d:

DIRSYS filespec

The DIRSYS command lists the names of files in the current directory that have the system (SYS) attribute. DIRSYS accept the * and? wildcards in the file specification. DIRSYS is a built-in utility.

DUMP

```
Syntax:
```

DUMP filespec

DUMP displays the contents of a file in and ASCII format.

ECHO (ZX Spectrum Next)

Syntax:

ECHO string

Echo characters to the terminal

The following special character sequences may be used

- \a alert (bell) (ASCII 7)
- \b backspace (ASCII 8)
- \e escape (ASCII 27)
- \n line feed (ASCII 10)
- \r carriage return (ASCII 13)
- \l interpret further characters as lower-case
- \u interpret further characters as upper-case
- \\backslash ('\')

Note that CP/M converts all your typed characters to upper-case before providing them to ECHO.COM. Therefore you will need to use \l and \u to specify the case of characters if it is important (in ESCape sequences, for example).

ED

Syntax:

ED

ED input-filespec

ED input-filespec {d: | output-filespec}

Character file editor. To redirect or rename the new version of the file specify the destination drive or destination filespec.

ERASE/ERA (built-in)

Syntax:

ERASE

ERASE filespec

ERASE filespec [CONFIRM]

The ERASE command removes one or more files from the directory of a disk. Wildcard characters are accepted in the filespec. Directory and data space are automatically reclaimed for later use by another file. The ERASE command can be abbreviated to ERA.

[CONFIRM] option informs the system to prompt for verification before erasing each file that matches the filespec. CONFIRM can be abbreviated to C.

```
EXIT (ZX Spectrum Next)
```

Syntax:

EXIT

The EXIT command leaves CP/M (rebooting the ZX Spectrum Next)

EXPORT (ZX Spectrum Next)

Syntax:

EXPORT cpm-filespec nextzxos-filespec

NextZXOS file export utility

Export file to a NextZXOS drive.

GENCOM

```
Syntax:
```

```
GENCOM COM-Eilespec RSX-filespec... RSX-Eilespec {[LOADER | SCB=(Offset,value)]} GENCOM RSX-filespec ... RSX-filespec {[NULL | SCB=(Offset,value)]} GENCOM filename [SCB=(offset,value)]
```

The GENCOM command attaches RSX files to a COM file, or creates a dummy COM file containing only RSXS. It can also restore a previously GENCOMed file to the original COM file without the header and RSXS, add or replace RSXs in already GENCOMed files, and attach header records to COM files without RSXS.

GENCPM

Syntax:

GENCPM {AUTO|AUTO DISPLAY}

GENCPM creates a memory image CPM3.SYS file, containing the CP/M 3 BDOS and customized BIOS. The GENCPM utility performs late resolution of intermodule references between system modules. GENCPM can accept its command input interactively from the console or from a file GENCPM.DAT.

In the nonbanked system, GENCPM creates a CPM3.SYS file from the BDOS3.SPR and BIOS3.SPR files. In the banked system, GENCPM creates the CPM3.SYS file from the RESBDOS3.SPR, the BNKBDOS3.SPR and the BNKBIOS3.SPR files. Remember to back up your CPM3.SYS file before executing GENCPM, because GENCPM deletes any existing CPM3.SYS file before it generates a new system.

GET

Syntax:

```
GET {CONSOLE INPUT FROM} FILE filespec options GET {CONSOLE INPUT FROM} CONSOLE
```

GET directs the system to take console input from a file for the next system comand or user program entered at the console.

Console input is taken from a file until the program terminates. If the file is exhausted before program input is terminated, the program looks for subsequent input from the console. If the program terminates before exhausting all its input, the system reverts back to the console for console input.

HELP

Syntax:

HELP

```
HELP topic
HELP topic subtopic
HELP topic [NOPAGE]
HELP topic subtopic1...subtopic8
HELP>topic
HELP>.subtopic
```

HELP displays a list of topics and provides summarized information for CP/M Plus commands.

Typing HELP topic displays information about that topic. Typing HELP topic subtopic displays information about that subtopics One or two letters is enough to identify the topics. After HELP displays information for your topic, it displays the special prompt HELP> on your screen, followed by a list of subtopics.

- Enter? to display list of main topics.
- Enter a period and subtopic name to access subtopics.
- Enter a period to redisplay what you just read.
- Press RETURN to return to the CP/M Plus system prompt.
- [NOPAGE] option disables the 24 lines per page console display.
- Press any key to exit a display and return to the HELP> prompt.

HEXCOM

Syntax:

HEXCOM filename

The HEXCOM Command generates a command file (filetype COM) from a HEX input file. it names the output tile with the same filename as the input file but with filetype COM. HEXCOM always looks for a file with filetype HEX.

```
IMPORT (ZX Spectrum Next)
```

Syntax:

```
IMPORT nextzxos-filespec IMPORT nextzxos-filespec cpm-filespec
```

NextZXOS file import utility

List or import files from a NextZXOS drive.

INITDIR (Not included)

Syntax:

INITDIR d:

The INITDIR command initializes a disk directory to allow date and time stamping of files on that disk. INITDIR can also recover time/date directory space.

NEXTREG (ZX Spectrum Next)

Syntax:

```
NEXTREG register {value}
```

NextReg Utility

Show or change a NextReg register (use at your own risk!)

LIB (Not included)

Syntax:

LIB filespec options

LIB filespec options=filespec <modifier> f,filespec<modifier>

A library is a file that contains a collection of object modules.

Use the LIB utility to create libraries, and to append, replace, select, or delete modules from an existing library. Use LIB to obtain information about the contents of library files. LIB creates and maintains library files that contain object modules in Microsoft REL file format. These modules are produced by the Digital Research relocatable macro-assembler program, RMAC, or other language translator that produces modules in Microsoft REL file format.

You can use LINK-80 to link the object modules contained in a library to other object files. LINK-80 automatically selects from the library only those modules needed by the program being linked, and then forms an executable file with a filetype of Com.

LINK (Not included)

Syntax:

LINK filespec [options]

LINK filespec [options],...filespec [options] LINK filespec [options]=filespec [options],...

LINK combines relocatable object modules such as those produced by RMAC and PL/I- 80 into a COM file ready for execution. Relocatable files can contain external references and publics. Relocatable files can reference modules in library files. LINK searches the library files and includes the referenced modules in the output file. See the Programmer's Utilities Guide for the CP/M Family of Operating Systems for a complete description of LINK-80.

Use LINK option switches to control execution parameters. Link options follow the file specifications and are enclosed within square brackets. Multiple switches are separated by commas.

MAC (Not included)

Syntax:

MAC filename [\$options]

MAC, the CP/M Plus macro assembler, reads assembly language statements from a file of type ASM, assembles the statements, and produces three output files with the input filename and filetypes of HEX, PRN, and SYM. File-

name.HEX contains Intel hexadecimal format object code. Filename.PRN contains an annotated source listing that you can print or examine at the console. Filename.SYM contains a sorted list of symbols defined in the program.

Use options to direct the input and output of MAC. Use a letter with the option to indicate the source and destination drives, and console, printer, or zero output. Valid drive names are A through 0. X, P, and Z specify console, printer, and zero output, respectively.

PATCH

Syntax:

PATCH filename.typ n

The PATCH command displays or installs patch number n to the $\mathrm{CP/M}$ Plus system or command files. The patch number n must be between 1 and 32 inclusive.

PIP

Syntax:

```
PIP Destination = Source
PIP d:[Gn]=filespec [options]
PIP filespec[Gn]=filespec [options]
PIP filespec[Gn]device=filespec [options] device
```

The file copy program PIP copies files, combines files, and transfers files between disks, printers, consoles, or other devices attached to your computer. The first filespec is the destination. The second filespec is the source. Use two or more source filespecs separated by commas to combine two or more files into one file. [options] is any combination of the available options. The [Gn] option in the destination filespec tells PIP to copy your file to that user number. PIP with no command tail displays an * prompt and awaits your series of commands, entered and processed one line at a time. The source or destination can optionally be any CP/M Plus logical device.

PUT

Syntax:

```
PUT CONSOLE {OUTPUT TO} FILE filespec {option}
PUT PRINTER {OUTPUT TO} FILE filespec {option}
PUT CONSOLE {OUTPUT TO} CONSOLE
PUT PRINTER {OUTPUT TO} PRINTER
```

PUT puts console or printer output to a file for the next command entered at the console, until the program terminates. Then console output reverts to the console. Printer output is directed to a file until the program terminates. Then printer output is put back to the printer.

PUT with the SYSTEM option directs all subsequent console/printer output to the specified file. This option terminates when you enter the PUT CONSOLE

or PUT PRINTER command.

RENAME/REN (built-in)

Syntax:

RENAME

RENAME new-filespec=old-filespec

RENAME lets you change the name of a file in the directory of a disk. To change several filenames in one command use the * or ? wildcards in the file specifications. You can abbreviate the RENAME command to REN. REN prompts you for input.

RMAC (Not included)

Syntax:

RMAC filespec options

RMAC, a relocatable macro assembler, assembles ASM files into REL files that you can link to create COM files.

RMAC options specify the destination of the output files. Replace d with the destination drive letter for the output files.

SAVE

Syntax:

SAVE

SAVE copies the contents of memory to a file. To use SAVE, first issue the SAVE command, then run your program which reads a file into memory. Your program exits to the SAVE utility which prompts you for a filespec to which it copies the contents of memory, and the beginning and ending address of the memory to be SAVED.

SET

Syntax:

SET [options]
SET d: [options]
SET filespec [options]
SET [option = modifier]
SET filespec [option = modifier]

SET initiates password protection and time stamping of files. It also sets the file and drive attributes Read/Write, Read/Only, DIR and SYS. It lets you label a disk and passord protect the label. To enable time stamping of files, you must first run INITDIR to format the disk directory.

SET Default password operation:

Syntax:

SET [DEFAULT=password]

Instructs the system to use a default password if you do not enter a password for a password-protected file.

SET Time-stamp operations:

Syntax:

```
SET d: [CREATE=ON|OFF]
SET d: [ACCESS=ON|OFF]
SET d: [UPDATE=ON|OFF]
```

The above set commands allw YOU to keep a record of the time and date of file creation and update or of the last access update of your files.

SET Drive operations:

```
Syntax:
```

```
SET d: [RO]
SET d: [RW]
```

Adds or removes write protection from a drive.

SETDEF

```
Syntax:
```

```
SETDEF
SETDEF [TEMPORARY=d:]
SETDEF d:i,d:i,d:i,d:i
SETDEF [ORDER= (typ1, typn)]
SETDEF [DISPLAY | NO DISPLAY)
SETDEF [PAGE | NOPAGE]
```

SETDEF allows the user to display or define up to four drives for the program search order, the drive for temporary files, and the filetype search order. The SETDEF definitions affect only the loading of programs and/or execution of SUBMIT (SUB) files. SETDEF turns on/off the system Display and Console Page modes. When on, the system displays the location and name of programs loaded or SUBmit files executed, and stops after displaying one full console screen of information.

SHOW

Syntax:

```
SHOW
SHOW d:
SHOW d: [SPACE]
SHOW d: [LABEL]
SHOW d: [USERS]
SHOW d: [DIR]
SHOW d: [DRIVE]
```

The SHOW command displays the following disk drive information:

- access mode and the amount of free disk space
- disk label
- current user number
- number of files for each user number on the disk
- number of free directory entries for the disk
- drive characteristics

SID

Syntax:

SID [pgm-filespec], {sym-filespec}

The SID symbolic debugger allows you to monitor and test programs developed for the 8080 microprocessor. SID supports real-time breakpoints, fully monitored execution, symbolic disassembly, assembly, and memory display and fill functions. SID can dynamically load SID utility programs to provide traceback and histogram facilities.

SUBMIT

Syntax:

SUBMIT

SUBMIT filespec

SUBMIT filespec argument ... argument

The SUBMIT command lets you execute a group (batch) of commands from a SUBmit file (a file with filetype of SUB).

SUB files:

The SUB file can contain the following types of lines:

- any valid CP/M Plus command
- any valid CP/M Plus command with SUBMIT parameters (\$0-\$9)
- any data input line
- any program input line with parameters (\$0 to \$9)

The command line cannot exceed 135 characters.

TERMINFO (ZX Spectrum Next)

Syntax:

TERMINFO

This program provides information on the terminal facilities provided by the BIOS on the ZX Spectrum Next.

TERMSIZE (ZX Spectrum Next)

Syntax:

TERMSIZE top left height width

Terminal resize utility

Size can be up to 32x80 (defaults to 24x80, suitable for many programs). If setting a reduced size, the top and left parameters can be used to make the image more centered on your screen.

```
TYPE/TYP (built-in)
```

Syntax:

TYPE

TYPE filespec

TYPE filespec [PAGE]

TYPE filespec [NOPAGE]

The TYPE command displays the contents of an ASCII character file on your screen.

UPGRADE (ZX Spectrum Next)

Syntax:

UPGRADE

UPGRADE CP/M from C:/NEXTZXOS/CPMBASE.P3D

USER/USE (built-in)

Syntax:

USER

USER n

The USER command sets the current user number. The disk directory can be divided into distinct groups according to a User Number. User numbers range from 0 through 15.

XREF (Not included)

Syntax:

XREF {d:} filename {\$P}

XREF provides a cross-reference summary of variable usage in a program. XREF requires the PRN and SYM files produced by MAC or RMAC for input to the program. The SYM and PRN files must have the same filename as the filename in the XREF command tail. XREF outputs a file of type XRF.

11.1.2 BDOS

From the CP/M 3 Programmers' Guide 1984

This section documents all BDOS system calls to include the parameters that must be passes to them and the values that are returned to the calling program.

BDOS function 0: SYSTEM RESET

Entry Parameters:

C: \$00

The System Reset function terminates the calling program and returns control to the CCP via a warm start sequence. Calling this function has the same effect as a jump to location \$0000 of Page Zero.

Note that the disk subsystem is not reset by System Reset under CP/M 3. The calling program can pass a return code to the CCP by calling Function 108, Get/Set Program Return Code, prior to making a System Reset call or jumping to location \$0000.

BDOS function 1: CONSOLE INPUT

Entry Parameters:

C: \$01

Returned Value:

A: ASCII Character

The Console Input function reads the next character from the logical console, CONIN:, to register A. Graphic characters, along with carriage return, line-feed, and backspace, CTRL-H, are echoed to the console. Tab characters, CTR-L-1, are expanded in columns of 8 characters. CTRL-S, CTRL-Q, and CTRL-P are normally intercepted as described below. All other non-graphic characters are returned in register A but are not echoed to the console.

When the Console Mode is in the default state Function 1 intercepts the stop scroll, CTRL-S, start scroll, CTRL-Q, and start/stop printer echo, CTRL-P, characters. Any characters that are typed following a CTRL-S and preceding a CTRL-Q are also intercepted. However, if start/stop scroll has been disabled by the Console Mode, the CTRL-S, CTRL-Q, and CTRL-P characters are not intercepted. Instead, they are returned in register A, but are not echoed to the console.

If printer echo has been invoked, all characters that are echoed to the console are also sent to the list device, LST:. Function 1 does not return control to the calling program until a non-intercepted character is typed, thus suspending execution if a character is not ready.

BDOS function 2: CONSOLE OUTPUT

Entry Parameters:

C: \$02

E: ASCII Character

The Console Output function sends the ASCII character from register E to the logical console device, CONOUT:. When the Console Mode is in the default state (see Section 2.2.1), Function 2 expands tab characters, CTRL-1, in columns of 8 characters, checks for stop scroll, CTRL-S, start scroll, CTRL-Q, and echoes characters to the logical list device, LST:, if printer echo, CTRL-P,

has been invoked.

BDOS function 3: AUXILIARY INPUT

Entry Parameters:

C: \$03

Returned Value:

A: ASCII Character

The Auxiliary Input function reads the next character from the logical auxiliary input device, AUXIN:, into register A. Control does not return to the calling program 'I the character is read. unti

BDOS function 4: AUXILIARY OUTPUT

Entry Parameters:

C: \$04

E: ASCII Character

The Auxiliary Output function sends the ASCII character from register E to the logical auxiliary output device, AUXOUT:.

BDOS function 5: LIST OUTPUT

Entry Parameters:

C: \$05

E: ASCII Character

The List Output function sends the ASCII character in register E to the logical list device, LST:.

BDOS function 6: **DIRECT CONSOLE I/O**

Entry Parameters:

C: \$06

E: function/data (see description)

Returned Value:

A: char/status/no value (see description)

CP/M 3 supports direct I/O to the logical console, CONIN:, for those specialized applications where unadorned console input and output is required. Use Direct Console I/O carefully because it bypasses all the normal control character functions. Programs that perform direct I/O through the BIOS under previous releases of CP/M should be changed to use direct I/O so that they can be fully supported under future releases of MP/M and CP/M.

A program calls Function 6 by passing one of four different values in register E.

• \$FF Console input/status command returns an input character; if no char-

acter is ready, a value of zero is returned.

- \$FE Console status command (On return, register A contains 00 if no character is ready; otherwise it contains \$FF.)
- \$FD Console input command, returns an input character; this function will suspend the calling process until a character is ready.
- ASCII Function 6 assumes that register E contains a valid ASCII chararacter and sends it to the console.

BDOS function 7: AUXILIARY INPUT STATUS

Entry Parameters:

C: \$07

Returned Value:

A: Auxiliary Input Status

The Auxiliary Input Status function returns the value \$FF in register A if a character is ready for input from the logical auxiliary input device, AUXIN:. If no character is ready for input, the value \$00 is returned.

BDOS function 8: AUXILIARY OUTPUT STATUS

Entry Parameters:

C: \$08

Returned Value:

A: Auxiliary Output Status

The Auxiliary Output Status function returns the value \$FF in register A if the logical auxiliary output device, AUXOUT:, is ready to accept a character for output. If the device is not ready for output, the value \$00 is returned.

BDOS function 9: PRINT STRING

Entry Parameters:

C: \$09

DE: String Address

The Print String function sends the character string addressed by register pair DE to the logical console, CONOUT:, until it encounters a delimiter in the string. Usually the delimiter is a dollar sign, \$, but it can be changed to any other value by Function 110, Get/Set Output Delimiter. If the Console Mode is in the default state, Function 9 expands tab characters, CTRL-I, in columns of 8 characters. It also checks for stop scroll, CTRL-S, start scroll, CTRL-Q, and echoes to the logical list device, LST:, if printer echo, CTRL-P, has been invoked.

BDOS function 10: READ CONSOLE BUFFER

Entry Parameters:

C: \$0A DE: Buffer Address

Returned Value:

Console Characters in Buffer

The Read Console Buffer function reads a line of edited console input from the logical console, CONIN:, to a buffer that register pair DE addresses. It terminates input and returns to the calling program when it encounters a return, CTRL-M, or a line feed, CTRL-J, character. Function 10 also discards all input characters after the input buffer is filled. In addition, it outputs a bell character, CTRL-G, to the console when it discards a character to signal the user that the buffer is full. The input buffer addressed by DE has the following format:

where mx is the maximum number of characters which the buffer holds, and nc is the number of characters placed in the buffer. The characters entered by the operator follow the nc value. The value mx must be set prior to making a Function 10 call and may range in value from 1 to 255. Setting mx to zero is equivalent to setting mx to one. The value nc is returned to the calling program and may range from zero to mx. If nc < mx, then uninitialized positions follow the last character, denoted by ?? in the figure. Note that a terminating return or line feed character is not placed in the buffer and not included in the count nc.

If register pair DE is set to zero, Function 10 assumes that an initialized input buffer is located at the current DMA address (see Function 26, Set DMA Address). This allows a program to put a string on the screen for the user to edit. To initialize the input buffer, set characters c1 through cn to the initial value followed by a binary zero terminator.

When a program calls Function 10 with an initialized buffer, Function 10 operates as if the user had typed in the string. When Function 10 encounters the binary zero terminator, it accepts input from the console. At this point, the user can edit the initialized string or accept it as it is by pressing the RETURN key. However, if the initialized string contains a return, CTRL-M, or a linefeed, CTRL-J, character, Function 10 returns to the calling program without giving the user the opportunity to edit the string.

The level of console editing supported by Function 10 differs for the banked and nonbanked versions of CP/M 3. Refer to the CPIM Plus (CPIM Version 3) Operating System User's Guide for a detailed description of console editing. In the nonbanked version, Function 10 recognizes the following edit control characters.

Nonbanked CP/M 3

- $\bullet\,$ rub/del Removes and echoes the last character; GENCPM can change this function to CTRL-H
- CTRL-C Reboots when at the beginning of line; the Console Mode can

disable this function

- CTRL-E Causes physical end of line
- CTRL-H Backspaces one character position; GENCPM can change this function to rub/del
- CTRL-J (Line-feed) terminates input line
- CTRL-M (Return) terminates input line
- CTRL-P Echoes console output to the list device
- CTRL-R Retypes the current line after new line
- CTRL-U Removes current line after new line
- CTRL-X Backspaces to beginning of current line

The banked version of CP/M 3 expands upon the editing provided in the non-banked version. The functionality of the two versions is similar when the cursor is positioned at the end of the line. However, in the banked version, the user can move the cursor anywhere in the current line, insert characters, delete characters, and perform other editing functions. In addition, the banked version saves the previous command line; it can be recalled when the current line is empty. In the banked version, Function 10 recognizes the following edit control characters.

Banked CP/M 3

- rub/del Removes and echoes the last character if at the end of the line; otherwise deletes the character to the left of the current cursor position; GENCPM can change this function to CTRL-H.
- CTRL-A Moves cursor one character to the left.
- CTRL-B Moves cursor to the beginning of the line when not at the beginning; otherwise moves cursor to the end of the line.
- CTRL-C Reboots when at the beginning of line; the Console Mode can disable this function.
- CTRL-E Causes physical end-of-line; if the cursor is positioned in the middle of a line, the characters at and to the right of the cursor are displayed on the next line.
- CTRL-F Moves cursor one character to the right.
- CTRL-G Deletes the character at the current cursor position when in the middle of the line; has no effect when the cursor is at the end of the line.
- CTRL-H Backspaces one character position when positioned at the end of the line,; otherwise deletes the character to the left of the cursor; GENCPM can change this function to rub/del.
- CTRL-J (Line-feed) terminates input; the cursor can be positioned anywhere in the line; the entire input line is accepted; sets the previous line buffer to the input line.
- CTRL-K Deletes all characters to the right of the cursor along with the character at the cursor.
- CTRL-M (Return) terminates input; the cursor can be positioned anywhere in the line; the entire input line is accepted; sets the previous line buffer to the input line.

- CTRL-P Echoes console output to the list device.
- CTRL-R Retypes the characters to the left of the cursor on the new line.
- CTRL-U Updates the previous line buffer to contain the characters to the left of the cursor; deletes current line, and advances to new line.
- CTRL-W Recalls previous line if current line is empty; otherwise moves cursor to end-of-line.
- CTRL-X Deletes all characters to the left of the cursor.

For banked systems, Function 10 uses the console width field defined in the System Control Block. If the console width is exceeded when the cursor is positioned at the end of the line, Function 10 automatically advances to the next line. The beginning of the line can be edited by entering a CTRL-R.

When a character is typed while the cursor is positioned in the middle of the line, the typed character is inserted into the line. Characters at and to the right of the cursor are shifted to the right. If the console width is exceeded, the characters disappear off the right of the screen. However, these characters are not lost. They reappear if characters are deleted out of the line, or if a CTRL-E is typed.

BDOS function 11: GET CONSOLE STATUS

Entry Parameters:

C: \$0B

Returned Value:

A: Console Status

The Get Console Status function checks to see if a character has been typed at the logical console, CONIN:. If the Console Mode is in the default state, Function 11 returns the value \$01 in register A when a character is ready. If a character is not ready, it returns a value of \$00.

If the Console Mode is in CTRL-C Only Status mode, Function 11 returns the value \$01 in register A only if a CTRL-C has been typed at the console.

BDOS function 12: RETURN VERSION NUMBER

Entry Parameters:

C: \$0C

Returned Value:

HL: Version Number

The Return Version Number function provides information that allows version independent programming. It returns a two-byte value in register pair HL: H contains \$00 for CP/M and L contains \$31, the BDOS file system version number. Function 12 is useful for writing applications programs that must run on multiple versions of CP/M and MP/M.

BDOS function 13: RESET DISK SYSTEM

Entry Parameters:

C: \$0D

The Reset Disk System function restores the file system to a reset state where all the disk drives are set to read-write (see Functions 28 and 29), the default disk is set to drive A, and the default DMA address is reset to \$0080. This function can be used, for example, by an application program that requires disk changes during operation. Function 37, Reset Drive, can also be used for this purpose.

BDOS function 14: **SELECT DISK**

Entry Parameters:

C: \$0E

E: Selected Disk

Returned Value:

A: Error Flag H: Physical Error

The Select Disk function designates the disk drive named in register E as the default disk for subsequent BDOS file operations. Register E is set to 0 for drive A, 1 for drive B, and so on through 15 for drive P in a full 16-drive system. In addition, Function 14 logs in the designated drive if it is currently in the reset state. Logging-in a drive activates the drive's directory until the next disk system reset or drive reset operation.

FCBs that specify drive code zero (dr = \$00) automatically reference the currently selected default drive. FCBs with drive code values between 1 and 16, however, gnore the selected default drive and directly reference drives A through P.

Upon return, register A contains a zero if the select operation was successful. If a physical error was encountered, the select function performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is in the default mode, a message identifying the error is displayed at the console, and the calling program is terminated. Otherwise, the select function returns to the calling program with register A set to \$FF and register H set to one of the following

physical error codes:

- 01 Disk I/O Error
- 04 Invalid drive

BDOS function 15: **OPEN FILE**

Entry Parameters:

C: \$0F

DE: FCB Address

Returned Value:

A: Directory Code

H: Physical or Extended Error

The Open File function activates the FCB for a file that exists in the disk directory under the currently active user number or user zero. The calling program passes the address of the FCB in register pair DE, with byte 0 of the FCB specifying the drive, bytes 1 through 11 specifying the filename and filetype, and byte 12 specifying the extent. Usually, byte 12 of the FCB is initialized to zero.

If the file is password protected in Read mode, the correct password must be placed in the first eight bytes of the current DMA, or have been previously established as the default password (see Function 106). If the current record field of the FCB, cr, is set to \$FF, Function 15 returns the byte count of the last record of the file in the cr field. You can set the last record byte count for a file with Function 30, Set File Attributes. Note that the current record field of the FCB, cr, must be zeroed by the calling program before beginning read or write operations if the file is to be accessed sequentially from the first record.

If the current user is non-zero, and the file to be opened does not exist under the current user number, the open function searches user zero for the file. If the file exists under user zero, and has the system attribute, t2', set, the file is opened under user zero. Write operations are not supported for a file that is opened under user zero in this manner.

If the open operation is successful, the user's FCB is activated for read and write operations. The relevant directory information is copied from the matching directory FCB into bytes d0 through dn of the FCB. If the file is opened under user zero when the current user number is not zero, interface attribute f8' is set to one in the user's FCB. In addition, if the referenced file is password protected in Write mode, and the correct password was not passed in the DMA, or did not match the default password, interface attribute f7' is set to one. Write operations are not supported for an activated FCB if interface attribute f7' or f8' is true.

When the open operation is successful, the open function also makes an Access date and time stamp for the opened file when the following conditions are satisfied: the referenced drive has a directory label that requests Access date and time stamping, and the FCB extent number field is zero.

Upon return, the Open File function returns a directory code in register A with the value \$00 if the open was successful, or \$FF, 255 decimal, if the file was not found. Register H is set to zero in both of these cases. If a physical or extended error was encountered, the Open File function performs different actions depending on the BDOS error mode (see Function 45). If the BDOS

error mode is in the default mode, a message identifying the error is displayed at the console and the program is terminated. Otherwise, the Open File function returns to the calling program with register A set to \$FF, and register H set to one of the following physical or extended error codes:

• 01 : Disk I/O Error

• 04 : Invalid drive error

• 07 : File password error

 $\bullet~09$: ? in the FCB file name or filetype field

BDOS function 16: CLOSE FILE

Entry Parameters:

C: \$10

DE: FCB Address

Returned Value:

A: Directory Code

H: Physical or Extended Error

The Close File function performs the inverse of the Open File function. The calling program passes the address of an FCB in register pair DE. The referenced FCB must have been previously activated by a successful Open or Make function call (see Functions 15 and 22). Interface attribute f5' specifies how the file is to be closed as shown below:

• f5' = 0 - Permanent close (default mode)

• f5' = 1 - Partial close

A permanent close operation indicates that the program has completed file operations on the file. A partial close operation updates the directory, but indicates that the file is to be maintained in the open state.

If the referenced FCB contains new information because of write operations to the FCB, the close function permanently records the new information in the referenced disk directory. Note that the FCB does not contain new information, and the directory update step is bypassed if only read or update operations have been made to the referenced FCB.

Upon return, the close function returns a directory code in register A with the value \$00 if the close was successful, or \$FF, 255 Decimal, if the file was not found. Register H is set to zero in both of these cases. If a physical or extended error is encountered, the close function performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is in the default mode, a message identifying the error is displayed at the console, and the calling program is terminated. Otherwise, the close function returns to the calling program with register A set to \$FF and register H set to one of the following physical error codes:

• 01 Disk I/O error

- 02 Read/only disk
- 04 Invalid drive error

BDOS function 17: SEARCH FOR FIRST

Entry Parameters:

C: \$11

DE: FCB Address

Returned Value:

A: Directory Code H: Physical Error

The Search For First function scans the directory for a match with the FCB addressed by register pair DE. Two types of searches can be performed. For standard searches, the calling program initializes bytes 0 through 12 of the referenced FCB, with byte 0 specifying the drive directory to be searched, bytes 1 through 11 specifying the file or files to be searched for,, and byte 12 specifying the extent. Usually byte 12 is set to zero. An ASCII question mark, 63 decimal, 3F hex, in any of the bytes 1 through 12 matches all entries on the directory in the corresponding position. This facility, called ambiguous reference, can be used to search for multiple files on the directory. When called in the standard mode, the Search function scans for the first file entry in the specified directory that matches the FCB, and belongs to the current user number.

The Search For First function also initializes the Search For Next function. After the Search function has located the first directory entry matching the referenced FCB, the Search For Next function can be called repeatedly to locate all remaining matching entries. In terms of execution sequence, however, the Search For Next call must either follow a Search For First or Search For Next call with no other intervening BDOS disk-related function calls.

If byte 0 of the referenced FCB is set to a question mark, the Search function ignores the remainder of the referenced FCB, and locates the first directory entry residing on the current default drive. All remaining directory entries can be located by making multiple Search For Next calls. This type of search operation is not usually made by application programs, but it does provide complete flexibility to scan all current directory values. Note that this type of search operation must be performed to access a drive's directory label.

Upon return, the Search function returns a Directory Code in register A with the value 0 to 3 if the search is successful, or \$FF, 255 Decimal, if a matching directory entry is not found. Register H is set to zero in both of these cases. For successful searches, the current DMA is also filled with the directory record containing the matching entry, and the relative starting position is A * 32 (that is, rotate the A register left 5 bits, or ADD A five times). Although it is not usually required for application programs, the directory information can be

extracted from the buffer at this position.

If the directory has been initialized for date and time stamping by INITDIR, then an SFCB resides in every fourth directory entry, and successful Directory Codes are restricted to the values 0 to 2. For successful searches, if the matching directory record is an extent zero entry, and if an SFCB resides at offset 96 within the current DMA, contents of (DMA Address + 96) = \$21, the SFCB contains the date and time stamp information, and password mode for the file. This information is located at the relative starting position of 97 + (A * 10) within the current DMA in the following format:

- 0 3 Create or Access Date and Time Stamp Field
- 4 7 Update Date and Time Stamp Field
- 8 : Password Mode Field

If a physical error is encountered, the Search function performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is in the default mode, a message identifying the error is displayed at the console, and the calling program is terminated. Otherwise, the Search function returns to the calling program with register A set to \$FF, and register H set to one of the following physical error codes:

- 01 Disk I/O error
- 04 Invalid drive error

BDOS function 18: SEARCH FOR NEXT

Entry Parameters:

C: \$12

Returned Value:

A: Directory Code H: Physical Error

The Search For Next function is identical to the Search For First function, except that the directory scan continues from the last entry that was matched. Function 18 returns a Directory code in register A, analogous to Function 17.

Note: in execution sequence, a Function 18 call must follow either a Function 17 or another Function 18 call with no other intervening BDOS disk-related function calls.

BDOS function 19: **DELETE FILE**

Entry Parameters:

C: \$13

DE: FCB Address

Returned Value:

A: Directory Code

H: Extended or Physical Error

The Delete File function removes files or XFCBs that match the FCB addressed in register pair DE. The filename and filetype can contain ambiguous references, that is, question marks in bytes f1' through t3', but the dr byte cannot be ambiguous, as it can in the Search and Search Next functions. Interface attribute f5' specifies the type of delete operation that is performed.

- f5' = 0 Standard Delete (default mode)
- f5' = 1 Delete only XFCBs

If any of the files that the referenced FCB specify are password protected, the correct password must be placed in the first eight bytes of the current DMA buffer, or have been previously established as the default password (see Function 106).

For standard delete operations, the Delete function removes all directory entries belonging to files that match the referenced FCB. All disk directory and data space owned by the deleted files is returned to free space, and becomes available for allocation to other files. Directory XFCBs that were owned by the deleted files are also removed from the directory. If interface attribute f5' of the FCB is set to 1, Function 19 deletes only the directory XFCBs that match the referenced FCB.

Note: if any of the files that match the input FCB specification fall the password check, or are Read-Only, then the Delete function does not delete any files or XFCBS. This applies to both types of delete operations.

In nonbanked systems, file passwords and XFCBs are not supported. Thus, if the Delete function is called with interface attribute f5' set to true, the Delete function performs no action but returns with register A set to zero.

Upon return, the Delete function returns a Directory Code in register A with the value 0 if the delete is successful, or \$FF, 255 Decimal, if no file that matches the referenced FCB is found. Register H is set to zero in both of these cases. If a physical, or extended error is encountered, the Delete function performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is the default mode, a message identifying the error is displayed at the console and the calling program is terminated. Otherwise, the Delete function returns to the calling program with register A set to \$FF and register H set to one of the following physical or extended error codes:

01 : Disk I/O error
02 : Read-Only disk
03 : Read-Only file
04 : Invalid drive error
07 : File password error

BDOS function 20: READ SEQUENTIAL

Entry Parameters:

C: \$14

DE: FCB Address

Returned Value:

A: Error Code H: Physical Error

The Read Sequential function reads the next 1 to 128 128-byte records from a file into memory beginning at the current DMA address. The BDOS Multi-Sector Count (see Function 44) determines the number of records to be read. The default is one record. The FCB addressed by register pair DE must have been previously activated by an Open or Make function call.

Function 20 reads each record from byte cr of the extent, then automatically increments the cr field to the next record position. If the cr field overflows, then the function automatically opens the next logical extent and resets the cr field to 0 in preparation for the next read operation. The calling program must set the cr field to 0 following the Open call if the intent is to read sequentially from the beginning of the file. Upon return, the Read Sequential function sets register A to zero if the read operation is successful. Otherwise, register A contains an error code identifying the error as shown below:

- 01 Reading unwritten data (end-of-file)
- 09 Invalid FCB
- 10 Media change occurred
- 255 Physical Error; refer to register H

Error Code 01 is returned if no data exists at the next record position of the file. Usually, the no data situation is encountered at the end of a file. However, it can also occur if an attempt is made to read a data block that has not been previously written, or an extent which has not been created. These situations are usually restricted to files created or appended with the BDOS random write functions (see Functions 34 and 40).

Error Code 09 is returned if the FCB is invalidated by a previous BDOS close call that returns an error.

Error Code 10 is returned if a media change occurs on the drive after the referenced FCB is activated by a BDOS Open, or Make Call.

Error Code 255 is returned if a physical error is encountered and the BDOS error mode is Return Error mode, or Return and Display Error mode (see Function 45). If the error mode is the default mode, a message identifying the physical error is displayed at the console, and the calling program is terminated. When a physical error is returned to the calling program, register H contains one of the following error codes:

- 01 Disk I/O error
- 04 Invalid drive error

On all error returns except for physical error returns, A=255, Function 20 sets register H to the number of records successfully read before the error is encountered. This value can range from 0 to 127 depending on the current BDOS Multi-Sector Count. It is always set to zero when the Multi-Sector Count is equal to one.

BDOS function 21: WRITE SEQUENTIAL

Entry Parameters:

C: \$15

DE: FCB Address

Returned Value:

A: Error Code H: Physical Error

The Write Sequential function writes 1 to 128 128-byte data records, beginning at the current DMA address into the file named by the FCB addressed in register pair DE. The BDOS Multi-Sector Count (see Function 44) determines the number of 128 byte records that are written. The default is one record. The referenced FCB must have been previously activated by a BDOS Open or Make function call.

Function 21 places the record into the file at the position indicated by the cr byte of the FCB, and then automatically increments the cr byte to the next record position. If the cr field overflows, the function automatically opens, or creates the next logical extent, and resets the cr field to 0 in preparation for the next write operation. If Function 21 is used to write to an existing file, then the newly written records overlay those already existing in the file. The calling program must set the cr field to 0 following an Open or Make call if the intent is to write sequentially from the beginning of the file.

Function 21 makes an Update date and time for the file if the following conditions are satisfied: the referenced drive has a directory label that requests date and time stamping, and the file has not already been stamped for update by a previous Make or Write function call.

Upon return, the Write Sequential function sets register A to zero if the write operation is successful. Otherwise, register A contains an error code identifying the error as shown below:

- 01 No available directory space
- 02 No available data block
- 09 Invalid FCB
- 10 Media change occurred
- 255 Physical Error : refer to register H

Error Code 01 is returned when the write function attempts to create a new extent that requires a new directory entry, and no available directory entries

exist on the selected disk drive.

Error Code 02 is returned when the write command attempts to allocate a new data block to the file, and no unallocated data blocks exist on the selected disk drive.

Error Code 09 is returned if the FCB is invalidated by a previous BDOS close call that returns an error.

Error Code 10 is returned if a media change occurs on the drive after the referenced FCB is activated by a BDOS Open or Make call.

Error Code 255 is returned if a physical error is encountered and the BDOS error mode is Return Error mode, or Return and Display Error mode (see Function 45). If the error mode is the default mode, a message identifying the physical error is displayed at the console, and the calling program is terminated. When a physical error is returned to the calling program, register H contains one of the following error codes:

- 01 Disk I/O error
- 02 Read-Only disk
- 03 Read-Only file or File open from user 0 when the current user number is non-zero or File password protected in Write mode
- 04 Invalid drive error

On all error returns, except for physical error returns, A=255, Function 21 sets register H to the number of records successfully written before the error was encountered. This value can range from 0 to 127 depending on the current BDOS Multi-Sector Count. It is always set to zero when the Multi-Sector Count is set to one.

BDOS function 22: MAKE FILE

Entry Parameters:

C: \$16

DE: FCB Address

Returned Value:

A: Directory Code

H: Physical or Extended Error

The Make File function creates a new directory entry for a file under the current user number. It also creates an XFCB for the file if the referenced drive has a directory label that enables password protection on the drive, and the calling program assigns a password to the file.

The calling program passes the address of the FCB in register pair DE, with byte 0 of the FCB specifying the drive, bytes 1 through 11 specifying the filename and filetype, and byte 12 set to the extent number. Usually, byte 12 is set to zero. Byte 32 of the FCB, the cr field, must be initialized to zero, before or

after the Make call, if the intent is to write sequentially from the beginning of the file

Interface attribute f6' specifies whether a password is to be assigned to the created file.

- f6' = 0 Do not assign password (default)
- f6' = 1 Assign password to created file

When attribute f6' is set to 1, the calling program must place the password in the first 8 bytes of the current DMA buffer, and set byte 9 of the DMA buffer to the password mode (see Function 102). Note that the Make function only interrogates interface attribute f6' if passwords are activated on the referenced drive. In nonbanked systems, file passwords are not supported, and attribute f6' is never interrogated.

The Make function returns with an error if the referenced FCB names a file that currently exists in the directory under the current user number.

If the Make function is successful, it activates the referenced FCB for file operations by opening the FCB, and initializes both the directory entry and the referenced FCB to an empty file. It also initializes all file attributes to zero. In addition, Function 22 makes a Creation date and time stamp for the file if the following conditions are satisfied: the referenced drive has a directory label that requests Creation date and time stamping and the FCB extent number field is equal to zero. Function 22 also makes an Update stamp if the directory label requests update stamping and the FCB extent field is equal to zero.

If the referenced drive contains a directory label that enables password protection, and if interface attribute f6' has been set to 1, the Make function creates an XFCB for the file. In addition, Function 22 also assigns the password, and password mode placed in the first nine bytes of the DMA, to the XFCB.

Upon return, the Make function returns a directory code in register A with the value 0 if the make operation is successful, or \$FF, 255 decimal, if no directory space is available. Register H is set to zero in both of these cases. If a physical or extended error is encountered, the Make function performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is the default mode, a message identifying the error is displayed at the console, and the calling program is terminated. Otherwise, the Make function returns to the calling program with register A set to \$FF, and register H set to one of the following physical or extended error codes:

- 01 : Disk I/O error
 02 : Read-Only disk
 04 : Invalid drive error
 08 : File already exists
- 09: ? in filename or filetype field

BDOS function 23: **RENAME FILE**

Entry Parameters:

C: \$17

DE: FCB Address

Returned Value:

A: Directory Code

H: Physical or Extended Error

The Rename function uses the FCB, addressed by register pair DE, to change all directory entries of the file specified by the filename in the first 16 bytes of the FCB to the filename in the second 16 bytes. If the file specified by the first filename is password protected, the correct password must be placed in the first eight bytes of the current DMA buffer, or have been previously established as the default password (see Function 106). The calling program must also ensure that the filenames specified in the FCB are valid and unambiguous, and that the new filename does not already exist on the drive. Function 23 uses the dr code at byte 0 of the FCB to select the drive. The drive code at byte 16 of the FCB is ignored.

Upon return, the Rename function returns a Directory Code in register A with the value 0 if the rename is successful, or \$0FF, 255 Decimal, if the file named by the first filename in the FCB is not found. Register H is set to zero in both of these cases. If a physical or extended error is encountered, the Rename function performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is the default mode, a message identifying the error is displayed at the console and the program is terminated. Otherwise, the Rename function returns to the calling program with register A set to \$0FF and register H set to one of the following physical or extended error codes:

- 01 Disk I/O error
- 02 Read-Only disk
- 03 Read-Only file
- 04 Invalid drive error
- 07 File password error
- 08 File already exists
- 09? in filename or filetype field

BDOS function 24: RETURN LOGIN VECTOR

Entry Parameters:

C: \$18

Returned Value:

HL: Login Vector

Function 24 returns the login vector in register pair HL. The login vector is a 16-bit value with the least significant bit of L corresponding to drive A, and the higher bit of H corresponding to the 16th drive, labelled P. A 0 bit indicates

that the drive is not on-line, while a 1 bit indicates the drive is active. A drive is made active by either an explicit BDOS Select Disk call, number 14, or an implicit selection when a BDOS file operation specifies a non-zero dr byte in the FCB. Function 24 maintains compatibilty with earlier releases since registers A and L contain the same values upon return.

BDOS function 25: RETURN CURRENT DISK

Entry Parameters:

C: \$19

Returned Value:

A: Current Disk

Function 25 returns the currently selected default disk number in register A. The disk numbers range from 0 through 15 corresponding to drives A through P.

BDOS function 26: SET DMA ADDRESS

Entry Parameters:

C: \$1A

DE: DMA Address

DMA is an acronym for Direct Memory Address, which is often used in connection with disk controllers that directly access the memory of the computer to transfer data to and from the disk subsystem. Under $\mathrm{CP/M}$ 3, the current DMA is usually defined as the buffer in memory where a record resides before a disk write, and after a disk read operation. If the BDOS Multi-Sector Count is equal to one (see Function 44), the size of the buffer is 128 bytes. However, if the BDOS Multi-Sector Count is greater than one, the size of the buffer must equal N * 128, where N equals the Multi-Sector Count.

Some BDOS functions also use the current DMA to pass parameters, and to return values. For example, BDOS functions that check and assign file passwords require that the password be placed in the current DMA. As another example, Function 46, Get Disk Free Space, returns its results in the first 3 bytes of the current DMA. When the current DMA is used in this context, the size of the buffer in memory is determined by the specific requirements of the called function.

When a transient program is initiated by the CCP, its DMA address is set to \$0080. The BDOS Reset Disk System function, Function 13, also sets the DMA address to \$0080. The Set DMA function can change this default value to another memory address. The DMA address is set to the value passed in the register pair DE. The DMA address remains at this value until it is changed by another Set DMA Address, or Reset Disk System call.

BDOS function 27: **GET ADDR(ALLOC)**

Entry Parameters:

C: \$1B

Returned Value:

HL: ALLOC Address

CP/M 3 maintains an allocation vector in main memory for each active disk drive. Some programs use the information provided by the allocation vector to determine the amount of free data space on a drive. Note, however, that the allocation information might be inaccurate if the drive has been marked Read-Only.

Function 27 returns in register pair HL, the base address of the allocation vector for the currently selected drive. If a physical error is encountered when the BDOS error mode is one of the return modes (see Function 45), Function 27 returns the value \$FFFF in the register pair HL.

In banked CP/M 3 systems, the allocation vector can be placed in bank zero. In this case, a transient program cannot access the allocation vector. However, the BDOS function, Get Disk Free Space (Function 46), can be used to directly return the number of free 128-byte records on a drive. The CP/M 3 utilities that display a drive's free space, DIR and SHOW, use Function 46 for that purpose.

BDOS function 28: WRITE PROTECT DISK

Entry Parameters:

C: \$1C

The Write Protect Disk function provides temporary write protection for the currently selected disk by marking the drive as Read-Only, No program can write to a disk that is in the Read-Only state. A drive reset operation must be performed for a Read-Only drive to restore it to the Read-Write state (see Functions 13 and 37).

BDOS function 29: GET READ-ONLY VECTOR

Entry Parameters:

C: 1\$D

Returned Value:

HL: R/O Vector Value

Function 29 returns a bit vector in register pair HL that indicates which drives have the temporary Read-Only bit set. The Read-Only bit can be set only by a BDOS Write Protect Disk call.

The format of the bit vector is analogous to that of the login vector returned by Function 24. The least significant bit corresponds to drive A, while the most significant bit corresponds to drive P.

BDOS function 30: SET FILE ATTRIBUTES

Entry Parameters:

C: \$1E

DE: FCB Address

Returned Value:

A: Directory Code

H: Physical or Extended error

By calling the Set File Attributes function, a program can modify a file's attributes and set its last record byte count. Other BDOS functions can be called to interrogate these file parameters, but only Function 30 can change them. The file attributes that can be set or reset by Function 30 are fl' through f4', Read-Only, t1', System, t2', and Archive, t3'. The register pair DE addresses an FCB containing a filename with the appropriate attributes set or reset. The calling program must ensure that it does not specify an ambiguous filename. In addition, if the specified file is password totected, the correct password must be placed in the first eight bytes of the current DMA buffer or have been previously established as the default password (see Function 106).

Interface attribute f6' specifies whether the last record byte count of the specified file is to be set:

- f6' = 0 Do not set byte count (default mode)
- f6' = 1 Set byte count

If interface attribute f6' is set, the calling program must set the cr field of the referenced FCB to the byte count value. A program can access a file's byte count value with the BDOS Open, Search, or Search Next functions.

Function 30 searches the referenced directory for entries belonging to the current user number that matches the FCB specified name and type fields. The function then updates the directory to contain the selected indicators, and if interface attribute f6' is set, the specified byte count value. Note that the last record byte count is maintained in byte 13 of a file's directory FCBS.

File attributes t1', t2', and t3' are defined by CP/M 3. (They are described in Section 2.3.4.) Attributes fl' through f4' are not presently used, but can be useful for application programs, because they are not involved in the matching program used by the BDOS during Open File and Close File operations. Indicators f5' through f8' are reserved for use as interface attributes.

Upon return, Function 30 returns a Directory Code in register A with the value 0 if the function is successful, or \$FF, 255 Decimal, if the file specified by the referenced FCB is not found. Register H is set to zero in both of these cases. If a physical or extended error is encountered', the Set File Attributes function performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is the default mode, a message identifying the

error is displayed at the console, and the program is terminated. Otherwise, Function 30 returns to the calling program with reg'ls-Ler A set to \$FF, and register H set to one of the following physical or extended error codes:

- 01 Disk I/O error
- 02 Read-Only disk
- 04 Select error
- 07 File password error
- 09 ? in filename or filetype field

BDOS function 31: GET ADDR(DPB PARMS)

Entry Parameters:

C: \$1F

Returned Value:

HL: DPB Address

Function 31 returns in register pair HL the address of the BIOS-resident Disk Parameter Block, DPB, for the currently selected drive. (Refer to the $\mathrm{CP/M}$ Plus ($\mathrm{CP/M}$ Version 3) Operating System System Guide for the format of the DPB). The calling program can use this address to extract the disk parameter values.

If a physical error is encountered when the BDOS error mode is one of the return modes (see Function 45), Function 31 returns the value \$FFFF in the register pair HL.

BDOS function 32: SET/GET USER CODE

Entry Parameters:

C: \$20

Returned Value:

E: \$FF (get) or User Code (set)
A: Current Code or (no value)

A program can change, or interrogate the currently active user number by calling Function 32. If register E = \$FF, then the value of the current user number is returned in register A, where the value is in the range of 0 to 15. If register E is not \$FF, then the current user number is changed to the value of E, modulo 16

BDOS function 33: **READ RANDOM**

Entry Parameters:

C: \$21

DE: FCB Address

Returned Value:

A: Error Code H: Physical Error

The Read Random function is similar to the Read Sequential function except that the read operation takes place at a particular random record number, selected by the 24-bit value constructed from the three byte, r0, r1, r2, field beginning at position 33 of the FCB. Note that the sequence of 24 bits is stored with the least significant byte first, r0, the middle byte next, rl, and the high byte last, r2. The random record number can range from 0 to 262,143. This corresponds to a maximum value of 3 in byte r2.

To read a file with Function 33, the calling program must first open the base extent, extent 0. This ensures that the FCB is properly initialized for subsequent random access operations. The base extent may or may not contain any allocated data. Function 33 reads the record specified by the random record field into the current DMA address. The function automatically sets the logical extent and current record values, but unlike the Read Sequential function, it does not advance the current record number. Thus, a subsequent Read Random call rereads the same record. After a random read operation, a file can be accessed sequentially, starting from the current randomly accessed position. However, the last randomly accessed record is reread or rewritten when switching from random to sequential mode.

If the BDOS Multi-Sector Count is greater than one (see Function 44), the Read Random function reads multiple consecutive records into memory beginning at the current DMA. The rO, rl, and r2 field of the FCB is automatically incremented to read each record. However, the FCBs random record number is restored to the first record's value upon return to the calling program.

Upon return, the Read Random function sets register A to zero if the read operation was successful. Otherwise, register A contains one of the following error codes:

- 01 Reading unwritten data (end-of-file)
- 03 Cannot close current extent
- 04 Seek to unwritten extent
- 06 Random record number out of range
- 10 Media change occurred
- 255 Physical Error: refer to register H

Error Code 01 is returned if no data exists at the next record position of the file. Usually, the no data situation is encountered at the end of a file. However, it can also occur if an attempt is made to read a data block that has not been previously written.

Error Code 03 is returned when the Read Random function cannot close the current extent prior to moving to a new extent.

Error Code 04 is returned when a read random operation accesses an extent that has not been created.

Error Code 06 is returned when byte 35, r2, of the referenced FCB is greater than 3.

Error Code 10 is returned if a media change occurs on the drive after the referenced FCB is activated by a BDOS Open or Make Call.

Error Code 255 is returned if a physical error is encountered, and the BDOS error mode is one of the return modes (see Function 45). If the error mode is the default mode, a message identifying the physical error is displayed at the console, and the calling program is terminated. When a physical error is returned to the calling program, register H contains one of the following error codes:

- 01 Disk I/O error
- 04 Invalid drive error

On all error returns except for physical errors, A=255, the Read Random function sets register H to the number of records successfully read before the error is encountered. This value can range from 0 to 127 depending on the current BDOS Multi-Sector Count. It is always set to zero when the Multi-Sector Count is equal to one.

BDOS function 34: WRITE RANDOM

Entry Parameters:

C: \$22

DE: FCB Address

Returned Value:

A: Error Code

H: Physical Error

The Write Random function is analogous to the Read Random function, except that data is written to the disk from the current DMA address. If the disk extent or data block where the data is to be written is not already allocated, the BDOS automatically performs the allocation before the write operation continues.

To write to a file using the Write Random function, the calling program must first open the base extent, extent 0. This ensures that the FCB is properly initialized for subsequent random access operations. If the file is empty, the calling program must create the base extent with the Make File function before calling Function 34. The base extent might or might not contain any allocated data, but it does record the file in the directory, so that the file can be displayed by the DIR utility.

The Write Random function sets the logical extent and current record positions to correspond with the random record being written, but does not change the random record number. Thus, sequential read or write operations can follow a random write, with the current record being reread or rewritten as the calling program switches from random to sequential mode.

Function 34 makes an Update date and time stamp for the file if the following conditions are satisfied: the referenced drive has a directory label that requests Update date and time stamping if the file has not already been stamped for update by a previous BDOS Make or Write call.

If the BDOS Multi-Sector Count is greater than one (see Function 44), the Write Random function reads multiple consecutive records into memory beginning at the current DMA. The rO, rl, and r2 field of the FCB is automatically incremented to write each record. However, the FCB's random record number is restored to the first record's value when it returns to the calling program. Upon return, the Write Random function sets register A to zero if the write operation is successful. Otherwise, register A contains one of the following error codes:

- 02 No available data block
- 03 Cannot Close current extent
- 05 No available directory space
- 06 Random record number out of range
- 10 Media change occurred
- 255 Physical Error: refer to register H

Error Code 02 is returned when the write command attempts to allocate a new data block to the file and no unallocated data blocks exist on the selected disk drive.

Error Code 03 is returned when the Write Random function cannot close the current extent prior to moving to a new extent.

Error Code 05 is returned when the write function attempts to create a new extent that requires a new directory entry and no available directory entries exist on the selected disk drive.

Error Code 06 is returned when byte 35, r2, of the referenced FCB is greater than 3.

Error Code 10 is returned if a media change occurs on the drive after the referenced FCB is activated by a BDOS Open or Make Call.

Error Code 255 is returned if a physical error is encountered and the BDOS error mode is one of the return modes (see Function 45). If the error mode is the default mode, a message identifying the physical error is displayed at the console, and the calling program is terminated. When a physical error is returned to the calling program, it is identified by register H as shown below:

- 01 Disk I/O error
- 02 Read-Only disk
- 03 Read-Only file or File open from user 0 when the current user number is nonzero or File password protected in Write mode
- 04 Invalid drive error

On all error returns, except for physical errors, A = 255, the Write Random

function sets register H to the number of records successfully written before the error is encountered. This value can range from 0 to 127 depending on the current BDOS Multi-Sector Count. It is always set to zero when the Multi-Sector Count is equal to one.

BDOS function 35: COMPUTE FILE SIZE

Entry Parameters:

C: \$23

DE: FCB Address

Returned Value:

A: Error Flag

H: Physical or Extended error

Random Record Field Set

The Compute File Size function determines the virtual file size, which is, in effect, the address of the record immediately following the end of the file. The virtual size of a file corresponds to the physical size if the file is written sequentially. If the file is written in random mode, gaps might exist in the allocation, and the file might contain fewer records than the indicated size. For example, if a single record with record number 262,143, the CP/M 3 maximum is written to a file using the Write Random function, then the virtual size of the file is 262,144 records even though only 1 data block 'is actually allocated.

To compute file size, the calling program passes in register pair DE the address of an FCB in random mode format, bytes rO, rl and r2 present. Note that the FCB must contain an unambiguous filename and filetype. Function 35 sets the random record field of the FCB to the random record number + 1 of the last record in the file. If the r2 byte is set to 04, then the file contains the maximum record count 262,144.

A program can append data to the end of an existing file by calling Function 35 to set the random record position to the end of file, and then performing a sequence of random writes starting at the preset record address.

Note: the BDOS does not require that the file be open to use Function 35. However, if the file has been written to, it must be closed before calling Function 35. Otherwise, an incorrect file size might be returned.

Upon return, Function 35 returns a zero in register A if the file specified by the referenced FCB is found, or an \$FF in register A if the file is not found. Register H is set to zero in both of these cases. If a physical error is encountered, Function 35 performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is the default mode, a message identifying the error is displayed at the console and the program is terminated. Otherwise, Function 35 returns to the calling program with register A set to \$FF, and register H set to one of the following physical errors:

- 01 Disk I/O error
- 04 Invalid drive error

BDOS function 36: SET RANDOM RECORD

Entry Parameters:

C: \$24

DE: FCB Address

Returned Value:

Random Record Field Set

The Set Random Record function returns the random record number of the next record to be accessed from a file that has been read or written sequentially to a particular point. This value is returned in the random record field, bytes rO, rl, and r2, of the FCB addressed by the register pair DE. Function 36 can be useful in two ways,

First, it is often necessary to initially read and scan a sequential file to extract the positions of various key fields. As each key is encountered, Function 36 is called to compute the random record position for the data corresponding to this key. If the data unit size is 128 bytes, the resulting record number minus one is placed into a table with the key for later retrieval. After scanning the entire file and tabularizing the keys and their record numbers, you can move directly to a particular record by performing a random read using the corresponding random record number that you saved earlier. The scheme is easily generalized when variable record lengths are involved, because the program need only store the buffer-relative byte position along with the key and record number to find the exact starting position of the keyed data at a later time.

A second use of Function 36 occurs when switching from a sequential read or write over to random read or write. A file is sequentially accessed to a particular point in the file, then Function 36 is called to set the record number, and subsequent random read and write operations continue from the next record in the file.

BDOS function 37: RESET DRIVE

Entry Parameters:

C: \$25

DE: Drive Vector

Returned Value:

A: \$00

The Reset Drive function programmatically restores specified drives to the reset state. A reset drive is not logged-in and is in Read-Write status. The passed parameter in register pair DE is a 16-bit vector of drives to be reset, where the least significant bit corresponds to the first drive A, and the high-order bit

corresponds to the sixteenth drive, labelled P. Bit values of 1 indicate that the specified drive is to be reset.

BDOS function 38: ACCESS DRIVE

Entry Parameters:

C: \$26

This is an MP/M function that is not supported under CP/M 3. If called, the file system returns a zero In register A indicating that the access request is successful.

BDOS function 39: FREE DRIVE

Entry Parameters:

C: \$27

This is an MP/M function that is not supported under CP/M 3. If called, the file system returns a zero In register A indicating that the free request is successful.

BDOS function 40: WRITE RANDOM WITH ZERO FILL

Entry Parameters:

C: \$28

DE: FCB address

Returned Value:

A: Error Code H: Physical Error

The Write Random With Zero Fill function is identical to the Write Random function (Function 34) with the exception that a previously unallocated data block is filled with zeros before the record is written. If this function has been used to create a file, records accessed by a read random operation that contain all zeros identify unwritten random record numbers. Unwritten random records in allocated data blocks of files created using the Write Random function (Function 34) contain uninitialized data.

BDOS function 41: TEST AND WRITE RECORD

Entry Parameters:

C: \$29

DE: FCB Address

Returned Value:

A: Error Code H: Physical Error

The Test and Write Record function is an MP/M function that is not supported

under $\mathrm{CP/M}$ 3. If called, Function 41 returns with register A set to \$FF and register H set to zero.

BDOS function 42: LOCK RECORD

Entry Parameters:

C: \$2A

DE: FCB Address

Returned Value:

A: \$00

The Lock Record function is an MP/M II function that is supported under CP/M 3 only to provide compatibility between CP/M 3 and MP/M. It is intended for use in situations where more than one running program has Read-Write access to a common file. Because CP/M 3 is a single-user operating system in which only one program can run at a time, this situation cannot occur. Thus, under CP/M 3, Function 42 performs no action except to return the value \$00 in register A indicating that the record lock operation is successful.

BDOS function 43: UNLOCK RECORD

Entry Parameters:

C: \$2B

DE: FCB Address

Returned Value:

A: \$00

The Unlock Record function is an MP/M II function that is supported under CP/M 3 only to provide compatibility between CP/M 3 and MP/M. It is intended for use in situations where more than one running program has Read-Write access to a common file. Because CP/M 3 is a single-user operating system in which only one program can run at a time, this situation cannot occur. Thus, under CP/M 3, Function 43 performs no action except to return the value \$00 in register A indicating that the record unlock operation is successful.

BDOS function 44: SET MULTI-SECTOR COUNT

Entry Parameters:

C: \$2C

E: Number of Sectors

Returned Value:

A: Return Code

The Set Multi-Sector Count function provides logical record blocking under CP/M 3. It enables a program to read and write from 1 to 128 records of 128 bytes at a time during subsequent BDOS Read and Write functions.

Function 44 sets the Multi-Sector Count value for the calling program to the value passed in register E. Once set, the specified Multi-Sector Count remains in effect until the calling program makes another Set Multi-Sector Count function call and changes the value. Note that the CCP sets the Multi-Sector Count to one when it initiates a transient program.

The Multi-Sector Count affects BDOS error reporting for the BDOS Read and Write functions. If an error interrupts these functions when the Multi-Sector is greater than one, they return the number of records successfully read or written in register H for all errors except for physical errors (A = 255).

Upon return, register A is set to zero if the specified value is in the range of 1 to 128. Otherwise, register A is set to \$FF.

BDOS function 45: **SET BDOS ERROR MODE**

Entry Parameters:

C: \$2D

E: BDOS Error Mode

Returned Value:

None

Function 45 sets the BDOS error mode for the calling program to the mode specified in register E. If register E is set to \$FF, 255 decimal, the error mode is set to Return Error mode. If register E is set to \$FE, 254 decimal, the error mode is set to Return and Display mode. If register E is set to any other value, the error mode is set to the default mode.

The SET BDOS Error Mode function determines how physical and extended errors (see Section 2.2.13) are handled for a program. The Error Mode can exist in three modes: the default mode, Return Error mode, and Return and Display Error mode. In the default mode, the BDOS displays a system message at the console that identifies the error and terminates the calling program. In the return modes, the BDOS sets register A to \$FF, 255 decimal, places an error code that identifies the physical or extended error in register H and returns to the calling program. In Return and Display mode, the BDOS displays the system message before returning to the calling program. No system messages are displayed, however, when the BDOS is in Return Error mode.

BDOS function 46: **GET DISK FREE SPACE**

Entry Parameters:

 $\mathrm{C} \colon \$2\mathrm{E}$

E: Drive

Returned Value:

First 3 bytes of current DMA buffer

A: Error Flag

H: Physical Error

The Get Disk Free Space function determines the number of free sectors, 128 byte records, on the specified drive. The calling program passes the drive number in register E, with 0 for drive A, 1 for B, and so on, through 15 for drive P in a full 16drive system. Function 46 returns a binary number in the first 3 bytes of the current DMA buffer. This number is returned in the following format:

fso fsl fs2

Disk Free Space Field Format

fso = low byte fsl = middle bytefs2 = high byte

Note that the returned free space value might be inaccurate if the drive has been marked Read-Only.

Upon return, register A is set to zero if the function is successful. However, if the BDOS Error Mode is one of the return modes (see Function 45), and a physical error is encountered, register A is set to \$FF, 255 decimal, and register H is set to one of the following values:

- 01 Disk I/O error
- 04 Invalid drive error

BDOS function 47: CHAIN TO PROGRAM

Entry Parameters:

C: \$2F

E: Chain Flag

The Chain To Program function provides a means of chaining from one program to the next without operator intervention. The calling program must place a command line terminated by a null byte, OOH, in the default DMA buffer. If register E is set to \$FF, the CCP initializes the default drive and user number to the current program values when it passes control to the specified transient program. Otherwise, these parameters are set to the default CCP values. Note that Function 108, Get/Set Program Return Code, can be used to pass a two byte value to the chained program.

Function 47 does not return any values to the calling program and any encountered errors are handled by the CCP.

BDOS function 48: FLUSH BUFFERS

Entry Parameters:

C: \$30

Returned Value:

A: Error Flag H: Physical Error

E: Purge Flag

The Flush Buffers function forces the write of any write-pending records contained in internal blocking/deblocking buffers. If register E is set to \$FF, this function also purges all active data buffers. Programs that provide write with read verify support need to purge internal buffers to ensure that verifying reads actually access the disk instead of returning data that is resident in internal data buffers. The $\mathrm{CP/M}$ 3 PIP utility is an example of such a program.

Upon return, register A is set to zero if the flush operation is successful. If a physical error is encountered, the Flush Buffers function performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is in the default mode,, a message identifying the error is displayed at the console and the calling program is terminated. Otherwise, the Flush Buffers function returns to the calling program with register A set to \$FF and register H set to the following physical error code:

- 0 1 Disk I/O error
- 02 Read/only disk
- 04 Invalid drive error

BDOS function 49: GET/SET SYSTEM CONTROL BLOCK

Entry Parameters:

C: \$31

DE: SCB PB Address

Returned Value:

A: Returned Byte HL: Returned Word

Function 49 allows access to parameters located in the CP/M 3 System Control Block (SCB). The SCB is a 100-byte data structure residing within the BDOS that contains flags and data used by the BDOS, CCP and other system components. Note that Function 49 is a CP/M 3 specific function. Programs intended for both MP/M 11 and CP/M 3 should either avoid the use of this function or isolate calls to this function in CP/M 3 version-dependent sections.

To use Function 49, the calling program passes the address of a data structure called the SCB parameter block in register pair DE. This data structure identifies the byte or word of the SCB to be updated or returned. The SCB parameter block is defined as:

SCBPB: DB OFFSET; Offset within SCB
DB SET; OFFH if setting a byte; OFEH if setting a word

```
; 001H - OFDH are reserved
; 000H if a get operation
DW VALUE ; Byte or word value to be set
```

The OFFSET parameter identifies the offset of the field within the SCB to be updated or accessed. The SET parameter determines whether Function 49 is to set a byte or word value in the SCB or if it is to return a byte from the SCB. The VALUE parameter is used only in set calls. In addition, only the first byte of VALUE is referenced in set byte calls.

Use caution when you set SCB fields. Some of these parameters reflect the current state of the operating system. If they are set to invalid values, software errors can result. In general, do not use Function 49 to set a system parameter if another BDOS function can achieve the same result. For example, Function 49 can be called to update the Current DMA Address field within the SCB. This is not equivalent to making a Function 26, Set DMA Address call, and updating the SCB Current DMA field in this way would result in system errors. However, you can use Function 49 to return the Current DMA address. The System Control Block is summarized in 11.1.

If Function 49 is called with the OFFSET parameter of the SCB parameter block greater than \$63, the function performs no action but returns with registers A and HL set to zero.

BDOS function 50: DIRECT BIOS CALLS

Entry Parameters:

C: \$32

DE: BIOS PB Address

Returned Value:

BIOS RETURN

Function 50 provides a direct BIOS call through the BDOS to the BIOS. The calling program passes the address of a data structure called the BIOS Parameter Block (BIOSPB) in register pair DE. The BIOSPB contains the BIOS function number and register contents as shown below:

```
BIOSPB: db FUNC ; BIOS function no.
db AREG ; A register contents
dw BCREG ; BC register contents
dw DEREG ; DE register contents
dw HLREG ; HL register contents
```

System Reset (Function 0) is equivalent to Function 50 with a BIOS function number of 1.

Note that the register pair BIOSPB fields (BCREG, DEREG, HLREG) arc defined in low byte, high byte order. For example, in the BCREG field, the first byte contains the C register value, the second byte contains the B register value.

Under CP/M 3, direct BIOS calls via the BIOS jump vector are only supported for the BIOS Console I/O and List functions. You must use Function 50 to call any other

BIOS functions. In addition, Function 50 intercepts BIOS Function 27 (Select Memory) calls and returns with register A set to zero. Refer to the CPIM Plus (CP/M Version 3) Operating System System Guide for the definition of the BIOS functions and their register passing and return conventions.

BDOS function 59: LOAD OVERLAY

Entry Parameters:

C: \$3B

DE: FCB Address

Returned Value:

A: Error Code H: Physical Error

Only transient programs with an RSX header can use the Load Overlay function because BDOS Function 59 is supported by the LOADER module. The calling program must have a header to force the LOADER to remain resident after the program is loaded (see Section 1.3).

Function 59 loads either an absolute or relocatable module. Relocatable modules are identified by a filetype of PRL. Function 59 does not call the loaded module.

The referenced FCB must be successfully opened before Function 59 is called. The load address is specified in the first two random record bytes of the FCB, rO and rl. The LOADER returns an error if the load address is less than \$100, or if performing the requested load operation would overlay the LOADER, or any other Resident System Extensions that have been previously loaded.

When loading relocatable files, the LOADER requires enough room at the load address for the complete PRL file including the header and bit map (see Appendix B). Otherwise an error is returned. Function 59 also returns an error on PRL file load requests if the specified load address is not on a page boundary.

Upon return, Function 59 sets register A to zero if the load operation is successful. If the LOADER RSX is not resident in memory because the calling program did not have a RSX header, the BDOS returns with register A set to \$FF and register H set to zero. If the LOADER detects an invalid load address, or if insufficient memory is available to load the overlay, Function 59 returns with register A set to \$FE. All other error returns are consistent with the error codes returned by BDOS Function 20, Read Sequential.

BDOS function 60: CALL RESIDENT SYSTEM EXTENSION

Entry Parameters:

C: \$3C

DE: RSX PB Address

Returned Value:

A: Error Code H: Physical Error

Function 60 is a special BDOS function that you use when you call Resident System Extensions. The RSX subfunction is specified in a structure called the RSX Parameter Block, defined as follows:

```
RSXPB: db FUNC; RSX Function number
db NUMPARMS; Number of word Parameters
dw PARMETER1; Parameter I
dw PARMETER2; Parameter 2
. . . .
dw PARMETERN; Parameter n
```

RSX modules filter all BDOS calls and capture RSX function calls that they can handle. If there is no RSX module present in memory that can handle a specific RSX function call, the call is not trapped, and the BDOS returns \$FF in registers A and L. RSX function numbers from 0 to 127 are available for ${\rm CP/M}$ 3 compatible software use. RSX function numbers 128 to 255 are reserved for system use.

BDOS function 98: FREE BLOCKS

Entry Parameters:

C: \$62

Returned Value:

A: Error Flag H: Physical Error

The Free Blocks function scans all the currently logged-in drives, and for each drive returns to free space all temporarily-allocated data blocks. A temporarily-allocated data block is a block that has been allocated to a file by a BDOS write operation but has not been permanently recorded in the directory by a BDOS close operation. The CCP calls Function 98 when it receives control following a system warm start. Be sure to close your file, particularly any file you have written to, prior to calling Function 98.

In the nonbanked version of CP/M 3, Function 98 frees only temporarily allocated blocks for systems that request double allocation vectors in GENCPM.

Upon return, register A is set to zero if Function 98 is successful. If a physical error is encountered, the Free Blocks function performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is in the default mode, a message identifying the error is displayed at the console and the calling program is terminated. Otherwise, the Free Blocks function returns to the calling program with register A set to \$FF and register H set to the

following physical error code:

• 04 : Invalid drive error

BDOS function 99: TRUNCATE FILE

Entry Parameters:

C: \$63

DE: FCB Address

Returned Value:

A: Directory Code

H: Extended or Physical Error

The Truncate File function sets the last record of a file to the random record number contained in the referenced FCB. The calling program passes the address of the FCB in register pair DE, with byte 0 of the FCB specifying the drive, bytes 1 through 11 specifying the filename and filetype, and bytes 33 through 35, rO, rl, and r2, specifying the last record number of the file. The last record number is a 24 bit value, stored with the least significant byte first, rO, the middle byte next, rl, and the high byte last, r2. This value can range from 0 to 262,143, which corresponds to a maximum value of 3 in byte r2.

If the file specified by the referenced FCB is password protected, the correct password must be placed in the first eight bytes of the current DMA buffer, or have been previously established as the default password (see Function 106).

Function 99 requires that the file specified by the FCB not be open, particularly if the file has been written to. In addition, any activated FCBs naming the file are not valid after Function 99 is called. Close your file before calling Function 99, and then reopen it after the call to continue processing on the file.

Function 99 also requires that the random record number field of the referenced FCB specify a value less than the current file size. In addition, if the file is sparse, the random record field must specify a record in a region of the file where data exists.

Upon return, the Truncate function returns a Directory Code in register A with the value 0 if the Truncate function is successful, or \$FF, 255 decimal, if the file is not found or the record number is invalid. Register H is set to zero in both of these cases. If a physical or extended error is encountered, the Truncate function performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is in the default mode, a message identifying the error is displayed at the console and the program is terminated. Otherwise, the Truncate function returns to the calling program with register A set to \$FF and register H set to one of the following physical or extended error codes:

- 01 Disk I/O error
- 02 Read-Only disk
- 03 Read-Only file

- 04 Invalid drive error
- 07 File password error
- 09? in filename or filetype field

BDOS function 100: SET DIRECTORY LABEL

Entry Parameters:

C: \$64

DE: FCB Address

Returned Value:

A: Directory Code

H: Physical or Extended Error

The Set Directory Label function creates a directory label, or updates the existing directory label for the specified drive. The calling program passes in register pair DE the address of an FCB containing the name, type, and extent fields to be assigned to the directory label. The name and type fields of the referenced FCB are not used to locate the directory label in the directory; they are simply copied into the updated or created directory label. The extent field of the FCB, byte 12, contains the user's specificat-on of the directory label data byte. The definition of the directory label data byte is:

- bit 7 Require passwords for password-protected files (Not supported in non-banked CP/M 3 systems)
- bit 6 Perform access date and time stamping
- bit 5 Perform update date and time stamping
- bit 4 Perform create date and time stamping
- bit 0 Assign a new password to the directory label

If the current directory label is password protected, the correct password must be placed in the first eight bytes of the current DMA, or have been previously established as the default password (see Function 106). If bit 0, the low-order bit, of byte 12 of the FCB is set to 1, it indicates that a new password for the directory label has been placed in the second eight bytes of the current DMA.

Note that Function 100 is implemented as an RSX, DIRLBL.RSX, in nonbanked $\mathrm{CP/M}$ 3 systems. If Function 100 is called in nonbanked systems when the DIRLBL.RSX is not resident an error code of \$0FF is returned.

Function 100 also requires that the referenced directory contain SFCBs to activate date and time stamping on the drive. If an attempt is made to activate date and time stamping when no SFCBs exist, Function 100 returns an error code of \$FF in register A and performs no action. The CP/M 3 INITDIR utility initializes a directory for date and time stamping by placing an SFCB record in every fourth entry of the directory.

Function 100 returns a Directory Code in register A with the value 0 if the directory label create or update is successful, or \$FF, 255 decimal, if no space

exists in the referenced directory to create a directory label, or if date and time stamping was requested and the referenced directory did not contain SFCBS. Register H is set to zero in both of these cases. If a physical error or extended error is encountered, Function 100 performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is the default mode, a message identifying the error is displayed at the console and the calling program is terminated. Otherwise, Function 100 returns to the calling program with register A set to \$FF and register H set to one of the following physical or extended error codes:

- 01 Disk I/O error
- 02 Read-Only disk
- 04 Invalid drive error
- 07 File password error

BDOS function 101: RETURN DIRECTORY LABEL DATA

Entry Parameters:

C: \$65

E: Drive

Returned Value:

A: Directory Label Data Byte

H: Physical Error

The Return Directory Label Data function returns the data byte of the directory label for the specified drive. The calling program passes the drive number in register E with 0 for drive A, 1 for drive B, and so on through 15 for drive P in a full sixteen drive system. The format of the directory label data byte is shown below:

- bit 7 Require passwords for password protected files
- bit 6 Perform access date and time stamping
- bit 5 Perform update date and time stamping
- bit 4 Perform create date and time stamping
- bit 0 Directory label exists on drive

Function 101 returns the directory label data byte to the calling program in register A. Register A equal to zero indicates that no directory label exists on the specified drive. If a physical error is encountered by Function 101 when the BDOS Error mode is in one of the return modes (see Function 45), this function returns with register A set to \$FF, 25S decimal, and register H set to one of the following:

- 01 Disk I/O error
- 04 Invalid drive error

BDOS function 102: **READ FILE DATE STAMPS AND PASSWORD MODE**

Entry Parameters:

C: \$66

DE: FCB Address

Returned Value:

A: Directory Code H: Physical Error

Function 102 returns the date and time stamp information and password mode for the specified file in byte 12 and bytes 24 through 32 of the specified FCB. The calling program passes in register pair DE, the address of an FCB in which the drive, filename, and filetype fields have been defined.

If Function 102 is successful, it sets the following fields in the referenced FCB:

byte 12: Password mode field

bit 7 - Read mode

bit 6 - Write mode

bit 4 - Delete mode

Byte 12 equal to zero indicates the file has not been assigned a password. In nonbanked systems, byte 12 is always set to zero.

byte 24 - 27 Create or Access time stamp field

byte 28 - 31 Update time stamp field

The date stamp fields are set to binary zeros if a stamp has not been made. The format of the time stamp fields is the same as the format of the date and time structure described in Function 104.

Upon return, Function 102 returns a Directory Code in register A with the value zero if the function is successful, or \$FF, 255 decimal, if the specified file is not found. Register H is set to zero in both of these cases. If a physical or extended error is encountered, Function 102 performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is in the default mode, a message identifying the error is displayed at the console and the calling program is terminated. Otherwise, Function 102 returns to the calling program with register A set to \$FF and register H set to one of the following physical or extended error codes:

- 01 Disk I/O error
- 04 Invalid drive error
- 09? in filename or filetype field

BDOS function 103: WRITE FILE XFCB

Entry Parameters:

C: \$67

DE: FCB Address

Returned Value:

A: Directory Code H: Physical Error

The Write File XFCB function creates a new XFCB or updates the existing XFCB for the specified file. The calling program passes in register pair DE the address of an FCB in which the drive, name, type, and extent fields have been defined. The extent field specifies the password mode and whether a new password is to be assigned to the file. The format of the extent byte is shown below:

FCB byte 12 (ex): XFCB password mode

bit 7 - Read mode

bit 6 - Write mode

bit 5 - Delete mode

bit 0 - Assign new password to the file

If the specified file is currently password protected, the correct password must reside in the first eight bytes of the current DMA, or have been previously established as the default password (see Function 106). If bit 0 is set to 1, the new password must reside in the second eight bytes of the current DMA.

Upon return, Function 103 returns a Directory Code in register A with the value zero if the XFCB create or update is successful, or \$FF, 255 decimal, if no directory label exists on the specified drive, or the file named in the FCB is not found, or no space exists in the directory to create an XFCB. Function 103 also returns with \$FF in register A if passwords are not enabled by the referenced directory's label. On nonbanked systems, this function always returns with register A = \$FF because passwords are not supported. Register H is set to zero in all of these cases. If a physical or extended error is encountered, Function 103 performs different actions depending on the BDOS error mode (see Function 45). If the BDOS error mode is the default mode, a message identifying the error is displayed at the console and the calling program is terminated. Otherwise, Function 103 returns to the calling program with register A set to \$FF and register H set to one of the following physical or extended error codes:

- 01 Disk I/O error
- 02 Read-Only disk
- 04 Invalid drive error
- 07 File password error
- 09? in filename or filetype field

BDOS function 104: **SET DATE AND TIME**

Entry Parameters:

C: \$68

DE: DAT Address

Returned Value:

none

The Set Date and Time function sets the system internal date and time. The calling program passes the address of a 4-byte structure containing the date and time specification in the register pair DE. The format of the date and time (DAT) data structure is:

byte 0 - 1 Date field byte 2 Hour field byte 3 Minute field

The date is represented as a 16-bit integer with day 1 corresponding to January 1, 1978. The time is represented as two bytes: hours and minutes are stored as two BCD digits.

This function also sets the seconds field of the system date and time to zero.

BDOS function 105: **GET DATE AND TIME**

Entry Parameters:

C: \$69

DE: DAT Address

Returned Value:

A: seconds DAT set

The Get Date and Time function obtains the system internal date and time. The calling program passes in register pair DE, the address of a 4-byte data structure which receives the date and time values. The format of the date and time, DAT, data structure is the same as the format described in Function 104. Function 105 also returns the seconds field of the system date and time in register A as a two digit BCD value.

BDOS function 106: SET DEFAULT PASSWORD

Entry Parameters:

C: \$6A

DE: Password Address

Returned Value:

none

The Set Default Password function allows a program to specify a password value before a file protected by the password is accessed. When the file system accesses a password-protected file, it checks the current DMA, and the default password for the correct value. If either value matches the file's password, full access to the file is allowed. Note that this function performs no action in nonbanked

 $\mathrm{CP/M}$ 3 systems because file passwords are not supported.

To make a Function 106 call, the calling program sets register pair DE to the address of an 8-byte field containing the password.

BDOS function 107: RETURN SERIAL NUMBER

Entry Parameters:

C: \$6B

DE: Serial Number Field

Returned Value:

Serial number field set

Function 107 returns the $\mathrm{CP/M}$ 3 serial number to the 6-byte field addressed by register pair DE.

BDOS function 108: GET/SET PROGRAM RETURN CODE

Entry Parameters:

C: \$6C

DE: \$0FFFF (Get) or Program Return Code (Set)

Returned Value:

HL: Program Return Code or (no value)

CP/M 3 allows programs to set a return code before terminating. This provides a mechanism for programs to pass an error code or value to a following job step in batch environments. For example, Program Return Codes are used by the CCP in CP/M 3's conditional command line batch facility. Conditional command lines are command lines that begin with a colon, :. The execution of a conditional command depends on the successful execution of the preceding command. The CCP tests the return code of a terminating program to determine whether it successfully completed or terminated in error. Program return codes can also be used by programs to pass an error code or value to a chained program (see Function 47, Chain To Program).

A program can set or interrogate the Program Return Code by calling Function 108. If re 'ster pair DE = \$FFFF, then the current Program Return Code is returned in register pair HL. Otherwise, Function 108 sets the Program Return Code to the 'value contained in register pair DE. Program Return Codes are defined in 11.2

BDOS function 109: **GET/SET CONSOLE MODE**

Entry Parameters:

C: \$6D

DE: \$FFFF (Get) or Console Mode (Set)

Returned Value:

HL: Console Mode or (no value)

A program can set or interrogate the Console Mode by calling Function 109. If register pair DE = FFFF, then the current Console Mode is returned in register HL. Otherwise, Function 109 sets the Console Mode to the value contained in register pair DE.

The Console Mode is a 16-bit system parameter that determines the action of certain BDOS Console I/O functions. The definition of the Console Mode is:

```
bit 0 = 1 - CTRL-C only status for Function 1 1.
```

- = 0 Normal status for Function 1 1.
- bit 1 = 1- Disable stop scroll, CTRL-S, start scroll, CTRL-Q, support.
 - = 0-Enable stop scroll, start scroll support.
- bit 2 = 1- Raw console output mode. Disables tab expansion for Functions 2, 9 and 111. Also disables printer echo, CTIRL-P, support.
 - = 0 Normal console output mode.
- bit 3 = 1 Disable CTRL-C program termination
 - = 0 Enable CTRL-C program termination
- bits 8,9 -Console status mode for RSXs that perform console input redirection from a file. These bits determine how the RSX responds to console status requests.

```
bit 8 = 0, bit 9 = 0 - conditional status
bit 8 = 0, bit 9 = 1 - false status
bit 8 = 1, bit 9 = 0 - true status
bit 8 = 1, bit 9 = 1 - bypass redirection
```

Note that the Console Mode bits are numbered from right to left.

The CCP initializes the Console Mode to zero when it loads a program unless the program has an RSX that overrides the default value. Refer to Section 2.2.1 for detailed information on Console Mode.

BDOS function 110: GET/SET OUTPUT DELIMITER

Entry Parameters:

```
C: $6E
DE: $FFFF (Get) or
E: Output Delimiter (Set)
```

Returned Value:

```
A: Output Delimiter or (no value)
```

A program can set or interrogate the current Output Delimiter by calling Function 110. If register pair DE = \$FFFF, then the current Output Delimiter is returned in register A. Otherwise, Function 110 sets the Output Delimiter to the value contained in register E.

Function 110 sets the string delimiter for Function 9, Print String. The default delimiter value is a dollar sign, \$. The CCP restores the Output Delimiter to

the default value when a transient program is loaded.

BDOS function 111: PRINT BLOCK

Entry Parameters:

C: \$6F

DE: CCB Address

Returned Value:

none

The Print Block function sends the character string located by the Character Control Block, CCB, addressed in register pair DE, to the logical console, CONOUT:. If the Console Mode is in the default state (see Section 2.2.1), Function 111 expands tab characters, CTRL-I, in columns of eight characters. It also checks for stop scroll, CTRL-S, start scroll, CTRL-Q, and echoes to the logical list device, LST:, if printer echo, CTRL-P, has been invoked.

The CCB format is:

byte 0 - 1 Address of character string (word value)

byte 2 - 3 Length of character string (word value)

BDOS function 112: LIST BLOCK

Entry Parameters:

C: \$70

DE: CCB Address

Returned Value:

none

The List Block function sends the character string located by the Character Control Block, CCB, addressed in register pair DE, to the logical list device, LST:.

The CCB format is:

byte 0 - 1 Address of character string (word value)

byte 2 - 3 Length of character string (word value)

BDOS function 152: PARSE FILENAME

Entry Parameters:

C: \$98

DE: PFCB Address

Returned Value:

HL: Return code

Parsed file control block

The Parse Filename function parses an ASCII file specification and prepares a File Control Block, FCB. The calling program passes the address of a data structure called the Parse Filename Control Block, PFCB, in register pair DE. The PFCB contains the address of the input ASCII filename string followed by the address of the target FCB as shown below:

```
PFCB: DW INPUT ; Address of input ASCII string DW FCB ; Address of target FCB
```

The maximum length of the input ASCII string to be parsed is 128 bytes. The target FCB must be 36 bytes in length.

Function 152 assumes the input string contains file specifications in the following form:

```
{d:}filename{.typ}{;password}
```

where items enclosed in curly brackets are optional. Function 152 also accepts isolated drive specifications d: in the input string. When it encounters one, it sets the filename, filetype, and password fields in the FCB to blank.

The Parse Filename function parses the first file specification it finds in the input string. The function first eliminates leading blanks and tabs. The function then assumes that the file specification ends on the first delimiter it encounters that is out of context with the specific field it is parsing. For instance, if it finds a colon, and it is not the second character of the file specification, the colon delimits the entire file specification.

Function 152 recognizes the following characters as detimiters:

```
space
tab
return
nut]
; (semicolon) - except before password field
= (equal)
< (less than)
> (greater than)
. (period) - except after filename and before filetype
: (colon) - except before filename and after drive
, (comma)
| (vertical bar)
[ (left square bracket)
] (right square bracket)
```

If Function 152 encounters a non-graphic character in the range 1 through 31 not listed above, it treats the character as an error. The Parse Filename function initializes the specified FCB shown in 11.3.

If an error occurs, Function 152 returns an \$FFFF in register pair HL.

On a successful parse, the Parse Filename function checks the next item in the input string. It skips over trailing blanks and tabs and looks at the next character. If the character is a null or carriage return, it returns a 0 indicating the end of the input string. If the character is a delimiter, it returns the address of the delimiter. If the character is not a delimiter, it returns the address of the first trailing blank or tab.

If the first non-blank or non-tab character in the input string is a null, 0, or carriage return, the Parse Filename function returns a zero indicating the end of string.

If the Parse Filename function is to be used to parse a subsequent file specification in the input string, the returned address must be advanced over the delimiter before placing it in the PFCB.

11.1.3 BIOS

System Initialization Functions

This section defines the BIOS system initialization routines BOOT, WBOOT, DEVTBL, DEVINI, and DRVTBL.

BIOS Function 0: BOOT

Get Control from Cold Start Loader and Initialize System

Entry Parameters: None Returned Values: None

The BOOT entry point gets control from the Cold Start Loader in Bank 0 and is responsible for basic system initialization. Any remaining hardware initialization that is not done by the boot ROMS, the Cold Boot Loader, or the LDRBIOS should be performed by the BOOT routine.

BIOS Function 1: WBOOT

Get Control When a Warm Start Occurs

Entry Parameters: None Returned Values: None

The WBOOT entry point is entered when a warm start occurs. A warm start is performed whenever a user program branches to location 0000H or attempts to return to the CCP.

BIOS Function 20: DEVTBL

Return Address of Character I/O Table

Entry Parameters: None

Returned Values: HL=address of Chrtbl

The DEVTBL and DEVINI entry points allow you to support device assignment

with a flexible, yet completely optional system. It replaces the IOBYTE facility of $\mathrm{CP/M}\ 2.2.$

BIOS Function 21: DEVINI

Initialize Character I/O Device

Entry Parameters: C=device number, 0-15

Returned Values: None

The DEVINI routine initializes the physical character device specified in register C to the baud rate contained in the appropriate entry of the CHRTBL.

BIOS Function 22: DRVTBL

Return Address of Disk Drive Table

Entry Parameters: None

Returned Values:

HL=Address of Drive Table of Disk Parameter Headers (DPH); Hashing can utilized if specified by the DPHs Referenced by this DRVTBL.

HL=\$ffff if no Drive Table; GENCPM does not set up buffers. Hashing is supported.

HL=\$fffe if no Drive Table; GENCPM does not set up buffers. Hashing is not supported.

The first instruction of this subroutine must be an LXI H,<address> where <address> is one of the above returned values. The GENCPM utility accesses the address in this instruction to locate the drive table and the disk parameter data structures to determine which system configuration to use.

Character I/O Functions

This section defines the CP/M 3 character I/O routines CONST, CONIN, CONOUT, LIST, AUXOUT, AUXIN, LISTST, CONOST, AUXIST, and AUX-OST. CP/M 3 assumes all simple character I/O operations are performed in eight-bit ASCII, upper and lowercase, with no parity. An ASCII CTRL-Z (\$1a) denotes an end-of-file condition for an input device.

In CP/M 3, you can direct each of the five logical character devices to any combination of up to twelve physical devices. Each of the five logical devices has a 16-bit vector in the System Control Block (SCB) . Each bit of the vector represents a physical device where bit 15 corresponds to device zero, and bit 4 is device eleven. Bits 0 through 3 are reserved for future system use.

BIOS Function 2: CONST

Sample the Status of the Console Input Device

Entry Parameters: None

Returned value:

A=\$ff if a console character is ready to read A=\$00 if no console character is ready to read

Read the status of the currently assigned console device and return \$ff in register A if a character is ready to read, and \$ff in register A if no console characters are ready.

BIOS Function 3: CONIN

Read a Character from the Console

Entry Parameters: None

Returned Values: A=Console Character

Read the next console character into register A with no parity. If no console character is ready, wait until a character is available before returning.

BIOS Function 4: CONOUT

Output Character to Console

Entry Parameters: C=Console Character

Returned Values: None

Send the character in register C to the console output device. The character is in ASCII with no parity.

BIOS Function 5: LIST

Output Character to List Device Entry Parameters: C=Character

Returned Values: None

Send the character from register C to the listing device. The character is in ASCII with no parity.

BIOS Function 6: AUXOUT

Output a Character to the Auxiliary Output Device

Entry Parameters: C=Character

Returned Values: None

Send the character from register C to the currently assigned AUXOUT device. The character is in ASCII with no parity.

BIOS Function 7: AUXIN

Read a Character from the Auxiliary Input Device

Entry Parameters: None

Returned Values: A=Character

Read the next character from the currently assigned AUXIN device into register A with no parity. A returned ASCII CTRL-Z (\$1a) reports an end-of-file.

BIOS Function 15: LISTST

Return the Ready Status of the List Device

Entry Parameters: None

Returned Values:

A=\$00 if list device is not ready to accept a character A=\$ff if list device is ready to accept a character

BIOS Function 17: CONOST

Return Output Status of Console Entry Parameters: None Returned Values:

> A=\$ff if ready A=\$00 if not ready

The CONOST routine checks the status of the console. CONOST returns an \$ff if the console is ready to display another character. This entry point allows for full polled handshaking communications support.

BIOS Function 18: AUXIST

Return Input Status of Auxiliary Port Entry Parameters: None Returned Values:

> A=\$ff if ready A=\$00 if not ready

The AUXIST routine checks the input status of the auxiliary port. This entry point allows full polled handshaking for communications support using an auxiliary port.

BIOS Function 19: AUXOST

Return Output Status of Auxiliary Port Entry Parameters: None Returned Values:

> A=\$ff if ready A=\$00 if not ready

The AUXOST routine checks the output status of the auxiliary port. This routine allows full polled handshaking for communications support using an auxiliary port.

Disk I/O Functions

This section defines the CP/M 3 BIOS disk I/O routines HOME, SELDSK, SETTRK, SETSEC, SETDMA, READ, WRITE, SECTRN, MULTIO, and FLUSH.

BIOS Function 8: HOME

Select Track 00 of the Specified Drive

Entry Parameters: None Returned Values: None

Return the disk head of the currently selected disk to the track 00 position. Usually, you can translate the HOME call into a call on SETTRK with a parameter of 0.

BIOS Function 9: SELDSK

Select the Specified Disk Drive Entry Parameters:

> C=Disk Drive (0-15) E=Initial Select Flag

Returned Values:

 $\operatorname{HL}=\operatorname{Address}$ of Disk Parameter Header (DPH) if drive exists

HL=0000H if drive does not exist

Select the disk drive specified in register C for further operations, where register C contains 0 for drive A, 1 for drive B, and so on to 15 for drive P. On each disk select, SELDSK must return in HL the base address of a 25-byte area called the Disk Parameter Header. If there is an attempt to select a nonexistent drive, SELDSK returns HL=\$0000 as an error indicator. On entry to SELDSK, you can determine if it is the first time the specified disk is selected. Bit 0, the least significant bit in register E, is set to 0 if the drive has not been previously selected. This information is of interest in systems that read configuration information from the disk to set up a dynamic disk definition table.

BIOS Function 10: SETTRK

Set Specified Track Number

Entry Parameters: BC=Track Number

Returned Values: None

Register BC contains the track number for a subsequent disk access on the currently selected drive. Normally, the track number is saved until the next READ or WRITE occurs.

BIOS Function 11: SETSEC

Set Specified Sector Number

Entry Parameters: BC=Sector Number

Returned Values: None

Register BC contains the sector number for the subsequent disk access on the currently selected drive. This number is the value returned by SECTRN. Usually, you delay actual sector selection until a READ or WRITE operation occurs.

BIOS Function 12: SETDMA

Set Address for Subsequent Disk I/O

Entry Parameters: BC=Direct Memory Access Address

Returned Values: None

Register BC contains the DMA (Direct Memory Access) address for the subsequent READ or WRITE operation. For example, if B=\$00 and C=\$80 when the BDOS calls SETDMA, then the subsequent read operation reads its data starting at \$80, or the subsequent write operation gets its data from 80H, until the next call to SETDMA occurs.

BIOS Function 13: READ

Read a Sector from the Specified Drive Entry Parameters: None

Returned Values:

A=\$00 if no errors occurred

A=\$01 if nonrecoverable error condition occurred

A=\$ff if media has changed

Assume the BDOS has selected the drive, set the track, set the sector, and specified the DMA address. The READ subroutine attempts to read one sector based upon these parameters, then returns one of the error codes in register A as described above.

If the value in register A is \$00, then CP/M 3 assumes that the disk operation completed properly. If an error occurs, the BIOS should attempt several retries to see if the error is recoverable before returning the error code.

If an error occurs in a system that supports automatic density selection, the system should verify the density of the drive. If the density has changed, return a \$ff in the accumulator. This causes the BDOS to terminate the current operation and relog in the disk.

BIOS Function 14: WRITE

Write a Sector to the Specified Disk Entry Parameters: C=Deblocking Codes Returned Values:

A=\$00 if no error occurred

A=\$01 if physical error occurred

A=\$02 if disk is Read-Only

A=\$ff if media has changed

Write the data from the currently selected DMA address to the currently selected drive, track, and sector. Upon each call to WRITE, the BDOS provides the following information in register C:

0 = deferred write

1 = nondeferred write

2 = deferred write to the first sector of a new data block

11.1. CP/M 173

This information is provided for those BIOS implementations that do blocking/deblocking in the BIOS instead of the BDOS.

BIOS Function 16: SECTRN

Translate Sector Number Given Translate Table Entry Parameters:

BC=Logical Sector Number DE=Translate Table Address

Returned Values: HL=Physical Sector Number

SECTRN performs logical sequential sector address to physical sector translation to improve the overall response of $\rm CP/M$ 3.

BIOS Function 23: MULTIO

Set Count of Consecutive Sectors for READ or WRITE

Entry Parameters: C=Multisector Count

Returned Values: None

To transfer logically consecutive disk sectors to or from contiguous memory locations, the BDOS issues a MULTIO call, followed by a series of READ or WRITE calls. This allows the BIOS to transfer multiple sectors in a single disk operation. The maximum value of the sector count is dependent on the physical sector size, ranging from 128 with 128-byte sectors, to 4 with 4096-byte sectors. Thus, the BIOS can transfer up to 16K directly to or from the TPA with a single operation.

BIOS Function 24: FLUSH

Force Physical Buffer Flushing for User-supported Deblocking

Entry Parameters: None

Returned Values:

A=\$00 if no error occurred

A=\$001 if physical error occurred

A=\$002 if disk is Read-Only

The flush buffers entry point allows the system to force physical sector buffer flushing when your BIOS is performing its own record blocking and deblocking. The BDOS calls the FLUSH routine to ensure that no dirty buffers remain in memory.

11.1.4 Memory Select and Move Functions

This section defines the memory management functions MOVE, XMOVE, SELMEM, and SETBNK.

BIOS Function 25: MOVE

Memory-to-Memory Block Move

Entry Parameters:

HL=Destination address

DE=Source address

BC=Count

Returned Values: HL and DE must point to next bytes following move operation

The BDOS calls the MOVE routine to perform memory to memory block moves to allow use of the Z80 LDIR instruction or special DMA hardware, if available. Note that the arguments in HL and DE are reversed from the Z8O machine instruction, necessitating the use of XCHG instructions on either side of the LDIR. The BDOS uses this routine for all large memory copy operations. On return, the HL and DE registers are expected to point to the next bytes following the move.

Usually, the BDOS expects MOVE to transfer data within the currently selected bank or common memory. However, if the BDOS calls the XMOVE entry point before calling MOVE, the MOVE routine must perform an interbank transfer.

BIOS Function 27: SELMEM

Select Memory Bank

Entry Parameters: A=Memory Bank

Returned Values; None

The SELMEM entry point is only present in banked systems. The banked version of the CP/M 3 BDOS calls SELMEM to select the current memory bank for further instruction execution or buffer references. You must preserve or restore all registers other than the accumulator, A, upon exit.

BIOS Function 28: SETBNK

Specify Bank for DMA Operation Entry Parameters: A=Memory Bank

Returned Values: None

SETBNK only occurs in the banked version of $\mathrm{CP/M}$ 3. SETBNK specifies the bank that the subsequent disk READ or WRITE routine must use for memory transfers. The BDOS always makes a call to SETBNK to identify the DMA bank before performing a READ or WRITE call. Note that the BDOS does not reference banks other than 0 or 1 unless another bank is specified by the BANK field of a Data Buffer Control Block (BCB).

BIOS Function 29: XMOVE

Set Banks for Following MOVE Entry Parameters:

B=destination bank C=source bank

Returned Values: None

11.1. CP/M 175

XMOVE is provided for banked systems that support memory-to- memory DMA transfers over the entire extended address range. Systems with this feature can have their data buffers located in an alternate bank instead of in common memory, as is usually required. An XMOVE call affects only the following MOVE call. All subsequent MOVE calls apply to the memory selected by the latest call to SELMEM. After a call to the XMOVE function, the following call to the MOVE function is not more than 128 bytes of data.

Clock Support Function

This section defines the clock support function TIME.

BIOS Function 26: TIME

Get and Set Time

Entry Parameters: C=Time Get/Set Flag

Returned values: None

The BDOS calls the TIME function to indicate to the BIOS whether it has just set the Time and Date fields in the SCB, or whether the BDOS is about to get the Time and Date from the SCB. On entry to the TIME function, a zero in register C indicates that the BIOS should update the Time and Date fields in the SCB. A \$ff in register C indicates that the BDOS has just set the Time and Date in the SCB and the BIOS should update its clock. Upon exit, you must restore register pairs HL and DE to their entry values.

Table 11.1: System Control Block

Offset-7 Description 00 - 04 Reserved For System Use 05 BDOS version number 06 - 09 User Flags 0A - 0F Reserved For System Use	
05 BDOS version number 06 - 09 User Flags	
06 - 09 User Flags	
9	
0A - 0F Reserved For System Use	
or or reserved for bystem osc	
10 - 11 Program Error return code	
12 - 19 Reserved For System Use	
1A Console Width (columns)	
1B Console Column Position	
1C Console Page Length	
1D - 21 Reserved For System Use	
22 - 23 CONIN Redirection flag	
24 - 25 CONOUT Redirection flag	
26 - 27 AUXIN Redirection flag	
2A - 2B LSTOUT Redirection flag	
2C Page Mode	
2D Reserved For System Use	
2E CTRL-H Active	
2F Rubout Active	
30 - 32 Reserved For System Use	
33 - 34 Console Mode	
35 - 36 Reserved For System Use	
37 Output Delimiter	
39 - 3B Reserved For System Use	
3C - 3D Current DMA Address	
3E Current Disk	
3F - 43 Reserved For System Use	
44 Current User Number	
45 - 49 Reserved For System Use	
4A BDOS Multi-Sector Count	
4B BDOS Error Mode	
4C - 4F Drive Search Chain (DISKS A: E: F	:)
50 Temporary File Drive	
51 Error Disk	
52 - 56 Reserved For System Use	
57 BDOS flags	
58 - 5C Date Stamp	
5D - 5E Common Memory Base Address	
5F - 63 Reserved For System Use	

11.1. *CP/M* 177

Table 11.2: Program Return Codes

Code	Meaning					
0000 - FEFF	Successful return					
FF00 - FFFE	FE Unsuccessful return					
0000	The CCP initializes the Program Return Code to zero unless the program is					
	loaded as the result of program chain.					
FF00 - FFFC	Reserved					
FFFD	The program is terminated because of a fatal BDOS error.					
FFFE	The program is terminated by the BDOS because the user typed a CTRL-C.					

Table 11.3: FCB Format

Location	Contents				
byte 0	The drive field is set to the specified drive. If the				
	drive is not specified the default drive code is used. $0 =$				
	default $1 = A 2 = B$.				
byte 1-8	The name is set to the specified filename. All letters				
	are converted to upper-case. If the name is not eight characters				
	long the remaining bytes in the filename field are padded with				
	blanks. If the filename has an asterisk * all remaining bytes				
	in the filename field are filled in with question marks?. An				
error occurs if the filename is more than eight bytes lon					
byte 9-11	The type is set to the specified filetype. If no				
filetype is specified the type field is initialized to					
blanks. All letters are converted to upper-case. If the typ					
	not three characters long the remaining bytes in the filetype				
	field are padded with blanks. If an asterisk * occurs all				
	remaining bytes are filled in with question marks?. An error				
	occurs if the type field is more than three bytes long.				
byte 12-15	Filled in with zeros.				
byte 16-23	The password field is set to the specified				
	password. If no password is specified it is initialized to				
	blanks. If the password is less than eight characters long				
	remaining bytes are padded with blanks. All letters are converted				
	to upper-case. If the password field is more than eight bytes				
	long an error occurs. Note that a blank in the first position of				
	the password field implies no password was specified.				
byte 24-31	Reserved for system use.				

11.2 NextZXOS

11.3 NextZXOS

A ZX Spectrum I/O system supported by the ZX Spectrum Next. This Documentation is largely from Garry Lancaster's DOCs at https://gitlab.com/thesmog358/tbblue/blob/maste Before making any calls disable writes to Layer 2 in the \$0000-\$3fff area with port \$123b.

11.3.1 + 3DOS compatible API

Generally to make these calls, you need to set up: place ROM 2 at \$0000-\$3fff, RAM bank 7 at \$c000-\$ffff, stack below \$bfe0, and set up the parameters for the call in the indicated registers. Call the function at its address. Then, restore your system to its previous configuration. In general the carry bit of F is cleared on error with the error code in A. Calls generally affect the contrats of AF, BC, DE, HL, and IX leaving AF', BC', DE', HL', IY, and SP intact. To simplify, descriptions will assume this is true and only indicate exceptions to the rule.

\$0056 IDE STREAM OPEN

Open stream to a channel

\$0059 IDE STREAM CLOSE

Close stream and attached channel

\$005c **IDE STREAM IN**

Get byte from current stream

 $$005f IDE_STREAM_OUT$

Write byte to current stream

\$0062 IDE STREAM PTR

Get or set pointer information for current stream

\$00A0 IDE VERSION

Get IDEDOS version number

\$00A3 IDE INTERFACE

Initialise card interfaces

\$00A6 IDE INIT

Initialise IDEDOS

\$00A9 **IDE DRIVE**

Get unit handle

\$00AC IDE SECTOR READ

Low-level sector read

\$00AF IDE SECTOR WRITE

Low-level sector write

\$00B2 IDE FORMAT

Format a partition

\$00B5 IDE PARTITION FIND

Find named partition

\$00B8 IDE PARTITION NEW

Create partition

\$00BB IDE PARTITION INIT

Initialise partition

\$00BE IDE PARTITION ERASE

Delete a partition

\$00C1 **IDE PARTITION RENAME**

Rename a partition

\$00C4 IDE PARTITON READ

Read a partition entry

\$00C7 IDE PARTITION WRITE

Write a partition entry

\$00CA IDE PARTITION WINFO

Write type-specific partition information

\$00CD IDE_PARTITION_OPEN

Open a partition

\$00D0 IDE PARTITION CLOSE

Close a partition

\$00D3 IDE PARTITION GETINFO

Get byte from type-specific partition information

\$00D6 IDE PARTITION SETINFO

Set byte in type-specific partition information

\$00D9 (217) **IDE SWAP OPEN**

Open a swap partition (file)

\$00DC IDE SWAP CLOSE

Close a swap partition

\$00DF IDE SWAP OUT

Write block to swap partition

\$00E2 **IDE SWAP IN**

Read block from swap partition

 $00E5 (231) IDE_SWAP_EX$

Exchange block with swap partition

Deprecated, use IDE_SWAP_IN and IDE_SWAP_OUT

\$00E8 IDE SWAP POS

Get current block number in swap partition

\$00EB IDE SWAP MOVE

Set current block number in swap partition

\$00EE IDE SWAP RESIZE

Change block size of swap partition

\$00F1 (241) **IDE DOS MAP**

Map drive to partition or physical device

\$00F4 (244) **IDE DOS UNMAP**

Unmap drive

\$00F7 (247) **IDE DOS MAPPING**

Get drive mapping

\$00FA IDE_DOS_UNPERMANENT

Remove permanent drive mapping

\$00FD (253) **IDE_SNAPLOAD**

Load a snapshot

\$0100 DOS INITIALISE

Initialise +3DOS

\$0103 DOS VERSION

Get +3DOS issue and version numbers

\$0106 (262) **DOS OPEN**

Create and/or open a file

\$0109 DOS CLOSE

Close a file

\$010C DOS ABANDON

Abandon a file

\$010F **DOS REF HEAD**

Point at the header data for this file

 $$0112 DOS_READ$

Read bytes into memory

\$0115 DOS WRITE

Write bytes from memory

 $$0118 \text{ DOS}_BYTE_READ$

Read a byte

\$011B **DOS BYTE WRITE**

Write a byte

\$011E (286) **DOS CATALOG**

Catalog disk directory

\$0121 (289) DOS FREE SPACE

Free space on disk

 $$0124 \text{ DOS} \quad \text{DELETE}$

Delete a file

 $$0127 \ \mathbf{DOS}_{\mathbf{RENAME}}$

Rename a file

\$012A **DOS BOOT**

Boot an operating system or other program

\$012D **DOS SET DRIVE**

Set/get default drive

\$0130 DOS SET USER

Set/get default user number

\$0133 (307) DOS GET POSITION

Get file pointer for random access

\$0136 DOS SET POSITION

Set file pointer for random access

\$0139 (313) **DOS GET EOF**

Get end of file position for random access

\$013C **DOS GET 1346**

Get memory usage in pages 1 3 4 6

013F **DOS_SET_1346**

Re-allocate memory usage in pages 1 3 4 6

 $$0142\ \mathbf{DOS_FLUSH}$

Bring disk up to date

 $$0145 \text{ DOS_SET_ACCESS}$

Change open file's access mode

\$0148 DOS SET ATTRIBUTES

Change a file's attributes

\$014B **DOS OPEN DRIVE**

Open a drive as a single file

 $$014E\ \mathbf{DOS_SET_MESSAGE}$

Enable/disable error messages

\$0151 DOS REF XDPB

Point at XDPB for low level disk access

\$0154 **DOS MAP B**

Map B: onto unit 0 or 1

 $$0157 \mathbf{DD} \mathbf{INTERFACE}$

Is the floppy disk driver interface present?

\$015A DD INIT

Initialise disk driver

\$015D **DD SETUP**

Specify drive parameters

\$0160 DD SET RETRY

Set try/retry count

 $$0163 \text{ DD}_{\mathbf{READ}_{\mathbf{SECTOR}}}$

Read a sector

\$0166 DD_WRITE_SECTOR

Write a sector

\$0169 DD CHECK SECTOR

Check a sector

\$016C **DD FORMAT**

Format a track

 $016F DD_READ_ID$

Read a sector identifier

\$0172 DD TEST UNSUITABLE

Test media suitability

 $\$0175~\mathbf{DD_LOGIN}$

Log in disk, initialise XDPB

 $$0178 \ \mathbf{DD_SEL_FORMAT}$

Pre-initialise XDPB for DD FORMAT

\$017B **DD ASK** 1

Is unit 1 (external drive) present?

\$017E DD DRIVE STATUS

Fetch drive status

 $$0181 \text{ DD} \quad \mathbf{EQUIPMENT}$

What type of drive?

 $$0184 \ \mathbf{DD_ENCODE}$

Set intercept routine for copy protection

 $$0187 \ \mathbf{DD} \ \mathbf{L} \ \mathbf{XDPB}$

Initialise an XDPB from a disk specification

 $$018A \ DD \ L \ DPB$

Initialise a DPB from a disk specification

 $018D \ \mathbf{DD_L} \ \mathbf{SEEK}$

uPD765A seek driver

 $$0190 \mathbf{DD} \mathbf{L} \mathbf{READ}$

uPD765A read driver

 $$0193 \ \mathbf{DD} \ \mathbf{L} \ \mathbf{WRITE}$

uPD765A write driver

 $0196 \ \mathbf{DD_L_ON_MOTOR}$

Motor on, wait for motor-on time

 $$0199 \text{ DD} \quad L \quad T \quad OFF \quad MOTOR$

Start the motor-off ticker

\$019C **DD** L **OFF MOTOR**

Turn the motor off

\$01a2 IDE IDENTIFY

Return IDE drive identity information

\$01a5 **IDE PARTITIONS**

Get number of open partitions

\$01b1 (433) **IDE PATH**

Create, delete, change or get directory

\$01b4 (436) **IDE CAPACITY**

Get card capacity

\$01b7 (439) **IDE GET LFN**

Get long filename

Obtain a long file name and other file information.

01ba (442) **IDE_BROWSER**

File browser

\$01bd (445) **IDE BANK**

Allocate or free 8K pages in ZX or DivMMC memory

 $01c0 \ \mathbf{IDE} BASIC$

Execute a BASIC command line

\$01c3 IDE WINDOW LINEIN

Input line from current window stream

\$01c6 IDE WINDOW STRING

Output string to current window stream

\$01c9 **IDE INTEGER VAR**

11.3. NEXTZXOS 185

Get or set NextBASIC integer variable

\$01cc **IDE RTC**

Query the real-time-clock module

\$01cf **IDE DRIVER**

Access the driver API

\$01d2 **IDE MOUNT**

Unmount/remount SD cards

\$01d2 **IDE_MOUNT**

Unmount/remount SD cards

 $$01d5 \text{ IDE} \quad MODE$

Query NextBASIC display mode info, or change mode

\$01d8 **IDE TOKENISER**

Convert BASIC between plain text & tokenised forms

11.3.2 esxDOS compatible API

11.3.3 Next Extensions

\$0085 **DISK FILEMAP**

```
 \begin{array}{lll} unsigned & char & esx\_disk\_filemap(uint8\_t & handle,struct & esx\_filemap & \leftarrow \\ & *fmap) \end{array}
```

Obtain a map of card addresses describing the space occupies by the file. Can be called multiple times if the buffer is filled, continuing from previous.

DISK STREAM BYTES

```
void *esx_disk_stream_bytes(void *dst,uint16_t len)
```

\$0087 DISK STREAM END

```
unsigned char esx_disk_stream_end(void)
```

Stop current streaming operation.

DISK STREAM SECTORS

```
void *esx_disk_stream_sectors(void *dst,uint8_t sectors)
```

\$0086 DISK STREAM START

```
 \begin{array}{lll} \textbf{unsigned char esx\_disk\_stream\_start(struct esx\_filemap\_entry *} \leftarrow \\ & \textbf{entry)} \end{array}
```

Start reading from the card in streaming mode.

DOS CATALOG

```
unsigned char esx_dos_catalog(struct esx_cat *cat)
```

DOS CATALOG NEXT

```
unsigned char esx_dos_catalog_next(struct esx_cat *cat)
```

DOS GETSET DRIVE

```
unsigned char esx_dos_get_drive(void)
unsigned char esx_dos_set_drive(unsigned char drive)
```

11.3.4 esxDOS compatible API

The exxDOS-compatible API is a bit simpler to use than the +3DOS-compatible API.

To make a call, you only need to set up the entry parameters as indicated and perform a RST \$08; DEFB hook_code. On return, registers AF,BC,DE,HL will all be changed. IX,IY and the alternate registers are never changed (except for M P3DOS).

(Note that the standard 48K BASIC ROM must be paged in to the bottom of memory, but this is the usual situation after starting a machine code program with a USR function call).

Notice that error codes are different from those returned by +3DOS calls, and also the carry flag is SET for an error condition when returning from an esxDOS call (instead of RESET, as is the case for +3DOS).

If desired, you can use the M_GETERR hook to generate a BASIC error report for any error returned, or even use it to generate your own custom BASIC error report.

All of the calls where a filename is specified will accept long filenames (LFNs) and most will accept wildcards (for an operation such as F_OPEN where a single file is always used, the first matching filename will be used).

\$00A9 F CHDIR

```
unsigned char esx_f_chdir(unsigned char *pathname)
```

Change directory.

11.3. NEXTZXOS

187

$$00AF F_CHMOD$

```
unsigned char esx_f_chmod(unsigned char *filename, uint8_t \hookleftarrow attr_mask, uint8_t attr)
```

Modify file attributes.

\$009B**F CLOSE**

```
unsigned char esx_f_close(unsigned char handle)
```

Close a file or directory.

F CLOSEDIR

```
unsigned char esx_f_closedir(unsigned char handle)
```

\$00A0 F FGETPOS

```
uint32_t esx_f_fgetpos(unsigned char handle)
```

Get current file position.

\$00A1 **F FSTAT**

```
unsigned char esx_f_fstat(unsigned char handle, struct esx_stat *\leftarrow es)
```

Get file information/status.

\$00A2 F FTRUNC

```
unsigned char esx_f_ftrunc(unsigned char handle, uint32_t size)
```

Truncate/extend file.

F GET CANONICAL PATH

```
unsigned char esx_f_get_canonical_path(char *pathname, char * \leftarrow canonical)
```

\$00A8 F GETCWD

```
unsigned char esx_f_getcwd(unsigned char *buf)
```

Get current working directory.

F GETCWD DRIVE

```
unsigned char esx_f_getcwd_drive(unsigned char drive, char *buf)
```

\$00B1 **F GETFREE**

```
uint32_t esx_f_getfree(void)
```

Gets free space on drive.

\$00AA F MKDIR

```
unsigned char esx_f_mkdir(unsigned char *pathname)
```

Create directory.

\$009A **F OPEN**

```
unsigned char esx_f_open(unsigned char *filename,unsigned char \hookleftarrow mode)
```

Open a file.

\$00A3 F OPENDIR

```
unsigned char esx_f_opendir(unsigned char *dirname)
unsigned char esx_f_opendir_ex(unsigned char *dirname,uint8_t 
mode)
```

Open directory.

$009A F_OPEN$

```
unsigned char esx_f_open_p3(unsigned char *filename,unsigned char \leftarrow mode,struct esx_p3_hdr *h)
```

Open a file.

\$009D F READ

```
uint16_t esx_f_read(unsigned char handle, void *dst, size_t \hookleftarrow nbytes)
```

Read bytes from file.

\$00A4 F **READDIR**

```
unsigned char esx_f_readdir(unsigned char handle,struct ↔ esx_dirent *dirent)
```

Read next directory entry.

\$00B0 **F RENAME**

Rename or move a file.

\$00A7 F **REWINDDIR**

```
unsigned char esx_f_rewinddir(unsigned char handle)
```

Rewind directory position to the start of the directory.

$00AB F_RMDIR$

```
unsigned char esx_f_rmdir(unsigned char *pathname)
```

Remove directory.

\$009F **F_SEEK**

Seek to position in file.

\$00A6 F SEEKDIR

```
unsigned char esx_f_seekdir(unsigned char handle,uint32_t pos)
```

Set current directory position.

\$00AC F STAT

Get unopened file information/status.

$\$009C F_SYNC$

```
unsigned char esx_f_sync(unsigned char handle)
```

Sync file changes to disk.

\$00A5 F TELLDIR

```
uint32_t esx_f_telldir(unsigned char handle)
```

Get current directory position.

\$00AE F TRUNC

```
unsigned char esx_f_trunc(unsigned char *filename,uint32_t size)
```

Truncate/extend unopened file.

\$00AD F UNLINK

```
unsigned char esx_f_unlink(unsigned char *filename)
```

Delete file.

```
$009E F WRITE
```

uint16_t esx_f_write(unsigned char handle, void *src, size_t \hookleftarrow nbytes)

Write bytes to file.

IDE BANK ALLOC

unsigned char esx_ide_bank_alloc(unsigned char banktype)

IDE BANK AVAIL

unsigned char esx_ide_bank_avail(unsigned char banktype)

IDE BANK FREE

unsigned char esx_ide_bank_free(unsigned char banktype, unsigned \hookleftarrow char page)

IDE BANK RESERVE

unsigned char esx_ide_bank_reserve(unsigned char banktype, \hookleftarrow unsigned char page)

IDE BANK TOTAL

unsigned char esx_ide_bank_total(unsigned char banktype)

IDE BROWSER

unsigned char esx_ide_browser(uint8_t browsercaps, void *←
 filetypes, char *help,char *dst_sfn, char *dst_lfn)

IDE GET LFN

unsigned char esx_ide_get_lfn(struct esx_lfn *dir, struct ←
 esx_cat_entry *query)

IDE MODE GET

unsigned char esx_ide_mode_get(struct esx_mode *mode)

IDE MODE SET

unsigned char esx_ide_mode_set(struct esx_mode *mode)

\$0088 M DOSVER

Get API version/mode information.

\$0092 M DRVAPI

unsigned char esx_m_drvapi(struct esx_drvapi *)

11.3. NEXTZXOS 191

Access API for installable drivers.

\$0095 M ERRH

```
void esx_m_errh(void (*handler)(uint8_t error))
```

Install error handler for dot command.

\$008F M EXECCMD

```
uint16_t esx_m_execcmd(unsigned char *cmdline)
```

Execute a dot command.

\$008E M GETDATE

```
unsigned char esx_m_getdate(struct dos_tm *)
```

Get the current date/time.

\$0093 M GETERR

```
void esx_m_geterr(uint16_t error,unsigned char *msg)
```

\$008D M GETHANDLE

```
unsigned char esx_m_gethandle(void)
```

Get the file handle of the currently running dot command

\$0089 M GETSETDRV

```
unsigned char esx_m_getdrv(void)
unsigned char esx_m_setdrv(unsigned char drive)
```

Get or set the default drive.

\$0091 M SETCAPS

```
unsigned char esx_m_setcaps(unsigned char caps)
```

$$008B M_TAPEIN$

```
unsigned char esx_m_tapein_close(void)
unsigned char esx_m_tapein_flags(uint8_t flags)
uint16_t esx_m_tapein_getpos(void)
unsigned char esx_m_tapein_info(uint8_t *drive,unsigned char *←
    filename)
unsigned char esx_m_tapein_open(unsigned char *filename)
unsigned char esx_m_tapein_setpos(uint16_t block)
unsigned char esx_m_tapein_toggle_pause(void)
```

Tape input redirection control.

\$008C M TAPEOUT

```
unsigned char esx_m_tapeout_close(void)
unsigned char esx_m_tapeout_info(uint8_t *drive,unsigned char *←
filename)
unsigned char esx_m_tapeout_open(unsigned char *appendname)
unsigned char esx_m_tapeout_trunc(unsigned char *filename)
```

Tape output redirection control.

SLICE DIRENT

```
struct esx_dirent_slice *esx_slice_dirent(struct esx_dirent *)
```

EXTENDED SNA LOAD

unsigned char extended_sna_load(unsigned char handle)

P3DOS COPY CSTR TO PSTR

```
unsigned char *p3dos_copy_cstr_to_pstr(char *pdst, const char *\leftarrow csrc)
```

P3DOS_COPY_PSTR_TO_CSTR

```
unsigned char *p3dos_copy_pstr_to_cstr(char *cdst, const char * \leftarrow psrc)
```

P3DOS CSTR TO PSTR

```
unsigned char *p3dos_cstr_to_pstr(unsigned char *s)
```

P3DOS DOSNAME FROM CATNAME

```
char *p3dos_dosname_from_catname(char *dosname, char *catname)
```

P3DOS EDRV FROM PDRV

```
unsigned char p3dos_edrv_from_pdrv(unsigned char pdrv)
```

P3DOS PDRV FROM EDRV

```
unsigned char p3dos_pdrv_from_edrv(unsigned char edrv)
```

$P3DOS_PSTR_TO_CSTR$

```
unsigned char *p3dos_pstr_to_cstr(unsigned char *s)
```

Appendix A

Ports

Table A.1: ZX Spectrum Ports

R	W	160	Port(hex)	Description	Disable
*	*	XXXX XXXX XXXX XXX0	\$fe	ULA	
*	*	XXXX XXXX 1111 1111	\$ff	Timex video/floating bus	Nextreg \$08 bit 2
i	*	0XXX XXXX XXXX XX01	\$7ffd	ZX Spectrum 128 memory	Port \$7ffd bit 5
i	*	01XX XXXX XXXX XX01	\$7ffd	ZX Spectrum 128 memory	Port \$7ffd bit 5
		011111 1111111 1111111 111101	01114	+3 only	l tott tind bit o
	*	1101 XXXX XXXX XX01	\$dffd	ZX Spectrum 128 memory	Port \$7ffd bit 5
		1101 1111111 1111111 111101	, varia	(precedence over AY)	l ore time ore o
	*	0001 XXXX XXXX XX01	\$1ffd	ZX Spectrum +3 memory	Port \$7ffd bit 5
*		0000 XXXX XXXX XX01		ZX Spectrum +3 floating bus	Port \$7ffd bit 5
*	*	0010 0100 0011 1011	\$243b	NextREG Register Select	Tore ornia bie o
*	*	0010 0101 0011 1011	\$253b	NextREG data/value	
	*	0001 0000 0011 1011	\$103b	i2c SCL (rtc)	
*	*	0001 0001 0011 1011	\$113b	i2c SDA (rtc)	
*	*	0001 0010 0011 1011	\$123b	Layer 2	
*	*	0001 0011 0011 1011	\$133b	UART tx	
*	*	0001 0100 0011 1011	\$143b	UART rx	
*	*	0001 0101 0011 1011	\$153b	UART control	
*	*	0001 1XXX 0011 1011	\$183b	CTC 8 channels \$183b-\$1f3b	
*	*	XXXX XXXX 0110 1011	\$6b	zxnDMA	
*	*	11XX XXXX XXXX X101	\$fffd	AY reg	Nextreg \$06 bit 0
*	*	10XX XXXX XXXX X101	\$bffd	AY dat (readable on +3 only)	Nextreg \$06 bit 0
*	i	10XX XXXX XXXX 0101	\$bff5	AY inf (inside bffd decoding)	
i	*	XXXX XXXX 0000 1111	\$0f	DAC A	Nextreg \$08 bit 3
i	*	XXXX XXXX 1111 0001	\$f1	DAC A (precedence over XXFD)	Nextreg \$08 bit 3
	*	XXXX XXXX 0011 1111	\$3f	DAC A	Nextreg \$08 bit 3
	*	XXXX XXXX 1101 1111	\$df	DAC A/C specdrum	Nextreg \$08 bit 3
	*	XXXX XXXX 0001 1111	\$1f	DAC B	Nextreg \$08 bit 3
	*	XXXX XXXX 1111 0011	\$f3	DAC B	Nextreg \$08 bit 3
	*	XXXX XXXX 0100 1111	\$4f	DAC C	Nextreg \$08 bit 3
	*	XXXX XXXX 1111 1001	\$f9	DAC C (precedence over XXFD)	Nextreg \$08 bit 3
	*	XXXX XXXX 0101 1111	\$5f	DAC D	Nextreg \$08 bit 3
	*	XXXX XXXX 1111 1011	\$fb	DAC D	Nextreg \$08 bit 3
i i	*	XXXX XXXX 1110 0111	\$e7	SPI /CS (sd card/flash/rpi)	Nextreg \$09 bit 2
*	*	XXXX XXXX 1110 1011	\$eb	SPI /DATA	Nextreg \$09 bit 2
*	*	XXXX XXXX 1110 0011	\$e3	divMMC Control	Nextreg \$09 bit 2
*		XXXX 1011 1101 1111	\$fbdf	Kempston mouse x	Nextreg \$09 bit 3
*		XXXX 1111 1101 1111	\$ffdf	Kempston mouse y	Nextreg \$09 bit 3
*		XXXX 1010 1101 1111	\$fadf	Kempston mouse wheel/buttons	Nextreg \$09 bit 3
*		XXXX XXXX 0001 1111	\$1f	Kempston joy 1	Nextreg \$05
*		XXXX XXXX 0011 0111	\$37	Kempston joy 2	Nextreg \$05
*	*	XXXX XXXX 0001 1111	\$1f	Multiface 1 disable	
*	*	XXXX XXXX 1001 1111	\$9f	Multiface 1 enable	
*	*	XXXX XXXX 0001 1111	\$1f	Multiface 128 v87.12 disable	
*	*	XXXX XXXX 1001 1111	\$9f	Multiface 128 v87.12 enable	
*	*	XXXX XXXX 0011 1111	\$3f	Multiface 128 v87.2 disable	
*	*	XXXX XXXX 1011 1111	\$bf	Multiface 128 v87.2 enable	
*	*	XXXX XXXX 1011 1111	\$bf	Multiface +3 disable	
*	*	XXXX XXXX 0011 1111	\$3f	Multiface +3 enable	
*	*	0011 0000 0011 1011	\$303b	Sprite slot/flags	
	*	XXXX XXXX 0101 0111	\$57	Sprite attributes	
	*	XXXX XXXX 0101 1011	\$5b	Sprite pattern	
	*	1011 1111 0011 1011	\$bf3b	ULAPlus register	
*	*	1111 1111 0011 1011	\$ff3b	ULAPlus data	
	•	•			•

A.1 8-bit

```
Port $6B (107) DMA Control (Z80 Mode, 3.01.02)
Port $0F (15) DAC B
     bits 7-0 = DAC Value
Disable with bit 3 of Nextreg $08
Port $1F (31) Kempston/Mega Drive Joystick 1/DAC A
Read
     bit 7 = "start" button
     bit 6 = A/X button
     bit 5 = C/Z button
     bit 4 = Fire/C/Y button
     bit 3 = Up
     bit 2 = Down
     bit 1 = Left
     bit 0 = Right
Disable with Nextreg $05
Write
     bits 7-0 = DAC Value
The XYZ buttons on md pads can be read through nextreg 0xB2.
The joysticks can also be placed in i/o mode see nextreg 0x0B.
All eleven md pad buttons can be assigned to the keyboard see nextreg 0x05.
Port $37 (55) Kempston/Mega Drive Joystick 2
Read
     bit 7 = "start" button
     bit 6 = A/X button
     bit 5 = C/Z button
     bit 4 = Fire/C/Y button
     bit 3 = Up
     bit 2 = Down
     bit 1 = Left
     bit 0 = Right
The XYZ buttons on md pads can be read through nextreg 0xB2.
The joysticks can also be placed in i/o mode see nextreg 0x0B.
All eleven md pad buttons can be assigned to the keyboard see nextreg 0x05.
```

Port \$3F (63) DAC A

bits 7-0 = DAC Value

Disable with bit 3 of Nextreg \$08

A.1. 8-BIT 195

```
Port $4F (79) DAC C
      bits 7-0 = DAC Value
Disable with bit 3 of Nextreg $08
Port $57 (87) Sprite Attributes
Byte 1
      bits 7-0 = LSB of X coordinate (bit 8 is in byte 3)
Byte 2
      bits 7-0 = LSB of Y coordinate (bit 8 is in byte 5)
Byte 3
      bits 7-4 = Palette Offset
      bit 3 = \text{Enable X Mirror}
      bit 2 = \text{Enable Y Mirror}
      bit 1 = \text{Enable Roration}
      bit 0 = By Sprite Type
           Anchor = MSB \text{ of } X \text{ coordinate}
           Relative = Enable relative palette offset
Byte 4
      bit 7 = Enable visibility
      bit 6 = \text{Enable Byte } 5
      bit 5-0 = Pattern Index ("name")
Byte 5 (optional)
Anchor
      bit 7-6 = type and pattern
           00 = 8-bit color
           01 = \text{relative}
           10 = 4-bit color, lower half of pattern (bytes 0-127)
           11 = 4-bit color, upper half of pattern (byets 128-255)
      bit 5 = Attached relative sprite type
           0 = composite
           1 = \text{big sprite}
      bit 4-3 = X-axis scale factor
           00 = 1 \times
           01 = 2 \times
           10 = 4 \times
           11 = 8 \times
      bit 2-1 = Y-axis scale factor
      bit 0 = MSB of Y coordinate
Composite Relative
      bits 7-6 = 01
```

```
bit 5 = N6
     8-bit
          Reserved, must be 0
     4-bit
          0 = \text{lower half of pattern (bytes 0-127)}
          1 = \text{upper half of pattern (bytes 128-255)}
     bit 4-3 = X-axis scale factor
     bit 2-1 = Y-axis scale factor
     bit 0 = Enable relative pattern offset
Big-sprite Relative
     bits 7-6 = 01
     bit 5 = N6
     8-bit
          Reserved, must be 0
     4-bit
          0 = \text{lower half of pattern (bytes 0-127)}
          1 = \text{upper half of pattern (bytes } 128-255)
     bit 4-1 = \text{Reserved}, must be 0
     bit 0 = Enable relative pattern offset
Port $5B (91) Sprite Pattern
Load data into sprite pattern memory auto-incrementing. Port $303B can be
used to set the starting sprite pattern number.
Port $5F (95) DAC D
     bits 7-0 = DAC Value
Disable with bit 3 of Nextreg $08
Port $6B (107) DMA Control (Next Mode, 3.01.02)
Port $DF (223) DAC A,D
     bits 7-0 = DAC Value
Disable with bit 3 of Nextreg $08
Port $E3 (227) divMMC Control
Disable with bit 2 of Nextreg $09
     bit 7 = conmem, enable divMMC memory
     bit 6 = mapram, enable divMMC allRAM mode
     bits 3-0 = bank, selected divMMC ram bank for $2000-$3FFF region
   • conmem can be used to manually control divMMC mapping. When en-
     $0000-$1FFF contains esxDOS ROM or esxDOS page 3
     2000-3FFF contains explose RAM page selected by bits 3-0
   • divMMC automatically maps itself in when instruction fetches hit specific
     addresses in the ROM. When this happens, the esxDOS ROM (or di-
```

A.1. 8-BIT 197

vMMC bank 3 if mapram is set) appears in \$0000-\$1FFF and the selected divMMC bank appears as RAM in \$2000-\$3FFF

• bit 6 can only be set, once set only a power cycle can reset it. nextreg \$09 bit 3 can be set to reset this bit.

divMMC automapping is normally disabled by NextZXOS see nextreg \$06 bit 4.

Port \$E7 (231) SPI $\overline{\text{CS}}$ (SD card, flash, rpi)

Disable with bit 2 of Nextreg \$09

Port \$EB (235) SPI DATA (SD card, flash, rpi)

Disable with bit 2 of Nextreg \$09

Port \$F1 (241) DAC A (precedence over \$xxFD)

bits 7-0 = DAC Value

Disable with bit 3 of Nextreg \$08

Port \$F3 (243) DAC B

bits 7-0 = DAC Value

Disable with bit 3 of Nextreg \$08

Port \$F9 (249) DAC C (precedence over \$xxFD)

bits 7-0 = DAC Value

Disable with bit 3 of Nextreg \$08

Port \$FB (251) DAC A,D

bits 7-0 = DAC Value

Disable with bit 3 of Nextreg \$08

Port \$FE (254) ULA

bits 7-5 = Unused

bit 4 = enable ear output

bit 3 = enable mic output

bit 2-0 = border colour

nextreg \$08 bit 0 can be set to delect issue 2 keyboard which will affect reads of bit 6.

Port \$FF (255) Timex Sinclair/Floating Bus

bit 7 = memory paging (not on ZX Next)

bit 6 = Disable generation of interrupts

bit 5-3 = Hi-res mode color combination

000 = Black on white (indexes 0, 135)

001 = Blue on Yellow (indexes 1, 134)

010 = Green on Magenta (indexes 2, 133)

011 = Cyan on Red (indexes 3, 132)

```
100 = \mathrm{Red} \ \mathrm{on} \ \mathrm{Cyan} \ (\mathrm{indexes} \ 4, 131)
101 = \mathrm{Magenta} \ \mathrm{on} \ \mathrm{Green} \ (\mathrm{indexes} \ 5, 130)
110 = \mathrm{Yellow} \ \mathrm{on} \ \mathrm{Blue} \ (\mathrm{indexes} \ 6, 129)
111 = \mathrm{White} \ \mathrm{on} \ \mathrm{Black} \ (\mathrm{indexes} \ 7, 128)
\mathrm{bit} \ 2\text{-}0 = \mathrm{ULA} \ \mathrm{Mode}
000 = \mathrm{Normal} \ \mathrm{ULA} \ \mathrm{address}
001 = \mathrm{Alternate} \ \mathrm{ULA} \ \mathrm{address}
010 = \mathrm{Hi\text{-}color} \ \mathrm{mode}
110 = \mathrm{Hi\text{-}res} \ \mathrm{mode}
```

Disable with bit 2 of Nextreg \$08

A.2 16-bit

```
Port $103B (4155) I<sup>2</sup>C SCL (rtc, rpi)
Port $113B (4411) I<sup>2</sup>C SDA (rtc, rpi)
Port 123B (4667) Layer 2
Bit 4 = 0
      bits 7-6 = Video RAM bank select
            00 = \text{first } 16\text{k}
            01 = second 16k
            10 = third 16k
            11 = first 48k
      bit 5 = \text{Reserved}, must be 0
      bit 4 = 0
      bit 3 = \text{Shadow layer 2 select}
      bit 2 = \text{Enable layer } 2 \text{ read paging}
      bit 1 = \text{Layer 2 visible (mirrored in register $69)}
      bit 0 = \text{Enable layer } 2 \text{ write paging}
Bit 4 = 1
      bits 7-5 = \text{Reserved}, must be 0
      bit 4 = 1
      bit 3 = \text{Reserved}, must be 0
      bit 2-0 = 16k bank relative offset
Port $133B (4923) UART tx
Read: UART Status
      bits 7-4 = Reserved(0)
      bit 3 = \text{UART} at least half full (3.01.09)
      bit 2 = UART full
      bit 1 = UART transmit busy
```

A.2. 16-BIT 199

```
bit 0 = UART receive has data
Write: UART Transmit
Port $143B (5179) UART rx
Read: UART Receive
Write: UART Prescalar
     bit 7 = select prescalar part
          0 = Bits 6-0 of prescalar
          1 = Bits 13-7 of prescalar
     bits 6-0 = Prescalar bits
Port $153B (5435) UART select
     bit 7 = Reserved(0)
     bit 6 = UART select (0 on soft reset) **
          0 = ESP
          1 = Pi *
     bit 5 = Reserved(0)
     bit 4 = \text{Prescalar valid in this write}
     bit 3 = \text{Reserved}(0)
     bits 2-0 = Bits 16-14 of prescalar (0 on hard reset)
* Pi GPIO must be configured for UART, see nextreg $A0
* Either UART can be redirected to the joystick ports, see port $037
Port $153B (5435) UART frame (upcoming)
($18 on hard reset)
     bit 7 = Immediately reset Rx and Tx to idle and empty FIFOs
     bit 6 = Assert break (Tx=0) when Tx reaches idle
     bit 5 = Enable hardware flow control *
     bits 4-3 = Number of bits in a frame
          00 = 5 bits
          01 = 6 bits
          10 = 7 \text{ bits}
          11 = 8 \text{ bits}
     bit 2 = \text{Enable parity}
     bit 1 = Parity
          0 = \text{Even parity}
          1 = Odd parity
     bit 0 = \text{Number of stop bits}
          0 = 1 stop bit
          1 = 2 stop bits
* The ESP ignores hardware flow control
In joystick i/o mode only cts is available
Port $183B (6203) CTC Channel 0 Port $193B (6459) CTC Channel 1 Port
```

1A3B (6715) CTC Channel 2 Port 1B3B (6971) CTC Channel 3 Port 1C3B

```
(7227) CTC Channel 4 Port $1D3B (7483) CTC Channel 5 Port $1E3B (7739)
CTC Channel 6 Port $183B (6203) CTC Channel 7 Port $1FFD (8189) Plus
3 Memory Paging Control
     bits 7-3 = \text{Unused}, nust be 0
     bit 2 = High bit of ROM selection (low bit is in Port $7FFD)
          00 = ROM0 = 128k editor and menu system
          01 = \text{ROM1} = 128\text{k} syntax checker
          10 = ROM2 = +3DOS
          11 = ROM3 = 48k BASIC
     bit 1 = Special mode: Low bit of memory configuration number
     bit 0 = \text{Paging mode}
          0 = Normal
          1 = Special
You should echo writes to $5B67
Port $243B (9275) Next Register Select
Port $253B (9531) Next Register Data
Port $303B (12347) Sprite Slot/Flags
Write: Sprite Slot Select
select sprite slot for Sprite Attribute and Sprite Pattern ports which indepen-
dently auto-increment
Read: Sprite status
     bits 7-2 = reserved
     bit 1 = \text{Max sprites per line}
     bit 0 = \text{Collision flag}
Port $7FFD (32765) Memory Paging Control
     bits 7-6 = Extra two bits for 16k RAM bank if in Pentagon 512k/1024k
     mapping mode (nextreg $8f)
     bit 5 = \text{Lock memory paging}
     bit 4 = \text{low bit of ROM Select (high bit is in Port $1FFD)}
          00 = ROM0 = 128k editor and menu system
          01 = ROM1 = 128k syntax checker
          10 = ROM2 = +3DOS
          11 = ROM3 = 48k BASIC
     bit 3 = \text{Shadow screen toggle}
     bits 2-0 = LSB of Bank number for slot 4 (MSB is in Port $DFFD)
Disable with bit 5 port $7FFD
Port $7FFE (32766) Keyboard 8 (read only)
     bit 0: 'B'
     bit 1: 'N'
     bit 2: 'M'
```

A.2. 16-BIT 201

```
bit 3: Symbol Shift
     bit 4: Space
Port $BF3B (48955) ULAplus register
     bits 7-6 = Select register group
        -00 = palette group
       -01 = mode group
     bits 5-0 = data
          If palette group, selects index 0-63 in ULAplus palette
          If mode group, ignored
Port $BFF5 (49141) AY Info (3.01.09)
(R)
     bits 7-6 = Active AY chip
       -01 = AY 0 active
       -10 = AY 1 active
       -11 = AY 2 active
     bit 5 = Reserved
     bits 4-0 = currently selected AY register
Port $BFFD (49149) AY Data
Port $BFFE (49150) Keyboard 7 (read only)
     bit 0 = 'H'
     bit 1 = 'J'
     bit 2 = K'
     bit 3 = L'
     bit 4 = Enter
Port $DFFD (57341) Next Memory Bank Select
     bits 7-4 = \text{Reserved}, must be 0
     bits 3-0 = MSB of bank number for slot 4 (LSB is in Port $7FFD)
Port $DFFE (57342) Keyboard 6 (read only)
     bit 0 = Y'
     bit 1 = 'U'
     bit 2 = I'
     bit 3 = 'O'
     bit 4 = P'
Port $EFF7 (61431) Pentagon 1024 paging
     bit 3 = 1 to overlay the bottom 16k with ram from 16k bank 0
     bit 2 = 0 to enable Pentagon 1024 mapping and disable bit 5 port 0x7ffd
     locking, 1 to select standard zx128 mapping **
     ** Applies only when pentagon 1024 mapping mode is enabled via nextreg
     0x8f.
```

```
Port $EFFE (61438) Keyboard 5 (read only)
     bit 0 = 6'
     bit 1 = '7'
     bit 2 = '8'
     bit 3 = '9'
     bit 4 = '0'
Port $F7FE (63486) Keyboard 4 (read only)
     bit 0 = 5
     bit 1 = '4'
     bit 2 = '3'
     bit 3 = '2'
     bit 4 = '1'
Port $FADF (64223) Kempston Mouse Buttons
     bits 7-4 = Wheel delta since last read
     bit 3 = fourth button
     bit 2 = middle button
     bit 1 = left button
     bit 0 = \text{right button}
Port $FBDF (64479) Kempston Mouse X
     bits 7-0 = X coordinate of mouse
Port $FBFE (64510) Keyboard 3 (read only)
     bit 0 = T'
     bit 1 = R'
     bit 2 = E'
     bit 3 = \text{'W'}
     bit 4 = 'Q'
Port $FDFE (65022) Keyboard 2 (read only)
     bit 0 = G'
     bit 1 = F'
     bit 2 = 'D'
     bit 3 = S
     bit 4 = 'A'
Port $FEFE (65278) Keyboard 1 (read only)
     bit 0 = V'
     bit 1 = 'C'
     bit 2 = 'X'
     bit 3 = 'Z'
     bit 4 = \text{Caps Shift}
Port $FF3B (65339) ULAplus data
```

A.2. 16-BIT 203

```
If palette group, 8-bit (RRRGGGBB) value for current index
     If mode group, bit 1 = \text{enable ULAplus}
Port $FFDF (65503) Kempston Mouse Y
     bits 7-0 = Y coordinate of mouse (0-192)
Port $FFFD (65533) AY Control and AY register Select (3.01.09)
Read
     bits 7-0 = data in selected register of active AY chip
Select Chip
     bit 7 = 1
     bit 6 = \text{Enable left}
     bit 5 = Enable Right
     bits 4-2 = Reserved, must be 1
     bits 1-0 = AY chip select
          00 = Unused
          01=AY\ 2
          10 = AY 1
          11=AY~0
Select Register
     bit 7 = 0
     bits 6-5 = \text{Reserved}, must be 0
     bits 4-0 = \text{Register Number}
```

Appendix B

Registers

B.1 ZX Spectrum Next Registers

The ZX Next stores configuration state in a field of registers. These registers are accessible via two I/O ports or via the special nextreg instructions.

Port \$243B (9275) is used to set the register number, listed below.

Port \$253B (9531) is used to access the register value.

Some registers are accessible only during the initialization process.

Register (R) $00 (0) \Rightarrow Machine ID$

- 00000001 = DE1A
- 00000010 = DE2A
- 00000101 = FBLABS
- 00000110 = VTRUCCO
- 00000111 = WXEDA
- 00001000 = EMULATORS
- 00001010 = ZX Spectrum Next
- 00001011 = Multicore
- 10101010 = ZX Spectrum Next Core on un
Amiga
- 10111010 = ZX Spectrum Next Core on SiDi
- 11001010 = ZX Spectrum Next Core on MIST
- 11011010 = ZX Spectrum Next Core on MiSTer
- 11011010 = ZX Spectrum Next Core on unAmiga Reloaded
- 11101010 = ZX Spectrum Next Core on ZX-DOS
- 11111010 = ZX Spectrum Next Anti-brick

Register (R) \$01 (1) \Rightarrow Core Version

• bits 7-4 = Major version number

bits 3-0 = Minor version number
 See register \$0E for sub minor version number

Register (R/W) 02 (2) \Rightarrow Reset Read

- bit $7 = \text{Expansion bus } \overline{\text{RESET}}$ Asserted
- bits 6-5 = Reserved
- bit $4 = \text{Multiface } \overline{\text{NMI}}$ generated by I/O trap (experimental) (3.01.11)
- bit $3 = \text{Indicates multiface } \overline{\text{NMI}}$ was generated by this nextreg (3.01.09)
- bit 2 = Indicates divmmc $\overline{\text{NMI}}$ was generated by this nextreg (3.01.09)
- bit 1 = Last reset was Hard reset
- bit 0 = Last reset was Soft reset

Write

- bit $7 = \text{Hold Expansion bus and ESP } \overline{\text{RESET}}$
- bits 6-5 = Reserved, must be 0
- bit 4 = clear I/O trap (experimental)(3.01.10)
- bit 3 = Generate multiface $\overline{\text{NMI}}$ ** (write zero to clear) (3.01.09)
- bit 2 = Generate divmmc $\overline{\text{NMI}}$ ** (write zero to clear) (3.01.09)
- bit 1 = generate Hard reset * (reboot)
- bit 0 = generate Soft reset *
- * Hard reset has precedence
- * These signals are ignored if the multiface, divmmc, dma or external $\overline{\text{NMI}}$ master is active Register (R/W) \$03 (3) \Rightarrow Machine Type

A write to this register disables the boot rom

bits 2-0 select machine type when in config mode

- bit 7 = (W) Display Timing change enable (allow changes to bits 6-4) (0 on hard reset)
- bits 6-4 = Display Timing
- bit 3 = Display Timing user lock control

Read

- -0 =No user lock on display timing
- -1 =User lock on display timing

Write

- -1 = Apply user lock on display timing (0 on hard reset)
- bits 2-0 = Machine Type (config mode only)

determines roms loaded

Machine Types/Display Timings

- -000 or 001 = ZX 48K
- -010 = ZX 128K/+2 (Grey)
- -011 = ZX + 2A-B/+3e/Next Native
- -100 = Pentagon 128K

Register (W) \$04 (4) \Rightarrow Configuration Mapping

• bits 7 = Reserved, must be 0

- bits 6-0 = 16k SRAM bank mapping* (\$00 on hard reset)
 - * Maps a 16k SRAM bank over the bottom 16k. Applies only in config mode when the bootrom is disabled
 - ** Odd multiples of 256k are unreliable if storing data in sram for the mext core started.
 - *** number of useful bits changed from 5 to 7 in coure 3.01.06

Register (R/W) 05 (5) \Rightarrow Peripheral 1 Settings

- bits 7-6 = joystick 1 mode (MSB)
- bits 5-4 = joystick 2 mode (MSB)
- bit 3 = joystick 1 mode (LSB)
- bit 2 = 50/60 Hz mode (0 = 50Hz, 1 = 60Hz)
- bit $1 = \text{joystick } 2 \mod \text{(LSB)}$
- bit 0 = Enable Scandoubler

Joystick modes

- 000 = Sinclair 2 (67890)
- 001 = Kempston 2 (port \$37)
- 010 = Kempston 1 (port \$1F)
- 011 = Megadrive 1 (port \$1F)
- 100 = Cursor
- 101 = Megadrive 2 (port \$37)
- 110 = Sinclair 1 (12345)
- 111 = User Defined Keys Joystick
- * Joysticks can be placed in i/o mode via nextreg 0x0B.
- * Programming the user defined keys joystick is done through the ps2 keymap interface on nextreg 0x28, 0x29 and 0x2B:
- 1. Write 128 to nextreg 0x28
- 2. Write 0 (left joystick) or 16 (right joystick) to nextreg 0x29
- 3. Write eleven bytes to nextreg 0x2B. The bytes correspond to the eleven buttons on an md pad (X=11 Z Y START A C B U D L R=1)
- 4. Each byte written identifies a key in the 8x7 membrane; bits 5:3 select the row and bits 2:0 select the column with 111 meaning no action. In all joystick modes, excess buttons on an md pad not read via ports will generate key input if so programmed.

Register (R/W) \$06 (6) \Rightarrow Peripheral 2 Settings

- bit 7 = Enable F8 cpu speed hotkey (soft reset = 1)
- bit 6 = Divert BEEP only to internal speaker (hard reset = 0)
- bit 5 = Enable F3 50/60 Hz hotkey (soft reset = 1)
- bit 4 = Enable divmmc nmi by DRIVE button (hard reset = 0)
- bit 3 = Enable multiface nmi by M1 button (hard reset = 0)
- bit 2 = PS/2 mode (config mode only)
 - -0 = keyboard primary
 - -1 = mouse primary

- bits 1-0 = Audio chip mode
 - -00 = YM
 - -01 = AY
 - -11 = Hold all AY in reset

Register (R/W) \$07 (7) \Rightarrow Turbo mode Read

- bits 7-6 = Reserved
- bits 5-4 = Current Actual CPU Speed
- bits 3-2 = Reserved
- bits 1-0 = Current Selected CPU Speed (00 on reset)

Write

- bits 7-2 = Reserved, must be 0
- bits 1-0 = Select CPU Speed

CPU Speeds

- 00 = 3.5 MHz
- 01 = 7 MHz
- 10 = 14 MHz
- 11 = 28 MHz

Register (R/W) \$08 (8) \Rightarrow Peripheral 3 Settings

- bit 7 = 128K Banking Unlock (inverse of port \$7FFD, bit 5) (0 on reset)
- bit 6 = Disable RAM and Port Contention (0 on reset)
- bit 5 = PSG Stereo Mode Control (0 = ABC, 1 = ACB) (0 on hard reset)
- bit 4 = Enable internal speaker (1 on hard reset)
- bit 3 = Enable DACs (0 on hard reset)
- bit 2 = Enable read of port \$FF (Timex) (0 on hard reset)
- bit 1 = Enable Multiple PSGs (0 on hard reset)
- bit 0 = Enable Issue 2 Keyboard

Register (R/W) \$09 (9) \Rightarrow Peripheral 4 setting:

- bit 7 = PSG 2 Mono Enable (0 on hard reset)
- bit 6 = PSG 1 Mono Enable (0 on hard reset)
- bit 5 = PSG 0 Mono Enable (0 on hard reset)
- \bullet bit 4 = Sprite ID lockstep enable (1 = Nextreg \$34 and IO Port \$303B are in lockstep, 0 on reset)
- bit 3 = divMMC mapRAM bit Control (reset bit 7 of port \$E3)
- bit 2 = HDMI audio mute (0 on hard reset)
- bits 1-0 = scanlines
 - -00 = scanlines off
 - -01 = scanlines 12.5%
 - -10 = scanlines 25%
 - -11 = scanlines 50%

In Sprite lockstep, NextREG \$34 and Port \$303B are in lockstep

Register (R/W) $$0A\ (10) \Rightarrow Peripheral 5 setting:$

```
• bits 7-6 = Multiface type (00 on hard reset)
        -00 = Multiface +3 (enable port 0x3F, disable port 0xBF)
        -01 = Multiface 128 v87.2 (enable port 0xBF, disable port 0x3F)
        -10 = Multiface 128 v87.12 (enable port 0x9F, disable port 0x1F)
        -11 = Multiface 1 (enable port 0x9F, disable port 0x1F)
   • bit 5 = Reserved, must be zero
   • bit 4 = \text{Enable divmmc automap (hard reset} = 0) (3.01.10)
   • bit 3 = 1 to reverse left and right mouse buttons (3.01.07)
   • bit 2 = \text{Reserved}, must be 0
   • bits 1-0 = \text{mouse dpi } (00 \text{ on hard reset}) (3.01.05)
        -00 = low dpi
        -01 = default
        -10 = \text{medium dpi}
        -11 = high dpi
Register (R/W) 0B (11) \Rightarrow Joystick I/O Mode
```

```
• bit 7 = 1 to enable i/o mode
• bit 6 = \text{Reserved}, must be 0
```

```
• bits 5-4 = I/O Mode
```

$$-00 = \text{bit bang}$$

$$-01 = clock$$

-10 = uart on left joystick port

-11 = uart on right joystick port

• bits 3-1 = Reserved, must be 0

```
• bit 0 = Parameter
```

```
bit bang: copied to pin 7
clock
  * 0 = \text{hold high when clock becomes high}
```

* 1 = run *

uart

* 0 = redirect esp uart0 to joystick

*1 = redirect pi uart1 to joystick

(Tx out on pin 7, Rx in from pin 9, CTS n in from pin 6 **)

The state of output pin 7 is stored internally in a register and is retained across changing modes and while i/o mode is disabled. While in i/o mode, keyboard joystick types (Sinclair, Cursor, etc) produce no readings but the current state of pins can still be read via the Kempston ports. When leaving i/o mode, joystick operation resumes after 64 scan lines have passed.

CTC channel 3 is currently used to drive pin 7 in clock mode. Freq = Fctc3 /

- * CTS n is only active if the seleced uart is in hw flow control mode. Register (R) \$0E (14) \Rightarrow Core Version (sub minor number)
 - bits 7-0 = Core sub minor version number

(see register \$01 for the major and minor version number)

Register (R/W) \$10 (16) \Rightarrow Core Boot Read

- bits 7-2 = Reserved
- bit 1 = Drive button pressed
- bit $0 = \overline{\text{NMI}}$ button pressed

Write

- bit 7 = Reboot FPGA using selected core (0 on reset)
- bits 6-5 = Reserved, must be 0
- bits 4-0 = Core ID

Core ID with bits 4-0 can only be set in configuration mode

Register (R/W) \$11 (17) \Rightarrow Video Timing (writable in config mode only)

- bits 7-3 = Reserved, must be 0
- bits 2-0 = Mode (VGA = 0..6, HDMI = 7)
 - -000 = Base VGA timing, clk28 = 28000000
 - -001 = VGA setting 1, clk28 = 28571429
 - -010 = VGA setting 2, clk28 = 29464286
 - -011 = VGA setting 3, clk28 = 30000000
 - -100 = VGA setting 4, clk28 = 31000000
 - 101 = VGA setting 5, clk28 = 32000000
 - -110 = VGA setting 6, clk28 = 33000000
 - -111 = HDMI, clk28 = 27000000

50/60Hz selection depends on bit 2 of register \$05 Only writable in config mode

Register (R/W) 12 (18) \Rightarrow Layer 2 Active RAM bank

- bits 7-6 = Reserved, must be 0
- bits 5-0 = RAM bank (point to bank 8 after a Reset, NextZXOS modifies to 9)

Register (R/W) \$13 (19) \Rightarrow Layer 2 Shadow RAM bank

- bits 7-6 = Reserved, must be 0
- bits 5-0 = RAM bank (point to bank 11 after a Reset, NextZXOS modifies to 12)

Register (R/W) \$14 (20) \Rightarrow Global transparency color

• bits 7-0 = Transparency color value (\$E3 after a reset)

(Note: this value is 8-bit, so the transparency is compared against only by the MSB bits of the final 9-bit colour)

(Note2: this only affects Layer 2, ULA and LoRes. Sprites use register \$4B for transparency and tilemap uses nextreg \$4C)

Register (R/W) \$15 (21) \Rightarrow Sprite and Layer System Setup

```
• bit 7 = LoRes mode (0 on reset)
```

- bit 6 = Sprite priority (1 = sprite 0 on top, 0 = sprite 127 on top) (0 on reset)
- bit 5 = Enable sprite clipping in over border mode (0 on reset)
- bits 4-2 = set layers priorities (000 on reset)
 - 000 S L U
 - 001 L S U
 - 010 S U L
 - 011 L U S
 - 100 U S L
 - 101 U L S
 - 110 S(U+L) ULA and Layer 2 combined, colours clamped to 7
 - 111 S(U+L-5) ULA and Layer 2 combined, colours clamped to [0,7]
- bit 1 = Enable Sprites Over border (0 on reset)
- bit 0 = Enable Sprites (0 on reset)

Register (R/W) \$16 (22) \Rightarrow Layer 2 Horizontal Scroll Control

• bits 7-0 = X Offset (0-255)(0 on reset)

Register (R/W) \$17 (23) \Rightarrow Layer 2 Vertical Scroll Control

• bits 7-0 = Y Offset (0-191)(0 on reset)

Register (R/W) \$18 (24) \Rightarrow Layer 2 Clip Window Definition

• bits 7-0 = Coords of the clip window

1st write - X1 position

2nd write - X2 position

3rd write - Y1 position

4rd write - Y2 position

Reads do not advance the clip position

The values are 0,255,0,191 after a Reset

Register (R/W) \$19 (25) \Rightarrow Sprite Clip Window Definition

• bits 7-0 = Cood. of the clip window

1st write - X1 position

2nd write - X2 position

3rd write - Y1 position

4rd write - Y2 position

The values are 0,255,0,191 after a Reset

Reads do not advance the clip position

When the clip window is enabled for sprites in "over border" mode, the X coords are internally doubled and the clip window origin is moved to the sprite origin inside the border.

Register (R/W) \$1A (26) \Rightarrow Layer 0 (ULA/LoRes) Clip Window Definition

bits 7-0 = Coord. of the clip window
1st write = X1 position
2nd write = X2 position
3rd write = Y1 position
4rd write = Y2 position

The values are 0,255,0,191 after a Reset Reads do not advance the clip position

Register (R/W) \$1B (27) \Rightarrow Layer 3 (Tilemap) Clip Window Definition

bits 7-0 = Coord. of the clip window
 1st write = X1 position
 2nd write = X2 position
 3rd write = Y1 position
 4rd write = Y2 position

The values are 0,159,0,255 after a Reset Reads do not advance the clip position The X coords are internally doubled.

Register (R/W) \$1C (28) \Rightarrow Clip Window Control Read

- bits 7-6 = Layer 3 Clip Index
- bits 5-4 = Layer 0/1 Clip Index
- bits 3-2 =Sprite clip index
- bits 1-0 = Layer 2 Clip Index

Write

- bits 7-4 = Reserved, must be 0
- $\bullet\,$ bit 3 reset Layer 3 clip index
- bit 2 reset Layer 0/1 clip index
- bit 1 reset sprite clip index.
- bit 0 reset Layer 2 clip index.

Register (R) \$1E (30) \Rightarrow Active video line (MSB)

- bits 7-1 = Reserved
- bit 0 = Active line MSB

Register (R) \$1F (31) \Rightarrow Active video line (LSB)

• bits 7-0 = Active line LSB (0-255)

Register (R/W) \$22 (34) \Rightarrow Line Interrupt control

- bit 7 = (R) ULA asserting interrupt
- bit 7 = (W) Reserved, must be 0
- bits 6-3 = Reserved, must be 0
- bit 2 = Disable ULA Interrupt (0 on reset)
- bit 1 = Enable Line Interrupt (0 on reset)

• bit 0 = MSB of Line Interrupt line value (0 on reset)

Register (R/W) \$23 (35) \Rightarrow Line Interrupt value LSB

• bits 7-0 = Line Interrupt line value LSB (0-255)(0 on reset)

Register (R/W) \$24 (36) \Rightarrow Reserved Protection against "OUT (\$3B),A"

Register (R/W) \$26 (38) \Rightarrow ULA Horizontal Scroll Control

• bits 7-0 = ULA X Offset (0-255) (0 on reset)

Register (R/W) $$27 (39) \Rightarrow ULA Vertical Scroll Control$

• bits 7-0 = ULA Y Offset (0-191) (0 on reset)

Register (R/W) \$28 (40) \Rightarrow Stored Palette Value and PS/2 Keymap Address MSB

Read

• bits 7-0 = Stored palette value (see NextREG \$44)

Write

- bit 7 = PS/2 or Joystick
 - -0 = PS/2 keymap
 - -1 = Key joystick
- bits 6-1 = Reserved, must be 0
- bit 0 = PS/2 Keymap Address MSB

Register (W) \$29 (41) \Rightarrow PS/2 Keymap Address LSB

 $\bullet\,$ bits 7-0 = PS/2 Keymap Address LSB

Register (W) 2A (42) $\Rightarrow PS/2$ Keymap Data MSB

- bits 7-1 = Reserved, must be 0
- bit 0 = PS/2 Keymap Data MSB

Register (W) \$2B (43) \Rightarrow PS/2 Keymap Data LSB

• bits 7-0 = PS/2 Keymap Data LSB

(writing this register auto-increments the address)

Register (R/W) \$2C (44) \Rightarrow DAC B Mirror (Left)/ $\rm I^2S$ Left Sample MSB Read

• bits $7-0 = I^2S$ Left Sample MSB

Write

• bits 7-0 = 8-bit sample left DAC (\$80 on reset)

Register (R/W) \$2D (45) \Rightarrow DAC A+D Mirror (mono/ I²S Sample LSB Read

• bits $7-0 = I^2S$ Last Sample LSB

Write

• bits 7-0 = 8-bit sample DACs A + D (\$80 on reset)

Register (R/W) \$2E (46) \Rightarrow DAC C Mirror (Right/ $\rm I^2S$ Risht Sample MSB Read

• bits 7-0 = I²S Right Sameple MSB

Write

• bits 7-0 = 8-bit sample Right DACs C (\$80 on reset)

Register (R/W) \$2F (47) \Rightarrow Layer 3 (Tilemap) Horizontal Scroll Control MSB

- bits 7-2 =Reserved, must be 0
- bits 1-0 = X Offset MSB (\$00 on reset)

Meaningful Range is 0-319 in 40 char mode, 0-639 in 80 char mode

Register (R/W) \$30 (48) \Rightarrow Layer 3 (Tilemap) Horizontal Scroll Control LSB

• bits 7-0 = X Offset LSB (\$00 on reset)

Meaningful range is 0-319 in 40 char mode, 0-639 in 80 char mode

Register (R/W) \$31 (49) \Rightarrow Layer 3 (Tilemap) Vertical Scroll Control

• bits 7-0 = Y Offset (0-255) (\$00 on reset)

Register (R/W) \$32 (50) \Rightarrow Layer 1,0 (LoRes) Horizontal Scroll Control)

• bits 7-0 = X Offset (0-255) (\$00 on reset)

Layer 1,0 (LoRes) scrolls in "half-pixels" at the same resolution and smoothness as Layer 2.

Register (R/W) \$33 (51) \Rightarrow Layer 1,0 (LoRes) Vertical Scroll Control)

• bits 7-0 = Y Offset (0-191) (\$00 on reset)

Layer 1,0 (LoRes) scrolls in "half-pixels" at the same resolution and smoothness as Layer 2.

Register (R/W) $$34 (52) \Rightarrow$ Sprite Number Lockstep (NextReg \$09 bit 4 set)

- bit 7 = Pattern address offset (Add 128 to pattern address)
- bits 6-0 = Sprite number 0-127, Pattern number 0-63 effectively performs an out to port \$303B

No Lockstep (NextReg \$09 bit 4 clear)

- bit 7 =Reserved, must be 0
- bits 6-0 = Sprite number 0-127

This register selects which sprite has its attributes connected to the sprite attribute registers

Register (W) \$35 (53) \Rightarrow Sprite Attribute 0

• bits 7-0 = Sprite X coordinate LSB (MSB in NextReg \$37)

Register (W) \$36 (54) \Rightarrow Sprite Attribute 1

• bits 7-0 = Sprite Y coordinate LSB (MSB in NextReg \$39)

Register (W) \$37 (55) \Rightarrow Sprite Attribute 2

- bits 7-4 = 4-bit Palette offset
- bit 3 = Enable horizontal mirror (reverse)
- bit 2 = Enable vertical mirror (reverse)
- bit $1 = \text{Enable } 90^{O} \text{ Clockwise Rotation}$

Normal Sprites

• bit 0 = X coordinate MSB

Relative Sprites

• bit 0 = Palette offset is relative to anchor sprite

Rotation is applied before mirroring

Register (W) \$38 (56) \Rightarrow Sprite Attribute 3

- bit 7 = Enable Visiblity
- bit 6 = Enable Attribute 4 (0 = Attribute 4 effectively \$00)
- bits 5-0 = Sprite Pattern Number

Register (W) \$39 (57) \Rightarrow Sprite Attribute 4 Normal Sprites

- bit 7 = 4-bit pattern switch (0 = 8-bit sprite, 1 = 4-bit sprite)
- bit 6 = Pattern number bit-7 for 4-bit, 0 for 8-bit
- bit 5 = Type of attached relative sprites (0 = Composite, 1 = Unified)
- bits 4-3 = X scaling (00 = 1x, 01 = 2x, 10 = 4x, 11 = 8x)
- bits 2-1 = Y scaling (00 = 1x, 01 = 2x, 10 = 4x, 11 = 8x)
- bit 0 = MSB of Y coordinate

Relative, Composite Sprites

- bit 7-6 = 01
- bit 5 = Pattern number bit-7 for 4-bit, 0 for 8-bit
- bits 4-3 = X scaling (00 = 1x, 01 = 2x, 10 = 4x, 11 = 8x)
- bits 2-1 = Y scaling (00 = 1x, 01 = 2x, 10 = 4x, 11 = 8x)
- bit 0 = Pattern number is relative to anchor

Relative, Unified Sprites

• bit 7-6 = 01

- bit 5 = Pattern number bit-7 for 4-bit, 0 for 8-bit
- bits 4-1 = 0000
- bit 0 = Pattern number is relative to anchor

Register (R/W) \$40 (64) \Rightarrow Palette Index Select

• bits 7-0 = Palette Index Number

Selects the palette index to change the associated colour

For ULA only, INKs are mapped to indices 0 through 7, BRIGHT INKs to indices 8 through 15, PAPERs to indices 16 through 23 and BRIGHT PAPERs to indices 24 through 31. In EnhancedULA mode, INKs come from a subset of indices from 0 through 127 and PAPERs from a subset of indices from 128 through 255.

The number of active indices depends on the number of attribute bits assigned to INK and PAPER out of the attribute byte.

In ULAplus mode, the last 64 entries (indices 192 to 255) hold the ULAplus palette. The ULA always takes border colour from PAPER for standard ULA and Enhanced ULA

Register (R/W) \$41 (65) \Rightarrow 8-bit Palette Data

• bits 7-0 = Colour Entry in RRRGGGBB format

The lower blue bit of the 9-bit internal colour will be the logical or of bits 0 and 1 of the 8-bit entry. After each write, the palette index auto-increments if autincrement has been enabled (NextReg \$43 bit 7), Reads do not auto-increment.

Register (R/W) \$42 (66) \Rightarrow ULANext Attribute Byte Format

• bits 7-0 = Attribute byte's INK representation mask (7 on reset)

The mask can only indicate a solid sequence of bits on the right side of the attribute byte (1, 3, 7, 15, 31, 63, 127 or 255).

INKs are mapped to base index 0 in the palette and PAPERs and border are mapped to base index 128 in the palette.

The 255 value enables the full ink colour mode making all the palette entries INK. PAPER and border both take on the fallback colour (nextreg \$4A) in this mode.

Register (R/W) \$43 (67) \Rightarrow Palette Control

- bit 7 = Disable palette write auto-increment.
- bits 6-4 = Select palette for reading or writing:
 - -000 = ULA first palette
 - -100 = ULA second palette
 - -001 = Layer 2 first palette
 - -101 = Layer 2 second palette
 - -010 = Sprite first palette

- 110 = Sprite second palette
- -011 = Layer 3 first palette
- -111 = Layer 3 second palette
- bit 3 = Select Sprite palette (0 = first palette, 1 = second palette)
- bit 2 = Select Layer 2 palette (0 = first palette, 1 = second palette)
- bit 1 =Select ULA palette (0 =first palette, 1 =second palette)
- bit 0 = Enable EnhancedULA mode if 1. (0 after a reset)

Register (R/W) \$44 (68) \Rightarrow 9-bit Palette Data Non Level 2

1st write

- bits 7-0 = MSB (RRRGGGBB)2nd write
- bits 7-1 = Reserved, must be 0
- bit 0 = LSB (B)

Level 2

1st write

- bits 7-0 = MSB (RRRGGGBB)2nd write
- bit 7 = Priority
- bits 6-1 = Reserved, must be 0
- bit 0 = LSB(B)

9-bit Palette Data is entered in two consecutive writes; the second write autoincrements the palette index if auto-increment is enabled in NextREG \$43 bit 7

If writing an L2 palette, the second write's D7 holds the L2 priority bit which if set (1) brings the colour defined at that index on top of all other layers. If you also need the same colour in regular priority (for example: for environmental masking) you will have to set it up again, this time with no priority.

Reads return the second byte and do not autoincrement. Writes to nextreg \$40, \$41, \$41, or \$43 reset to the first write.

Register (R/W) 4A (74) \Rightarrow Fallback Colour Value

• bits 7-0 = 8-bit colour if all layers are transparent (\$E3 on reset)

(black on reset = 0)

Register (R/W) \$4B (75) \Rightarrow Sprite Transparency Index

• bits 7-0 = Index value (\$E3 if reset)

For 4-bit sprites only the bottom 4-bits are relevant.

Register (R/W) \$4C (76) \Rightarrow Level 3 Transparency Index

• bits 7-4 = Reserved, must be 0

• bits 3-0 = Index value (\$0F on reset)

Register (R/W) \$50 (80) \Rightarrow MMU Slot 0 Control

• bits 7-0 = 8k RAM page at position \$0000 to \$1FFF (\$ff on reset)

Pages can be from 0 to 223 on a fully expanded Next.

A 255 value causes the ROM to become visible.

Register (R/W) \$51 (81) \Rightarrow MMU Slot 1 Control

• bits 7-0 = 8k RAM page at position \$2000 to \$3FFF (\$ff on reset)

Pages can be from 0 to 223 on a fully expanded Next.

A 255 value causes the ROM to become visible.

Register (R/W) \$52 (82) \Rightarrow MMU Slot 2 Control

• bits 7-0 = 8k RAM page at position \$4000 to \$5FFF (\$0A on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Register (R/W) \$53 (83) \Rightarrow MMU Slot 3 Control

• bits 7-0 = 8k RAM page at position \$6000 to \$7FFF (\$0B on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Register (R/W) \$54 (84) \Rightarrow MMU Slot 4 Control

• bits 7-0 = 8k RAM page at position \$8000 to \$9FFF (\$04 on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Register (R/W) \$55 (85) \Rightarrow MMU Slot 5 Control

• bits 7-0 = 8k RAM page at position \$A000 to \$BFFF (\$05 on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Register (R/W) \$56 (86) \Rightarrow MMU Slot 6 Control

• bits 7-0 = 8k RAM page at position \$C000 to \$DFFF (\$00 on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Register (R/W) \$57 (87) \Rightarrow MMU Slot 7 Control

• bits 7-0 = 8k RAM page at position \$E000 to \$FFFF (\$01 on reset)

Pages can be from 0 to 223 on a fully expanded Next.

Writing to ports \$1FFD, \$7FFD and \$DFFD writes \$FF to MMU0 and MMU1 and writes appropriate values to MMU6 and MMU7 to map in the selected 16k bank.

+3 special modes override the MMUs if used.

Register (W) \$60 (96) \Rightarrow Copper Data 8-bit Write

• bits 7-0 = Byte to write to copper instruction memory

Note that each copper instruction is two bytes long, after a write, the coppen address is auto-incremented to the next memory position.

After a write, the index is auto-incremented to the next memory position.

Register (W) $$61 (97) \Rightarrow \text{Copper Address LSB}$

• bits 7-0 = Copper instruction memory address LSB (0 on reset)

Register (W) $$62 (98) \Rightarrow \text{Copper Control}$

- bits 7-6 = Start Control
 - 00 =Copper fully stopped
 - 01 = Copper start, execute the list from index 0, and loop to the start
 - 10 =Copper start, execute the list from last point, and loop to the start
 - 11 =Copper start, execute the list from index 0, and restart the list when the raster reaches position (0,0)
- bits 2-0 = Copper instruction memory address (MSB) (0 on reset)

Register (W) $$63 (99) \Rightarrow \text{Copper Data 16-bit Write}$

• bits 7-0 = Byte to write to copper instruction memory

The 16-bit value is written in pairs. The first 8-bits are the MSB and are destined for an even copper instruction address. The sesond 8-bits are the LSB and are destined for an odd copper instruction address.

After each write, the copper address is auto-incremented to the next memory position.

After a write to an odd address, the all 16-bits are written to copper memory at once.

Register (R/W) \$64 (100) \Rightarrow Vertical Line Count Offset (3.01.05)

- bits 7-0 = Offset added to the vertical line counter affects copper, line interrupt and active line count.

 Normally the ula's pixel row 0 aligns with vertical line count 0. With a non-zero offset, the ula's pixel row 0 will align with the vertical line offset. Eg, if the offset is 32 then vertical line 32 will correspond to the first pixel row in the ula and vertical line 0 will align with the first pixel row of the tilemap and sprites.
- * Since a change in offset takes effect when the ula reaches row 0, the change can take up to one frame to occur.

Register (R/W) $$68 (104) \Rightarrow ULA Control$

- bit 7 = Disable ULA output (0 on reset)
- bit 6-5 = Color blending control for layering modes 6 & 7 (3.01.01)

- -00 = ULA as blend colour
- -01 = No blending
- -10 = ULA/Tilemap mix result as blend colour
- -11 = Tilemap as blend colour
- bit 4 = Cancel entries in 8x5 matrix for extended keys (3.01.04)
- bit 3 = Enable ULAplus (0 on reset)
- bit 2 = Enable ULA half pixel scroll (0 on reset) may change
- bit 1 = Reserved (must be 0)
- bit 0 = Enable stencil mode (0 on reset)

When ULA and Layer 3 are enabled, if either are transparent, the result is transparent, otherwise the result is the logical AND of both colours.

Register (R/W) \$69 (105) \Rightarrow Display Control 1

- bit 7 = Layer 2 Enable (Port \$123B bit 1 alias)
- bit 6 = ULA Shadow display enable (Port \$7FFD bit 3 alias)
- bits 5-0 = Timex alias (Port \$FF alias)

Register (R/W) 6A (106) \Rightarrow Layer 1,0 (LoRes) Control

- bits 7-6 = reserved, must be 0
- bit 5 = Enable Radistan (16-colour) (0 on reset)
- bit 4 = Radistan DFILE switch (xor with bit 0 of port \$ff) (0 on reset)
- bits 3-0 = Radistsan palette offset (0 on reset)
- bits 1-0 = ULAplus palette offset (0 on reset)

Register (R/W) 6B (107) \Rightarrow Layer 3 (Tilemap) Control

- bit 7 = Layer 3 Enable (0 on reset)
- bit 6 = Layer 3 Size control (0 on reset)
 - -0 = 40x32
 - -1 = 80x32
- bit 5 = Disable Arrtibute Entry (0 on reset)
- bit 4 = palette select (0 on reset)
- bit 3 = Enable Text mode (1-bit tilemap) (0 on reset)
- bit 2 = Reserved, must be 0
- bit 1 = Activate 512 tile mode (0 on reset)
- bit 0 = Enable Layer 3 on top of ULA (0 on reset)

Register (R/W) 6C (108) \Rightarrow Default Layer 3 Attribute*

- bits 7-4 = Palette Offset (\$00 on reset)
- bit 3 = X mirror (0 on reset)
- bit 2 = Y mirror (0 on reset)
- bit 1 = Rotate (0 on reset)
- bit 0 = Bit 8 of the tile number (512 tile mode) (0 on reset)
- bit 0 = ULA over tilemap (256 tile mode) (0 on reset)

^{*}Active tile attribute if bit 5 of nextreg \$6B is set.

Register (R/W) 6E (110) \Rightarrow Layer 3 Tilemap Base Address

- bit 7 = Bank Select (3.01.08) 0 = Bank 51 = Bank 7
- bit 6 = Reserved, must be 0
- bits 5-0 = MSB of address of the tilemap in Bank 5 (16k) or 7 (8k) (\$2C on reset)

Soft Reset default \$2C - This is because the address is \$6C00 so the MSB is \$6C. But the stored value is only the lower 6 bits so it's an offset into the 16k Bank 5. To calculate therefore subtract \$40 leaving you with \$2C.

The value written is an offset into the 16k Bank 5 or the 8k lower half of Bank 7 allowinf the tilemap to be placed at any multiple of 256 bytes. Register (R/W) $$6F\ (111) \Rightarrow Layer\ 3$ Tile Definitions Base Address

- bit 7 =Select bank (3.01.08) 0 =Bank 51 =Bank 7
- bit 6 = Reserved, must be 0
- bits 5-0 = MSB of address of the tile definitions in Bank 5 (16k) or 7 (8k) (\$0C on reset)

Soft Reset default \$0C - This is because the address is \$4C00 so the MSB is \$4C. But the stored value is only the lower 6 bits so it's an offset into the 16k Bank 5. To calculate therefore subtract \$40 leaving you with \$0C.

The value written is an offset into the 16k Bank 5 or the 8k lower half of Bank 7 allowing the tilemap to be placed at any multiple of 256 bytes. Register (R/W) \$70 (112) \Rightarrow Layer 2 Control

- bits 7-6 = Reserved, must be 0
- bits 5-4 = Resolution (00 on soft reset)
 - $-00 = 256 \times 192 \times 256$
 - $-01 = 320 \times 256 \times 256$
 - $-10 = 640 \times 256 \times 16$
 - -11 = Do not use
- bits 3-0 = Palette offset (\$0 on soft reset)

Register (R/W) \$71 (113) \Rightarrow Layer 2 X Scroll MSB

- bits 7-1 = Reserved, must be 0
- bits 0 = MSB of X Offset

Register (W) \$75 (117) \Rightarrow Sprite Attribute 0 (Auto-incrementing) See nextreg \$35

Register (W) \$76 (118) \Rightarrow Sprite Attribute 1 (Auto-incrementing) See nextreg \$36

Register (W) \$77 (119) \Rightarrow Sprite Attribute 2 (Auto-incrementing)

See nextreg \$37

Register (W) \$78 (120) \Rightarrow Sprite Attribute 3 (Auto-incrementing) See nextreg \$38

Register (W) \$79 (121) \Rightarrow Sprite Attribute 4 (Auto-incrementing) See nextreg \$39

Register (R/W) \$7F (127) \Rightarrow User Register 0

• bits 7-0 = User Register (\$FF on hard reset)

Caution NextReg numbers above \$7F are inaccessible to the Copper

Register (R/W) \$80 (128) \Rightarrow Expansion Bus Enable Immediate

- bit 7 = Expansion Bus Enable (0 on hard reset)(3.01.07)
- bit 6 = Enable ROMCS ROM replacement from divmmc banks 14/15 (experimental, 3.01.03)
- bit 5 = I/O cycle Disable/Ignore $\overline{IORQULA}$ (0 on hard reset)
- bit $4 = \text{Memory cycle Disable/Ignore } \overline{\text{ROMCS}}$ (0 on hard reset)

After Soft Reset (Copied into bits 7-4)

- bit 3 = Expansion Bus Enable (0 on hard reset)
- bit 2 = Enable ROMCS ROM replacement from divmmc banks 14/15 (experimental, 3.01.03)
- bit 1 = I/O cycle Disable/Ignore $\overline{IORQULA}$ (0 on hard reset)
- bit $0 = \text{Memory cycle Disable/Ignore } \overline{\text{ROMCS}}$ (0 on hard reset)

Register (R/W) \$81 (129) \Rightarrow Expansion Bus Control

- bit 7 = (R) Expansion bus \overline{ROMCS} asserted
- bit 6 = Allow peripherials to override the ULA on some even port reads (\$00-\$0E)(Rotoronics Wafadrive)(3.01.07)
- bit 5 = Disable expansion bus NMI debounce (Opus Discovery)(3.01.07)
- bit 4 = (W) Propagate max CPU clock at all times (0 on hard reset)
- bits 3-2 = Reserved, must be 0
- bits 1-0 = Max CPU Speed when Expansion Bus is enabled (\$00 on hard reset, currently fixed at \$00)
 - -00 = 3.5 MHz
 - -01 = 7 MHz
 - -10 = 14 MHz
 - -11 = 28 MHz

Register (R/W) \$82 (130) \Rightarrow Internal Port decoding control 1/4

- bit 7 = Enable Kempston Port 2 (Port \$37) (1 on reset)
- bit 6 = Enable Kempston Port 1 (Port \$1F) (1 on reset)
- bit 5 = Enable DMA (Port \$6B) (1 on reset)
- bit 4 = Enable + 3 Floating Bus (1 on reset)

- bit 3 = Enable +3 Paging (Port \$1FFD) (1 on reset)
- bit 2 = Enable Next Memory Paging (Port \$DFFD) (1 on reset)
- bit 1 = Enable Paging (Port \$7FFD) (1 on reset)
- bit 0 = Enable Timex (Port \$FF) (1 on reset)

Register (R/W) \$83 (131) \Rightarrow Internal Port decoding control 2/4

- bit 7 = Enable Layer 2 (Port \$123B) (1 on reset)
- bit 6 = Enable Sprites (Ports \$57, \$5B, \$303B) (1 on reset)
- \bullet bit 5 = Enable Kempston Mouse (Ports \$FADF, \$FBDF, \$FFDF) (1 on reset)
- bit 4 = Enable UART (Ports \$133B, \$143B, \$153B) (1 on reset)
- bit 3 = Enable SPI (Ports \$E7, \$EB) (1 on reset)
- bit $2 = \text{Enable I}^2\text{C (Ports $103B, $113B) (1 on reset)}$
- bit 1 = Enable Multiface (two variable ports) (1 on reset)
- bit 0 = Enable divMMC (Port \$E3) (1 on reset)

Register (R/W) \$84 (132) \Rightarrow Internal Port decoding control 3/4

- bit 7 = Enable SPECdrum Mono DAC (Port \$DF) (1 on reset)
- bit 6 = Enable Covox/GS Mono DAC (Port \$B3) (1 on reset)
- bit 5 = Enable Pentagon/ATM DAC (Port \$FB) (1 on reset)
- bit 4 = Enable Covox Stereo DAC (Ports \$0F, \$4F) (1 on reset)
- bit 3 = Enable Profi/Covox Stereo DAC (Ports \$3F, \$5F) (1 on reset)
- bit 2 = Enable Soundrive DAC Mode 2 (Ports \$F1, \$F3, \$F9, \$FB) (1 on reset)
- bit 1 = Enable Soundrive DAC Mode 1 (Ports \$0F, \$1F, \$4F, \$5F) (1 on reset)
- bit 0 = Enable AY (Ports \$FFFD, \$BFFD) (1 on reset)

Register (R/W) \$85 (133) \Rightarrow Internal Port decoding control 4/4

- bit 7 = Enable configuration of port decoding on soft reset (3.01.01)
- bits 6-4 = Reserved
- bit 3 = Enable Z80 CTC ports \$183B, \$193B, \$1A3B, \$1B3B, \$1C3B, \$1D3B, \$1E3B, and \$1F3B
- bit 2 = Enable Pentagon 1024 memory port \$EFF7
- bit 1 = Enable DMA port \$0B (3.01.02)
- bit 0 = Enable ULAplus (Ports \$BF3B, \$FF3B) (1 on reset)

Register (R/W) \$86 (134) \Rightarrow Expansion Port decoding control 1/4

- bit 7 = Enable Kempston Port 2 (Port \$37) (1 on reset)
- bit 6 = Enable Kempston Port 1 (Port \$1F) (1 on reset)
- bit 5 = Enable DMA (Port \$6B) (1 on reset)
- bit 4 = Enable + 3 Floating Bus (1 on reset)
- bit 3 = Enable + 3 Paging (Port \$1FFD) (1 on reset)
- bit 2 = Enable Next Memory Paging (Port \$DFFD) (1 on reset)
- bit 1 = Enable Paging (Port \$7FFD) (1 on reset)
- bit 0 = Enable Timex (Port \$FF) (1 on reset)

Register (R/W) \$87 (135) \Rightarrow Expansion Port decoding control 2/4

- bit 7 = Enable Layer 2 (Port \$123B) (1 on reset)
- bit 6 = Enable Sprites (Ports \$57, \$5B, \$303B) (1 on reset)
- bit 5 = Enable Kempston Mouse (Ports \$FADF, \$FBDF, \$FFDF) (1 on reset)
- bit 4 = Enable UART (Ports \$133B, \$143B, \$153B) (1 on reset)
- bit 3 = Enable SPI (Ports \$E7, \$EB) (1 on reset)
- bit $2 = \text{Enable I}^2\text{C (Ports $103B, $113B) (1 on reset)}$
- bit 1 = Enable Multiface (two variable ports) (1 on reset)
- bit 0 = Enable divMMC (Port \$E3) (1 on reset)

Register (R/W) \$88 (136) \Rightarrow Expansion Port decoding control 3/4

- bit 7 = Enable SPECdrum Mono DAC (Port \$DF) (1 on reset)
- bit 6 = Enable Covox/GS Mono DAC (Port \$B3) (1 on reset)
- bit 5 = Enable Pentagon/ATM DAC (Port \$FB) (1 on reset)
- bit 4 = Enable Covox Stereo DAC (Ports \$0F, \$4F) (1 on reset)
- bit 3 = Enable Profi/Covox Stereo DAC (Ports \$3F, \$5F) (1 on reset)
- bit 2 = Enable Soundrive DAC Mode 2 (Ports \$F1, \$F3, \$F9, \$FB) (1 on reset)
- bit 1 = Enable Soundrive DAC Mode 1 (Ports \$0F, \$1F, \$4F, \$5F) (1 on reset)
- bit 0 = Enable AY (Ports \$FFFD, \$BFFD) (1 on reset)

Register (R/W) \$89 (137) \Rightarrow Expansion Port decoding control 4/4

- bit 7 = Enable configuration of port decoding on soft reset (3.01.01)
- bits 6-4 = Reserved
- bit 3 = Enable Z80 CTC ports \$183B, \$193B, \$1A3B, \$1B3B, \$1C3B, \$1D3B, \$1E3B, and \$1F3B
- bit 2 = Enable Pentagon 1024 memory port \$EFF7
- bit 1 = Enable DMA port \$0B (3.01.02)
- bit 0 = Enable ULAplus (Ports \$BF3B, \$FF3B) (1 on reset)

The Internal Port Decoding Enables always apply.

When the Expansion Bus is enabled, the Expansion Bus Port Decoding Enables are logically ANDed with the Internal Enables. A result of 0 for the corresponding bit indicates the internal device is *disabled*. If the Expansion Bus is enabled, this allows I/O cycles for disabled ports to propagate to the Expansion Bus, otherwise corresponding I/O cycles to the Expansion Bus are filtered.

Register (R/W) A (138) \Rightarrow Expansion Bus I/O Propagate Control

- bits 7-3 = Reserved, must be 0
- bit 4 = Propagate port \$FF I/O Cycles (0 on hard reset, 3.01.02)
- bit 3 = Propagate port \$1FFD I/O Cycles (0 on hard reset)
- bit 2 = Propagate port \$DFFD I/O Cycles (0 on hard reset)
- bit 1 = Propagate port \$7FFD I/O Cycles (0 on hard reset)

• bit 0 = Propagate port \$FE I/O Cycles (1 on hard reset, 3.01.03: 0 on hard reset)

Register (R/W) 8C (140) \Rightarrow Alternate ROM Immediate

- bit 7 = Alt ROM Enable (0 on hard reset)
- bit 6 = Alt ROM visible ONLY during writes (0 on hard reset)
- bit 5 = Reserved, must be 0
- bit 4 = 48k ROM Lock (0 on hard reset)

After Soft Reset (copied into bits 7-4)

- bit 3 = Alt ROM Enable (0 on hard reset)
- bit 2 = Alt ROM visible ONLY during writes (0 on hard reset)
- bit 1 = Reserved, must be 0
- bit 0 = 48k ROM Lock (0 on hard reset)

Register (R/W) \$8E (142) \Rightarrow Spectrum 128k Memory Mapping (3.01.01)

- bit 7 = Bank number bit 3 (port \$dffd bit 0)
- bit 6-4 = Bank number bits 2-0 (port \$7ffd bits 2-0)
- bit 3 = Enable change ram page (read as 1)
- bit 2 = Paging mode (port \$1ffd bit 0)
 - -0 = Normal paging mode
 - -1 =Special paging mode (lot bit of memory configuration)

Normal Paging Mode

- bits 1-0 = ROM selection (port \$1ffd bit 1 and \$7ffd bit 4) Special (all RAM) Paging Mode
- bits 1-0 = RAM configuration selection (port \$1ffd bits 2-1)

Writes can affect all ports \$7ffd, \$dffd, and \$1ffd

Writes can always change the ROM/allRAM mapping

Writes immediately change the current MMU mapping as if by port write.

Register (R/W) \$8F (143) \Rightarrow Memory Mapping Mode (3.01.06)

- bits 7-2 = Reserved, must be zero
- bits 1-0 = Mapping mode applied
 - -00 = Standard ZX 128k +3
 - -01 = Profi (removed in 3.01.09)
 - -10 = Pentagon 512k
 - 11 = Pentagon 1024k (limited to 768k on 1MB machines)
- * Standard ZX 128k +3 = principally ports \$7FFD, \$DFFD, and \$1FFD

Pentagon 512k = principally port \$7FFD

Pentagon 1024k = principally ports \$7FFD and \$EFF7

* The mapping modes affect how ports \$7FFD, \$DFFD, \$1FFD, and \$EFF7 carry out memory paging, see ports

Register (R/W) \$90 (144) \Rightarrow Pi GPIO output enable 1/4

- bit 7 = Enable Pin 7 (0 on reset)
- bit 6 = Enable Pin 6 (0 on reset)
- bit 5 = Enable Pin 5 (0 on reset)
- bit 4 = Enable Pin 4 (0 on reset)
- bit 3 = Enable Pin 3 (0 on reset)
- bit 2 = Enable Pin 2 (0 on reset)
- bit 1 = Enable Pin 1 (cannot be enabled) (0 on reset)
- bit 0 = Enable Pin 0 (cannot be enabled) (0 on reset)

Register (R/W) \$91 (145) \Rightarrow Pi GPIO output enable 2/4

- bit 7 = Enable Pin 15 (0 on reset)
- bit $6 = \text{Enable Pin } 14 \ (0 \text{ on reset})$
- bit $5 = \text{Enable Pin } 13 \ (0 \text{ on reset})$
- bit $4 = \text{Enable Pin } 12 \ (0 \text{ on reset})$
- bit 3 = Enable Pin 11 (0 on reset)
- bit $2 = \text{Enable Pin } 10 \ (0 \text{ on reset})$
- bit 1 = Enable Pin 9 (0 on reset)
- bit $0 = \text{Enable Pin } 8 \ (0 \text{ on reset})$

Register (R/W) \$92 (146) \Rightarrow Pi GPIO output enable 3/4

- bit 7 = Enable Pin 23 (0 on reset)
- bit 6 = Enable Pin 22 (0 on reset)
- bit 5 = Enable Pin 21 (0 on reset)
- bit $4 = \text{Enable Pin } 20 \ (0 \text{ on reset})$
- bit 3 = Enable Pin 19 (0 on reset)
- bit 2 = Enable Pin 18 (0 on reset)
- bit 1 = Enable Pin 17 (0 on reset)
- bit $0 = \text{Enable Pin } 16 \ (0 \text{ on reset})$

Register (R/W) \$93 (147) \Rightarrow Pi GPIO output enable 4/4

- bits 7-4 = Reserved
- bit 3 = Enable Pin 27 (0 on reset)
- bit $2 = \text{Enable Pin } 26 \ (0 \text{ on reset})$
- bit $1 = \text{Enable Pin } 25 \ (0 \text{ on reset})$
- bit $0 = \text{Enable Pin } 24 \ (0 \text{ on reset})$

Register (R/W) \$98 (152) \Rightarrow Pi GPIO Pin State 1/4

- bit 7 = Pin 7 Data (1 on reset)
- bit 6 = Pin 6 Data (1 on reset)
- bit 5 = Pin 5 Data (1 on reset)
- bit $4 = Pin \ 4 Data \ (1 \text{ on reset})$
- bit 3 = Pin 3 Data (1 on reset)
- bit $2 = Pin \ 2 Data \ (1 \text{ on reset})$
- bit 1 = Pin 1 Data (1 on reset)
 bit 0 = Pin 0 Data (1 on reset)

Register (R/W) \$99 (153) \Rightarrow Pi GPIO Pin State 2/4

- bit 7 = Pin 15 Data (1 on reset)
- bit 6 = Pin 14 Data (1 on reset)
- bit 5 = Pin 13 Data (1 on reset)
- bit 4 = Pin 12 Data (1 on reset)
- bit 3 = Pin 11 Data (1 on reset)
- bit 2 = Pin 10 Data (1 on reset)
- bit 1 = Pin 9 Data (1 on reset)
- bit $0 = Pin \ 8 Data \ (1 on reset)$

Register (R/W) \$9A (154) \Rightarrow Pi GPIO Pin State 3/4

- bit 7 = Pin 23 Data (1 on reset)
- bit 6 = Pin 22 Data (1 on reset)
- bit 5 = Pin 21 Data (1 on reset)
- bit 4 = Pin 20 Data (1 on reset)
- bit 3 = Pin 19 Data (1 on reset)
- bit 2 = Pin 18 Data (1 on reset)
- bit 1 = Pin 17 Data (1 on reset)
- bit 0 = Pin 16 Data (1 on reset)

Register (R/W) \$9B (155) \Rightarrow Pi GPIO Pin State 4/4

- bits 7-4 = Reserved
- bit 3 = Pin 27 Data (1 on reset)
- bit 2 = Pin 26 Data (1 on reset)
- bit 1 = Pin 25 Data (1 on reset)
- bit 0 = Pin 24 Data (1 on reset)

Register (R/W) A0 (160) \Rightarrow Pi Peripheral Enable

- bits 7-6 = Reserved, must be 0
- bit $5 = \text{Enable UART on GPIO } 14, 15 (0 \text{ on reset})^*$
- bit 4 = Communication Type (0 on reset)
 - -0 = Rx to GPIO 15, Tx to GPIO 14 (Pi)
 - -1 = Rx to GPIO 14, Tx to GPIO 15 (Pi Hats)
- bit $3 = \text{Enable I}^2\text{C on GPIO } 2, 3 (0 \text{ on reset})^*$
- bits 2-1 = Reserved, must be 0
- bit $0 = \text{Enable SPI on GPIO } 7, 8, 9, 10, 11 (0 \text{ on reset})^*$

Register (R/W) \$A2 (162) \Rightarrow Pi I²S Audio Control

- bits $7-6 = I^2S$ State (\$00 on reset)
 - $-00 = I^2S$ Disabled
 - $-01 = I^2S$ is mono, source R
 - $-10 = I^2S$ is mono, source L
 - $-11 = I^2S$ is stereo
- bit 5 = Reserved, must be 0

^{*}Overrides GPIO Enables

- bit 4 = Audio Flow Direction (0 on reset)
 - -0 = PCM DOUT to Pi, PCM DIN from Pi (Hats)
 - -1 = PCM DOUT from Pi, PCM DIN to Pi (Pi)
- bit 3 = Mute left (0 on reset)
- bit 2 = Mute right (0 on reset)
- bit 1 = Slave mode, Reserved must be 1 (remove in 3.01.05)
- bit $0 = \text{Direct I}^2S$ audio to EAR on port \$FE (0 on reset)

Register (R/W) \$A3 (163) \Rightarrow Pi $\ I^2S$ Clock Divide (Master Mode) (removed in 3.01.05)

• bits 7-0 = Clock divide value (\$0B on reset)

$$Divider = \frac{538461}{Rate} - 1 \text{ or } Rate = \frac{538461}{Divider + 1}$$

Register (R/W) \$A8 (168) \Rightarrow ESP WiFi GPIO Output Enable

- bits 7-3 = Reserved, must be sero
- bit 2 = GPIO2 output enable (fixed at 0, GPIO2 is read-only)
- bit 1 = Reserved, must be zero
- bit 0 = GPIO0 output enable (fixed at 0, GPIO2 is read-only)

Register (R/W) $A9 (169) \Rightarrow ESP WiFi GPIO$

- bits 7-3 = Reserved, must be sero
- bit 2 = Read/Write GPIO2 (reset = 1)
- bit 1 = Reserved, must be zero
- bit 0 = Read/Write GPIO0 (reset = 1)

Register (R) \$B0 (176) \Rightarrow Extended Keys 0 (3.01.04)

- bit 7 = 1 if; pressed
- bit 6 = 1 if \ddot{p} ressed
- bit 5 = 1 if, pressed
- bit 4 = 1 if pressed
- bit 3 = 1 if UP pressed
- bit 2 = 1 if DOWN pressed
- bit 1 = 1 if LEFT pressed
- bit 0 = 1 if RIGHT pressed

Register (R) \$B1 (177) \Rightarrow Extended Keys 1 (3.01.04)

- bit 7 = 1 if DELETE pressed
- bit 6 = 1 if EDIT pressed
- bit 5 = 1 if BREAK pressed
- bit 4 = 1 if INV VIDEO pressed
- bit 3 = 1 if TRUE VIDEO pressed
- bit 2 = 1 if GRAPH pressed
- bit 1 = 1 if CAPS LOCK pressed
- bit 0 = 1 if EXTEND pressed

Register (R) \$B2 (178) \Rightarrow Extended MD Pad Buttons (3.01.10)

```
• bit 7 = 1 if Right Pad X Pressed
```

- bit 6 = 1 if Right Pad Z Pressed
- bit 5 = 1 if Right Pad Y Pressed
- bit 4 = 1 if Right Pad START Pressed
- bit 3 = 1 if Left Pad X Pressed
- bit 2 = 1 if Left Pad Z Pressed
- bit 1 = 1 if Left Pad Y Pressed
- bit 0 = 1 if Left Pad START Pressed

Register (R/W) \$C0 (192) \Rightarrow Interrupt Control (3.01.09) (\$00 on reset)

- bits 7-5 = Programmable portion of IM2 vector *
- bit 4 =Reserved, must be 0
- bit $3 = \text{Enable stackless } \overline{\text{NMI}} \text{ response**}$
- bits 2-1 = Reserved, must be 0
- bit 0 = Maskable interrupt mode
 - 0 pulse
 - 1 IM2
- * In IM2 mode vector generated is:
 - bits 7-5 = nextreg \$C0 bits 7-5
 - bits 4-1 = Interrupt source
 - 0 line interrupt (highest priority)
 - 1 UART 0 Rx
 - 2 UART 1 $\rm Rx$
 - 3-10 CTC channels 0-7
 - 11 ULA
 - 12 UART 0 Tx
 - 13 UART 1 Tx (lowest priority)
 - bit 0 = 0
- * In IM2 mode the expansion bus is the lowest priority interrupter and if no vector is supplied externally the \$FF is generated.
- ** The return address pushed during an nmi acknowledge cycle will be written to the appropriate nextreg instead of memory (the stack pointer will be decremented) and the RETN after acknowledge will take its return address from nextreg instead of memory (the stack pointer will be incremented). If bit 3=0 and in other circumstances, RETN functions normally.

Register (R/W) \$C2 (194) \Rightarrow NMI Return Address LSB (3.01.09) (\$00 on reset)

Register (R/W) \$C3 (195) $\Rightarrow \overline{\text{NMI}}$ Return Address MSB (3.01.09) (\$00 on reset)

Register (R/W) C4 (196) \Rightarrow Interrupt Enable 0 (3.01.08)

(\$81 on reset)

- bit $7 = \text{Expansion bus } \overline{\text{INT}}$
- bits 6-2 = Reserved must be zero
- bit 1 = Line
- bit 0 = ULA

Register (R/W) \$C5 (197) \Rightarrow Interrupt Enable 1 (3.01.08) (\$00 on reset)

- bit 7 = ctc channel 7 zc/to
- bit 6 = ctc channel 6 zc/to
- bit 5 = ctc channel 5 zc/to
- bit 4 = ctc channel 4 zc/to
- \bullet bit 3 = ctc channel 3 zc/to
- ullet bit 2 = ctc channel 2 zc/to
- bit 1 = ctc channel 1 zc/to
- bit 0 = ctc channel 0 zc/to

Register (W) \$C6 (198) \Rightarrow Interrupt Enable 2 (3.01.08) (\$00 on reset)

- bit 7 =Reserved, must be 0
- bit 6 = UART1 Tx empty
- bit 5 = UART1 Rx half full *
- bit 4 = UART1 Rx available *
- bit 3 = Reserved, must be 0
- bit 2 = UART0 Tx empty
- bit 1 = UART0 Rx half full *
- bit 0 = UART0 Rx available *

Register (W) $C7 (199) \Rightarrow Reserved (3.01.09)$

Register (R/W) \$C8 (200) \Rightarrow Interrupt Status 0 (3.01.09) (\$00 on reset)

- bits 7-2 = Reserved, must be zero
- bit 1 = Line
- bit 0 = ULA

Register (R/W) $C9 (201) \Rightarrow Interrupt Status 1 (3.01.09)$

- bit 7 = ctc channel 7 zc/to
- bit 6 = ctc channel 6 zc/to
- bit 5 = ctc channel 5 zc/to
- bit 4 = ctc channel 4 zc/to
- bit 3 = ctc channel 3 zc/to

^{*} For each UART, Rx half full and Rx available are shared interrupts

^{*} Set bits indicate the device generated an interrupt in the past * Writes clear bits where bits are set except in IM2 mode

- bit 2 = ctc channel 2 zc/to
- bit 1 = ctc channel 1 zc/to
- bit 0 = ctc channel 0 zc/to
- * Set bits indicate the device generated an interrupt in the past * Writes clear bits where bits are set except in IM2 mode

Register (R/W) CA (202) \Rightarrow Interrupt Status 2 (3.01.09) (\$00 on reset)

- bit 7 = Reserved, must be zero
- bit 6 = UART1 Tx empty
- bit 5 = UART1 Rx almost full *
- bit 4 = UART1 Rx available *
- bit 3 = Reserved must be zero
- bit 2 = UART0 Tx empty
- bit 1 = UART0 Rx almost full *
- bit 0 = UART0 Rx available *
- * For each UART Rx half full and Rx available are shared interrupts ** Set bits indicate the device generated an interrupt in the past ** Writes clear bits where bits are set except in IM2 mode

Register (W) \$CB (203) \Rightarrow Reserved (3.01.09)

Register (R/W) $CC(204) \Rightarrow DMA$ Interrupt Enable 0 (3.01.09) (\$00 on reset)

- bits 7-2 = Reserved, must be 0
- bit 1 = Line
- bit 0 = ULA
- * Set bits indicate the specified interrupt will interrupt a DMA operation when in IM2 mode

Register (R/W) $CD (205) \Rightarrow DMA$ Interrupt Enable 1 (3.01.09) (\$00 on reset)

- bit 7 = CTC channel 7 zc/to
- bit 6 = CTC channel 6 zc/to
- bit 5 = CTC channel 5 zc/to
- bit 4 = CTC channel 4 zc/to
- bit 3 = CTC channel 3 zc/to
- bit 2 = CTC channel 2 zc/to
- $\bullet \ \, \mbox{bit} \ 1 = \mbox{CTC channel} \ 1 \ \mbox{zc/to}$
- bit 0 = CTC channel 0 zc/to
- * Set bits indicate the corresponding interrupt will interrupt a DMA operation when in IM2 mode

Register (R/W) $CE (206) \Rightarrow DMA$ Interrupt Enable 2 (3.01.09) (\$00 on reset)

- bit 7 =Reserved, must be 0
- bit 6 = UART1 Tx empty
- bit 5 = UART1 Rx half full

- bit 4 = UART1 Rx available
- bit 3 = Reserved, must be 0
- bit 2 = UART0 Tx empty
- bit 1 = UART0 Tx half full
- bit 0 = UART0 Tx available

* Set bits indicate the corresponding interrupt will interrupt a DMA operation when in IM2 mode.

Register (W) $CF(207) \Rightarrow Reserved(3.01.09)$

Register (R/W) \$B8 (184) \Rightarrow Divmmc Entry Points 0 (3.01.10) (\$83 on reset)

- bit 7 = enable automap on address \$0038 (instruction fetch)
- bit 6 = enable automap on address \$0030 (instruction fetch)
- bit 5 = enable automap on address \$0028 (instruction fetch)
- bit 4 = enable automap on address \$0020 (instruction fetch)
- bit 3 = enable automap on address \$0018 (instruction fetch)
- bit 2 = enable automap on address \$0010 (instruction fetch)
- bit 1 = enable automap on address \$0008 (instruction fetch)
- bit 0 = enable automap on address \$0000 (instruction fetch)

Register (R/W) \$B9 (185) \Rightarrow Divmmc Entry Points Valid 0 (3.01.10) (\$01 on reset)

- bit 7 = address \$0038
- bit 6 = address \$0030
- bit 5 = address \$0028
- bit 4 = address \$0020
- bit 3 = address \$0018
- bit 2 = address \$0010
- bit 1 = address \$0008
 bit 0 = address \$0000
 - 0 = Only when ROM3 is present
 - 1 = Always

Register (R/W) \$B9 (185) \Rightarrow Divmmc Entry Points Timing 0 (3.01.10) (\$00 on reset)

- bit 7 = address \$0038
- bit 6 = address \$0030
- bit 5 = address \$0028
- bit 4 = address \$0020
- bit 3 = address \$0018
- bit 2 = address \$0010
- bit 1 = address \$0008
- bit 0 = address \$0000
 - 0 =Delayed mapping
 - 1 = Instant mapping

B.2. AY-3-8912 233

Register (R/W) \$B8 (184) \Rightarrow Divmmc Entry Points 1 (3.01.10) (\$CD on reset)

- bit 7 = enable automap on address \$3Dxx (instant, ROM3, TRDOS)
- bit 6 = enable automap on address \$1FF8-1FFF (delayed)
- bit 5 = enable automap on address \$056A (delayed, ROM3, tape traps, nextzxos)
- bit 4 = enable automap on address \$04D7 (delayed, ROM3, tape traps, nextzxos)
- bit 3 = enable automap on address \$0562 (delayed, ROM3, tape traps, esxdos, divmmc)
- bit 2 = enable automap on address \$04C6 (delayed, ROM3, tape traps, esxdos, divmmc)
- bit 1 = enable automap on address \$0066 (instant, button)
- bit 0 = enable automap on address \$0066 (delayed, button)

Register (R/W) \$D8 (216) \Rightarrow I/O Traps (experimental)(3.01.10)

- bits 7-1 = Reserved, must be 0
- bit 0 = Enable FDC traps on ports \$2ffd and \$3ffd

Traps cannot be triggered by the DMA or while the multiface, dma, or external $\overline{\text{NMI}}$ is active Register (R/W) \$D9 (217) \Rightarrow I/O Trap Write (experimental)(3.01.10)

• bits 7-0 = The byte written during trapped I/O

Register (W) \$FF (255) \Rightarrow Debug LEDs (DE-1, DE-2 am Multicore only)

B.2 AY-3-8912

(R/W) \$00 (0) \Rightarrow Channel A fine tune

• bits 7-0 = Channel A frequency bits 7-0

(R/W) \$01 (1) \Rightarrow Channel A coarse tune

- bits 7-4 = Reserved
- bits 4-0 = Channel A frequency bits 11-8

(R/W) \$02 (0) \Rightarrow Channel B fine tune

• bits 7-0 = Channel A frequency bits 7-0

(R/W) \$03 (1) \Rightarrow Channel B coarse tune

- bits 7-4 = Reserved
- bits 4-0 = Channel A frequency bits 11-8

^{*} An i/o trap generates a multiface $\overline{\rm NMI}$ with next reg \$02 indicating which trap occurred

- (R/W) \$04 (0) \Rightarrow Channel C fine tune
 - bits 7-0 = Channel A frequency bits 7-0
- (R/W) \$05 (1) \Rightarrow Channel C coarse tune
 - bits 7-4 = Reserved
 - bits 4-0 = Channel A frequency bits 11-8
- (R/W) \$06 (6) \Rightarrow Noise period
 - bits 7-5 = Reserved
 - bits 4-0 = Noise period to noise generator
- (R/W) \$07 (7) \Rightarrow Mixer control I/O Enable

Active low (0=enable, 1= disable)

- bit 7-6: Reserved
- bit 5: Channel C noise enable
- bit 4: Channel B noise enable
- bit 3: Channel A noise enable
- bit 2: Channel C tone enable
- bit 1: Channel B tone enable
- bit 0: Channel A tone enable
- (R/W) \$0A (10) \Rightarrow Channel A amplitude
 - bits 7-5 = Reserved
 - bit 4 = Amplitude mode
 - 0=fixed amplitude
 - 1=use envelope generator (bits 0-3 ignored)
 - bits 0-3 = value of fixed amplitude
- (R/W) \$0B (11) \Rightarrow Channel B amplitude

like channel A amplitude

(R/W) \$0C (12) \Rightarrow Channel C amplitude

like channel A amplitude

- (R/W) \$0D (13) \Rightarrow Envelope period fine
 - bits 7-0 = Envelop period LSB
- (R/W) \$0E (14) \Rightarrow Envelope period coarse
 - bits 7-0 = Envelop period MSB
- (R/W) \$0F (15) \Rightarrow Envelope shape
 - bits 7-4 = Reserved
 - bit 3 = Continue
 - 0=drop to amplitude 0 after 1 cycle
 - 1=use 'Hold' value

B.3. ZXDMA 235

- \bullet bit 2 = Attack
 - -0=generator counts down
 - 1=generator counts up
- bit 1-0 = Alternate & Hold
 - -00=generator resets after each cycle
 - -01=hold final value
 - 10=generator reverses direction each cycle
 - 11=hold initial value

B.3 zxDMA

Group	Register Function Description	Bitmask	Notes
WR0	Direction Operation and Port A configuration	0XXXXXAA	AA must NOT be 00
WR1	Port A configuration	0XXXX100	
WR2	Port B configuration	0XXXX000	
WR3	Activation	1XXXXXX00	It's best to use WR6
WR5	Ready and Stop configuration	10XXX010	
WR6	Command Register	1XXXXXX11	

Appendix C

Extended Opcodes to Mnemonics

C.1 Single Byte Opcodes

			Tab	le C.	1: \$00-	-\$1F			
Op	Z80	8080	Sz	Т	Op	Z80	8080	Sz	Т
\$00	nop	nop	1	4	\$10	djnz x	_	2	13/8
\$01	ld bc,xx	lxi b,xx	3	10	\$11	ld de,xx	lxi d,xx	3	10
\$02	ld (bc),a	stax b	1	7	\$12	ld (de),a	stax d	1	7
\$03	inc bc	inx b	1	6	\$13	inc de	inx d	1	6
\$04	inc b	inr b	1	4	\$14	inc d	inr d	1	4
\$05	dec b	der b	1	4	\$15	dec d	dcr d	1	4
\$06	ld b,x	mvi b,x	2	7	\$16	ld d,x	mvi d,x	2	7
\$07	rlca	rlc	1	4	\$17	rla	ral	1	4
\$08	ex af,af'	_	1	4	\$18	jr x	_	2	12
\$09	add hl,bc	dad b	1	11	\$19	add hl,de	dad d	1	11
\$0A	ld a,(bc)	ldax b	1	7	\$1A	ld a,(de)	ldax d	1	7
\$0B	dec bc	dcx b	1	6	\$1B	dec de	dcx d	1	6
\$0C	inc c	icr c	1	4	\$1C	inc e	icr e	1	4
\$0D	dec c	dcr c	1	4	\$1D	dec e	dcr e	1	4
\$0E	ld c,x	mvi c,x	2	7	\$1E	ld e,x	mvi e,x	2	7
\$0F	rrca	rrc	1	4	\$1F	rra	rar	1	4

Table C.2: \$20-\$3F

	Table C.2. \$20-\$3F										
Op	Z80	8080	Sz	Т	Op	Z80	8080	Sz	Т		
\$20	jr nz,x	_	2	12/7	\$30	jr nc,x	_	2	12/7		
\$21	ld hl,xx	lxi h,xx	3	10	\$31	ld sp,xx	lxi sp,xx	3	10		
\$22	ld (xx),hl	shld xx	3	16	\$32	ld (xx),a	sta xx	3	13		
\$23	inc hl	inx h	1	6	\$33	inc sp	inx sp	1	6		
\$24	inc h	inr h	1	4	\$34	inc (hl)	inr m	1	11		
\$25	dec h	dcr h	1	4	\$35	dec (hl)	dcr m	1	11		
\$26	ld h,x	mvi h,x	2	7	\$36	ld (hl),x	mvi m,x	2	10		
\$27	daa	daa	1	4	\$37	scf	stc	1	4		
\$28	jr z,x	_	2	12/7	\$38	jr c,x	_	2	12/7		
\$29	add hl,hl	dad h	1	11	\$39	add hl,sp	dad sp	1	11		
\$2A	ld hl,(xx)	lhld xx	3	16	\$3A	ld a,(xx)	lda xx	3	13		
\$2B	dec hl	dcx h	1	6	\$3B	dec sp	dcx sp	1	6		
\$2C	inc l	inr l	1	4	\$3C	inc a	inr a	1	4		
\$2D	dec l	dcr l	1	4	\$3D	dec a	dcr a	1	4		
\$2E	ld l,x	mvi l,x	2	7	\$3E	ld a,x	mvi a,x	2	7		
\$2F	cpl	cma	1	4	\$3F	ccf	cmc	1	4		

Table C.3: \$40-\$5F

			Lanic	\sim . \circ	 Ψ±0- 	Ψ Ο Ι			
Op	Z80	8080	Sz	Т	Op	Z80	8080	Sz	Т
\$40	ld b,b	mov b,b	1	4	\$50	ld d,b	mov d,b	1	4
\$41	ld b,c	mov b,c	1	4	\$51	ld d,c	mov d,c	1	4
\$42	ld b,d	mov b,d	1	4	\$52	ld d,d	mov d,d	1	4
\$43	ld b,e	mov b,e	1	4	\$53	ld d,e	mov d,e	1	4
\$44	ld b,h	mov b,h	1	4	\$54	ld d,h	mov d,h	1	4
\$45	ld b,l	mov b,l	1	4	\$55	ld d,l	mov d,l	1	4
\$46	ld b,(hl)	mov b,m	1	7	\$56	ld d,(hl)	mov d,m	1	7
\$47	ld b,a	mov b,a	1	4	\$57	ld d,a	mov d,a	1	4
\$48	ld c,b	mov c,b	1	4	\$58	ld e,b	mov e,b	1	4
\$49	ld c,c	mov c,c	1	4	\$59	ld e,c	mov e,c	1	4
\$4A	ld c,d	mov c,d	1	4	\$5A	ld e,d	mov e,d	1	4
\$4B	ld c,e	mov c,e	1	4	\$5B	ld e,e	mov e,e	1	4
\$4C	ld c,h	mov c,h	1	4	\$5C	ld e,h	mov e,h	1	4
\$4D	ld c,l	mov c,l	1	4	\$5D	ld e,l	mov e,l	1	4
\$4E	ld c,(hl)	mov c,m	1	7	\$5E	ld e,(hl)	mov e,m	1	7
\$4F	ld c,a	mov c,a	1	4	\$5F	ld e,a	mov e,a	1	4

Table C.4: \$60-\$7F

Op	Z80	8080	Sz	Т	Op	Z80	8080	Sz	T
\$60	ld h,b	mov h,b	1	4	\$70	ld (hl),b	mov m,b	1	4
\$61	ld h,c	mov h,c	1	4	\$71	ld (hl),c	mov m,c	1	4
\$62	ld h,d	mov h,d	1	4	\$72	ld (hl),d	mov m,d	1	4
\$63	ld h,e	mov h,e	1	4	\$73	ld (hl),e	mov m,e	1	4
\$64	ld h,h	mov h,h	1	4	\$74	ld (hl),h	mov m,h	1	4
\$65	ld h,l	mov h,l	1	4	\$75	ld (hl),l	mov m,l	1	4
\$66	ld h,(hl)	mov h,m	1	7	\$76	halt	halt	1	4+
\$67	ld h,a	mov h,a	1	4	\$77	ld (hl),a	mov m,a	1	7
\$68	ld l,b	mov l,b	1	4	\$78	ld a,b	mov a,b	1	4
\$69	ld l,c	mov l,c	1	4	\$79	ld a,c	mov a,c	1	4
\$6A	ld l,d	mov l,d	1	4	\$7A	ld a,d	mov a,d	1	4
\$6B	ld l,e	mov l,e	1	4	\$7B	ld a,e	mov a,e	1	4
\$6C	ld l,h	mov l,h	1	4	\$7C	ld a,h	mov a,h	1	4
\$6D	ld l,l	mov l,l	1	4	\$7D	ld a,l	mov a,l	1	4
\$6E	ld l,(hl)	mov l,m	1	7	\$7E	ld a,(hl)	mov a,m	1	7
\$6F	ld l,a	mov l,a	1	4	\$7F	ld a,a	mov a,a	1	4

	\$80-\$9F

0-	Z80	8080	Sz	T		Z80	8080	Sz	Т
Op	200	8080	bz	1	Op	200	0000	SZ	1
\$80	add a,b	add b	1	4	\$90	sub b	sub b	1	4
\$81	add a,c	add c	1	4	\$91	sub c	sub c	1	4
\$82	add a,d	add d	1	4	\$92	sub d	sub d	1	4
\$83	add a,e	add e	1	4	\$93	sub e	sub e	1	4
\$84	add a,h	add h	1	4	\$94	sub h	sub h	1	4
\$85	add a,l	add l	1	4	\$95	sub l	sub l	1	4
\$86	add a,(hl)	add m	1	7	\$96	sub (hl)	sub m	1	7
\$87	add a,a	add a	1	4	\$97	sub a	sub a	1	4
\$88	adc a,b	adc b	1	4	\$98	$_{ m sbc}$ a,b	sbb b	1	4
\$89	adc a,c	adc c	1	4	\$99	sbc a,c	sbb c	1	4
\$8A	adc a,d	adc d	1	4	\$9A	$_{ m sbc}$ a,d	sbb d	1	4
\$8B	adc a,e	adc e	1	4	\$9B	$_{ m sbc}$ a,e	sbb e	1	4
\$8C	adc a,h	adc h	1	4	\$9C	sbc a,h	sbb h	1	4
\$8D	adc a,l	adc l	1	4	\$9D	sbc a,l	sbb l	1	4
\$8E	adc a,(hl)	adc m	1	7	\$9E	sbc a,(hl)	sbb m	1	7
\$8F	adc a,a	adc a	1	4	\$9F	sbc a,a	sbb a	1	4

Table C.6: \$A0-\$BF

			andre	\circ . \circ .	$\Phi 1 1 0 - \Phi$				
Op	Z80	8080	Sz	T	Op	Z80	8080	Sz	Т
\$A0	and b	ana b	1	4	\$B0	or b	ora b	1	4
\$A1	and c	ana c	1	4	\$B1	or c	ora c	1	4
\$A2	and d	ana d	1	4	\$B2	or d	ora d	1	4
\$A3	and e	ana e	1	4	\$B3	or e	ora e	1	4
\$A4	and h	ana h	1	4	\$B4	or h	ora h	1	4
\$A5	and l	ana l	1	4	\$B5	or l	ora l	1	4
\$A6	and (hl)	ana m	1	7	\$B6	or (hl)	ora m	1	7
\$A7	and a	ana a	1	4	\$B7	or a	ora a	1	4
\$A8	xor b	xra b	1	4	\$B8	ср b	cmp b	1	4
\$A9	xor c	xra c	1	4	\$B9	срс	cmp c	1	4
\$AA	xor d	xra d	1	4	\$BA	cp d	cmp d	1	4
\$AB	xor e	xra e	1	4	\$BB	сре	cmp e	1	4
\$AC	xor h	xra h	1	4	\$BC	cp h	cmp h	1	4
\$AD	xor l	xra l	1	4	\$BD	cp l	cmp l	1	4
\$AE	xor (hl)	xra m	1	7	BE	cp (hl)	cmp m	1	7
\$AF	xor a	xra a	1	4	BF	сра	cmp a	1	4

Table C.7: \$C0-\$DF

Op	Z80	8080	Sz	Т	Op	Z80	8080	Sz	Т
\$C0	ret nz	rnz	1	11/5	\$D0	ret nc	rnc	1	11/5
\$C1	pop bc	pop b	1	10	\$D1	pop de	pop d	1	10
\$C2	jp nz,xx	jnz xx	3	10	\$D2	jp nc,xx	jnc xx	3	10
\$C3	jp xx	jmp xx	3	10	\$D3	out (x),a	out x	2	11
\$C4	call nz,xx	cnz xx	3	17/10	\$D4	call nc,xx	cnc xx	3	17/10
\$C5	push bc	push b	1	11	\$D5	push de	push d	1	11
\$C6	add a,x	adi x	2	7	\$D6	sub x	sui x	2	7
\$C7	rst 00h	rst 0	1	11	\$D7	rst 10h	rst 2	1	11
\$C8	ret z	rz	1	11/5	\$D8	ret c	rc	1	11/5
\$C9	ret	ret	1	10	\$D9	exx	_	1	4
\$CA	jp z,xx	jz xx	3	10	\$DA	jp c,xx	jc xx	3	10
\$CB	xxBITxx	_	+1	_	\$DB	in a,(x)	in x	2	11
\$CC	call z,xx	cz xx	3	17/10	\$DC	call c,xx	cc xx	3	17/11
\$CD	call xx	call xx	3	17	\$DD	xxIXxx	_	+1	
\$CE	adc a,x	aci x	2	7	\$DE	sbc a,x	sbi x	2	7
\$CF	rst 08h	rst 1	1	11	\$DF	rst 18h	rst 3	1	11

Table C.8: \$E0-\$FF

	Table C.S. 9E0-9FF									
Op	Z80	8080	Sz	T	Op	Z80	8080	Sz	Т	
\$E0	ret po	rpo	1	11/5	\$F0	ret p	rp	1	11/5	
\$E1	pop hl	pop h	1	10	\$F1	pop af	pop psw	1	10	
\$E2	jp po,xx	јро хх	3	10	\$F2	jp p,xx	jp xx	3	10	
\$E3	ex (sp),hl	xthl	1	19	\$F3	di	di	1	4	
\$E4	call po,xx	сро хх	3	17/10	\$F4	call p,xx	cp xx	3	17/10	
\$E5	push hl	push h	1	11	\$F5	push af	push psw	1	11	
\$E6	and x	ani x	2	7	\$F6	or x	ori x	2	7	
\$E7	rst 20h	rst 4	1	11	\$F7	rst 30h	rst 6	1	11	
\$E8	ret pe	rpe	1	11/5	\$F8	ret m	rm	1	11/5	
\$E9	jp (hl)	pchl	1	4	\$F9	ld sp,hl	sphl	1	6	
\$EA	jp pe,xx	jpe xx	3	10	\$FA	jp m,xx	jm xx	3	10	
\$EB	ex de,hl	xchg	1	4	\$FB	ei	ei	1	4	
\$EC	call pe,xx	cpe	3	17/10	\$FC	call m,xx	cm xx	3	17/10	
\$ED	xx80xx	_	+1	_	\$FD	xxIYxx	_	+1	_	
\$EE	xor x	xri x	2	7	\$FE	ср х	cpi x	2	7	
\$EF	rst 28h	rst 5	1	11	\$FF	rst 38h	rst 7	1	11	

C.2 \$CBxx Bit Operations

Table C.9: \$CB00-\$CB1F

Op	Mnemonic	Sz	T	Op	Mnemonic	Sz	Т
\$CB00	rlc b	2	8	\$CB10	rl b	2	8
\$CB01	rlc c	2	8	\$CB11	rl c	2	8
\$CB02	rlc d	2	8	\$CB12	rl d	2	8
\$CB03	rlc e	2	8	\$CB13	rl e	2	8
\$CB04	rlc h	2	8	\$CB14	rl h	2	8
\$CB05	rlc l	2	8	\$CB15	rl l	2	8
\$CB06	rlc (hl)	2	15	\$CB16	rl (hl)	2	15
\$CB07	rlc a	2	8	\$CB17	rl a	2	8
\$CB08	rrc b	2	8	\$CB18	rr b	2	8
\$CB09	rrc c	2	8	\$CB19	rr c	2	8
\$CB0A	rrc d	2	8	\$CB1A	rr d	2	8
\$CB0B	rrc e	2	8	\$CB1B	rr e	2	8
\$CB0C	rrc h	2	8	\$CB1C	rr h	2	8
\$CB0D	rrc l	2	8	\$CB1D	rr l	2	8
\$CB0E	rrc (hl)	2	15	\$CB1E	rr (hl)	2	15
\$CB0F	rrc a	2	8	\$CB1F	rr a	2	8

Table C.10: \$CB20-\$CB3F

Op	Mnemonic	Sz	T	Op	Mnemonic	Sz	T
\$CB20	sla b	2	8	\$CB30	sll b	2	8
\$CB21	sla c	2	8	\$CB31	sll c	2	8
\$CB22	sla d	2	8	\$CB32	sll d	2	8
\$CB23	sla e	2	8	\$CB33	sll e	2	8
\$CB24	sla h	2	8	\$CB34	sll h	2	8
\$CB25	sla l	2	8	\$CB35	sll l	2	8
\$CB26	sla (hl)	2	15	\$CB36	sll (hl)	2	15
\$CB27	sla a	2	8	\$CB37	sll a	2	8
\$CB28	sra b	2	8	\$CB38	srl b	2	8
\$CB29	sra c	2	8	\$CB39	srl c	2	8
\$CB2A	sra d	2	8	\$CB3A	srl d	2	8
\$CB2B	sra e	2	8	\$CB3B	srl e	2	8
\$CB2C	sra h	2	8	\$CB3C	srl h	2	8
\$CB2D	sra l	2	8	\$CB3D	srl l	2	8
\$CB2E	sra (hl)	2	15	\$CB3E	srl (hl)	2	15
\$CB2F	sra a	2	8	\$CB3F	srl a	2	8

Table C 11: \$CB40-\$CB5E

Table C.11: \$CB40-\$CB5F								
Op	Mnemonic	Sz	T	Op	Mnemonic	Sz	T	
\$CB40	bit 0,b	2	8	\$CB50	bit 2,b	2	8	
\$CB41	bit 0,c	2	8	\$CB51	bit 2,c	2	8	
\$CB42	bit 0,d	2	8	\$CB52	bit 2,d	2	8	
\$CB43	bit 0,e	2	8	\$CB53	bit 2,e	2	8	
\$CB44	bit 0,h	2	8	\$CB54	bit 2,h	2	8	
\$CB45	bit 0,l	2	8	\$CB55	bit 2,l	2	8	
\$CB46	bit 0,(hl)	2	12	\$CB56	bit 2,(hl)	2	12	
\$CB47	bit 0,a	2	8	\$CB57	bit 2,a	2	8	
\$CB48	bit 1,b	2	8	\$CB58	bit 3,b	2	8	
\$CB49	bit 1,c	2	8	\$CB59	bit 3,c	2	8	
\$CB4A	bit 1,d	2	8	\$CB5A	bit 3,d	2	8	
\$CB4B	bit 1,e	2	8	\$CB5B	bit 3,e	2	8	
\$CB4C	bit 1,h	2	8	\$CB5C	bit 3,h	2	8	
\$CB4D	bit 1,l	2	8	\$CB5D	bit 3,l	2	8	
\$CB4E	bit 1,(hl)	2	12	\$CB5E	bit 3,(hl)	2	12	
\$CB4F	bit 1,a	2	8	\$CB5F	bit 3,a	2	8	

Table C.12: \$CB60-\$CB7F

Op	Mnemonic	Sz	Т	Op	Mnemonic	Sz	Т
\$CB60	bit 4,b	2	8	\$CB70	bit 6,b	2	8
\$CB61	bit 4,c	2	8	\$CB71	bit 6,c	2	8
\$CB62	bit 4,d	2	8	\$CB72	bit 6,d	2	8
\$CB63	bit 4,e	2	8	\$CB73	bit 6,e	2	8
\$CB64	bit 4,h	2	8	\$CB74	bit 6,h	2	8
\$CB65	bit 4,l	2	8	\$CB75	bit 6,l	2	8
\$CB66	bit 4,(hl)	2	12	\$CB76	bit 6,(hl)	2	12
\$CB67	bit 4,a	2	8	\$CB77	bit 6,a	2	8
\$CB68	bit 5,b	2	8	\$CB78	bit 7,b	2	8
\$CB69	bit 5,c	2	8	\$CB79	bit 7,c	2	8
\$CB6A	bit 5,d	2	8	\$CB7A	bit 7,d	2	8
\$CB6B	bit 5,e	2	8	\$CB7B	bit 7,e	2	8
\$CB6C	bit 5,h	2	8	\$CB7C	bit 7,h	2	8
\$CB6D	bit 5,l	2	8	\$CB7D	bit 7,l	2	8
\$CB6E	bit 5,(hl)	2	12	\$CB7E	bit 7,(hl)	2	12
\$CB6F	bit 5,a	2	8	\$CB7F	bit 7,a	2	8

Table C.13: \$CB80-\$CB9F

Op	Mnemonic	Sz	Т	Op	Mnemonic	Sz	Т
\$CB80	res 0,b	2	8	\$CB90	res 2,b	2	8
\$CB81	res 0,c	2	8	\$CB91	res 2,c	2	8
\$CB82	res 0,d	2	8	\$CB92	res 2,d	2	8
\$CB83	res 0,e	2	8	\$CB93	res 2,e	2	8
\$CB84	res 0,h	2	8	\$CB94	res 2,h	2	8
\$CB85	res 0,l	2	8	\$CB95	res 2,l	2	8
\$CB86	res 0,(hl)	2	15	\$CB96	res 2,(hl)	2	15
\$CB87	res 0,a	2	8	\$CB97	res 2,a	2	8
\$CB88	res 1,b	2	8	\$CB98	res 3,b	2	8
\$CB89	res 1,c	2	8	\$CB99	res 3,c	2	8
\$CB8A	res 1,d	2	8	\$CB9A	res 3,d	2	8
\$CB8B	res 1,e	2	8	\$CB9B	res 3,e	2	8
\$CB8C	res 1,h	2	8	\$CB9C	res 3,h	2	8
\$CB8D	res 1,l	2	8	\$CB9D	res 3,l	2	8
\$CB8E	res 1,(hl)	2	15	\$CB9E	res 3,(hl)	2	15
\$CB8F	res 1,a	2	8	\$CB9F	res 3,a	2	8

Table C.14: \$CBA0-\$CBBF

Table C.14. \$CDA0-\$CDD1									
Op	Mnemonic	Sz	T	Op	Mnemonic	Sz	Т		
\$CBA0	res 4,b	2	8	\$CBB0	res 6,b	2	8		
\$CBA1	res 4,c	2	8	\$CBB1	res 6,c	2	8		
\$CBA2	res 4,d	2	8	\$CBB2	res 6,d	2	8		
\$CBA3	res 4,e	2	8	\$CBB3	res 6,e	2	8		
\$CBA4	res 4,h	2	8	\$CBB4	res 6,h	2	8		
\$CBA5	res 4,l	2	8	\$CBB5	res 6,l	2	8		
\$CBA6	res 4,(hl)	2	15	\$CBB6	res 6,(hl)	2	15		
\$CBA7	res 4,a	2	8	\$CBB7	res 6,a	2	8		
\$CBA8	res 5,b	2	8	\$CBB8	res 7,b	2	8		
\$CBA9	res 5,c	2	8	\$CBB9	res 7,c	2	8		
\$CBAA	res 5,d	2	8	\$CBBA	res 7,d	2	8		
\$CBAB	res 5,e	2	8	\$CBBB	res 7,e	2	8		
\$CBAC	res 5,h	2	8	\$CBBC	res 7,h	2	8		
\$CBAD	res 5,l	2	8	\$CBBD	res 7,l	2	8		
\$CBAE	res 5,(hl)	2	15	\$CBBE	res 7,(hl)	2	15		
\$CBAF	res 5,a	2	8	\$CBBF	res 7,a	2	8		

Table C.15: \$CBC0-\$CBDF

Table C.19. #CDC0-#CDD1									
Op	Mnemonic	Sz	Т	Op	Mnemonic	Sz	Т		
\$CBC0	set 0,b	2	8	\$CBD0	set 2,b	2	8		
\$CBC1	set 0,c	2	8	\$CBD1	set 2,c	2	8		
\$CBC2	set 0,d	2	8	\$CBD2	set 2,d	2	8		
\$CBC3	set 0,e	2	8	\$CBD3	set 2,e	2	8		
\$CBC4	set 0,h	2	8	\$CBD4	set 2,h	2	8		
\$CBC5	set 0,l	2	8	\$CBD5	set 2,l	2	8		
\$CBC6	set 0,(hl)	2	15	\$CBD6	set 2,(hl)	2	15		
\$CBC7	set 0,a	2	8	\$CBD7	set 2,a	2	8		
\$CBC8	set 1,b	2	8	\$CBD8	set 3,b	2	8		
\$CBC9	set 1,c	2	8	\$CBD9	set 3,c	2	8		
\$CBCA	set 1,d	2	8	\$CBDA	set 3,d	2	8		
\$CBCB	set 1,e	2	8	\$CBDB	set 3,e	2	8		
\$CBCC	set 1,h	2	8	\$CBDC	set 3,h	2	8		
\$CBCD	set 1,l	2	8	\$CBDD	set 3,l	2	8		
\$CBCE	set 1,(hl)	2	15	\$CBDE	set 3,(hl)	2	15		
\$CBCF	set 1,a	2	8	\$CBDF	set 3,a	2	8		

Table C.16: \$CBE0-\$CBFF

Op	Mnemonic	Sz	Т	Op	Mnemonic	Sz	Т
\$CBE0	set 4,b	2	8	\$CBF0	set 6,b	2	8
\$CBE1	set 4,c	2	8	\$CBF1	set 6,c	2	8
\$CBE2	set 4,d	2	8	\$CBF2	set 6,d	2	8
\$CBE3	set 4,e	2	8	\$CBF3	set 6,e	2	8
\$CBE4	set 4,h	2	8	\$CBF4	set 6,h	2	8
\$CBE5	set 4,l	2	8	\$CBF5	set 6,l	2	8
\$CBE6	set 4,(hl)	2	15	\$CBF6	set 6,(hl)	2	15
\$CBE7	set 4,a	2	8	\$CBF7	set 6,a	2	8
\$CBE8	set 5,b	2	8	\$CBF8	set 7,b	2	8
\$CBE9	set 5,c	2	8	\$CBF9	set 7,c	2	8
\$CBEA	set 5,d	2	8	\$CBFA	set 7,d	2	8
\$CBEB	set 5,e	2	8	\$CBFB	set 7,e	2	8
\$CBEC	set 5,h	2	8	\$CBFC	set 7,h	2	8
\$CBED	set 5,l	2	8	\$CBFD	set 7,l	2	8
\$CBEE	set 5,(hl)	2	15	\$CBFE	set 7,(hl)	2	15
\$CBEF	set 5,a	2	8	\$CBFF	set 7,a	2	8

C.3 \$DDxx IX

Table C.17: \$DD00-\$DD5F

Table C.17. #DD00-#DD01										
Op	Mnemonic	Sz	T	Op	Mnemonic	Sz	T			
\$DD09	add ix,bc	2	15	\$DD35	dec (ix+x)	3	23			
\$DD19	add ix,de	2	15	\$DD36	ld (ix+x),x	5	19			
\$DD21	ld ix,xx	4	14	\$DD39	add ix,sp	2	15			
\$DD22	ld (xx),ix	4	20	\$DD44	ld b,ixh	2	8			
\$DD23	inc ix	2	10	\$DD45	ld b,ixl	2	8			
\$DD24	inc ixh	2	8	\$DD46	ld b,(ix+x)	2	19			
\$DD25	dec ixh	2	8	\$DD4C	ld c,ixh	2	8			
\$DD26	ld ixh,x	3	11	\$DD4D	ld c,ixl	2	8			
\$DD29	add ix,ix	2	15	\$DD4E	ld c,(ix+x)	3	19			
\$DD2A	ld ix,(xx)	4	20	\$DD54	ld d,ixh	2	8			
\$DD2B	dec ix	2	10	\$DD55	ld d,ixl	2	8			
\$DD2C	inc ixl	2	8	\$DD56	$\operatorname{ld} d, (\operatorname{ix} + \operatorname{x})$	3	19			
\$DD2D	dec ixl	2	8	\$DD5C	ld e,ixh	2	8			
\$DD2E	ld ixl,x	4	11	\$DD5D	ld e,ixl	2	8			
\$DD34	inc (ix+x)	3	23	\$DD5E	ld e,(ix+x)	3	19			

Table C.18: \$DD60-\$CB8F

Op	Mnemonic	Sz	T	Op	Mnemonic	Sz	T
\$DD60	ld ixh,b	2	8	\$DD70	ld (ix+x),b	3	19
\$DD61	ld ixh,c	2	8	\$DD71	ld (ix+x),c	3	19
\$DD62	ld ixh,d	2	8	\$DD72	ld (ix+x),d	3	19
\$DD63	ld ixh,e	2	8	\$DD73	ld (ix+x),e	3	19
\$DD64	ld ixh,ixh	2	8	\$DD74	ld (ix+x),h	3	19
\$DD65	ld h,(ix+x)	3	19	\$DD75	ld (ix+x),l	3	19
\$DD65	ld ixh,ixl	2	8	\$DD77	ld (ix+x),a	3	19
\$DD67	ld ixh,a	2	8	\$DD7C	ld a,ixh	2	8
\$DD68	ld ixl,b	2	8	\$DD7D	ld a,ixl	2	8
\$DD69	ld ixl,c	2	8	\$DD7E	ld a,(ix+x)	3	19
\$DD6A	ld ixl,d	2	8	\$DD84	add a,ixh	2	8
\$DD6B	ld ixl,e	2	8	\$DD85	add a,ixl	2	8
\$DD6C	ld ixl,ixh	2	2	\$DD86	$add \ a,(ix+x)$	3	19
\$DD6D	ld ixl,ixl	2	2	\$DD8C	adc a,ixh	2	8
\$DD6E	ld l,(ix+x)	3	19	\$DD8D	adc a,ixl	2	8
\$DD6F	ld ixl,a	2	8	\$DD8E	adc a,(ix+x)	3	19

Table	C.19:	DD90-DDFF
-------	-------	-----------

Op	Mnemonic	Sz	Т	Op	Mnemonic	Sz	Т
\$DD94	sub ixh	2	8	\$DDB4	or ixh	2	8
\$DD95	sub ixl	2	8	\$DDB5	or ixl	2	8
\$DD96	sub (ix+x)	3	19	\$DDB6	or (ix+x)	3	19
\$DD9C	sbc a,ixh	2	8	\$DDBC	cp ixh	2	8
\$DD9D	sbc a,ixl	2	8	\$DDBD	cp ixl	2	8
\$DD9E	sbc a,(ix+x)	3	1	\$DDBE	cp (ix+x)	2	19
\$DDA4	and ixh	2	8	\$DDCB	xBIT+IXx	+1	_
\$DDA5	and ixl	2	8	\$DDE1	pop ix	2	14
\$DDA6	and (ix+x)	3	19	\$DDE3	ex (sp),ix	2	23
\$DDAC	xor ixh	2	8	\$DDE5	push ix	2	15
\$DDAD	xor ixl	2	8	\$DDE9	jp (ix)	3	8
\$DDAE	xor (ix+x)	3	19	\$DDF9	ld sp,ix	2	10

C.4 \$EDxx Block/Port

Table C.20: \$ED00-\$ED4F

Op	Mnemonic	Sz	Т	Op	Mnemonic	Sz	Т
\$ED23	swapinb *	2	8	\$ED40	in b,(c)	2	12
\$ED24	mirror a *	2	8	\$ED41	out (c),b	2	12
\$ED27	test x *	3	11	\$ED42	sbc hl,bc	2	15
\$ED28	bsla de,b *	2	8	\$ED43	ld (xx),bc	4	20
\$ED29	bsra de,b *	2	8	\$ED44	neg	2	8
\$ED2A	bsrl de,b *	2	8	\$ED45	retn	2	14
\$ED2B	bsrf de,b *	2	8	\$ED46	im 0	2	8
\$ED2C	brlc de,b *	2	8	\$ED47	ld i,a	2	9
\$ED30	mul d,e *	2	8	\$ED48	in c,(c)	2	12
\$ED31	add hl,a *	2	8	\$ED49	out (c),c	2	12
\$ED32	add de,a *	2	8	\$ED4A	adc hl,bc	2	15
\$ED33	add bc,a *	2	8	\$ED4B	ld bc,(xx)	4	20
\$ED34	add hl,xx *	4	16	\$ED4D	reti	2	14
\$ED35	add de,xx *	4	16	\$ED4F	ld r,a	2	9
\$ED36	add bc,xx *	4	16				

^{*} ZX Spectrum Next extension

Table C.21: \$ED50-\$ED8F

Table C.21. #ED90-#ED01											
Op	Mnemonic	Sz	Т	Op	Mnemonic	Sz	Т				
\$ED50	in d,(c)	2	12	\$ED67	rrd	2	18				
\$ED51	out (c),d	2	12	\$ED68	in l,(c)	2	12				
\$ED52	sbc hl,de	2	15	\$ED69	out (c),l	2	12				
\$ED53	ld (xx),de	4	20	\$ED6A	adc hl,hl	2	15				
\$ED56	im 1	2	8	\$ED6B	ld hl,(xx)	4	20				
\$ED57	ld a,i	2	9	\$ED6F	rld	2	18				
\$ED58	in e,(c)	2	12	\$ED70	in f,(c)	2	12				
\$ED59	out (c),e	2	12	\$ED71	out (c),f	2	12				
\$ED5A	adc hl,de	2	15	\$ED72	sbc hl,sp	2	15				
\$ED5B	ld de,(xx)	4	20	\$ED73	ld (xx),sp	4	20				
\$ED5E	im 2	2	8	\$ED78	in a,(c)	2	12				
\$ED5F	ld a,r	2	9	\$ED79	out (c),a	2	12				
\$ED60	in h,(c)	2	12	\$ED7A	adc hl,sp	2	15				
\$ED61	out (c),h	2	12	\$ED7B	ld sp,(xx)	4	20				
\$ED62	sbc hl,hl	2	15	\$ED8A	push xx	4	*				
\$ED63	ld (xx),hl	4					İ				

Table C.22: ED90-EDFF

		,10 0	`				
Op	Mnemonic	Sz	T	Op	Mnemonic	Sz	Т
\$ED90	outinb *	2	16	\$EDAA	ind	2	16
\$ED91	nextreg r,v *	4	20	\$EDAB	outd	2	16
\$ED92	nextreg r,a *	3	17	\$EDAC	lddx *	2	16
\$ED93	pixeldn *	2	8	\$EDB0	ldir	2	21/16
\$ED94	pixelad *	2	8	\$EDB1	cpir	2	21/16
\$ED95	setae *	2	8	\$EDB2	inir	2	21/16
\$ED98	jp (c) *	2	13	\$EDB3	otir	2	21/16
\$EDA0	ldi	2	16	\$EDB4	ldirx *	2	21/16
\$EDA1	cpi	2	16	\$EDB7	ldpirx *	2	21/16
\$EDA2	ini	2	16	\$EDB8	lddr	2	21/16
\$EDA3	outi	2	16	\$EDB9	cpdr	2	21/16
\$EDA4	ldix *	2	16	\$EDBA	indr	2	21/16
\$EDA5	ldws *	2	14	\$EDBB	otdr	2	12/16
\$EDA8	ldd	2	16	\$EDBC	lddrx *	2	21/16
\$EDA9	cpd	2	16				i i

^{*} ZX Spectrum Next extension

C.5 \$FDxx IY

Table C.23: \$FD00-\$FD5F

1able C.23. #P D00-#P D31								
Op	Mnemonic	Sz	T	Op	Mnemonic	Sz	Т	
\$FD09	add iy,bc	2	15	\$FD35	dec (iy+x)	3	23	
\$FD19	add iy,de	2	15	\$FD36	ld (iy+x),x	5	19	
\$FD21	ld iy,xx	4	14	\$FD39	add iy,sp	2	15	
\$FD22	ld (xx),iy	4	20	\$FD44	ld b,iyh	2	8	
\$FD23	inc iy	2	10	\$FD45	ld b,iyl	2	8	
\$FD24	inc iyh	2	8	\$FD46	ld b,(iy+x)	2	19	
\$FD25	dec iyh	2	8	\$FD4C	ld c,iyh	2	8	
\$FD26	ld iyh,x	3	11	\$FD4D	ld c,iyl	2	8	
\$FD29	add iy,iy	2	15	\$FD4E	ld c,(iy+x)	3	19	
\$FD2A	ld iy,(xx)	4	20	\$FD54	ld d,iyh	2	8	
\$FD2B	dec iy	2	10	\$FD55	ld d,iyl	2	8	
\$FD2C	inc iyl	2	8	\$FD56	ld d,(iy+x)	3	19	
\$FD2D	dec iyl	2	8	\$FD5C	ld e,iyh	2	8	
\$FD2E	ld iyl,x	4	11	\$FD5D	ld e,iyl	2	8	
\$FD34	inc (iy+x)	3	23	\$FD5E	ld e,(iy+x)	3	19	

Table C.24: \$FD60-\$FD8F

1able 0.24. ψΓ D00-ψΓ D0Γ										
Op	Mnemonic	Sz	T	Op	Mnemonic	Sz	Т			
\$FD60	ld iyh,b	2	8	\$FD70	ld (iy+x),b	3	19			
\$FD61	ld iyh,c	2	8	\$FD71	ld (iy+x),c	3	19			
\$FD62	ld iyh,d	2	8	\$FD72	ld (iy+x),d	3	19			
\$FD63	ld iyh,e	2	8	\$FD73	ld (iy+x),e	3	19			
\$FD64	ld iyh,iyh	2	8	\$FD74	ld (iy+x),h	3	19			
\$FD65	ld h,(iy+x)	3	19	\$FD75	ld (iy+x),l	3	19			
\$FD65	ld iyh,iyl	2	8	\$FD77	ld (iy+x),a	3	19			
\$FD67	ld iyh,a	2	8	\$FD7C	ld a,iyh	2	8			
\$FD68	ld iyl,b	2	8	\$FD7D	ld a,iyl	2	8			
\$FD69	ld iyl,c	2	8	\$FD7E	ld a,(iy+x)	3	19			
\$FD6A	ld iyl,d	2	8	\$FD84	add a,iyh	2	8			
\$FD6B	ld iyl,e	2	8	\$FD85	add a,iyl	2	8			
\$FD6C	ld iyl,iyh	2	2	\$FD86	add a,(iy+x)	3	19			
\$FD6D	ld iyl,iyl	2	2	\$FD8C	adc a,iyh	2	8			
\$FD6E	ld l, (iy+x)	3	19	\$FD8D	adc a,iyl	2	8			
\$FD6F	ld iyl,a	2	8	\$FD8E	adc a,(iy+x)	3	19			

Table C.25: \$FD90-\$FDFF

On	Op Mnemonic Sz T Op Mnemonic Sz T								
Op	Minemonic	SZ	1	Op	Milemonic	SZ	1		
\$FD94	sub iyh	2	8	\$FDB4	or iyh	2	8		
\$FD95	sub iyl	2	8	\$FDB5	or iyl	2	8		
\$FD96	$\operatorname{sub} (iy+x)$	3	19	\$FDB6	or (iy+x)	3	19		
\$FD9C	sbc a,iyh	2	8	\$FDBC	cp iyh	2	8		
\$FD9D	sbc a,iyl	2	8	\$FDBD	cp iyl	2	8		
\$FD9E	$sbc \ a,(iy+x)$	3	1	\$FDBE	cp (iy+x)	2	19		
\$FDA4	and iyh	2	8	\$FDCB	xBIT+IYx	+1	_		
\$FDA5	and iyl	2	8	\$FDE1	pop iy	2	14		
\$FDA6	and (iy+x)	3	19	\$FDE3	ex (sp),iy	2	23		
\$FDAC	xor iyh	2	8	\$FDE5	push iy	2	15		
\$FDAD	xor iyl	2	8	\$FDE9	jp (iy)	3	8		
\$FDAE	xor(iy+x)	3	19	\$FDF9	ld sp,iy	2	10		

C.6 \$DDCBxx IX Bit Operations

Table C.26: \$DDCB00-\$DDCBFF

Op	Mnemonic	Sz	Т	Op	Mnemonic	Sz	Т
\$DDCB06	rlc (ix+x)	4	23	\$DDCB0E	rrc (ix+x)	4	23
\$DDCB16	rl (ix+x)	4	23	\$DDCB1E	rr (ix+x)	4	23
\$DDCB26	sla (ix+x)	4	23	\$DDCB2E	sra (ix+x)	4	23
\$DDCB36	sll (ix+x)	4	23	\$DDCB3E	srl (ix+x)	4	23
\$DDCB46	bit $0,(ix+x)$	4	20	\$DDCB4E	bit $1,(ix+x)$	4	20
\$DDCB56	bit $2,(ix+x)$	4	20	\$DDCB5E	bit 3 ,(ix+x)	4	20
\$DDCB66	bit 4 ,(ix+x)	4	20	\$DDCB6E	bit 5 ,(ix+x)	4	20
\$DDCB76	bit 6 ,(ix+x)	4	20	\$DDCB7E	bit 7 ,(ix+x)	4	20
\$DDCB86	res 0,(ix+x)	4	23	\$DDCB8E	res 1,(ix+x)	4	23
\$DDCB96	res 2 ,(ix+x)	4	23	\$DDCB9E	res 3,(ix+x)	4	23
\$DDCBA6	res 4,(ix+x)	4	23	\$DDCBAE	res 5,(ix+x)	4	23
\$DDCBB6	res 6 ,(ix+x)	4	23	\$DDCBBE	res 7,(ix+x)	4	23
\$DDCBC6	set 0,(ix+x)	4	23	\$DDCBCE	set 1,(ix+x)	4	23
\$DDCBD6	set 2,(ix+x)	4	23	\$DDCBDE	set 3,(ix+x)	4	23
\$DDCBE6	set 4,(ix+x)	4	23	\$DDCBEE	set 5,(ix+x)	4	23
\$DDCBF6	set 6 ,(ix+x)	4	23	\$DDCBFE	set 7,(ix+x)	4	23

C.7 \$FDCBxx IY Bit Operations

Table C.27: FDCB00-FDCBFF

Op	Mnemonic	Sz	T	Op	Mnemonic	Sz	T
\$FDCB06	rlc (iy+x)	4	23	\$FDCB0E	rrc (iy+x)	4	23
\$FDCB16	rl (iy+x)	4	23	\$FDCB1E	rr (iy+x)	4	23
\$FDCB26	sla (iy+x)	4	23	\$FDCB2E	sra (iy+x)	4	23
\$FDCB36	sll (iy+x)	4	23	\$FDCB3E	srl (iy+x)	4	23
\$FDCB46	bit $0,(iy+x)$	4	20	\$FDCB4E	bit $1,(iy+x)$	4	20
\$FDCB56	bit $2,(iy+x)$	4	20	\$FDCB5E	bit $3,(iy+x)$	4	20
\$FDCB66	bit 4 ,(iy+x)	4	20	\$FDCB6E	bit $5,(iy+x)$	4	20
\$FDCB76	bit 6 ,(iy+x)	4	20	\$FDCB7E	bit 7 ,(iy+x)	4	20
\$FDCB86	res 0,(iy+x)	4	23	\$FDCB8E	res 1,(iy+x)	4	23
\$FDCB96	res 2,(iy+x)	4	23	\$FDCB9E	res 3,(iy+x)	4	23
\$FDCBA6	res 4 ,(iy+x)	4	23	\$FDCBAE	res 5,(iy+x)	4	23
\$FDCBB6	res 6,(iy+x)	4	23	\$FDCBBE	res 7 , $(iy+x)$	4	23
\$FDCBC6	set 0 ,(iy+x)	4	23	\$FDCBCE	set $1,(iy+x)$	4	23
\$FDCBD6	set 2 ,(iy+x)	4	23	\$FDCBDE	set 3 ,(iy+x)	4	23
\$FDCBE6	set 4,(iy+x)	4	23	\$FDCBEE	set 5 ,(iy+x)	4	23
\$FDCBF6	set 6,(iy+x)	4	23	\$FDCBFE	set 7 , $(iy+x)$	4	23

Appendix D

Mnemonics to Extended Opcodes

	1	\mathbf{T}	-1		1
Tah	JD.	1)	١٠	aci-	മർമ

	-	Lanic	,	. acraac			
Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	T
aci x	\$CE	2	7	adc a,l	\$8D	1	4
adc a,(hl)	\$8E	1	7	adc a,x	\$CE	2	7
adc a,(ix+x)	\$DD8E	3	19	adc a	\$8F	1	4
adc a,(iy+x)	\$FD8E	3	19	adc b	\$88	1	4
adc a,a	\$8F	1	4	adc c	\$89	1	4
adc a,b	\$88	1	4	adc d	\$8A	1	4
adc a,c	\$89	1	4	adc e	\$8B	1	4
adc a,d	\$8A	1	4	adc hl,bc	\$ED4A	2	15
adc a,e	\$8B	1	4	adc hl,de	\$ED5A	2	15
adc a,h	\$8C	1	4	adc hl,hl	\$ED6A	2	15
adc a,ixh	\$DD8C	2	8	adc hl,sp	\$ED7A	2	15
adc a,ixl	\$DD8D	2	8	adc h	\$8C	1	4
adc a,iyh	\$FD8C	2	8	adc l	\$8D	1	4
adc a,iyl	\$FD8D	2	8	adc m	\$8E	1	7

Table D.2: add Sz | T | Mnemonic Mnemonic Opcode Opcode add a,(hl) add de,xx * \$ED35 16 add a,(ix+x) DD863 19 $\operatorname{add} d$ \$82 1 4 add a,(iy+x) PD8619 ${\rm add}\ {\rm e}$ \$83 1 add a,b \$80 4 add hl,bc \$09 1 11 1 add a,d \$82 4 add hl,hl \$29 1 11 add a,e \$83 1 4 add hl,sp \$39 1 11 add a,ixh \$DD84 8 add h \$84 1 4 add a,ixl \$DD85 8 add ix,bc \$DD09 2 2 2 2 15 2 2 add a,iyh \$FD84 8 add ix,de \$DD19 15 add a,iyl \$FD85 8 \$DD29 15 add ix,ix add a,l \$85 1 4 add ix,sp \$DD39 15 add a,x \$C6 2 $\frac{7}{4}$ \$FD09 15 add iy,bc $\begin{array}{c} 2 \\ 2 \\ 2 \\ 2 \end{array}$ add iy,de add a \$87 \$FD19 15 add iy,iy add iy,sp add bc,a * \$ED33 \$FD29 15 2 8 add bc,xx * \$ED36 4 16 \$FD39 15 add b \$80 4 add l \$85 1 1 $\frac{4}{7}$ 1 add c \$81 add m \$86 1 add de,
a * \$ED32 8

	,	Table	e D.3	: adi-ani			
Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	Т
adi x	\$C6	2	7	and b	\$A0	1	4
ana a	\$A7	1	4	and c	\$A1	1	4
ana b	\$A0	1	4	and d	\$A2	1	4
ana c	\$A1	1	4	and e	\$A3	1	4
ana d	\$A2	1	4	and h	\$A4	1	4
ana e	\$A3	1	4	and ixh	\$DDA4	2	8
ana h	\$A4	1	4	and ixl	\$DDA5	2	8
ana l	\$A5	1	4	and iyh	\$FDA4	2	8
ana m	\$A6	1	7	and iyl	\$FDA5	2	8
and (hl)	\$A6	1	7	and l	\$A5	1	4
and (ix+x)	\$DDA6	3	19	and x	\$E6	2	7
and (iy+x)	\$FDA6	3	19	ani x	\$E6	2	7
and a	\$A7	1	4				

	Τ	able	D.4:	bit 0-bit 3			
Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	T
bit 0,(hl)	\$CB46	2	12	bit 2,(hl)	\$CB56	2	12
bit $0,(ix+x)$	\$DDCB46	4	20	bit $2,(ix+x)$	\$DDCB56	4	20
bit 0 , $(iy+x)$	\$FDCB46	4	20	bit 2 , $(iy+x)$	\$FDCB56	4	20
bit 0,a	\$CB47	2	8	bit 2,a	\$CB57	2	8
bit 0,b	\$CB40	2	8	bit 2,b	\$CB50	2	8
bit 0,c	\$CB41	2	8	bit 2,c	\$CB51	2	8
bit 0,d	\$CB42	2	8	bit 2,d	\$CB52	2	8
bit 0,e	\$CB43	2	8	bit 2,e	\$CB53	2	8
bit 0,h	\$CB44	2	8	bit 2,h	\$CB54	2	8
bit 0,l	\$CB45	2	8	bit 2,l	\$CB55	2	8
bit 1,(hl)	\$CB4E	2	12	bit 3,(hl)	\$CB5E	2	12
bit 1,(ix+x)	\$DDCB4E	4	20	bit 3 ,(ix+x)	\$DDCB5E	4	20
bit 1,(iy+x)	\$FDCB4E	4	20	bit 3 ,(iy+x)	\$FDCB5E	4	20
bit 1,a	\$CB4F	2	8	bit 3,a	\$CB5F	2	8
bit 1,b	\$CB48	2	8	bit 3,b	\$CB58	2	8
bit 1,c	\$CB49	2	8	bit 3,c	\$CB59	2	8
bit 1,d	\$CB4A	2	8	bit 3,d	\$CB5A	2	8
bit 1,e	\$CB4B	2	8	bit 3,e	\$CB5B	2	8
bit 1,h	\$CB4C	2	8	bit 3,h	\$CB5C	2	8
bit 1,l	\$CB4D	2	8	bit 3,l	\$CB5D	2	8

Table D.5: bit 4-bit 7

Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	T
bit 4,(hl)	\$CB66	2	12	bit 6,(hl)	\$CB76	2	12
bit 4 ,(ix+x)	\$DDCB66	4	20	bit 6 ,(ix+x)	\$DDCB76	4	20
bit 4 ,(iy+x)	\$FDCB66	4	20	bit 6 ,(iy+x)	\$FDCB76	4	20
bit 4,a	\$CB67	2	8	bit 6,a	\$CB77	2	8
bit 4,b	\$CB60	2	8	bit 6,b	\$CB70	2	8
bit 4,c	\$CB61	2	8	bit 6,c	\$CB71	2	8
bit 4,d	\$CB62	2	8	bit $6,d$	\$CB72	2	8
bit 4,e	\$CB63	2	8	bit 6,e	\$CB73	2	8
bit 4,h	\$CB64	2	8	bit 6,h	\$CB74	2	8
bit 4,l	\$CB65	2	8	bit 6,l	\$CB75	2	8
bit 5,(hl)	\$CB6E	2	12	bit $7,(hl)$	\$CB7E	2	12
bit 5 ,(ix+x)	\$DDCB6E	4	20	bit 7 ,(ix+x)	\$DDCB7E	4	20
bit 5 ,(iy+x)	\$FDCB6E	4	20	bit 7 ,(iy+x)	\$FDCB7E	4	20
bit 5,a	\$CB6F	2	8	bit 7,a	\$CB7F	2	8
bit 5,b	\$CB68	2	8	bit 7,b	\$CB78	2	8
bit 5,c	\$CB69	2	8	bit 7,c	\$CB79	2	8
bit 5,d	\$CB6A	2	8	bit $7,d$	\$CB7A	2	8
bit 5,e	\$CB6B	2	8	bit 7,e	\$CB7B	2	8
bit 5,h	\$CB6C	2	8	bit 7,h	\$CB7C	2	8
bit 5,l	\$CB6D	2	8	bit 7,l	\$CB7D	2	8

Table D.6: brlc-cnz

			DIC 20.0				
Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	T
brlc de,b *	\$ED2C	2	8	ccf	\$3F	1	4
bsla de,b *	\$ED28	2	8	cm xx	\$FC	3	17/10
bsra de,b *	\$ED29	2	8	cma	\$2F	1	4
bsrf de,b *	\$ED2B	2	8	cmc	\$3F	1	4
bsrl de,b *	\$ED2A	2	8	cmp a	\$BF	1	4
call c,xx	\$DC	3	17/11	cmp b	\$B8	1	4
call m,xx	\$FC	3	17/10	стр с	\$B9	1	4
call nc,xx	\$D4	3	17/10	cmp d	\$BA	1	4
call nz,xx	\$C4	3	17/10	cmp e	\$BB	1	4
call p,xx	\$F4	3	17/10	cmp h	\$BC	1	4
call pe,xx	\$EC	3	17/10	cmp l	\$BD	1	4
call po,xx	\$E4	3	17/10	cmp m	\$BE	1	7
call xx	\$CD	3	17	cnc xx	\$D4	3	17/10
call z,xx	\$CC	3	17/10	cnz xx	\$C4	3	17/10
cc xx	\$DC	3	17/11				

Table D.7: cp-dcr

Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	T
cp (hl)	\$BE	1	7	cpir	\$EDB1	2	21/16
cp (ix+x)	\$DDBE	2	19	cpi	\$EDA1	2	16
cp (iy+x)	\$FDBE	2	19	cpl	\$2F	1	4
сра	\$BF	1	4	сро хх	\$E4	3	17/10
cp b	\$B8	1	4	cz xx	\$CC	3	17/10
ср с	\$B9	1	4	daa	\$27	1	4
cp d	\$BA	1	4	dad b	\$09	1	11
ср е	\$BB	1	4	dad d	\$19	1	11
cp h	\$BC	1	4	dad h	\$29	1	11
cp ixh	\$DDBC	2	8	dad sp	\$39	1	11
cp ixl	\$DDBD	2	8	dcr a	\$3D	1	4
cp iyh	\$FDBC	2	8	dcr b	\$05	1	4
cp iyl	\$FDBD	2	8	dcr c	\$0D	1	4
cp l	\$BD	1	4	dcr d	\$15	1	4
cp xx	\$F4	3	17/10	dcr e	\$1D	1	4
ср х	\$FE	2	7	dcr h	\$25	1	4
cpdr	\$EDB9	2	21/16	dcr l	\$2D	1	4
cpd	\$EDA9	2	16	dcr m	\$35	1	11
cpe	\$EC	3	17/10				

		Tab	le D	.8: dcx-im			
Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	T
dcx b	\$0B	1	6	dec iyl	\$FD2D	2	8
dcx d	\$1B	1	6	dec iy	\$FD2B	2	10
dcx h	\$2B	1	6	dec l	\$2D	1	4
dcx sp	\$3B	1	6	dec sp	\$3B	1	6
dec (hl)	\$35	1	11	di	\$F3	1	4
dec (ix+x)	\$DD35	3	23	djnz x	\$10	2	13/8
dec (iy+x)	\$FD35	3	23	ei	\$FB	1	4
dec a	\$3D	1	4	ex (sp),hl	\$E3	1	19
dec bc	\$0B	1	6	ex (sp),ix	\$DDE3	2	23
dec b	\$05	1	4	ex (sp),iy	\$FDE3	2	23
dec c	\$0D	1	4	ex af,af'	\$08	1	4
dec de	\$1B	1	6	ex de,hl	\$EB	1	4
dec d	\$15	1	4	exx	\$D9	1	4
dec e	\$1D	1	4	halt	\$76	1	4+
dec hl	\$2B	1	6	icr c	\$0C	1	4
dec h	\$25	1	4	icr e	\$1C	1	4
dec ixh	\$DD25	2	8	im 0	\$ED46	2	8
dec ixl	\$DD2D	2	8	im 1	\$ED56	2	8
dec ix	\$DD2B	2	10	im 2	\$ED5E	2	8
dec iyh	\$FD25	2	8				

		T_{2}	blo I	0.9: in-inx			
Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	Т
in a,(c)	\$ED78	2	12	inc ixl	\$DD2C	2	8
in a,(x)	\$DB	2	11	inc ix	\$DD23	2	10
in b,(c)	\$ED40	2	12	inc iyh	\$FD24	2	8
in c,(c)	\$ED48	2	12	inc iyl	\$FD2C	2	8
in d,(c)	\$ED50	2	12	inc iy	\$FD23	2	10
in e,(c)	\$ED58	2	12	inc l	\$2C	1	4
in f,(c)	\$ED70	2	12	inc sp	\$33	1	6
in h,(c)	\$ED60	2	12	indr	\$EDBA	2	21/16
in l,(c)	\$ED68	2	12	ind	\$EDAA	2	16
in x	\$DB	2	11	inir	\$EDB2	2	21/16
inc (hl)	\$34	1	11	ini	\$EDA2	2	16
inc (ix+x)	\$DD34	3	23	inr a	\$3C	1	4
inc (iy+x)	\$FD34	3	23	inr b	\$04	1	4
inc a	\$3C	1	4	inr d	\$14	1	4
inc bc	\$03	1	6	inr h	\$24	1	4
inc b	\$04	1	4	inr l	\$2C	1	4
inc c	\$0C	1	4	inr m	\$34	1	11
inc de	\$13	1	6	inx b	\$03	1	6
inc d	\$14	1	4	inx d	\$13	1	6
inc e	\$1C	1	4	inx h	\$23	1	6
inc hl	\$23	1	6	inx sp	\$33	1	6
inc h	\$24	1	4			-	_

Table D.10: jc-jz										
Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	T			
jc xx	\$DA	3	10	jp pe,xx	\$EA	3	10			
jm xx	\$FA	3	10	jp po,xx	\$E2	3	10			
jmp xx	\$C3	3	10	jp xx	\$C3	3	10			
jnc xx	\$D2	3	10	jp xx	\$F2	3	10			
jnz xx	\$C2	3	10	jp z,xx	\$CA	3	10			
jp (c) *	\$ED98	2	13	jpe xx	\$EA	3	10			
jp (hl)	\$E9	1	4	jpo xx	\$E2	3	10			
jp (ix)	\$DDE9	3	8	jr c,x	\$38	2	12/7			
jp (iy)	\$FDE9	3	8	jr nc,x	\$30	2	12/7			
jp c,xx	\$DA	3	10	jr nz,x	\$20	2	12/7			
jp m,xx	\$FA	3	10	jr x	\$18	2	12			
jp nc,xx	\$D2	3	10	jr z,x	\$28	2	12/7			
jp nz,xx	\$C2	3	10	jz xx	\$CA	3	10			
jp p,xx	\$F2	3	10							

Table D.11: ld (bc),a-ld (iy+x),x

					/ ;		
Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	Т
ld (bc),a	\$02	1	7	ld (ix+x),e	\$DD73	3	19
ld (de),a	\$12	1	7	ld (ix+x),h	\$DD74	3	19
ld (hl),a	\$77	1	7	ld (ix+x),l	\$DD75	3	19
ld (hl),b	\$70	1	4	ld (ix+x),x	\$DD36	5	19
ld (hl),c	\$71	1	4	ld (iy+x),a	\$FD77	3	19
ld (hl),d	\$72	1	4	ld (iy+x),b	\$FD70	3	19
ld (hl),e	\$73	1	4	ld (iy+x),c	\$FD71	3	19
ld (hl),h	\$74	1	4	ld (iy+x),d	\$FD72	3	19
ld (hl),l	\$75	1	4	ld (iy+x),e	\$FD73	3	19
ld (hl),x	\$36	2	10	ld (iy+x),h	\$FD74	3	19
ld (ix+x),a	\$DD77	3	19	ld (iy+x),l	\$FD75	3	19
ld (ix+x),b	\$DD70	3	19	ld (iy+x),x	\$FD36	5	19
ld (ix+x),c	\$DD71	3	19	//			

Table D.12: ld (xx),a-ld a,x

Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	T
ld (xx),a	\$32	3	13	ld a,b	\$78	1	4
ld (xx),bc	\$ED43	4	20	ld a,c	\$79	1	4
ld (xx),de	\$ED53	4	20	ld a,d	\$7A	1	4
ld (xx),hl	\$22	3	16	ld a,e	\$7B	1	4
ld (xx),ix	\$DD22	4	20	ld a,ixh	\$DD7C	2	8
ld (xx),iy	\$FD22	4	20	ld a,ixl	\$DD7D	2	8
ld (xx),sp	\$ED73	4	20	ld a,iyh	\$FD7C	2	8
ld a,(bc)	\$0A	1	7	ld a,iyl	\$FD7D	2	8
ld a,(de)	\$1A	1	7	ld a,i	\$ED57	2	9
ld a,(hl)	\$7E	1	7	ld a,l	\$7D	1	4
ld a,(ix+x)	\$DD7E	3	19	ld a,r	\$ED5F	2	9
ld a,(iy+x)	\$FD7E	3	19	ld a,x	\$3E	2	7
ld a,(xx)	\$3A	3	13				

Table D.13: ld b,(hl)-ld c,x

Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	T
ld b,(hl)	\$46	1	7	ld c,(hl)	\$4E	1	7
ld b,(ix+x)	\$DD46	2	19	ld c, (ix+x)	\$DD4E	3	19
ld b,(iy+x)	\$FD46	2	19	ld c,(iy+x)	\$FD4E	3	19
ld b,a	\$47	1	4	ld c,a	\$4F	1	4
ld b,b	\$40	1	4	ld c,b	\$48	1	4
ld b,c	\$41	1	4	ld c,c	\$49	1	4
ld b,d	\$42	1	4	ld c,d	\$4A	1	4
ld b,e	\$43	1	4	ld c,e	\$4B	1	4
ld b,h	\$44	1	4	ld c,h	\$4C	1	4
ld b,ixh	\$DD44	2	8	ld c,ixh	\$DD4C	2	8
ld b,ixl	\$DD45	2	8	ld c,ixl	\$DD4D	2	8
ld b,iyh	\$FD44	2	8	ld c,iyh	\$FD4C	2	8
ld b,iyl	\$FD45	2	8	ld c,iyl	\$FD4D	2	8
ld b,l	\$45	1	4	ld c,l	\$4D	1	4
ld b,x	\$06	2	7	ld c,x	\$0E	2	7
ld bc,(xx)	\$ED4B	4	20				

Table D.14: ld d,(hl)-ld e,x

				/ (/	/		
Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	T
ld d,(hl)	\$56	1	7	ld e,(hl)	\$5E	1	7
ld d,(ix+x)	\$DD56	3	19	ld e,(ix+x)	\$DD5E	3	19
ld d,(iy+x)	\$FD56	3	19	ld e,(iy+x)	\$FD5E	3	19
ld d,a	\$57	1	4	ld e,a	\$5F	1	4
ld d,b	\$50	1	4	ld e,b	\$58	1	4
ld d,c	\$51	1	4	ld e,c	\$59	1	4
ld d,d	\$52	1	4	ld e,d	\$5A	1	4
ld d,e	\$53	1	4	ld e,e	\$5B	1	4
ld d,h	\$54	1	4	ld e,h	\$5C	1	4
ld d,ixh	\$DD54	2	8	ld e,ixh	\$DD5C	2	8
ld d,ixl	\$DD55	2	8	ld e,ixl	\$DD5D	2	8
ld d,iyh	\$FD54	2	8	ld e,iyh	\$FD5C	2	8
ld d,iyl	\$FD55	2	8	ld e,iyl	\$FD5D	2	8
ld d,l	\$55	1	4	ld e,l	\$5D	1	4
ld d,x	\$16	2	7	ld e,x	\$1E	2	7
ld de,(xx)	\$ED5B	4	20				

Table D.15: ld h,(hl)-ld ixl,x

Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	T
ld h,(hl)	\$66	1	7	ld ixh,a	\$DD67	2	8
ld h, (ix+x)	\$DD65	3	19	ld ixh,b	\$DD60	2	8
ld h,(iy+x)	\$FD65	3	19	ld ixh,c	\$DD61	2	8
ld h,a	\$67	1	4	ld ixh,d	\$DD62	2	8
ld h,b	\$60	1	4	ld ixh,e	\$DD63	2	8
ld h,c	\$61	1	4	ld ixh,ixh	\$DD64	2	8
ld h,d	\$62	1	4	ld ixh,ixl	\$DD65	2	8
ld h,e	\$63	1	4	ld ixh,x	\$DD26	3	11
ld h,h	\$64	1	4	ld ixl,a	\$DD6F	2	8
ld h,l	\$65	1	4	ld ixl,b	\$DD68	2	8
ld h,x	\$26	2	7	ld ixl,c	\$DD69	2	8
ld hl,(xx)	\$2A	3	16	ld ixl,d	\$DD6A	2	8
ld hl,(xx)	\$ED6B	4	20	ld ixl,e	\$DD6B	2	8
ld hl,xx	\$21	3	10	ld ixl,ixh	\$DD6C	2	2
ld i,a	\$ED47	2	9	ld ixl,ixl	\$DD6D	2	2
ld ix,(xx)	\$DD2A	4	20	ld ixl,x	\$DD2E	4	11
ld ix,xx	\$DD21	4	14				

Table D.16: ld iyh,a-ld sp,xx

Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	T
ld iyh,a	\$FD67	2	8	ld l,(ix+x)	\$DD6E	3	19
ld iyh,b	\$FD60	2	8	ld l,(iy+x)	\$FD6E	3	19
ld iyh,c	\$FD61	2	8	ld l,a	\$6F	1	4
ld iyh,d	\$FD62	2	8	ld l,b	\$68	1	4
ld iyh,e	\$FD63	2	8	ld l,c	\$69	1	4
ld iyh,iyh	\$FD64	2	8	ld l,d	\$6A	1	4
ld iyh,iyl	\$FD65	2	8	ld l,e	\$6B	1	4
ld iyh,x	\$FD26	3	11	ld l,h	\$6C	1	4
ld iyl,a	\$FD6F	2	8	ld l,l	\$6D	1	4
ld iyl,b	\$FD68	2	8	ld l,x	\$2E	2	7
ld iyl,c	\$FD69	2	8	ld r,a	\$ED4F	2	9
ld iyl,d	\$FD6A	2	8	ld sp,(xx)	\$ED7B	4	20
ld iyl,e	\$FD6B	2	8	ld sp,hl	\$F9	1	6
ld iyl,iyh	\$FD6C	2	2	ld sp,ix	\$DDF9	2	10
ld iyl,iyl	\$FD6D	2	2	ld sp,iy	\$FDF9	2	10
ld iyl,x	\$FD2E	4	11	ld sp,xx	\$31	3	10
ld l,(hl)	\$6E	1	7				

Table D.17: lda-mirror

Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	T
lda xx	\$3A	3	13	ldi	\$EDA0	2	16
ldax b	\$0A	1	7	ldpirx *	\$EDB7	2	21/16
ldax d	\$1A	1	7	ldws *	\$EDA5	2	14
lddrx *	\$EDBC	2	21/16	lhld xx	\$2A	3	16
lddr	\$EDB8	2	21/16	lxi b,xx	\$01	3	10
lddx *	\$EDAC	2	16	lxi d,xx	\$11	3	10
ldd	\$EDA8	2	16	lxi h,xx	\$21	3	10
ldirx *	\$EDB4	2	21/16	lxi sp,xx	\$31	3	10
ldir	\$EDB0	2	21/16	mirror a *	\$ED24	2	8
ldix *	\$EDA4	2	16				

Table D.18: mov a,a-mov d,m

Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	T
mov a,a	\$7F	1	4	mov c,b	\$48	1	4
mov a,b	\$78	1	4	mov c,c	\$49	1	4
mov a,c	\$79	1	4	mov c,d	\$4A	1	4
mov a,d	\$7A	1	4	mov c,e	\$4B	1	4
mov a,e	\$7B	1	4	mov c,b	\$4C	1	4
mov a,h	\$7C	1	4	mov c,l	\$4D	1	4
mov a,l	\$7D	1	4	mov c,m	\$4E	1	7
mov a,m	\$7E	1	7	mov d,a	\$57	1	4
mov b,a	\$47	1	4	mov d,b	\$50	1	4
mov b,b	\$40	1	4	mov d,c	\$51	1	4
mov b,c	\$41	1	4	mov d,d	\$52	1	4
mov b,d	\$42	1	4	mov d,e	\$53	1	4
mov b,e	\$43	1	4	mov d,h	\$54	1 1	4
mov b,h	\$44	1	4	mov d,l	\$55	1 1	4
mov b,l	\$45	1	4	mov d,n	\$56	1 1	7
mov b,m	\$46	1	7	1110 4,111	400	*	'
mov b,m	940	1	- 1				

Table D.19: mov e,a-mov m,l

	Table B.19. Mov c,a-mov m,i										
Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	Т				
mov e,a	\$5F	1	4	mov l,a	\$6F	1	4				
mov e,b	\$58	1	4	mov l,b	\$68	1	4				
mov e,c	\$59	1	4	mov l,c	\$69	1	4				
mov e,d	\$5A	1	4	mov l,d	\$6A	1	4				
mov e,e	\$5B	1	4	mov l,e	\$6B	1	4				
mov e,h	\$5C	1	4	mov l,h	\$6C	1	4				
mov e,l	\$5D	1	4	mov l,l	\$6D	1	4				
mov e,m	\$5E	1	7	mov l,m	\$6E	1	7				
mov h,a	\$67	1	4	mov m,a	\$77	1	7				
mov h,b	\$60	1	4	mov m,b	\$70	1	4				
mov h,c	\$61	1	4	mov m,c	\$71	1	4				
mov h,d	\$62	1	4	mov m,d	\$72	1	4				
mov h,e	\$63	1	4	mov m,e	\$73	1	4				
mov h,h	\$64	1	4	mov m,h	\$74	1	4				
mov h,l	\$65	1	4	mov m,l	\$75	1	4				
mov h,m	\$66	1	7								

	ŗ	Γ able	D.2	0: mul-otir			
Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	Т
mul d,e *	\$ED30	2	8	or e	\$B3	1	4
mvi a,x	\$3E	2	7	or h	\$B4	1	4
mvi b,x	\$06	2	7	or ixh	\$DDB4	2	8
mvi c,x	\$0E	2	7	or ixl	\$DDB5	2	8
mvi d,x	\$16	2	7	or iyh	\$FDB4	2	8
mvi e,x	\$1E	2	7	or iyl	\$FDB5	2	8
mvi h,x	\$26	2	7	or l	\$B5	1	4
mvi l,x	\$2E	2	7	or x	\$F6	2	7
mvi m,x	\$36	2	10	ora a	\$B7	1	4
neg	\$ED44	2	8	ora b	\$B0	1	4
nextreg r,a *	\$ED92	3	17	ora c	\$B1	1	4
nextreg r,v *	\$ED91	4	20	ora d	\$B2	1	4
nop	\$00	1	4	ora e	\$B3	1	4
or (hl)	\$B6	1	7	ora h	\$B4	1	4
or (ix+x)	\$DDB6	3	19	ora l	\$B5	1	4
or (iy+x)	\$FDB6	3	19	ora m	\$B6	1	7
or a	\$B7	1	4	ori x	\$F6	2	7
or b	\$B0	1	4	otdr	\$EDBB	2	12/16
or c	\$B1	1	4	otir	\$EDB3	2	21/16
or d	\$B2	1	4				

	Table D.21: out-rc										
Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	T				
out (c),a	\$ED79	2	12	pop hl	\$E1	1	10				
out (c),b	\$ED41	2	12	pop h	\$E1	1	10				
out (c),c	\$ED49	2	12	pop ix	\$DDE1	2	14				
out (c),d	\$ED51	2	12	pop iy	\$FDE1	2	14				
out (c),e	\$ED59	2	12	pop psw	\$F1	1	10				
out (c),f	\$ED71	2	12	push af	\$F5	1	11				
out (c),h	\$ED61	2	12	push bc	\$C5	1	11				
out (c),l	\$ED69	2	12	push b	\$C5	1	11				
out (x),a	\$D3	2	11	push de	\$D5	1	11				
out x	\$D3	2	11	push d	\$D5	1	11				
outd	\$EDAB	2	16	push hl	\$E5	1	11				
outinb *	\$ED90	2	16	push h	\$E5	1	11				
outi	\$EDA3	2	16	push ix	\$DDE5	2	15				
pchl	\$E9	1	4	push iy	\$FDE5	2	15				
pixelad *	\$ED94	2	8	push psw	\$F5	1	11				
pixeldn *	\$ED93	2	8	push xx	\$ED8A	4	*				
pop af	\$F1	1	10	ral	\$17	1	4				
pop bc	\$C1	1	10	rar	\$1F	1	4				
pop b	\$C1	1	10	rc	\$D8	1	11/5				
pop de	\$D1	1	10				,				

	Ta	able l	D.22:	res 0-res 3			
Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	Т
res 0,(hl)	\$CB86	2	15	res 2,(ix+x)	\$DDCB96	4	23
res 0,(ix+x)	\$DDCB86	4	23	res 2,(iy+x)	\$FDCB96	4	23
res 0,(iy+x)	\$FDCB86	4	23	res 2,a	\$CB97	2	8
res 0,a	\$CB87	2	8	res 2,b	\$CB90	2	8
res 0,b	\$CB80	2	8	res 2,c	\$CB91	2	8
res 0,c	\$CB81	2	8	res 2,d	\$CB92	2	8
res 0,d	\$CB82	2	8	res 2,e	\$CB93	2	8
res 0,e	\$CB83	2	8	res 2,h	\$CB94	2	8
res 0,h	\$CB84	2	8	res 2,l	\$CB95	2	8
res 0,l	\$CB85	2	8	res 3,(hl)	\$CB9E	2	15
res 1,(hl)	\$CB8E	2	15	res 3 ,(ix+x)	\$DDCB9E	4	23
res 1,(ix+x)	\$DDCB8E	4	23	res 3 ,(iy+x)	\$FDCB9E	4	23
res $1,(iy+x)$	\$FDCB8E	4	23	res 3,a	\$CB9F	2	8
res 1,a	\$CB8F	2	8	res 3,b	\$CB98	2	8
res 1,b	\$CB88	2	8	res 3,c	\$CB99	2	8
res 1,c	\$CB89	2	8	res 3,d	\$CB9A	2	8
res 1,d	\$CB8A	2	8	res 3,e	\$CB9B	2	8
res 1,e	\$CB8B	2	8	res 3,h	\$CB9C	2	8
res 1,h	\$CB8C	2	8	res 3,l	\$CB9D	2	8
res 1,l	\$CB8D	2	8				

	Ta	able 1	D.23:	res 4-res 7			
Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	T
res 4,(hl)	\$CBA6	2	15	res 6,(ix+x)	\$DDCBB6	4	23
res 4,(ix+x)	\$DDCBA6	4	23	res 6,(iy+x)	\$FDCBB6	4	23
res 4,(iy+x)	\$FDCBA6	4	23	res 6,a	\$CBB7	2	8
res 4,a	\$CBA7	2	8	res 6,b	\$CBB0	2	8
res 4,b	\$CBA0	2	8	res 6,c	\$CBB1	2	8
res 4,c	\$CBA1	2	8	res 6,d	\$CBB2	2	8
res 4,d	\$CBA2	2	8	res 6,e	\$CBB3	2	8
res 4,e	\$CBA3	2	8	res 6,h	\$CBB4	2	8
res 4,h	\$CBA4	2	8	res 6,l	\$CBB5	2	8
res 4,l	\$CBA5	2	8	res 7,(hl)	\$CBBE	2	15
res 5,(hl)	\$CBAE	2	15	res 7 ,(ix+x)	\$DDCBBE	4	23
res 5,(ix+x)	\$DDCBAE	4	23	res 7 ,(iy+x)	\$FDCBBE	4	23
res 5,(iy+x)	\$FDCBAE	4	23	res 7,a	\$CBBF	2	8
res 5,a	\$CBAF	2	8	res 7,b	\$CBB8	2	8
res 5,b	\$CBA8	2	8	res 7,c	\$CBB9	2	8
res 5,c	\$CBA9	2	8	res 7,d	\$CBBA	2	8
res 5,d	\$CBAA	2	8	res 7,e	\$CBBB	2	8
res 5,e	\$CBAB	2	8	res 7,h	\$CBBC	2	8
res 5,h	\$CBAC	2	8	res 7,l	\$CBBD	2	8
res 5,l	\$CBAD	2	8				

Table D.24: ret-rp

Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	Т
ret c	\$D8	1	11/5	rla	\$17	1	4
ret m	\$F8	1	11/5	rlc (hl)	\$CB06	2	15
ret nc	\$D0	1	11/5	rlc (ix+x)	\$DDCB06	4	23
ret nz	\$C0	1	11/5	rlc (iy+x)	\$FDCB06	4	23
ret pe	\$E8	1	11/5	rlc a	\$CB07	2	8
ret po	\$E0	1	11/5	rlc b	\$CB00	2	8
ret p	\$F0	1	11/5	rlc c	\$CB01	2	8
ret z	\$C8	1	11/5	rlc d	\$CB02	2	8
reti	\$ED4D	2	14	rlc e	\$CB03	2	8
retn	\$ED45	2	14	rlc h	\$CB04	2	8
ret	\$C9	1	10	rlc l	\$CB05	2	8
rl (hl)	\$CB16	2	15	rlca	\$07	1	4
rl (ix+x)	\$DDCB16	4	23	rlc	\$07	1	4
rl (iy+x)	\$FDCB16	4	23	rld	\$ED6F	2	18
rl a	\$CB17	2	8	rm	\$F8	1	11/5
rl b	\$CB10	2	8	rnc	\$D0	1	11/5
rl c	\$CB11	2	8	rnz	\$C0	1	11/5
rl d	\$CB12	2	8	rpe	\$E8	1	11/5
rl e	\$CB13	2	8	rpo	\$E0	1	11/5
rl h	\$CB14	2	8	rp	\$F0	1	11/5
rl l	\$CB15	2	8	_			,

Tab	le D.	25:	rr-rz

Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	T
rr (hl)	\$CB1E	2	15	rrca	\$0F	1	4
rr (ix+x)	\$DDCB1E	4	23	rrc	\$0F	1	4
rr (iy+x)	\$FDCB1E	4	23	rrd	\$ED67	2	18
rr a	\$CB1F	2	8	rst 00h	\$C7	1	11
rr b	\$CB18	2	8	rst 08h	\$CF	1	11
rr c	\$CB19	2	8	rst 0	\$C7	1	11
rr d	\$CB1A	2	8	rst 10h	\$D7	1	11
rr e	\$CB1B	2	8	rst 18h	\$DF	1	11
rr h	\$CB1C	2	8	rst 1	\$CF	1	11
rr l	\$CB1D	2	8	rst 20h	\$E7	1	11
rra	\$1F	1	4	rst 28h	\$EF	1	11
rrc (hl)	\$CB0E	2	15	rst 2	\$D7	1	11
rrc (ix+x)	\$DDCB0E	4	23	rst 30h	\$F7	1	11
rrc (iy+x)	\$FDCB0E	4	23	rst 38h	\$FF	1	11
rrc a	\$CB0F	2	8	rst 3	\$DF	1	11
rrc b	\$CB08	2	8	rst 4	\$E7	1	11
rrc c	\$CB09	2	8	rst 5	\$EF	1	11
rrc d	\$CB0A	2	8	rst 6	\$F7	1	11
rrc e	\$CB0B	2	8	rst 7	\$FF	1	11
rrc h	\$CB0C	2	8	rz	\$C8	1	11/5
rrc l	\$CB0D	2	8				, í

Table D.26: sbb-scf

				<u>). 800-801</u>			
Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	T
sbb a	\$9F	1	4	sbc a,e	\$9B	1	4
sbb b	\$98	1	4	sbc a,h	\$9C	1	4
sbb c	\$99	1	4	sbc a,ixh	\$DD9C	2	8
sbb d	\$9A	1	4	sbc a,ixl	\$DD9D	2	8
sbb e	\$9B	1	4	sbc a,iyh	\$FD9C	2	8
sbb h	\$9C	1	4	sbc a,iyl	\$FD9D	2	8
sbb l	\$9D	1	4	sbc a,l	\$9D	1	4
sbb m	\$9E	1	7	sbc a,x	\$DE	2	7
sbc a,(hl)	\$9E	1	7	sbc hl,bc	\$ED42	2	15
sbc a,(ix+x)	\$DD9E	3	1	sbc hl,de	\$ED52	2	15
sbc a,(iy+x)	\$FD9E	3	1	sbc hl,hl	\$ED62	2	15
sbc a,a	\$9F	1	4	sbc hl,sp	\$ED72	2	15
sbc a,b	\$98	1	4	sbi x	\$DE	2	7
sbc a,c	\$99	1	4	scf	\$37	1	4
sbc a,d	\$9A	1	4				

Table D.27: set 0-set 3

1able D.21. Set 0-set 0							
Mnemonic	Opcode	Sz	T	Mnemonic	Opcode	Sz	Т
set 0,(hl)	\$CBC6	2	15	set 2 ,(ix+x)	\$DDCBD6	4	23
set 0,(ix+x)	\$DDCBC6	4	23	set 2,(iy+x)	\$FDCBD6	4	23
set $0,(iy+x)$	\$FDCBC6	4	23	set 2,a	\$CBD7	2	8
set 0,a	\$CBC7	2	8	set 2,b	\$CBD0	2	8
set 0,b	\$CBC0	2	8	set 2,c	\$CBD1	2	8
set 0,c	\$CBC1	2	8	set 2,d	\$CBD2	2	8
set 0,d	\$CBC2	2	8	set 2,e	\$CBD3	2	8
set 0,e	\$CBC3	2	8	set 2,h	\$CBD4	2	8
set 0,h	\$CBC4	2	8	set 2,l	\$CBD5	2	8
set 0,l	\$CBC5	2	8	set 3,(hl)	\$CBDE	2	15
set 1,(hl)	\$CBCE	2	15	set 3 ,(ix+x)	\$DDCBDE	4	23
set 1,(ix+x)	\$DDCBCE	4	23	set 3 ,(iy+x)	\$FDCBDE	4	23
set $1,(iy+x)$	\$FDCBCE	4	23	set 3,a	\$CBDF	2	8
set 1,a	\$CBCF	2	8	set 3,b	\$CBD8	2	8
set 1,b	\$CBC8	2	8	set 3,c	\$CBD9	2	8
set 1,c	\$CBC9	2	8	set 3,d	\$CBDA	2	8
set 1,d	\$CBCA	2	8	set 3,e	\$CBDB	2	8
set 1,e	\$CBCB	2	8	set 3,h	\$CBDC	2	8
set 1,h	\$CBCC	2	8	set 3,l	\$CBDD	2	8
set 1,l	\$CBCD	2	8				

Table D.28: set 4-set 7

Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	T
set 4,(hl)	\$CBE6	2	15	set 6,(ix+x)	\$DDCBF6	4	23
set 4,(ix+x)	\$DDCBE6	4	23	set 6 , $(iy+x)$	\$FDCBF6	4	23
set 4,(iy+x)	\$FDCBE6	4	23	set 6,a	\$CBF7	2	8
set 4,a	\$CBE7	2	8	set 6,b	\$CBF0	2	8
set 4,b	\$CBE0	2	8	set 6,c	\$CBF1	2	8
set 4,c	\$CBE1	2	8	set 6,d	\$CBF2	2	8
set 4,d	\$CBE2	2	8	set 6,e	\$CBF3	2	8
set 4,e	\$CBE3	2	8	set 6,h	\$CBF4	2	8
set 4,h	\$CBE4	2	8	set 6,l	\$CBF5	2	8
set 4,l	\$CBE5	2	8	set 7,(hl)	\$CBFE	2	15
set 5,(hl)	\$CBEE	2	15	set 7 ,(ix+x)	\$DDCBFE	4	23
set 5,(ix+x)	\$DDCBEE	4	23	set 7 , $(iy+x)$	\$FDCBFE	4	23
set 5,(iy+x)	\$FDCBEE	4	23	set 7,a	\$CBFF	2	8
set 5,a	\$CBEF	2	8	set 7,b	\$CBF8	2	8
set 5,b	\$CBE8	2	8	set 7,c	\$CBF9	2	8
set 5,c	\$CBE9	2	8	set $7,d$	\$CBFA	2	8
set 5,d	\$CBEA	2	8	set 7,e	\$CBFB	2	8
set 5,e	\$CBEB	2	8	set 7,h	\$CBFC	2	8
set 5,h	\$CBEC	2	8	set 7,l	\$CBFD	2	8
set 5,l	\$CBED	2	8				

Table D.29: setae-stc Opcode Mnemonic Opcode Mnemonic Т Sz\$ED95 2 \$DDCB2E 23 setae * sra (ix+x) 4 shld xx \$22 3 16 sra (iy+x) \$FDCB2E 4 23CB26sla (hl) 2 15 sra à CB2F2 8 sla (ix+x) $\$ \mathrm{DDCB26}$ 4 23 sra b \$CB28 2 8 sla (iy+x) \$FDCB26 23sra c CB292 8 sla a CB272 8 $\operatorname{sra} d$ \$CB2A 2 8 sla b CB202 sra e CB2B2 2 sla c CB218 $\operatorname{sra}\,h$ $\$\mathrm{CB2C}$ 2 8 2 sla dCB22sra l CB2D2 2 sla e CB238 srl (hl) CB3E2 15 sla h CB248 srl (ix+x) DDCB3E23 2 sla l CB25srl (iy+x) FDCB3E23 sll (hl) CB3615 CB3F2 sll (ix+x) \$DDCB36 4 23 srl b \$CB38 2 8 sll (iy+x) FDCB3623 $\mathrm{srl}\ \mathrm{c}$ \$CB39 $\frac{2}{2}$ sll à CB37 $\mathrm{srl}\ \mathrm{d}$ \$CB3A 8 sll b \$CB30 ${\rm srl}\ {\rm e}$ CB3B $\frac{2}{2}$ sll c \$CB31 2 8 srl h \$CB3C 8 sll d \$CB32 8 srl l \$CB3D 2 2 2 8 sll e \$CB33 8 sta xx \$32 3 13 sll h \$CB34 8 stax b \$02 1 7 \$CB35 2 8 \$12 7 sll l $\operatorname{stax} d$ 1 \$F9 1 6 \$37 4 sphlstcsra (hl) \$CB2E 2

Table D.30: sub-xthl							
Mnemonic	Opcode	Sz	Т	Mnemonic	Opcode	Sz	Т
sub (hl)	\$96	1	7	xor a	\$AF	1	4
sub (ix+x)	\$DD96	3	19	xor b	\$A8	1	4
sub (iy+x)	\$FD96	3	19	xor c	\$A9	1	4
sub a	\$97	1	4	xor d	\$AA	1	4
sub b	\$90	1	4	xor e	\$AB	1	4
sub c	\$91	1	4	xor h	\$AC	1	4
sub d	\$92	1	4	xor ixh	\$DDAC	2	8
sub e	\$93	1	4	xor ixl	\$DDAD	2	8
sub h	\$94	1	4	xor iyh	\$FDAC	2	8
sub ixh	\$DD94	2	8	xor iyl	\$FDAD	2	8
sub ixl	\$DD95	2	8	xor l	\$AD	1	4
sub iyh	\$FD94	2	8	xor x	\$EE	2	7
sub iyl	\$FD95	2	8	xra a	\$AF	1	4
sub l	\$95	1	4	xra b	\$A8	1	4
sub m	\$96	1	7	xra c	\$A9	1	4
sub x	\$D6	2	7	xra d	\$AA	1	4
sui x	\$D6	2	7	xra e	\$AB	1	4
swapinb *	\$ED23	2	8	xra h	\$AC	1	4
test x *	\$ED27	3	11	xra l	\$AD	1	4
xchg	\$EB	1	4	xra m	\$AE	1	7
xor (hl)	\$AE	1	7	xri x	\$EE	2	7
xor (ix+x)	\$DDAE	3	19	xthl	\$E3	1	19
xor (iy+x)	\$FDAE	3	19				

Appendix E

File Formats

E.1 AKY

Music file

E.2 BAS

Basic file

E.3 BMP

Windows bitmap. On the ZX Spectrum next, these must be uncompressed and 8 bpp.

E.4 DOT, DOTX, DOTN, DOTN-X

DOT A command file which returns after completion. Can be no longer than 8k and must be compiled to reside in memory starting at \$2000. Rather than using this extension, these live in the dot directory. This is loaded into divmmc memory.

DOTX An extended dot file than can be more than 8k

DOTN A ZX Next Specific extention to a dot file, allowed to be over 8k

DOTN-X An extended version of a dotn file.

E.5 DSK

Disk image

E.6 ESP

Update file for Wi-Fi module

E.7 GDE

ZX Spectrum Next Guide hypertext file

E.8 MOD

Modtracker music file (requires Pi accelerator to play).

E.9 NDR

Nexdaw music file

E.10 NEX

ZX Spectrum Next executable file.

E.11 O

ZX-80 executable file

E.12 P3D

Disk image file

E.13. PT3 263

E.13 PT3

Protracker 3 music file

E.14 P

ZX-81 executable file

E.15 SDH

Music file (requires Pi accelerator to play)

E.16 SID

Commodore 64 SID music file (requires Pi accelerator to play)

E.17 SCR

ZX Spectrum screen dump

In basic form a 6912 byte file containing the bitmap and colour map for a standard spectrum image. May have ULAPlus or ULANext color data appended.

ULAplus

- $\bullet\,$ bytes 0-6143 bitmap: memory order
- bytes 6144-6911 colour map: memory order
- bytes 6912-6975 ULAPlus palette data

ULANext

- $\bullet\,$ bytes 0-6143 bitmap: memory order
- $\bullet\,$ bytes 6144-6911 colour map: memory order
- $\bullet\,$ byte 6912 ULAN
ext mode
- bytes 6913-between 6228 and 7426 ULANext palette data, size is dependent on specific ULANext mode and 8 or 9 bit palette entries.

mode	ink	paper	8-bit	9-bit
\$01	2	128	130	260
\$03	4	64	68	136
\$07	8	32	40	80
\$0F	16	16	32	64
\$1F	32	8	40	80
\$3F	64	4	68	136
\$7F	128	2	130	260
FF	256	1	257	514

E.18 SHC, MC, MLT

SHC Timex hi-color screen dump

In basic form the 12,288 byte file containing the bitmap and colour map for a Timex hi-color image. May have ULAPlus or ULANext color data appended.

ULAplus

- bytes 0-6143 bitmap: memory order
- $\bullet\,$ bytes 6144-12287 colour map: memory order
- $\bullet\,$ bytes 12288-12351 ULAPlus palette data

ULANext

- bytes 0-6143 bitmap: memory order
- bytes 6144-12287 colour map: memory order
- byte 12288 ULANext mode
- bytes 12289-between 12304 and 12802 ULANext palette data, size is dependent on specific ULANext mode and 8 or 9 bit palette entries.

mode	ink	paper	8-bit	9-bit
\$01	2	128	130	260
\$03	4	64	68	136
\$07	8	32	40	80
\$0F	16	16	32	64
\$1F	32	8	40	80
\$3F	64	4	68	136
\$7F	128	2	130	260
\$FF	256	1	257	514

 \mathbf{MC} $\,$ A Timex hi-color image. Like .shc, but the bitmap and colour map are stored in display order.

MLT A Timex hi-color image. Like .shc, but the colour map is stored in display order.

E.19. SHR 265

E.19 SHR

Timex hi-resolution screen dump.

A 12,288 or 12,289 byte file containing a memory dump of the two 6k screen areas used by Timex hi-resolution mode in memory order with an optional byte indicating the colours used.

E.20 SL2, NXI

SL2 ZX Spectrum Next layer 2 screen dump

In its most basic standard form, this is a 49,152 byte file containing the memory for the image data.

256x192x8

- bytes 0-49151 image data: row dominant
- optional bytes 49152-49407 or 49663 palette data (256 bytes for 8-bit entries, 512 bytes for 9-bit entries)

320x256x8

- bytes 0-81919 image data: column dominant
- \bullet optional bytes 81920-82175 or 82431 palette data (256 bytes for 8-bit entries, 512 bytes for 9-bit entries)

640x256x4

- bytes 0-81919 image data: column dominant, nybbles in adjacent columns
- optional bytes 81920-81935 or 81951 palette data (16 bytes for 8-bit entries, 32 bytes for 9-bit entries)

NXI A version of a 256x192x8 layer 2 image.

- bytes 0-511 palette data
- \bullet bytes 512-49663 image data

E.21 SLR

ZX Spectrum Next low-resolution screen dump.

Basic standard form 12,288 byte file containing the memory for the two 6k areas for 128x96x8 image files

192x96x8

• bytes 0-12287 - image data: row dominant

 \bullet optional bytes 12288-12543 or 12799 - palette data (256 bytes for 8-bit entries, 512 bytes for 9-bit entries)

192x96x4 (Radistan)

- bytes 0-6143 image data: row dominant
- optional bytes 6144-6159 or 6175 palette data (16 bytes for 8-bit entries, 32 bytes for 9-bit entries)

E.22 SNA

ZX Spectrum memory snapshot

E.23 SND

Music file (requires Pi accelerator to play)

E.24 SNX

Extended ZX Spectrum memory snapshot to be run in ZX Spectrum Next mode

E.25 SPR

Sprite file

E.26 TAP

ZX Spectrum tape image

E.27 TXT,DOC,ASM,INI,CFG,MD

Text files

E.28. TZX 267

E.28 TZX

ZX Spectrum tape image (able to handle custom tape formats). Requires Pi accelerator to load.

E.29 WAV

PCM audio file

E.30 XM

XM tracker music file (requires Pi accelerator to play)

E.31 Z3 to Z8

Inform interactive fiction files

E.32 Z80

ZX Spectrum memory snapshot

E.33 ZIP

Zip compressed file

Appendix F

Call Tables

F.1 BDOS Call Table

Name		Parameters	Return Value
SYSTEM RESET	\$00 (0)		
CONSOLE INPUT	\$01 (1)		A=character
CONSOLE OUTPUT	\$02 (2)	E=character	
AUXILIARY INPUT	\$03 (3)		A=character
AUXILIARY OUTPUT	\$04 (4)	E=character	
LIST OUTPUT	\$05 (5)	E=character	
DIRECT CONSOLE I/O	\$06 (6)	E=function/data	A=char/status
AUXILIARY INPUT STATUS	\$07 (7)		A=status
AUXILIARY OUTPUT STATUS	\$08 (8)		A=status
PRINT STRING	\$09 (9)	DE=string address	
READ CONSOLE BUFFER	\$0A (10)	DE=buffer address	data in buffer
GET CONSOLE STATUS	\$0B (11)		A=status
RETURN VERSTION NUMBER	\$0C (12)		HL=version number
RESET DISK SYSTEM	\$0D (13)		
SELECT DISK	\$0E (14)	E=disk	A=error flag, E=error
OPEN FILE	\$0F (15)	DE=FCB address	A=dir code, H=error
CLOSE FILE	\$10 (16)	DE=FCB address	A=dir code, H=error
SEARCH FOR FIRST	\$11 (17)	DE=FCB address	A=dir code, H=error
SEARCH FOR NEXT	\$12 (18)		A=dir code, H=error
DELETE FILE	\$13 (19)	DE=FCB address	A=dir code, H=error
READ SEQUENTIAL	\$14 (20)	DE=FCB address	A=error code, H=phys error
WRITE SEQUENTIAL	\$15 (21)	DE=FCB address	A=error code, H=phys error
MAKE FILE	\$16 (22)	DE=FCB address	A=dir code, H=error
RENAME FILE	\$17 (23)	DE=FCB address	A=dir code, H=error
RETURN LOGIN VECTOR	\$18 (24)		HL=login vector
RETURN CURRENT DISK	\$19 (25)		A=current disk
SET DMA ADDRESS	\$1A (26)	DE=DMA address	
GET ADDRESS (ALLOC)	\$1B (27)		HL=ALLOC address
WRITE PROTECT DISK	\$1C (28)		
GET READ-ONLY VECTOR	\$1D (29)		HL=R/O Vector Value
SET FILE ATTRIBUTES	\$1E (30)	DE=FCB address	A=dir code, H=error
GET ADDR (DPB PARAMS)	\$1F (31)		HL=DPB address
GET USER CODE	\$20 (32)	E=\$FF	A=user code
SET USER CODE	\$20 (32)	E=user code	
READ RANDOM	\$21 (33)	DE=FCB address	A=error code, H=phys error
WRITE RANDOM	\$22 (34)	DE=FCB address	A=error code, H=phys error
COMPUTE FILE SIZE	\$23 (35)	DE=FCB address	A=error flag, H=error,

Name		Parameters	Return Value
			FCB modified
SET RANDOM RECORD	\$24 (36)	DE=FCB address	FCB modified
RESET DRIVE	\$25 (37)	DE=Drive vector	A=\$00
ACCESS DRIVE	\$26 (38)		
FREE DRIVE	\$27 (39)		
WRITE RANDOM WITH ZERO	\$28 (40)	DE=FCB address	A=error code, H=phys error
FILL			
TEST AND WRITE RECORD	\$29 (41)	DE=FCB address	A=error code, H=phys error
LOCK RECORD	\$2A (42)	DE=FCB address	A=\$00
UNLOCK RECORD	\$2B (43)	DE=FCB address	A=\$00
SET MULTI-SECTOR COUNT	\$2C (44)	E=Number of sectors	A=return code
SET BDOS ERROR MODE	\$2D (45)	E=BDOS Error mode	
GET FREE DISK SPACE	\$2E (46)	E=Drive	DMA Buffer modified,
	\		A=error flag, H=error code
CHAIN TO PROGRAM	\$2F (47)	E=chain flag	no return
FLUSH BUFFERS	\$30 (48)		A=error flag, H=error
GET/SET SYSTEM CONTROL	\$31 (49)	DE=SCB PB address	A=returned byte,
BLOCK			HL=returned word
DIRECT BIOS CALL	\$32 (50)	DE=BIOS PB address	BIOS return
LOAD OVERLAY	\$3B (59)	DE=FCB address	A=error code, H=phys error
CALL RESIDENT SYSTEM	\$3C (60)	DE=RSX PB address	A=error code, H=phys error
EXTENSION			
FREE BLOCKS	\$62 (98)		A=error flag, H=error
TRUNCATE FILE	\$63 (99)	DE=FCB address	A=dir code, H=error
SET DIRECTORY LABEL	\$64 (100)	DE=FCB address	A=dir code, H=error
RETURN DIRECTORY	\$65 (101)	E=drive	A=dir label data byte
LABEL DATA			H=error
READ FILE STAMPS AND	\$66 (102)	DE=FCB address	A=dir code, H=error
PASSWORD MODE			
WRITE XFCB	\$67 (103)	DE=FCB address	A=dir code, H=error
SET DATE AND TIME	\$68 (104)	DE=DAT address	
GET DATE AND TIME	\$69 (105)	DE=DAT address	DAT modified, A=seconds
SET DEFAULT PASSWORD	\$6A (106)	DE=password address	
RETURN SERIAL NUMBER	\$6B (107)	DE=serial number files	serial number field set
GET PROGRAM RET CODE	\$6C (108)	DE=\$FFFF	HL=program return code
SET PROGRAM RET CODE	\$6C (108)	DE=program return code	
GET CONSOLE MODE	\$6D (109)	DE=\$FFFF	HL=console mode
SET CONSOLE MODE	\$6D (109)	DE=console mode	
PRINT BLOCK	\$6F (111)	DE=CCB address	
LIST BLOCK	\$70 (112)	DE=CCB address	
PARSE FILENAME	\$98 (152)	DE=PCFB address	HL=return code, PCFB modified

F.2 BIOS Call Table

F.3 NextZXOS Calls

${\bf F.3.1 \quad +3DOS \ Compatible \ Calls}$

Filesystem Calls		
DOS VERSION	\$0103 (259)	Get +3DOS issue and version numbers
DOS OPEN*	\$0106 (262)	Create and/or open a file
DOS CLOSE	\$0109 (265)	Close a file
DOS ABANDON	\$010C (268)	Abandon a file
DOS REF HEAD	\$010F (271)	Point at the header data for this file
DOS READ	\$0112 (274)	Read bytes into memory
DOS WRITE	\$0115 (277)	Write bytes from memory
DOS BYTE READ	\$0118 (280)	Read a byte
DOS BYTE WRITE	\$011B (283)	Write a byte
DOS CATALOG*	\$011E (286)	Catalog disk directory
DOS FREE SPACE*	\$0121 (289)	Free space on disk
DOS DELETE	\$0124 (292)	Delete a file
DOS_BELETE DOS_RENAME	\$0127 (295)	Rename a file
DOS_BOOT	\$012A (298)	Boot an operating system or other program
DOS SET DRIVE	\$012D (301)	Set/get default drive
DOS SET USER	\$0130 (304)	Set/get default user number
DOS GET POSITION*	\$0133 (307)	Get file pointer for random access
DOS SET POSITION	\$0136 (310)	Set file pointer for random access
DOS GET EOF*	\$0139 (313)	Get end of file position for random access
DOS GET 1346	\$013C (316)	Get memory usage in pages 1, 3, 4, 6
DOS SET 1346	\$013F (319)	Re-allocate memory usage in pages 1, 3, 4, 6
DOS_SET_1340 DOS_FLUSH	\$0142 (322)	Bring disk up to date
DOS SET ACCESS	\$0145 (325)	Change open file's access mode
DOS SET ATTRIBUTES	\$0148 (328)	Change a file's attributes
DOS_SET_ATTRIBUTES DOS_SET_MESSAGE	\$014E (334)	Enable/disable error messages
DOS_SET_MESSAGE	Ψ014L (334)	Eliable/disable effor messages
DD L XDPB	\$0187 (391)	Initialise an XDPB from a disk specification
DD L DPB	\$018A (394)	Initialise a DPB from a disk specification
System Calls	` '	
DOS INITIALISE	\$0100 (256)	Initialise +3DOS
IDE INTERFACE	\$00A3 (163)	Initialise card interfaces
IDE INIT	\$00A6 (166)	Initialise IDEDOS
IDE ^{DRIVE}	\$00A9 (169)	Get unit handle
IDE SECTOR READ*	\$00AC (172)	Low-level sector read
IDE SECTOR WRITE*	\$00AF (175)	Low-level sector write
IDE PARTITON READ	\$00C4 (196)	Read a partition entry
IDE_PARTITON_READ IDE_PARTITION_OPEN		Read a partition entry Open a partition
	\$00C4 (196)	
IDE_PARTITION_OPEN	\$00C4 (196) \$00CD (205)	Open a partition
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE	\$00C4 (196) \$00CD (205) \$00D0 (208)	Open a partition Close a partition
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS	\$00C4 (196) \$00CD (205) \$00D0 (208)	Open a partition Close a partition
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls	\$00C4 (196) \$00CD (205) \$00D0 (208) \$01A5 (421)	Open a partition Close a partition Get number of open partitions
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B	\$00C4 (196) \$00CD (205) \$00D0 (208) \$01A5 (421) \$014B (331) \$0154 (340)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE	\$00C4 (196) \$00CD (205) \$00D0 (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present?
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT	\$00C4 (196) \$00CD (205) \$00D0 (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP	\$00C4 (196) \$00CD (205) \$00DD (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP DD_SET_RETRY	\$00C4 (196) \$00CD (205) \$00D0 (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP DD_SET_RETRY DD_READ_SECTOR	\$00C4 (196) \$00CD (205) \$00D0 (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SET_RETRY DD_READ_SECTOR DD_WRITE_SECTOR	\$00C4 (196) \$00CD (205) \$00DD (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector
IDE PARTITION OPEN IDE PARTITION CLOSE IDE PARTITIONS Unimplemented Calls DOS OPEN DRIVE DOS MAP B DD INTERFACE DD INIT DD SETUP DD SET RETRY DD READ SECTOR DD WRITE SECTOR DD CHECK SECTOR	\$00C4 (196) \$00CD (205) \$00DO (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$0169 (361)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP DD_SET_RETRY DD_READ_SECTOR DD_WRITE_SECTOR DD_CHECK_SECTOR DD_FORMAT	\$00C4 (196) \$00CD (205) \$00DD (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$0169 (361) \$016C (364)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector Format a track
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP DD_SET_RETRY DD_READ_SECTOR DD_WRITE_SECTOR DD_CHECK_SECTOR DD_FORMAT DD_READ_ID	\$00C4 (196) \$00CD (205) \$00D0 (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$0166 (364) \$016C (364) \$016F (367)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector Format a track Read a sector identifier
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP DD_SET RETRY DD_READ_SECTOR DD_WRITE_SECTOR DD_CHECK_SECTOR DD_FORMAT DD_READ_ID DD_TEST_UNSUITABLE	\$00C4 (196) \$00CD (205) \$00D0 (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$0169 (361) \$016C (364) \$016F (367) \$0172 (370)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector Format a track Read a sector identifier Test media suitability
IDE PARTITION OPEN IDE PARTITION CLOSE IDE PARTITION CLOSE IDE PARTITIONS Unimplemented Calls DOS OPEN DRIVE DOS MAP B DD INTERFACE DD INIT DD SETUP DD SET RETRY DD READ SECTOR DD WRITE SECTOR DD CHECK SECTOR DD FORMAT DD READ ID DD TEST UNSUITABLE DD LOGIN	\$00C4 (196) \$00CD (205) \$00DO (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$0169 (361) \$016C (364) \$016F (367) \$0175 (373)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector Format a track Read a sector identifier Test media suitability Log in disk, initialise XDPB
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP DD_SET_RETRY DD_READ_SECTOR DD_WRITE_SECTOR DD_WRITE_SECTOR DD_FORMAT DD_READ_ID DD_TEST_UNSUITABLE DD_LOGIN DD_SEL_FORMAT	\$00C4 (196) \$00CD (205) \$00DO (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$0166 (364) \$016F (367) \$0172 (370) \$0175 (373) \$0178 (376)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector Format a track Read a sector identifier Test media suitability Log in disk, initialise XDPB Pre-initialise XDPB for DD FORMAT
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP DD_SET_RETRY DD_READ_SECTOR DD_WRITE_SECTOR DD_CHECK_SECTOR DD_FORMAT DD_READ_ID DD_TEST_UNSUITABLE DD_LOGIN DD_SEL_FORMAT DD_SEL_FORMAT DD_ASK_1	\$00C4 (196) \$00CD (205) \$00DD (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$0166 (364) \$016F (367) \$0172 (370) \$0175 (373) \$0178 (376) \$017B (379)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector Format a track Read a sector identifier Test media suitability Log in disk, initialise XDPB Pre-initialise XDPB for DD FORMAT Is unit 1 & external drive & present?
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP DD_SET_RETRY DD_READ_SECTOR DD_WRITE_SECTOR DD_CHECK_SECTOR DD_FORMAT DD_READ_ID DD_TEST_UNSUITABLE DD_LOGIN DD_SEL_FORMAT DD_ASK_1 DD_DRIVE_STATUS	\$00C4 (196) \$00CD (205) \$00D0 (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$0169 (361) \$016F (367) \$0172 (370) \$0175 (373) \$0178 (376) \$017B (379) \$017E (382)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector Format a track Read a sector identifier Test media suitability Log in disk, initialise XDPB Pre-initialise XDPB for DD FORMAT Is unit 1 & external drive & present? Fetch drive status
IDE PARTITION OPEN IDE PARTITION CLOSE IDE PARTITIONS Unimplemented Calls DOS OPEN DRIVE DOS MAP B DD INTERFACE DD INIT DD SETUP DD SET RETRY DD READ SECTOR DD WRITE SECTOR DD FORMAT DD FORMAT DD TEST UNSUITABLE DD LOGIN DD SEL FORMAT DD SEL FORMAT DD ASK 1 DD DRIVE STATUS DD EQUIPMENT	\$00C4 (196) \$00CD (205) \$00DO (208) \$01A5 (421) \$01AB (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$016F (367) \$0172 (370) \$0175 (373) \$0178 (376) \$017B (379) \$017E (382) \$0181 (385)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector Format a track Read a sector identifier Test media suitability Log in disk, initialise XDPB Pre-initialise XDPB for DD FORMAT Is unit 1 & external drive & present? Fetch drive status What type of drive?
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP DD_SET RETRY DD_READ_SECTOR DD_WRITE_SECTOR DD_CHECK_SECTOR DD_FORMAT DD_READ_ID DD_TEST_UNSUITABLE DD_LOGIN DD_SEL_FORMAT DD_ASK_1 DD_DRIVE_STATUS DD_EQUIPMENT DD_ENCODE	\$00C4 (196) \$00CD (205) \$00DO (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$016F (367) \$0175 (373) \$0175 (373) \$0175 (373) \$0178 (376) \$017B (379) \$017E (382) \$0181 (385) \$0184 (388)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector Format a track Read a sector identifier Test media suitability Log in disk, initialise XDPB Pre-initialise XDPB for DD FORMAT Is unit 1 & external drive & present? Fetch drive status What type of drive? Set intercept routine for copy protection
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP DD_SET_RETRY DD_READ_SECTOR DD_WRITE_SECTOR DD_WRITE_SECTOR DD_FORMAT DD_READ_ID DD_TEST_UNSUITABLE DD_LOGIN DD_SEL_FORMAT DD_ASK_1 DD_DRIVE_STATUS DD_EQUIPMENT DD_ENCODE DD_L_SEEK	\$00C4 (196) \$00CD (205) \$00DD (208) \$01A5 (421) \$01AB (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$016F (367) \$0172 (370) \$0175 (373) \$0178 (376) \$017B (379) \$017B (382) \$0181 (385) \$018D (397)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector Format a track Read a sector identifier Test media suitability Log in disk, initialise XDPB Pre-initialise XDPB for DD FORMAT Is unit 1 & external drive & present? Fetch drive status What type of drive? Set intercept routine for copy protection uPD765A seek driver
IDE_PARTITION_OPEN IDE_PARTITION_CLOSE IDE_PARTITIONS Unimplemented Calls DOS_OPEN_DRIVE DOS_MAP_B DD_INTERFACE DD_INIT DD_SETUP DD_SET RETRY DD_READ_SECTOR DD_WRITE_SECTOR DD_CHECK_SECTOR DD_FORMAT DD_READ_ID DD_TEST_UNSUITABLE DD_LOGIN DD_SEL_FORMAT DD_ASK_1 DD_DRIVE_STATUS DD_EQUIPMENT DD_ENCODE	\$00C4 (196) \$00CD (205) \$00DO (208) \$01A5 (421) \$014B (331) \$0154 (340) \$0157 (343) \$015A (346) \$015D (349) \$0160 (352) \$0163 (355) \$0166 (358) \$016F (367) \$0175 (373) \$0175 (373) \$0175 (373) \$0178 (376) \$017B (379) \$017E (382) \$0181 (385) \$0184 (388)	Open a partition Close a partition Get number of open partitions Open a drive as a single file Map B: onto unit 0 or 1 Is the floppy disk driver interface present? Initialise disk driver Specify drive parameters Set try/retry count Read a sector Write a sector Check a sector Format a track Read a sector identifier Test media suitability Log in disk, initialise XDPB Pre-initialise XDPB for DD FORMAT Is unit 1 & external drive & present? Fetch drive status What type of drive? Set intercept routine for copy protection

DD_L_ON_MOTOR DD_L_T_OFF_MOTOR	\$0196 (406) \$0199 (409)	Motor on, wait for motor-on time Start the motor-off ticker
DD_L_OFF_MOTOR	\$019C (412)	Turn the motor off
IDE_FORMAT	\$00B2 (178)	Format a partition
IDE PARTITION NEW	\$00B8 (184)	Create partition
IDE PARTITION INIT	\$00BB (187)	Initialise partition
IDE PARTITION ERASE	\$00BE (190)	Delete a partition
IDE PARTITION RENAME	\$00C1 (193)	Rename a partition
IDE PARTITION WRITE	\$00C7 (199)	Write a partition entry
IDE PARTITION WINFO	\$00CA (202)	Write type-specific partition information
IDE PARTITION GETINFO	\$00D3 (211)	Get byte from type-specific partition information
IDE PARTITION SETINFO	\$00D6 (214)	Set byte in type-specific partition information
IDE DOS UNPERMANENT	\$00FA (250)	Remove permanent drive mapping
IDE_IDENTIFY	\$01A2 (418)	Return IDE drive identity information

F.3.2 +3DOS compatible error codes

\overline{Re}	coverable disl	k errors
0	rc ready	Drive not ready
1	rc_wp	Disk is write protected
2	rc seek	Seek fail
3	rc crc	CRC data error
4	rc nodata	No data
5	rc mark	Missing address mark
6	rc unrecog	Unrecognised disk format
7	rc unknown	Unknown disk error
8	rc_diskchg	Disk changed whilst +3DOS was using it
9	rc_unsuit	Unsuitable media for drive
	${f n} ext{-}{f R}$ ecoverabl	
20	$rc_badname$	Bad filename
21	$rc_badparam$	Bad parameter
22	rc_nodrive	Drive not found
23	rc_nofile	File not found
24	rc_exists	File already exists
25	rc_eof	End of file
26	$rc_diskfull$	Disk full
27	rc_dirfull	Directory full
28	rc_ro	Read-only file
29	rc_number	File number not open (or open with wrong access)
30	rc_denied	Access denied
31	$rc_norename$	Cannot rename between drives
32	rc_extent	Extent missing
33	rc_uncached	Uncached
34	rc_toobig	File too big
35	rc_notboot	Disk not bootable
36	$^{\rm rc}$ _inuse	Drive in use
56	rc invpartition	Invalid partition
57	rc_partexist	Partition already exists
58	rc notimp	Not implemented
59	rc_partopen	Partition open
60	rc nohandle	Out of handles
61	$rc_notswap$	Not a swap partition
62	rc mapped	Drive already mapped
63	rc_noxdpb	No XDPB
64	rc_noswap	No suitable swap partition
65	rc_invdevice	Invalid device
67	$rc_cmdphase$	Command phase error
68	rc_dataphase	Data phase error
69	rc_notdir	Not a directory
74	$rc_fragmented$	File is fragmented, use .DEFRAG
	*	

${\bf F.3.3 \quad esxDOS \ Compatible \ Calls}$

Low-level ca	alls			
disk filemap	\$85 (133)	obtain file allocation map		
disk strmstart	\$86 (134)	start streaming operation		
disk_strmend	\$87 (135)	end streaming operation		
Miscellaneo	us calls			
m_dosversion	\$88 (136)	get NextZXOS version/mode information		
$m_{getsetdrv}$	\$89 (137)	get/set default drive		
m_tapein	\$8B (139)	tape redirection control (input)		
$m_tapeout$	\$8C (140)	tape redirection control (output)		
$m_{gethandle}$	\$8D (141)	get handle for current dot command		
$m_{getdate}$	\$8E (142)	get current date/time		
$m_{execcmd}$	\$8F (143)	execute a dot command		
$m_setcaps$	\$91 (145)	set additional capabilities		
m_{drvapi}	\$92 (146)	access API for installable drivers		
m_{geterr}	\$93 (147)	get or generate error message		
m_p3dos	\$94 (148)	execute $+3DOS/IDEDOS/NextZXOS$ call		
m_errh	\$95 (149)	register dot command error handler		
File calls				
f_open	\$9A (154)	open file		
f_close	\$9B (155)	close file		
f_sync	\$9C (156)	sync file changes to disk		
f_{read}	\$9D (157)	read file		
f_write	\$9E (158)	write file		
f_{seek}	\$9F (159)	set file position		
$f_{fgetpos}$	\$A0 (160)	get file position		
f_fstat	\$A1 (161)	get open file information		
$f_{ftruncate}$	\$A2 (162)	truncate/extend open file		
$f_{opendir}$	\$A3 (163)	open directory for reading		
$f_{readdir}$	\$A4 (164)	read directory entry		
f_{telldir}	A5 (165)	get directory position		
$f_{seekdir}$	\$A6 (166)	set directory position		
$f_{\text{rewinddir}}$	A7 (167)	rewind to start of directory		
f_{getcwd}	\$A8 (168)	get current working directory		
f_{chdir}	\$A9 (169)	change directory		
$_{\mathrm{mkdir}}$	\$AA (170)	make directory		
$f_{ m rmdir}$	\$AB (171)	remove directory		
f_stat	\$AC (172)	get unopen file information		
f_unlink	\$AD (173)	delete file		
$_{ m truncate}$	\$AE (174)	truncate/extend unopen file		
f_{chmod}	\$AF (175)	change file attributes		
f_rename	\$B0 (176)	rename/move file		
$f_{getfree}$	\$B1 (177)	get free space		

Appendix G

Keyboard Codes

G.1 ZX Spectrum Next (keymap data)

	0	1	2	3	4	5	6
0	CAPS SHIFT	Z	X	С	V	EXTEND	1
1	A	S	D	F	G	CAPS LOCK	GRAPH
2	Q	W	E	R	Т	TRUE VID	INV VID
3	1	2	3	4	5	BREAK	EDIT
4	0	9	8	7	6	;	"
5	P	О	I	U	Y	, (comma)	. (period)
6	RET	L	K	J	Н	DELETE	\Rightarrow
7	' '(space)	SYM SHIFT	M	N	В	<=	

G.2 PS/2 (keymap address)

	0	1	2	3	4	5	6	7	8	9	A	В	С	D	Е	F
00x		F9		F5	F3	F1	F2	F12		F10	F8	F6	F4	tab	٠/	
01x		LAlt	LShift		LCtl	Q	1/!				Z	S	A	W	2@	
02x		С	X	D	Е	4/\$	3/#			٠,	V	F	Т	R	5/%	
03x		N	В	Н	G	Y	6/"				M	J	U	7/&	8/*	
04x		,/<	K	I	0	0/)	9/(./>	//?	L	;/:	P	-/	
05x			1/"		[/{	=/+					- / /		,,		bs	
06x		[1]	,	[4]	[7]	,			[0]	[.]	[2]	[5]	[6]	[8]	Esc	NumLk
07x	F11	[+]	[3]	[-]	[*]	[9]	ScrLk					F7				
08x			. 1													
09x																
0Ax																
0Bx																
0Cx																
0Dx																
0Ex																
0Fx																
10x										RAlt	PrtSc		RCtl			
11x								LWin								RWin
12x								Menu								Power
13x								Sleep								
14x			[/]													
15x			[Enter]				Wake									
16x		End		=	Home				Ins	Del			\Rightarrow	1		
17x			PgDown			PgUp										
18x																
19x																
1Ax																
1Bx																
1Cx																
1Dx																
1Ex																
1Fx																

List of Figures

2.1	Pattern Example	33
2.2	All Rotate and Mirror Flags	36

List of Tables

2.1	Layer 1 Mode summary $\dots \dots
2.2	Layer 1 Memory Map
2.3	ULA Colour
2.4	ULANext
2.5	Hi-Resolution Colours
5.1	Special Paging Modes
6.1	zxnDMA Registers
7.1	Vertical Line Counts and Dot Clock Combinations 81
7.2	Dot Clocks per Second
7.3	Maximum Horizontal COPPER Compare 82
7.4	Slack Dot Clocks After Maximum Compare
7.5	Horizontal Timing
7.6	Vertical Timing
7.7	Ideal Extended Resolutions for Both VGA and HDMI $$ 84
7.8	Ideal Extended Resolution Display Parameters 84
7.9	Instruction Bit Definition
7.10	Register Bit Definitions
7.11	Control Mode Definitions
7.12	Summary of Video Modes
11.1	System Control Block

280 LIST OF TABLES

11.2 Program Return Codes	77
11.3 FCB Format	77
A.1 ZX Spectrum Ports	93
C.1 \$00-\$1F	37
C.2 \$20-\$3F	38
C.3 \$40-\$5F	38
C.4 \$60-\$7F	38
C.5 \$80-\$9F	39
C.6 \$A0-\$BF	39
C.7 \$C0-\$DF	39
C.8 \$E0-\$FF	40
C.9 \$CB00-\$CB1F	41
C.10 \$CB20-\$CB3F	41
C.11 \$CB40-\$CB5F	42
C.12 \$CB60-\$CB7F	42
C.13 \$CB80-\$CB9F	42
C.14 \$CBA0-\$CBBF	43
C.15 \$CBC0-\$CBDF	43
C.16 \$CBE0-\$CBFF	43
C.17 \$DD00-\$DD5F	44
C.18 \$DD60-\$CB8F	44
C.19 \$DD90-\$DDFF	45
C.20 \$ED00-\$ED4F	45
C.21 \$ED50-\$ED8F	46
C.22 \$ED90-\$EDFF	46
C.23 \$FD00-\$FD5F	47
C.24 \$FD60-\$FD8F	47
C.25 \$FD90-\$FDFF	
C.26 \$DDCB00-\$DDCBFF	48

LIST OF TABLES	281
C.27 \$FDCB00-\$FDCBFF	248
D.1 aci-adc	249
D.2 add	250
D.3 adi-ani	250
D.4 bit 0-bit 3	250
D.5 bit 4-bit 7	251
D.6 brlc-cnz	251
D.7 cp-dcr	251
D.8 dcx-im	252
D.9 in-inx	252
$D.10\mathrm{jc\text{-}jz}$	252
D.11 ld (bc), a-ld (iy+x), x	253
D.12 ld (xx),a-ld a,x \dots	253
D.13 ld b,(hl)-ld c,x	253
D.14 ld d,(hl)-ld e,x	254
D.15 ld h,(hl)-ld ixl,x	254
D.16 ld iyh,a-ld sp,xx	254
D.17 lda-mirror	255
D.18 mov a,a-mov d,m	255
D.19 mov e,a-mov m,l	255
D.20 mul-otir	256
D.21 out-rc	256
D.22 res 0-res 3	257
D.23 res 4-res 7	257
D.24 ret-rp	258
D.25 rr-rz	258
D.26 sbb-scf	259
D.27 set 0-set 3	259
D.28 set 4-set 7	259
D.29 setae-stc	260

282									LIST OF						TABLE				
D.30 sub-xthl	 																	260)

Index

access drive, 149 address, 26 attribute, 26 auxiliary input, 124 auxiliary input status, 125 auxiliary output, 124 auxiliary output status, 125 AUXIN, 169 AUXIST, 170 AUXOST, 170 AUXOUT, 169

BOOT, 167

call resident system extension, 155 chain to program, 152 clip window, 29, 43 close file, 131 compute file size, 147 CONIN, 169 CONOST, 170 CONOUT, 169 console input, 123 console output, 123 CONST, 168

delete file, 133
DEVINI, 168
DEVTBL, 167
direct BIOS calls, 154
direct console I/O, 124
DOS_CATALOG, 181
DOS_FREE_SPACE, 181
DOS_GET_EOF, 182
DOS_GET_POSITION, 181
DOS_OPEN, 180
DRVTBL, 168

FLUSH, 173 flush buffers, 152 free blocks, 156 free drive, 149

get addr(alloc), 140 get addr(DPB parms), 143 get console mode, 163 get console status, 128 get date and time, 162 get disk free space, 151 get output delimiter, 164 get program return code, 163 get read-only vector, 141 get system control bock, 153 get user code, 143

HOME, 170

IDE_BANK, 184
IDE_BROWSER, 184
IDE_CAPACITY, 184
IDE_DOS_MAP, 180
IDE_DOS_MAPPING, 180
IDE_DOS_UNMAP, 180
IDE_GET_LFN, 184
IDE_PATH, 184
IDE_SNAPLOAD, 180
IDE_SWAP_EX, 180
IDE_SWAP_OPEN, 179

LIST, 169 list block, 165 list output, 124 LISTST, 169 load overlay, 155 lock record, 150 284 INDEX

make file, 137 MOVE, 173 MULTIO, 173

open file, 129

palette, 5, 34 parse filename, 165 print block, 165 print string, 125

READ, 172

read console buffer, 125

read file date stamps and password mode, WBOOT, 167
159
WRITE, 172

159

read random, 143 read sequential, 134 rename file, 138 reset disk system, 128

reset drive, 148 return current disk, 140

return directory label data, 159

return login vector, 139 return serial number, 163

return version number, 128

scroll offset, 29

search for first, 132

search for next, 133

SECTRN, 173

SELDSK, 171

select disk, 129

SELMEM, 174

set BDOS error mode, 151

set console mode, 163

set date and time, 161

set default password, 162

set directory label, 158

set dma address, 140

set file attributes, 141

set multi-sector count, 150

set output delimiter, 164

set program return code, 163

set random record, 148

set system control bock, 153

set user code, 143

SETBNK, 174 SETDMA, 171 SETSEC, 171 SETTRK, 171 system reset, 122

test and write record, 149

TIME, 175

transparency, 4, 27, 44 truncate file, 157

unlock record, 150

write file XFCB, 160 write protect disk, 141 write random, 145

write random with zero fill, 149

write sequential, 136

XMOVE, 174