Pilot Plant


MES PLANNING TOOL / PO BUILDING





HOW TO SCHEDULE

Production Orders?







Schedule from PO and INSP Predefined Templates





Select INSP LOT Template






Select Start and End and Schedule Step#3







SCHEDULE






Schedule Inspection LOT for Dairy Liquid Receiving (Internal2165i)




















EDIT PO and Inspection LOT Templates





EDIT SPEC, Attribute and AttrGroup



Same process applies to screens below NIR MOJO AV 52.50 51.00 54.00 CMDR RENNET ADD VAT RENNET Edit Specification. X INDIVIDUAL D-OK-NOK 40.50000000000 NIR MOJO AVERAGE 40.000000 CHEM-VAT WHEY CHEM-VAT WHEY 0000131 44.00000000000 CM-DRYMIX 10040117 VATL1 236 2033 • ClearAll •