

Causes of Lumix GX880 Live View Stream Drop (Wi-Fi Remote)

Panasonic's Lumix GX880 (a.k.a. GF10/GX800 series) can stream a live-view feed to a smartphone or PC via Wi-Fi, but users often report the feed cutting out unexpectedly. Through reverse-engineering insights and user feedback, several common causes have been identified – ranging from built-in power-saving behaviors to network and application issues. Below we break down each cause and how to mitigate it, with technical details where relevant.

Power-Saving and Idle Timeout Factors

Auto Sleep Timers: The GX880 firmware aggressively conserves power during Wi-Fi remote control. By design, the camera's own LCD is turned off whenever a Wi-Fi remote session is active ¹. More critically, the camera may enter sleep or shut down after a period of perceived "inactivity." In particular, Lumix cameras have a **"Sleep Mode (Wi-Fi)"** setting that will automatically power off the camera after a set duration if no active operation is detected ². On many models this timeout is ~15 minutes of idle time (or if Wi-Fi was enabled but no connection was made) ². If the remote app isn't constantly engaging the camera (e.g. no focus or capture commands for several minutes), the GX880 might decide to shut off to save battery. This would obviously stop the live-view stream.

Auto Power-Off Overrides: Fortunately, when an official remote control session is active, the camera **should** disable its normal sleep timer – it's intended to stay on as long as it's "in use." However, if the camera incorrectly interprets that it's not being used (for example, if the app fails to send periodic keep-alive commands), the sleep timer could still kick in. Ensuring **Sleep Mode** and **Sleep Mode(Wi-Fi)** are turned *off* in the camera's menus can prevent any automatic shut-off ³. In practice, some users disable these settings entirely during remote shoots to avoid unwanted timeouts. Keeping the camera on AC power or a dummy battery is also recommended for long sessions, not only to prevent battery drain but because the GX880 **cannot charge via USB while in use**, meaning a regular battery will eventually die and end the stream ⁴.

Interruptions from Camera Operations and User Actions

Capture & Playback Actions: Certain camera operations will intentionally or unintentionally interrupt the live view stream. For example, capturing a photo may momentarily pause the feed – the camera has to process the image, and if "image review" is enabled it might not continue streaming video frames during that moment. In most cases the stream should resume after a brief pause, but if the camera enters an image playback/review state, the remote live view can stop. Many Lumix models actually suppress the usual on-camera image review when in remote mode (to prioritize the live feed), but a lengthy operation (like long exposure NR processing, burst processing, etc.) could still stall the feed.

Mode Changes: The Wi-Fi live view works only in shooting mode. If **either the user or the app triggers a mode change** – for instance, switching the dial to Playback or entering a menus screen – the camera will typically terminate the remote control session (and thus the stream) ⁵. The Panasonic Image App has separate “Live Control” vs. “Playback” modes ⁶; entering the Playback menu to view images will cut off the live view. Essentially, any action that takes the camera out of its remote shooting state (even inadvertently) will stop the stream. Users have noted that you should **avoid pressing physical controls on the camera** during Wi-Fi control unless necessary. Even changing certain settings can briefly disrupt the feed if the camera has to adjust (for example, toggling from record video to capture photo mode). Generally, it's best to initiate critical actions (like starting/stopping video recording) from the remote app rather than the camera itself to keep the session stable.

Recording Limitations: It's worth noting the GX880's own recording limitations – for instance, it imposes a 20-minute continuous video recording cap in some modes ⁷. If you are remotely recording video and hit such a limit, the recording (and possibly the live view) will stop by design. While this doesn't directly “disconnect” the Wi-Fi, it does interrupt the live feed if the camera stops the video. The live view should return once the camera is back in standby, but there could be a momentary drop. In summary, be mindful of the camera's operational limits during remote use, as hitting a limit (thermal, file-length, buffer, etc.) might appear as an unexpected stream drop.

Network Instability and UDP Packet Loss

UDP Stream Fragility: The GX880 streams live-view frames as **MJPEG video over UDP** – a lightweight method with minimal latency, but no built-in recovery for lost packets ⁸ ⁹. Each frame is sent as a series of UDP packets. If any packets are lost in transit due to Wi-Fi interference or poor signal, that video frame cannot be fully decoded, often causing a visible freeze or drop in the feed ⁹. Unlike a robust streaming protocol (e.g. TCP or RTP with retransmission), UDP doesn't guarantee delivery. Thus, **network instability (weak Wi-Fi signal, interference, crowded channels)** is a common culprit for the live view stalling. The symptom is usually a frozen image or choppy, erratic video. The stream might appear to stop, when in reality the camera is still broadcasting but packets aren't reaching the app intact.

No.	Time	Source	Destination	Protocol	Length	Info
253	1.303940452	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=23680, ID=41e0) [Reassembled in #255]
254	1.304571053	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=25160, ID=41e0) [Reassembled in #255]
255	1.304699170	192.168.0.6	192.168.0.10	UDP	456	65416 → 49199 Len=27054
256	1.305631347	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=0, ID=41e1) [Reassembled in #274]
257	1.306250002	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=1480, ID=41e1) [Reassembled in #274]
258	1.306879098	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=2960, ID=41e1) [Reassembled in #274]
259	1.310508513	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=4440, ID=41e1) [Reassembled in #274]
260	1.311368369	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=5920, ID=41e1) [Reassembled in #274]
261	1.312077044	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=7400, ID=41e1) [Reassembled in #274]
262	1.312695602	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=8880, ID=41e1) [Reassembled in #274]
263	1.313431922	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=10360, ID=41e1) [Reassembled in #274]
264	1.314111957	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=11840, ID=41e1) [Reassembled in #274]
265	1.314758739	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=13320, ID=41e1) [Reassembled in #274]
266	1.315413373	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=14800, ID=41e1) [Reassembled in #274]
267	1.316095786	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=16280, ID=41e1) [Reassembled in #274]
268	1.317531864	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=17760, ID=41e1) [Reassembled in #274]
269	1.318155605	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=19240, ID=41e1) [Reassembled in #274]
270	1.318868587	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=20720, ID=41e1) [Reassembled in #274]
271	1.319488066	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=22200, ID=41e1) [Reassembled in #274]
272	1.320168675	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=23680, ID=41e1) [Reassembled in #274]
273	1.320796556	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=25160, ID=41e1) [Reassembled in #274]
274	1.321115446	192.168.0.6	192.168.0.10	UDP	461	65416 → 49199 Len=27059
275	1.321770261	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=0, ID=41e2)
276	1.322431359	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=1480, ID=41e2)
277	1.323121405	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=2960, ID=41e2)
278	1.323731900	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=4440, ID=41e2)
279	1.324413120	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=5920, ID=41e2)
280	1.325032694	192.168.0.6	192.168.0.10	IP	1514	Fragmented IP protocol (proto=UDP 17, off=7400, ID=41e2)

Figure: Wireshark capture of a Lumix Wi-Fi live view stream, showing a single MJPEG video frame broken into many UDP fragments (each ~1514 bytes). In this example, one 27 KB frame is split across 19 UDP packets (IDs 0x4e10–

0x4e12). If any one fragment is dropped, the entire frame is lost ¹⁰. Multiple lost frames can lead to extended freezes as buffers overflow.

Impact of Packet Loss: Because each frame can require ~15–20 UDP packets, losing just a few percent of packets can translate to many dropped frames. Users have described the live view feed as **randomly degrading or freezing** especially on congested Wi-Fi networks ⁹. In testing, Michael Tandy noted the “mjpeg-over-UDP protocol doesn’t work very well in the presence of dropped packets or link congestion,” leading to apparent random freezes ⁹. In some cases, the stream may halt for several seconds if the receiver’s UDP buffer saturates. (On Linux, for example, a backlog of incomplete UDP fragments can build up if multiple large frames are lost, causing the socket to stop delivering new data until older fragments time out ¹¹.) This manifests as an extended freeze despite the camera still sending packets. In short, **Wi-Fi reliability is crucial** – any blip can stop the video.

Mitigations for Network Issues: To maintain a stable stream, treat it like a video call – ensure strong signal strength and minimal interference. Keeping the phone/tablet **very close to the camera** helps; in fact, one user found their Lumix stream would **drop if the phone was more than a few feet away**, given the GX880’s limited Wi-Fi range and antenna power ¹². If greater range is needed, you can have the camera join a dedicated Wi-Fi router network (placing a portable router near the camera) rather than using the camera’s direct hotspot – this can improve signal reliability and throughput. Also consider that the GX880 only supports 2.4 GHz Wi-Fi (802.11b/g/n); using a less crowded channel can reduce interference. In technical setups, some have even tuned OS network settings (e.g. increasing UDP reassembly buffers) to better handle the fragment bursts ¹³, though such tweaks are only applicable if you’re custom-building a PC interface. For most users, the key is simply a **clean, strong Wi-Fi connection**: maintain line-of-sight, stay close, and avoid environments with heavy Wi-Fi traffic to prevent packet loss from glitching the stream.

Application Behavior: Keep-Alives and Session Management

Keep-Alive Messages: The Panasonic Image App (or any third-party control app) isn’t just displaying video – it’s also constantly communicating with the camera via HTTP API calls. The GX880’s Wi-Fi API (accessible at `/cam.cgi` endpoints) requires periodic commands to keep the session alive. For instance, the app frequently polls status (`getstate` or similar) and sends keep-alive pings. If the app **stops sending commands for too long**, the camera might assume the session has ended. This can happen if the app crashes, or if your phone’s OS suspends the app in the background. The result is the camera dropping the connection, which in turn stops the live view.

Phone OS Interference: Many connection losses are actually caused by the smartphone or tablet, not the camera. Both iOS and Android will, by default, treat a camera’s ad-hoc Wi-Fi as a “no internet” network and may disconnect or deprioritize it. On Android, a **notification about “No Internet on this Wi-Fi”** often appears – if the user doesn’t confirm that they want to stay connected, the phone will drop back to cellular data and sever the camera link. One GX85 user discovered an option hidden in that notification: “*Stay connected even without Internet*” – enabling this was necessary to keep the Wi-Fi session stable ¹⁴. After tapping the checkbox and **allowing the no-internet connection to remain**, he achieved half-hour long sessions without drops until manually turning off the camera ¹⁵. This illustrates that the app wasn’t failing – the phone was literally dropping the Wi-Fi unless instructed otherwise.

For iPhone users, the issue is similar but the settings are buried. iOS will “jump away” from a Wi-Fi with no internet in favor of one with internet (or just idle on cellular data) unless you disable this behavior ¹⁶.

Reportedly, one must **turn off Wi-Fi Assist and auto-join for other networks, and even disable cellular data** while using the Lumix Image App ¹⁷. These steps force the iPhone to stick to the camera's network. If not, the iPhone might disconnect in the background after a minute or two, causing the live view to stop. Additionally, if the phone's screen locks or the app is minimized, the OS might suspend the network session for battery reasons. The takeaway: **keep your device awake and committed to the camera's Wi-Fi**. Any loss of the Wi-Fi link or lengthy pause in app<->camera communication will terminate the live view.

App Behavior: The design of the remote app itself can also impact stream continuity. Some third-party PC tools note that if their **viewer window loses focus, the video stream can freeze**, likely because the application thread stops reading the UDP packets ¹⁸. This is a programming quirk – the camera keeps sending video, but the app wasn't pulling data fast enough when unfocused, leading to a buffer overrun. The official Panasonic Image App is designed to continuously grab frames, but if you switch apps or get a phone call, the stream may pause. In summary, the app must actively maintain the session. If it fails to send periodic commands or if the phone OS interrupts network access, the live view will drop. Always use the latest version of the app (Panasonic has replaced "Image App" with **Lumix Sync/Lumix Link** for newer models), as updates sometimes improve stability or background behavior.

GX880 Firmware Quirks and Limitations

Live-View Quality Limits: A fundamental limitation of the GX880's live view is resolution and framerate. The stream is capped at **640×480 (VGA) at ~30 fps** ¹⁹. This is a firmware-imposed ceiling to conserve bandwidth. Users expecting an HD remote feed may inadvertently strain the connection if they try to force higher quality (which isn't possible through official means). The VGA stream is relatively low-bandwidth (~6–7 Mbps ²⁰), which should be manageable for Wi-Fi – but it's still heavily compressed and can appear laggy. Notably, the frame rate might drop if the signal is poor or if the camera is under load. The GX880 also has a [Live View Mode] setting (often with options like *ECO* vs. *Smooth* display). In **ECO mode**, the camera reduces the live-view frame rate (and perhaps quality) to save power ²¹. While this helps battery life, it could make the stream choppier. Conversely, a "smooth" mode might use more power and potentially heat, which could trigger other issues. Understanding this trade-off is part of the GX880's quirks – it was not engineered for high-performance live streaming, but rather basic remote framing and capture.

Firmware Stability: Unfortunately, there are some firmware quirks that can cause outright freezes. Enthusiasts who have reverse-engineered Lumix Wi-Fi control report occasional camera firmware bugs that *crash the camera*. Michael Tandy noted that in his experiments with the GX80 (close cousin of the GX880), he *"managed to trigger several bugs in the camera's firmware – including one that froze the camera's entire interface, requiring a battery pull to restart"* ²². This mirrors user reports on newer models: for example, Lumix S5 owners have observed that using the Wi-Fi live view can sometimes **lock up the camera**, leaving it unresponsive even after toggling the power switch ²³ ²⁴. In one case, the camera got stuck "terminating" the Wi-Fi connection and wouldn't shut down until the battery was removed ²³. These appear to be rare edge cases, but they underscore that the GX880's Wi-Fi stack isn't 100% crash-proof. Long sessions or certain sequences of remote commands might hit a bug. Panasonic's firmware for these consumer models prioritizes ease of use over bulletproof network uptime, so encountering a glitch is possible – e.g. the live view feed freezing permanently until a reboot.

No Multi-Tasking: Another limitation is that the camera can only handle one remote client and one operation mode at a time. If you attempt any unsupported action, the camera might simply stop responding. For instance, initiating a Wi-Fi remote session means you *cannot* simultaneously use the

camera's HDMI output or do tethered USB – the GX880 doesn't support those together. While not directly causing "unexpected stops," it's a limitation to be aware of: the Wi-Fi live view is meant for one device at a time. If another device tries to ping the camera or if you switch the camera to playback to send images, that ends the live view mode. The **best practice is to dedicate the camera solely to the live-view remote control during the session** – avoid changing modes or doing heavy in-camera processing. The more modest hardware of the GX880 (which lacks features like an active cooling or advanced processing) means it can get overwhelmed more easily than pro models.

Workarounds and Best Practices for a Stable Stream

Maintaining a reliable live view over Wi-Fi with the GX880 requires optimizing both camera settings and the connection environment. Here are the key tips and mitigations:

- **Disable Power Saves:** Turn **Sleep Mode** and **Sleep Mode(Wi-Fi)** to "Off" in the camera's Power Save menu ³. This ensures the camera won't auto-sleep during a remote session. Also disable any **auto power-off** or **economy live-view** settings if possible. Yes, this will use battery faster, but it keeps the camera awake. Using a dummy AC power adapter (DC coupler) is highly recommended for long shoots so you don't worry about battery level ⁴.
- **Keep the Camera Busy:** If you suspect the camera might be idling out, occasionally send a command (focus, half-shutter press, etc.) via the app. The official app usually does this for you behind the scenes by constantly polling status. But if you're scripting your own control, consider issuing a periodic `getState` or a no-op command every few seconds to act as a heartbeat. This will reassure the camera that the connection is active, resetting any internal idle timer.
- **Optimize Phone Settings:** On your smartphone or tablet, **prevent OS interference:**
 - For Android: when you connect to the camera's Wi-Fi, you'll often get a "No Internet, switch networks?" prompt – choose to **stay connected** (and tick "don't ask again") ¹⁴. This stops Android from dropping the Lumix network. Also, disable any battery-saver or adaptive Wi-Fi features that might shut off inactive apps.
 - For iOS: turn off **Wi-Fi Assist** (which uses cellular if Wi-Fi has no internet) ¹⁷. Also turn off auto-join for your other known networks so the phone doesn't sneak away in the background ²⁵. In some cases, you might even disable cellular data entirely while using the Lumix remote ²⁶, forcing the iPhone to cling to the camera's Wi-Fi. And as always, keep the app in the foreground and the screen unlocked – iOS tends to pause background tasks aggressively.
- **Minimize Interference:** Treat the wireless connection as part of your camera gear setup. Use the 2.4 GHz band smartly: try to operate away from microwave ovens, cordless phones, or dense apartment Wi-Fi environments. If you're out in the field, the direct camera-to-phone link is usually fine. If you're indoors and encountering dropouts, configure the camera to use a single designated Wi-Fi channel (if that option exists) that is least congested. Sometimes connecting through a portable router can help because you can manually set the channel and power – for example, have the camera join a travel router on channel 1, and your phone join that router as well, which can give a stronger, more controlled connection (at the cost of a bit more setup). The goal is reducing packet loss to near zero.

- **Stay in Range:** Simple but crucial – keep your remote device **close to the camera**. The effective range for a stable high-bandwidth stream may be much shorter than for basic camera control. Many users find they need to stay within a few meters. Walls or obstacles can seriously degrade the signal (the GX880's tiny internal Wi-Fi antenna isn't very powerful). If you need to be farther away, consider repositioning the camera's Wi-Fi antenna if possible (not really feasible on GX880), or again, use an intermediate Wi-Fi access point placed midway. In one report, using an AP allowed a user's iPhone to view the feed from further distances without dropouts ¹².
- **Avoid Heavy Camera Tasks:** As a best practice, do not initiate long operations while relying on the live view. For example, avoid bursting 4K Photo mode, in-camera RAW processing, etc. which could hog the camera's resources. If you need to change a setting, do it gently and give the camera a moment – e.g., switching from photo to video mode, wait a second for the stream to reinitialize. If you take a photo, consider turning off image review so that the live view returns immediately instead of the camera trying to send a thumbnail to the app. Essentially, keep the camera in its live-view loop as much as possible without interruption.
- **Keep Firmware Updated:** Check if Panasonic released firmware updates for the GX880. Sometimes stability issues (Wi-Fi drops or freezes) are quietly improved in updates. While no major Wi-Fi overhauls are common via firmware, any bug fixes could help. Users on similar models noted improvements in connection stability after firmware updates for the camera and the Image App.
- **Have a Plan B:** Ultimately, Wi-Fi streaming on the GX880 is a bit of a “freebie” feature – **convenient but not foolproof**. Professional users often treat it as a secondary monitor for setup or casual shooting, but not for critical continuous monitoring. If you absolutely require a rock-solid feed (e.g. for a long video shoot or live event), you might need to use the GX880's HDMI output with a wireless HDMI transmitter or a tethered capture solution. Several Lumix users comment that they “would not trust it for monitoring” and instead use external wireless HDMI for important work ²⁷ ²⁸. That said, for most scenarios like tripod selfies, vlogging, or remotely composing shots, the Wi-Fi live view can be made to work reliably by following the steps above – just always test your setup beforehand.

In summary, the live-view stream on the Lumix GX880 can stop for a variety of known reasons: the camera might time-out or power-save if it thinks you're idle; certain user actions can inadvertently halt the stream; the underlying UDP video feed is fragile to any Wi-Fi hiccups; and the controlling app or phone can cause disconnections if not configured properly. The GX880's firmware and hardware place some limits on how robust this can be – it's a 640×480 MJPEG stream intended for convenience, not high-end broadcasting, and it's known to be “spotty” under less-than-ideal conditions ²⁷. By understanding these causes, you can mitigate most of them: keep the camera awake and cool, keep the connection strong and uninterrupted, and avoid doing things that trigger the camera to exit live view. With those precautions, users have successfully maintained streams for extended periods (tens of minutes to hours). But if you do encounter a sudden drop, you can usually trace it to one of the causes above – and apply the appropriate workaround to get the shot. Happy (and stable) remote shooting!

Sources:

- Panasonic Lumix GX series manual and menu descriptions ² ²¹ (power save and live-view settings)
- Reverse-engineering notes on Lumix Wi-Fi (HTTP API and UDP stream) ⁸ ²⁹ ¹⁰ ¹¹

- User reports and expert commentary on Lumix Wi-Fi reliability (forum threads and Reddit) 27 23 14 16 17 12
- JustAnswer expert explanation of Lumix Wi-Fi screen behavior 1 and EOSHD community insights 3 .

1 In reality the question is rather debated on social networks. All Lumix cameras turn off the screen if connected to any

<https://www.justanswer.com/video-camera-repair/j9gb9-reality-question-rather-debated-social.html>

2 PANASONIC DX-GX800 OPERATING INSTRUCTION AND ADVANCED FEATURES Pdf Download | ManualsLib

<https://www.manualslib.com/manual/1233288/Panasonic-Dx-Gx800.html>

3 Panasonic S series battery problems (including S5 II) - Cameras - EOSHD Forum

<https://www.eoshd.com/comments/topic/76515-panasonic-s-series-battery-problems-including-s5-ii/>

4 8 9 10 11 13 19 20 22 29 Streaming live video over Wifi from the Panasonic Lumix GX80

<https://www.mjt.me.uk/posts/wifi-streaming-video-lumix-gx80/>

5 Changing Settings on the Live View Screen | LUMIX Tether ...

[https://mslinn.com/av_studio/panasonic/OperationGuide\(en\)/page11.html](https://mslinn.com/av_studio/panasonic/OperationGuide(en)/page11.html)

6 About menu screen - LUMIX LINK | Panasonic Global

https://av.jpn.support.panasonic.com/support/spn/global/dsc/help/l_link2.1/en/menu.html

7 Panasonic Lumix GX880 Announced For Europe - ePHOTOzine

<https://www.ephotozine.com/article/panasonic-lumix-gx880-announced-for-europe-33571>

12 14 15 16 17 25 26 SOLVED (???): Image App connection problems / Android : r/Lumix

https://www.reddit.com/r/Lumix/comments/i5jf0s/solved_image_app_connection_problems_android/

18 GitHub · Where software is built

<https://github.com/peci1/lumix-link-desktop/issues>

21 [PDF] Owner's Manual for advanced features - Panasonic

https://help.na.panasonic.com/wp-content/uploads/2023/02/DMCGM1_VQT5D68_ENG.pdf

23 24 27 28 Panasonic LUMIX S5 glitches (WiFi, focus peaking) : r/Lumix

https://www.reddit.com/r/Lumix/comments/nncztd/panasonic_lumix_s5_glitches_wifi_focus_peaking/