# Exp 04

LAPTOP

```
5V
USB
```


MPU-6050

1. THE OUTPUT FROM THE MPU-6050 IS SHOWN ON THE SERIAL MONITOR.

2. HERE PIN AD0 IS PULLED DOWN TO GROUND (LOW). I BELIEVE IT IS GROUNDED INTERNALLY BUT HERE I'M DOING IT EXPLICITLY. SEE SECTION 9.2.