




LEVELS54 STOCK KEYMAP




Base



Lower



Raise



Mouse

OPERATION

Power Switch:
Facing back of keyboard is on.
Facing front is off.

Charging:
Connect USB-C cable. Orange LED
located on bottom of keyboard will light
while charging and turn off when done.

Acting as a USB keyboard:
Connect USB-C cable on right side to host.

PROGRAMMING (easy)

Use the GUI at <https://zmk.studio>

PROGRAMMING (expert)

Reset:
Button is located on bottom of keyboard.

Flashing new firmware:
1. Connect side you wish to flash to host.
2. Double-tap reset button.
3. Keyboard will mount as a "USB Drive."
4. Drag appropriate uf2 file into drive.
5. Keyboard will disconnect when
upload is complete.
6. Repeat for other side.

Firmware:
github.com/Good-Great-Grand-Wonderful/levels54/releases