



LEVELS ASSEMBLY MANUAL


6. PLACE PCB IN BOTTOM CASE



7. INSTALL POWER SWITCH



8. INSTALL TOP CASE



Connect then install battery into cubby on top case, ensure no wires are pinched

PLEASE BE CAREFUL AND DO NOT PINCH WIRES
LI-PO BATTERIES ARE A FIRE HAZARD

9. FINAL ASSEMBLY

Take the carrier
Press in the 5mm Ceramic Bearings
Ensure the bearings are fully seated
Place the carrier into the keyboard
Place the top onto the carrier
Flip the keyboard over while holding the carrier
Use fasteners to attach carrier
Remove the yellow stickers from the sensor
Place the lens, add your keycaps, and have fun!

NOTE: The keyboard comes loaded with firmware

