PART II - PRIMARY SYSTEMS INFORMATION

III. Fire Protection

1. Operation

i. Safety Instructions:

Any equipment installed is to be done so in accordance with the National Electrical Code (NFPA 70), the National Fire Alarm Code (NFPA 72) and the local Authority Having Jurisdiction (AHJ).

NFPA 72 requires a complete system-wide functional test be performed following any modifications, repair, upgrades or adjustments made to the system's components, hardware, wiring, programming and software.

Inform the operator and the local Authority Having Jurisdiction (AHJ) before installing this module in an existing system. Disconnect all power to the FACP before installing this module.

Boards are static-sensitive. Make sure you touch ground before handling the board. Doing so will discharge any static electricity in your body.

Disconnect all power (AC and battery) before servicing the NAC Wait until the High Voltage LED is off before handling any connections.

It is assumed that the user of this document is a suitably trained installer who is familiar with the relevant regulations.

Do not remove or insert a data module while the BT2-7 is powered.