

Division of Advance Fiberglass, LLC. 7516 Counts Massie Road North Little Rock, AR 72113 Ph. 800-342-7367 Fax. 501-758-9496

## **Operations and Maintenance Procedures**

## **Operation and Maintenance Instructions**

Maintenance of fiberglass doors is virtually non-existent. A fiberglass doors' high corrosion resistance, structural integrity, and light weight, contribute greatly to its low maintenance. The following guidelines have been provided by FIB-R-DOR to insure the durability of the doors and assist in eliminating possible future problems.

- Do not use the doors for any purpose other than what it is designed.
   If the door is not labeled with a UL label it should not be used in a fire door application. Fire retardant doors are not to be used as equivalent to UL rated doors.
- 2) Door is warranted for the chemicals or environment specified before purchase.
- Periodically check moving parts of hardware for wear, and lubricate as required. Refer to hardware manufacturers' literature for hardware maintenance.
- 4) Periodically check the interior and exterior of the door for damage. If surface is punctured, a patch may be applied to effectively seal the door. The exterior may be maintained with an occasional non abrasive waxing similar to what you would use on an automobile or fiberglass boat.
- 5) Chemical spills and splashes should be cleaned in a timely manner to protect the finish from fading or discoloration.