TABLE OF CONTENTS

| CTION | | | |
|----------|----------|---|--------------------------|
| 1 | GE | PAGE 1 | |
| | PΑ | ARTS IDENTIFICATION | |
| | | PARTS IDENTIFICATION | PAGE 2-3 |
| | FA | ABRICATION | |
| | A) | SCREW SPLINE FABRICATION 1) TEMPLATE for SCREW SPLINE | PAGE 4 PAGE 5 |
| | D) | DJ17 DRILL GUIDE SHEAR BLOCKS at SCREW SPLINE DOOR JAMB | PAGE 6 PAGE 7 |
| | B) | | PAGE 7 PAGE 8 |
| | | TEMPLATE for SHEAR BLOCKS DJ16 DRILL GUIDE | PAGE 9 |
| | | 3) TEMPLATE for TRANSOM BAR SHEAR BLOCK (K978) | PAGE 10 |
| | | 4) TEMPLATE for TRANSOM BAR w/ C.O.C. SHEAR BLOCK (K996) | PAGE 11 |
| | | 5) DJ16 DRILL GUIDE for TRANSOM BAR SHEAR BLOCK | PAGE 12 |
| | | 6) DJ16 DRILL GUIDE for TRANSOM BAR w/ C.O.C. SHEAR BLOCK | PAGE 13 |
| | C) | SHEAR BLOCK FABRICATION - FRAMES | |
| | | 1) DJ18 DRILL GUIDE at INTERMEDIATE HORIZONTAL | PAGE 14 |
| | | 2) DJ18 DRILL GUIDE at TRANSOM HEAD | PAGE 15 |
| | D) | SNAP-IN GLAZING POCKET & SCREW APPLIED GLAZING | |
| | | 1) SNAP-IN GLAZING POCKET END PREP | PAGE 16 |
| | | 2) SCREW APPLIED GLAZING END PREPS | PAGE 16 |
| IV | ΛΩ | SEMBLY & INSTALLATION | |
| IV | | SCIVIDET & INSTALLATION | |
| | A) | DOOR FRAME ASSEMBLY | PAGE 17-22 |
| | B) C) | DOOR FRAME INSTALLATION SILL FLASHING INSTALLATION | PAGE 23-24 PAGE 25-29 |
| | D) | SCREW SPLINE FRAMES & SIDE LITE TO DOOR JAMB ASSEMBLY | PAGE 30-31 |
| | E) | WATER DEFLECTOR INSTALLATION | PAGE 32 |
| <u>V</u> | GL | _AZING | |
| | A) | GLASS SIZE FORMULAS | PAGE 33 |
| | B) | GLASS INSTALLATION | PAGE 34-37 |

PAGE 38-39

ANTIWALK BLOCK INSTALLATION

C)

SECTION I - GENERAL NOTES

SERIES 406 2" x 6 1/2" - 1" GLAZING (THERMAL)

- Check shop drawings, installation instructions, and glazing instructions to become thoroughly familiar with the project. The shop drawings take precedence for extrusions and details on the project. THESE INSTALLATION INSTRUCTIONS ARE OF A GENERAL NATURE AND COVER THE MOST COMMON CONDITIONS AND SITUATIONS.
 REFERENCE THE STANDARD STOREFRONT INSTALLATION INSTRUCTIONS FOR COVERAGE OF ITEMS COMMON TO STOREFRONT SYSTEMS.
- 2) Check all of the materials upon arrival and be sure you have everything required to begin installation. See Section II "PARTS IDENTIFICATION", also particular parts from the standard 403 - 2" x 4 1/2" can be used with this deep system.
- 3) All work should start from bench marks and/or column center lines as established by the architectural drawings and the general contractor. Check construction for compliance with the contract documents.
- 4) NOTE:
 - Sealants must be compatible with all surfaces. Consult with the sealant manufacturer for recommendations regarding compatibility and adhesion.
- 5) All materials are to be installed plumb, level, and true.
- 6) Protect materials after erection. Cement, plaster, alkaline solutions, and acid based materials can be harmful to the finish.

 Masonry runoff may leach harmful acids onto the storefront.

 This situation must also be taken into consideration at installation.
- 7) Clean aluminum surfaces with a mild detergent and water. No abrasive agent shall be used.

REFERENCE THESE OTHER MANUALS:

| STOREFRONT INSTALLATION INSTRUCTIONS | |
|--|------|
| SYSTEMS 401, 402, and 403 | Y001 |
| DORMA RTS 88 CONCEALED OVERHEAD CLOSERS | Y013 |
| INTERNATIONAL 200 CONCEALED OVERHEAD CLOSERS | Y014 |
| DOOR, DOOR GLASS, and HARDWARE | Y015 |

| SECTION II PARTS IDENTIFICATION. | | | | | | | |
|---|--|-------------|-------------|--|----------------------------------|-------------|--|
| | RIPTION | PART NO. | DESCRIPTION | | | PART NO. | |
| Tun un | HEAD or JAMB | 0250 | 1" | APPLIED FIX USED w/ 913 FOR TRANSOM L AT JA | 33 STOP ITES OVER 4 FT. | 9250 | |
| | 2" X 6 1/2" DEEP USE w/ 9358 | 9359 | - J | | APPLIED OOR STOP 5 & W138 | 9154 | |
| 4 | VERTICAL/HORIZONTAL GLAZING ADAPTOR 2" X 6 1/2" DEEP | 0050 | | SCREW APPLIED DOOR STOP COVER USE w/ 9154 & W138 | | 9155 | |
| | USE WITH 9357, 9359, & 8402 | 9358 | | 5/8" DOO AT HEAI USE w/ 9155 | | 4437 | |
| | | | | AT H | OOR STOP EADER WEATHERING | 9914 | |
| | SCREW SPLINE DOOR JAMB 2" X 6 1/2" DEEP | 8402 | <u>}</u>] | AT H | DOOR STOP EADER VEATHERING | 9933 | |
| | USE w/ 9358 | | | | STD. SILL FLASHING | 1G83 | |
| | COC TRANSOM BAR 2" X 6 1/2" DEEP USE 9123 STOPS | 8400 | | | SILL FLASHING WITH | 1G86 | |
| | 2 pc. OPEN BACK HORIZONTAL / SILL 2" X 6 1/2" DEEP USE w/ 9358, USE 9229 STOP (SHEAR BLOCKS APPLICABLE AT SILL ONLY) | 9357 | | MALE EX | STOOL CLIP | | |
| TUBULAR HORIZONTAL 2" X 6 1/2" DEEP USE 9229 STOP | | 8401 | | | ON HALF w/ 4461 | 4462 | |
| | HORIZONTAL GLAZING STOP, USE WITH 9357 & 8401 | 9229 | | | | | |
| TRANSOM JAMB GLAZING POCKET w/ 8402 JAMB 48" CUT OUT MAX. | | 8403 | | FEMALE EXPANSION MULLION HALF USE w/ 4462 | | 4461 | |
| 1" | TRANSOM BAR GLAZING STOP 1" GLAZING USE w/ 8400 | 9123 | - | | | | |
| 15 " | REMOVABLE STOP USE w/ 9250 for 1" APPLIED GLAZING FOR TRANSOM LITES OVER 4' AT JAMBS | 9133 | | PARTS ON THIS P | AGE ARE NOT TO | SCALE | |

| SECTION II PARTS IDENTIFICATION cont. | | | | | | | |
|---------------------------------------|--|-------------|--|--|------|--|--|
| | CRIPTION | PART NO. | DES | PART NO. | | | |
| ACCESSORIES | | | FRAME SPLINE ATTACHMENT SCREW #10 x 1" SL-HW-SMS | | S129 | | |
| | GLAZING GASKET for UNDERSIZED GLASS 3/4" INFILL @ 1" POCKET | W165 | | K979 | | | |
| | GLAZING GASKET for OVERSIZED GLASS 1 1/8" INFILL @ 1" POCKET | W166 | | (1) FV34, (1) WM96 SILL FLASHING END CAP PKG. USE WITH 1G83 & 1G86 (1) FV35, (2) SFP6 | K980 | | |
| | STANDARD GLAZING GASKET 1" INFILL @ 1" POCKET | W164 | | HEAD & HORIZONTAL SHEAR BLOCK PKG. USE w/ 9359 & 8401 (1) FV36,(2) STB9, (4) S100, (2) S101 | K977 | | |
| | EXTERIOR GLAZED SETTING BLOCK at SILL & HORIZ. USE w/ 9357 & 8401 | HN32 | | SILL SHEAR BLOCK PKG. USE w/ 9357 (1) FU49, (1) STB9, (4) S100 | KN65 | | |
| | INTERIOR GLAZED SETTING BLOCK at HORIZ. INTERMEDIATE USE w/ 8401 | HN92 | | TRANSOM BAR SHEAR BLOCK PKG. OPP. COC @ SINGLE DR USE w/ 8400 (1) FV33, (3) STV2, (4) STK4 | K978 | | |
| | TRANSOM BAR SETTING BLOCK 1" GLAZING USE w/ 8400 | HNA3 | | TRANSOM BAR SHEAR BLOCK PKG. USE W/ COC 'F' CLIP or FT16 ANGLE CLIP at CLOSER END (1) FU31, (2) STV2, (4) STK4 | K996 | | |
| | STANDARD WEATHER SEAL @ DOOR STOPS | W138 | | WATER DEFLECTOR @ INT. HORIZONTAL | HWD1 | | |
| Cum(s) | APPLIED DOOR STOP ATTACHMENT SCREW USE w/ 9154 & 9155 | STT6 | M | 5/8" ANTIWALK BLOCK at DEEP POCKET ONLY | HN52 | | |
| | HORIZ. to SHEAR BLOCK | STB9 | | PLASTIC CAULK BACKER 10 FT. LENGTHS | LB78 | | |
| <u> Эшининининин</u> | SHEAR BLOCK to VERT. | S100 | <u></u> | 3" CUT LENGTHS USED AT FASTENERS | FV16 | | |
| | DOOR HEADER TO SHEAR BLOCK | STK4 | SYST | EM DRILL J | IGS | | |
| | TRANSOM HEAD TO SHEAR BLOCK | S101 | SHEAR BLOCK | | | | |
| | TRANSOM BAR SHEAR BLOCK to VERT. | STV2 | | DRILL JIG | DJ16 | | |
| (Junn) | SILL FLASHING END CAP ATTACHMENT SCREW | STC7 | | SCREW SPLINE DRILL JIG | DJ17 | | |
| 406 STORFFRON | T | | | SHEAR BLOCK DRILL FIXTURE (HORIZONTALS to SHEAR BLOCKS) | DJ18 | | |

406 STOREFRONT CDB SEPT 2009

SECTION III FABRICATION A - SCREW SPLINE FABRICATION

The screw spline system is a fabrication and erection method that permits the preassembly of single units in the shop or at the job site. These units are then erected by mating the male mullion with the female mullion counterpart.

When an entrance is required, screw spline joinery may be used with the screw spline door jambs only.

- NOTE) DUE TO THE SCREW TENSIONS REQUIRED FOR CORRECT INSTALLATION, IT IS NECESSARY TO 'WAX' THE FRAME ASSEMBLY SCREWS TO PREVENT GALLING AND BREAKAGE.
 - STEP 1) MEASURE THE OPENING TO DETERMINE THE CUT LENGTH OF THE FRAME COMPONENTS.

NOTE: Allow minimum 1/2" shim and caulk space around the perimeter.

NOTE: Allow extra clearances, if necessary, to accommodate building tolerances and building movement.

NOTE: Consult A.D.A. requirements to verify compliance.

- STEP 2) CUT THE VERTICALS TO FRAME SIZE.
 - NOTE: Verticals must run through.

If the opening has an entrance, see the appropriate frame and door fabrication installation sheets.

- NOTE: The screw spline door jamb runs to the floor and is cut longer than other verticals. The glazing adaptor will be cut to the standard jamb and vertical intermediate length.
- STEP 3) DRILL THE HOLES FOR ASSEMBLY SCREWS ON VERTICAL MEMBERS. (See Fig. # 1 page 5).

NOTE: Drill jigs are available. See page 3 of the parts identification section.

STEP 4) CUT THE HORIZONTAL MEMBERS TO DAY LITE OPENINGS.
(BETWEEN VERTICAL MULLIONS)
CUT THE HORIZONTAL GLASS STOPS TO DAYLITE OPENINGS
MINUS 1/32". (D.L.O. - 1/32")


406 STOREFRONT MDM 04/2008

SECTION III FABRICATION A - SCREW SPLINE FABRICATION

(CONT.)

1) TEMPLATE FOR O. G. SCREW SPLINE


(INVERT FOR INSIDE GLAZE)



SECTION III FABRICATION A - SCREW SPLINE FABRICATION

(CONT.)

2) DJ17 DRILL GUIDE FOR SCREW SPLINE APPLICATION



Because the screw spline door jamb is actually a tubular member, it will be necessary to shear block the transom bar, the transom head, and any intermediate horizontal that is being incorporated in the transom area.

STEP 1) MEASURE THE OPENINGS AND SUBTRACT THE VERTICAL MEMBER'S SIGHT LINES TO DETERMINE THE HORIZONTAL FRAME CUT LENGTHS.

Horizontals and transom bar cut length = D.L.O. Horizontal glass stop cut length = D.L.O. - 1/32". Transom bar glass stop cut length = D.L.O. - 25/32"

NOTE: Consult A.D.A. requirements to verify door opening width compliance.

STEP 2) CUT THE DOOR JAMBS TO ROUGH OPENING MINUS 1/4".

NOTE: Door jambs run to the floor and are cut longer than other verticals.

- STEP 3) DRILL THE HOLES FOR THE SHEAR BLOCK SCREWS ON THE DOOR JAMBS AS SHOWN ON PAGES 8 THROUGH 13.
- STEP 4) PROCEED TO SECTION III C FOR HORIZONTAL TO SHEAR BLOCK PREPS, AS SHOWN ON PAGES 14 AND 15.

NOTE: Drill jigs are available. (See page 3 of the parts identification section.

STEP 5) PLEASE REFER TO DOOR, DOOR GLASS, AND HARDWARE MANUAL (PART #Y015), FOR THE DOOR HINGING PREPS, STRIKE PREPS, AND THRESHOLD PREPS. THESE PREPS SHOULD BE DONE TO THE DOOR JAMBS AT THIS TIME FOR EASE OF ASSEMBLY.

406 STOREFRONT CSJ 12/2006


1) TEMPLATE FOR O.G. SHEAR BLOCKS

HEAD & HORIZONTAL SHEAR BLOCK TO S.S. DOOR JAMB INVERT #8401 HORIZONTAL FOR I.G. TRANSOM

CAUTION:


Door jambs must run to the floor and are cut longer than other verticals. Shear blocks are not applicable with 2 pc. horizontal intermediates.

NOTE: (2) pc. horizontal (9357/9358) cannot be shear block assembled.



USE BLOCKED OUT HOLE LOCATIONS FOR O.G. SHEAR BLOCK APPLICATIONS OUTSIDE GLAZED AS SHOWN, INVERT PATTERN FOR INSIDE GLAZE APPLICATIONS DRILL JIGS ARE ALSO AVAILABLE


2) DJ16 DRILL GUIDE FOR TRANSOM - HEAD AND HORIZONTAL INTERMEDIATE SHEAR BLOCK APPLICATION



3) TEMPLATE FOR TRANSOM BAR SHEAR BLOCK TO S.S. DOOR JAMB

OPPOSITE A C.O.C. AT A SINGLE DOOR

NOTE: ALL OTHER STD. 402 DOOR FRAME PREPS WILL APPLY FOR C.O.C.'S, PIVOTS, AND OTHER HINGING.




DRILL JIGS ARE ALSO AVAILABLE

4) TEMPLATE FOR TRANSOM BAR SHEAR BLOCK TO S.S. DOOR JAMB

WITH C.O.C. 'F' CLIP OR FT16 ANGLE CLIP

NOTE: ALL OTHER STD. 402 DOOR FRAME PREPS WILL APPLY FOR C.O.C.'S, PIVOTS, AND OTHER HINGING.




SEE Y013 DORMA C.O.C. INSTALLATION INSTRUCTIONS FOR DIMENSIONS AND APPLICATIONS FOR THE CLOSER

FIG. #6

DRILL JIGS ARE ALSO AVAILABLE

5) **DJ16 DRILL GUIDE**


TRANSOM BAR SHEAR BLOCK TO DOOR JAMB OPPOSITE A C.O.C. AT A SINGLE DOOR



DPS 12/2002


6) DJ16 DRILL GUIDE


TRANSOM BAR SHEAR BLOCK TO DOOR JAMB WITH A C.O.C - SINGLE OR PAIRS OF DOORS



SECTION III FABRICATION C- SHEAR BLOCK FABRICATION - FRAMES

1) DJ18 DRILL GUIDE APPLICATION AT TUBULAR INTERMEDIATE HORIZONTAL AND OPEN BACK SILL






SECTION III FABRICATION C- SHEAR BLOCK FABRICATION - FRAMES (CONT.)


2) DJ18 DRILL GUIDE APPLICATION AT OPEN BACK TRANSOM HEAD

TRANSOM HEAD END PREP FOR ATTACHMENT TO SHEAR BLOCKS




SECTION III FABRICATION D - SNAP-IN GLAZING POCKET & SCREW APPLIED GLAZING

1) SNAP-IN GLAZING POCKET END PREP




SCREW APPLIED GLAZING END PREPS 2)




SECTION IV ASSEMBLY & INSTALLATION A - DOOR FRAME ASSEMBLY

NOTE: If an entrance frame is required, it must be installed first. Attach the transom bar to the jamb with the #K978 shear block or the K996 and the 'F' clip or angle bracket (#FT16) for a C.O.C. Be sure the snap-in glazing pocket has been notched to clear the glazing stop tracks on the top of the transom bar. Please see page 16 for this end prep.




SECTION IV ASSEMBLY & INSTALLATION A - DOOR FRAME ASSEMBLY (CONT.)

NOTE: If an entrance frame is required, it must be installed first. The transom jamb glazing pocket will snap into the cut out cavity. The glazing pocket will flush with the top of the transom bar or with the top of the horizontal intermediate, if used.




SECTION IV ASSEMBLY & INSTALLATION A - DOOR FRAME ASSEMBLY

(CONT.)




SECTION IV ASSEMBLY & INSTALLATION A - DOOR FRAME ASSEMBLY (CONT.)

FOR TRANSOM D.L.O. OVER 48" USE #9250 AND #9133 APPLIED GLAZING AT JAMB APPLIED STOPS RUN THROUGH AT TRANSOM BAR GLAZING STOPS.



DORMA RTS 88 w/ BUTT HINGES, **GEARED HINGES & DUAL ACTING** #8403 #K977 **EXPLODED VIEW** #9359 #K996 **FCLIP** (BY DORMA) F045 #8400 #8402 DOOR JAMB **FACTORY PREP SHOWN** #9954/#9955 DOOR STOP Fig. # 19 REFER TO Y013 DORMA RTS 88 INSTALLATION INSTRUCTIONS


DORMA RTS 88 w/ OFFSET PIVOTS



SECTION IV ASSEMBLY & INSTALLATION B - DOOR FRAME INSTALLATION

NOTE: If an entrance frame is required, it must be installed first.

- STEP 1) CORRECTLY LOCATE THE ENTRANCE FRAME IN THE OPENING.
- STEP 2) APPLY A BEAD OF SEALANT AROUND THE INTERIOR PORTION OF THE JAMB TO SET THE MEMBER INTO. THEN MARRY THE SIDE LITE SEALANT OR CONDITION SEALANT INTO THE BEAD OS SEALANT TO BE APPLIED UNDER THE THRESHOLD. THE CONCEPT IS TO HAVE A CONTINUOUS BEAD OF SEALANT AT THE INTERIOR, CONNECTED FROM THE SILL FLASHING/CONDITION THROUGH THE DOOR JAMB AND CONTINUING UNDER THE THRESHOLD TO THE OPPOSITE JAMB AND SO ON.
- STEP 3) SET THE ASSEMBLED DOOR FRAME IN THE OPENING, PLUMB AND LEVEL.
- STEP 4) ANCHOR THE DOOR FRAME AS INDICATED BELOW AND IN FIG. #22 THROUGH FIG. #25 ON PAGE 24.




(CONT.)

SECTION IV ASSEMBLY & INSTALLATION

B-DOOR FRAME INSTALLATION

At the open back head and jamb, EFCO recommends using full lengths of caulk backer (LB78) or use 3" pieces (FV16) and locate them at the frame and door frame anchors. This is to prevent collapsing the glazing pockets or distorting the door jamb. 9359 frame jamb & 9357 frame sill require LB78/FV16 similar.



Anchor through the S.S. jamb at the door stop centerline with flat head screws located 6" from the ends and 16" on center, maximum spacing.






Fig. # 25



Anchor through the transom head/frame head glazing pocket with flat head screws located 6" from the ends and 16" on center, maximum spacing.



Anchor through the transom bar at the door stop centerline with flat head screws located 6" from the ends and 16" on center, maximum spacing.


Attach through the threshold with flat head screws located 6" from the ends and 15" on center, typical spacing.

Continuous bead of sealant at the back of the threshold and sides of the jambs and tied into mullion sealant at the condition.


NOTE: These are general anchor locations. It may be necessary to use 9358 as the perimeter filler if structural loads require a greater shear strength at the anchor locations. All projects should be reviewed by a structural engineer for exact anchoring requirements

SECTION IV ASSEMBLY & INSTALLATION C - SILL FLASHING INSTALLATION

STEP 1) INSTALL THE SILL FLASHING CONTINUOUSLY BETWEEN THE MASONRY JAMBS OR BETWEEN THE DOOR FRAME AND THE MASONRY JAMB. SEE FIGURES BELOW.




NOTE: ALL THERMAL STRUT SILL FLASHING THAT COULD ENCOUNTER MOISTURE MIGRATION MUST HAVE THE THERMAL STRUT SEALED OVER WITH SILICONE.



SECTION IV ASSEMBLY & INSTALLATION C - SILL FLASHING INSTALLATION


(CONT.)

STEP 2) INSTALL THE SILL FLASHING IN A CONTINUOUS BEAD OF SEALANT BETWEEN THE MASONRY JAMB AND THE DOOR FRAME. THE BEAD OF SEALANT WILL TIE INTO THE SEALANT THAT FILLS THE CAVITY IN THE DOOR JAMB AND TIES INTO THE BEAD OF SEALANT THAT THE THRESHOLD IS SET INTO. SEAL THE END OF THE SILL FLASHING TO THE DOOR JAMB THOROUGHLY. FILL THE HOLLOW AREA OF THE DOOR JAMB WITH SEALANT LEVEL WITH THE SILL FLASHING TO DIVERT ANY WATER ONTO THE SILL FLASHING. SEE FIGURE BELOW.



SECTION IV ASSEMBLY & INSTALLATION C - SILL FLASHING INSTALLATION (CONT.)

VIEW OF JAMB AT CONDITION




STEP 3)

INCORPORATING THE SILL FLASHING END CAPS WILL COMPLEMENT THE SEALING PROCEDURE. THE END CAPS MUST BE SEALED TO THE CONDITION AND THE SEALANT MUST TIE-IN WITH THE JAMB BLOCKING AND THE PERIMETER SEALS. THE END CAP EDGES MUST ALSO BE CONCEALED WITH THE SEALANT TO PRESENT A NEAT CLEAN INSTALLATION. THIS MAY CAUSE THE CAULK JOINT AT THE JAMB TO INCREASE IN THICKNESS, IF THE CONDITION IN IRREGULAR.


SECTION IV ASSEMBLY & INSTALLATION C - SILL FLASHING INSTALLATION

(CONT.)

STEP 4) SILL FLASHING CUT LENGTH = ROUGH OPENING MINUS 1/2" WITH END CAPS. END CAPS WOULD BE INCORPORATED IF THE SILL FLASHING COULD NOT BE SEALED TO THE CONDITION COMPLETELY. AN EXAMPLE WOULD BE, IF THE JAMB CONDITION IS LESS THAN THE SILL FLASHING DEPTH OR IF THERE IS A VOID IN THE CONDITION.



STEP 5) SPLICE THE FLASHING EVERY 20'-0" AS SHOWN IN FIG. #31 BELOW. USE K979 FOR S406 HIGH PERFORMANCE FLASHING. IT IS NOT ADVISED TO LOCATE THE SPLICE JOINT DIRECTLY AT A VERTICAL INTERMEDIATE. ALLOW 6" MINIMUM SPACING FROM THE VERTICALS. FOR MITERED CORNERS, SEE PAGE 29.




406 STOREFRONT CSJ 02/2007

SECTION IV ASSEMBLY & INSTALLATION C - SILL FLASHING INSTALLATION


(CONT.)

STEP 6) IF A CORNER IS REQUIRED, MITER THE FLASHING TO THE REQUIRED ANGLE AND THEN INSTALL AS SHOWN IN THE FIGURES BELOW. LOCATE FASTENERS 3" AWAY FROM ANY CORNER AND 1 1/2" FROM THE EDGE OF THE SILL FLASHING SPLICE.



SECTION IV ASSEMBLY & INSTALLATION

D - SCREW SPLINE FRAME & SIDE LITE TO DOOR JAMB ASSEMBLY




NOTE: Use full lengths of LB78 perimeter adaptor at the head and jambs as a caulk backer and to keep from collapsing the glazing pocket. Use 3" lengths of LB78 perimeter adaptor (FV16) at the sill member and locate them at the fastener, to keep the anchors or weight of the glazing material from collapsing the glazing pocket.

406 STOREFRONT CSJ 11/2007

(CONT.)

SECTION IV ASSEMBLY & INSTALLATION

D - SCREW SPLINE FRAME & SIDE LITE TO DOOR JAMB ASSEMBLY




NOTE:

Make sure the bead of sealant under the threshold is continuous through the door jamb and married into the bead of sealant that the sill flashing is set into.


SECTION IV ASSEMBLY & INSTALLATION E - WATER DEFLECTOR INSTALLATION

Water deflectors are used at the ends of all horizontal intermediates to prevent any accumulated moisture in the glazing pocket from dropping on the top edge of the 1" glass unit below.



SECTION V GLAZING A - GLASS SIZE FORMULAS

System 406 (2" sight line) = D.L.O. + 7/8" (HORIZONTAL) System 406 (2" sight line) = D.L.O. + 7/8" (VERTICAL)




SECTION V GLAZING

B-GLASS INSTALLATION

STEP 1) GASKET INSTALLATION FOR OUTSIDE GLAZE.

- A) Apply sealant to the ends of all horizontals to seal the intersections at the verticals. At all 4 corners of the D.L.O., apply sealant in the gasket race 1" away from the intersection of the vertical and horizontal members. See detail # 40 below.
- B) Cut the interior and exterior push-in gasket to an approximate length of D.L.O. x 1.02 (DLO PLUS 2%).
- C) Install the interior glazing gasket. NOTE: The vertical gaskets run through.
- D) Start at the ends and work toward the center, firmly pushing the gasket in place. DO NOT STRETCH THE GASKET OR IT WILL RETURN TO ITS ORIGINAL FORM, CREATING GAPS AT THE GASKET INTERSECTIONS.
- E) Clean the glazing gaskets with denatured alcohol at the intersection area. Apply a small amount of sealant at the intersect area to marry the vertical and horizontal glazing gaskets. Tool all sealant to present a neat, clean appearance.


NOTE: These steps are included in the test lab procedure and are requirements to achieve the test report results for air and water infiltration.



SECTION V GLAZING B - GLASS INSTALLATION

(CONT.)

STEP 1) GASKET INSTALLATION FOR OUTSIDE GLAZE TRANSOM BAR GLAZING STOP SEAL.



IF SCREW APPLIED GLAZING STOPS ARE USED VERTICALLY INSTEAD OF THE SNAP-IN GLAZING POCKET, THE SEALING SCENARIO WILL BE THE SAME. BE SURE TO SET THE GLAZING BASE IN A BEAD OF SEALANT


BEFORE ATTACHING IT TO THE DOOR JAMB.

SECTION V GLAZING B - GLASS INSTALLATION (CONT.)

STEP 2) GLASS INSTALLATION

- A) Position the glass unit in front of the opening to be glazed. Lift the unit to just clear the sill stop area, and then shift the glass into the deep pocket.
- B) Swing the opposite edge of the glass around to align with the glazing pocket.
- C) Shift the glass into the shallow pocket until there is equal glass bite on both edges of the glass.

NOTE: If using antiwalk blocks, refer to page 38.



SECTION V GLAZING B - GLASS INSTALLATION

STEP 2) GLASS INSTALLATION

- D) Lift the glass into the head member's glazing pocket.
- E) Insert the setting blocks under the glass at the proper locations, typically 1/4 points of the D.L.O. Then lower the glass onto the setting blocks.
- F) Snap on the removable glass stop and install the exterior glazing gasket.




Fig. # 43

400 OTODEEDONT CO. L44/0005

SECTION V GLAZING C - ANTIWALK BLOCK INSTALLATION

STEP 1) ANTIWALK BLOCK INSTALLATION

- A) Install the interior gasket following the steps on page 34.
- B) Position the glass as described in the steps on pages 36 and 37.
- C) Stretch the antiwalk block as shown in Fig. 44 below, and insert it from the exterior at midlite and deep pocket side only.
- D) Recenter the glass unit to maintain equal glass bite all around.
- E) Install the exterior gasket.

HN52 ANTIWALK BLOCK






FIG. # 44

SECTION V GLAZING C - ANTIWALK BLOCK INSTALLATION

(CONT.)

STEP 2) ANTIWALK BLOCK DEGLAZING

- A) Remove the interior and exterior glazing gaskets.
- B) Push the glass back to the interior side.
- C) Remove the antiwalk block with a sharp hook shaft tool from the exterior side.




FIG. # 45