

DC-INPUT / ENTRY
DC-INPUT / ESS-Y
PHASE-U / DRIVE-UL
PHASE-W / MODULE-W
GATE-POWER / FLY-LS
LV-POWER / PROT-L
DC-INPUT / HVIL
DC-LINK / DISCH-F
LV-POWER / VCC1-LDO
DC-LINK / LINK-BANK
PHASE-V / MODULE-V
PHASE-W / DRIVE-WH
HV-SENSING / SENSE-VDC
HV-SENSING / SENSE-VDC2
HV-SENSING / ISO-BIAS
LV-POWER / BOOST-15V
PHASE-U / MODULE-U
PHASE-V / DRIVE-VH
PHASE-W / DRIVE-WL
HV-SENSING / ASC-BUFFER
LV-POWER / PROT-H
PHASE-U / DRIVE-UH
PHASE-V / DRIVE-VL
GATE-POWER / FLY-HS
ASIL-D SAFETY CONCEPT + DC-LINK DISCHARGE VERIFICATION
CONTROL-IF / HARNESS
SHEET INDEX
NET NAMING
Traction Inverter 220 kW — Power board (3x EconoDUAL 3 SiC)
Traction Inverter 220 kW pk - Power (HV), sheet 1 of 3
2026-09-09 · rev A.3