

DISCHARGE / ACTIVE

The schematic diagram illustrates the DISCHARGE / ACTIVE circuit. It features three main functional blocks: PSQD, UQD, and QDIS. The PSQD block has inputs V18Q, QA01C-18, and DCN, and outputs PSQD and V1S. The UQD block has inputs QDA, DGND, and TLP152, and outputs UQD and QDVO. The QDIS block has inputs G_QDIS, DCN, and DCN, and output QD_D. The circuit is populated with several resistors: RQDL (470R) between QDIS_CMD and QDA, RQDG (47R) between QDVO and G_QDIS, RQDPD (10k) between G_QDIS and DCN, and CQD (100nF) between V18Q and DCN. A capacitor is also connected between V18Q and DCN.

DISCHARGE / ENTRY

DISCHARGE / BLEED

Traction Inverter — Discharge board (bolt-on, XM3 pattern)

Traction Inverter 220 kW pk - Discharge (HV, bolt-on), sheet 3 of 4

2026-09-09 · rev A.4.3