iPad Blotter/Keyboard/Pen Overview

Pre Check-In

- o Key Items: Required tools (only use hand tools. No power tools)
 - 2.5 mm hex bit/allen wrench
 - Philips head bit/screw driver
 - Putty knife
 - Cutting tool (scissors)
 - Blue painters tape

IDL Supplied

- MTI Tools
- Power strips
- Cable Ties
- VHB Tape
- Templates for FS/WB (Planogram A)
- Template for SOTF 1-Table (Planogram B)
- Planograms/Install Guide
- IDL Merchandiser Badge

Check-In

- First with AT&T Associate then ask for Manager
 - Let them know you are there to install for Apple, adding iPad Blotter/Keyboard/Pen for their Apple fixture.
 - Ask for MTI security key to unlock and disarm MTI Security
 - Ask for X packages that shipped to store
 - Ask for X power supply for demo units iPads to be used.

MTI Stem Removal process (confirm y/n)

- Remove MTI Security from iPad(s)
- Remove MTI power source from strap (strap to be used later to install power strip)
- Remove two Cat 5 cables and replace with 6 ft Cat 5 E cable

Sync Pencil with iPad

Verify Pencil is synced

Power Strip

- Install power strip
 - Use existing support/strap
- WB plug into wall outlet
- FS plug into tri-tip whip
- If unable plug into empty power strip outlet

Lay provide cable out / measure and mark placement

• Cables marked/taped

- Tape cables to table
- Blotter (only for FS/WB)
 - o Packaging includes blotter, adhesives, and adhesive removal tool
 - o Install blotter following the install guide using the template provided
- Apple Pencil Tub (only for SOTF 1 or 2 table)
- iPad Pro with Smart Keyboard
 - Install security cables
 - Mount on smart keyboard (magnetic attachment built in)
- Apple Pencil
 - Attach secure cable ensuring proper amount of slack (validate in install guide)
 - Pencil cap removal and given to store manager for secure keeping
- Under Shelf / Table Components
 - Use the X bracket to install Se-Kure alarm
- Pencil Timer
 - o Goal: charge the pencil during non-store hours
 - Timer Instructions provided in kit (Woods 50007)
 - Set Pencil Timer (see instructions)
 - Set 30 minutes from 2:30 pm to 3 pm local time
 - Set 2 hours from 2 am to 4 am
 - Install Pencil timer
- Zip Ties
 - Use Zip Ties to tie up loose cords

Verify iPad is charging

Arm security

- Place batteries in new alarm box
- Plug in box to power strip
- Test security for pencil and iPad
- Lock security box

Check Out

- Ensure all tools are accounted for. Do not leave anything behind
- Leave MTI and Se-Kure Alarm Box keys with Manager
- Leave Cat 5 cables with AT&T
- Train Manager on Alarm Box
- Sign out with Manager (possible handover doc)