

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
										in effect
	0E _h	92 _h	DC bus overvoltage protection point	uint16	0~65535	RW	NO	100	1V	Suspension in effect
	0F _h	93 _h	DC bus voltage relief point	uint16	0~65535	RW	NO	55	1V	Suspension in effect
	10 _h	94 _h	DC bus voltage undervoltage point	uint16	0~65535	RW	NO	24	1V	Suspension in effect
	11 _h	95 _h	Driver overcurrent protection point	uint16	0~65535	RW	NO	10	1A	Suspension in effect
	18 _h	9C _h	Current Sampling Filter Parameters	uint16	0~65535	RW	NO	100	0.01	Suspension in effect
	1C _h	A0 _h	Current loop cutoff frequency	uint16	0~65535	RW	NO	800	1Hz	Suspension in effect
	1D _h	A1 _h	Open loop operating current	uint16	0~65535	RW	NO	625	0.01A	Suspension in effect
2002_h (basic control parameters)	01 _h	B1 _h	Control mode selection	uint16	0~5	RW	NO	4	-	The shutdown setting takes effect immediately
			Specific descriptions: 0~ CIA402 mode, 1~ NiMotion position mode, 2~ NiMotion speed mode, 3~ NiMotion torque mode, 4~ NiMotion open-loop mode, 5~ offline identification of motor parameters							
	04 _h	B4 _h	Duty cycle of output pulse	uint16	0~100	RW	NO	50	1%	Running setup stop go into

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
										effect
	13 _h	C3 _h	Internal and External Suppression Resistor Selection	uint16	0~2	RW	NO	0	1	Re-energized.
	1C _h	CD _h	firmware code	uint32	-	RO	NO	0	-	-
	1E _h	CF _h	IAP software version	uint32	-	RO	NO	0	-	-
	1F _h	D1 _h	hardware version	uint32	-	RO	NO	0	-	-
2003_h (Entity terminal input parameters)	03 _h	D5 _h	DI1 terminal function selection	uint16	0~55	RW	NO	1	1	Suspension in effect
			Specific description: see section 6.1 for details							
	04 _h	D6 _h	DI1 terminal logic selection	uint16	0~4	RW	NO	0	1	Suspension in effect
			Specific description: see section 6.1 for details							
	05 _h	D7 _h	DI2 terminal function selection	uint16	0~48	RW	NO	2	1	Suspension in effect
	06 _h	D8 _h	DI2 terminal logic selection	uint16	0~4	RW	NO	2	1	Suspension in effect
	07 _h	D9 _h	DI3 terminal function selection	uint16	0~48	RW	NO	12	1	Suspension in effect
	08 _h	DA _h	DI3 terminal logic selection	uint16	0~4	RW	NO	0	1	Suspension in effect
	09 _h	DB _h	DI4 terminal function selection	uint16	0~48	RW	NO	0	1	Suspension in effect
	0A _h	DC _h	DI4 terminal logic selection	uint16	0~4	RW	NO	0	1	Suspension in effect
	0B _h	DD _h	DI5 terminal function	uint16	0~48	RW	NO	0	1	Suspension

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
2003_h (Entity terminal input parameters)			selection							in effect
	0C _h	DE _h	DI5 terminal logic selection	uint16	0~4	RW	NO	0	1	Suspension in effect
	0D _h	DF _h	DI6 terminal function selection	uint16	0~48	RW	NO	0	1	Suspension in effect
	0E _h	E0 _h	DI6 terminal logic selection	uint16	0~4	RW	NO	0	1	Suspension in effect
	0F _h	E1 _h	DI7 terminal function selection	uint16	0~48	RW	NO	0	1	Suspension in effect
	10 _h	E2 _h	DI7 terminal logic selection	uint16	0~4	RW	NO	0	1	Suspension in effect
	11 _h	E3 _h	DI8 terminal function selection	uint16	0~48	RW	NO	0	1	Suspension in effect
	12 _h	E4 _h	DI8 terminal logic selection	uint16	0~4	RW	NO	0	1	Suspension in effect
	13 _h	E5 _h	DI9 terminal function selection	uint16	0~48	RW	NO	0	1	Suspension in effect
	14 _h	E6 _h	DI9 terminal logic selection	uint16	0~4	RW	NO	0	1	Suspension in effect
	15 _h	E7 _h	Power-Up Effective Function Assignment	uint16	0~65535	RW	NO	0	1	Suspension in effect
			Specific description: bit0-DI1, bit1-DI2, bit2-DI3; a corresponding bit of 1 indicates that the corresponding DI port is at a high level of 3.0V							
	16 _h	E8 _h	Power-Up Effective Function Assignment	uint16	0~65535	RW	NO	0	1	Suspension in effect
			Specific description: bit0-DI1, bit1-DI2, bit2-DI3; a corresponding bit of 1 indicates that the corresponding DI port is							

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
			at a high level of 3.0V							
	17 _h	E9 _h	AI1 bias	int16	-32768~32767	RW	NO	0	1mV	Suspension in effect
	18 _h	EA _h	AI1 input filter time constant	int16	0~65535	RW	NO	0	-	Suspension in effect
	19 _h	EB _h	AI1 dead zone	uint16	0~65535	RW	NO	0	1mV	Suspension in effect
	1A _h	EC _h	AI1 multiplier	int16	-32768~32767	RW	NO	0	0.001	Suspension in effect
	1B _h	ED _h	AI2 bias	int16	-32768~32767	RW	NO	0	1mV	Suspension in effect
	1C _h	EE _h	AI2 input filter time constant	int16	0~65535	RW	NO	0	-	Suspension in effect
	1D _h	EF _h	AI2 dead zone	uint16	0~65535	RW	NO	0	1mV	Suspension in effect
	1E _h	F0 _h	AI2 multiplier	int16	-32768~32767	RW	NO	0	0.001	Suspension in effect
	1F _h	F1 _h	Analog 10V corresponds to the speed value	uint16	0~4000	RW	NO	0	rpm	Suspension in effect
	20 _h	F2 _h	Analog 10V corresponds to the torque value	uint16	0~1000	RW	NO	0	0.1%	Suspension in effect
2004 _h (terminal output parameters)	01 _h	F8 _h	DO1 terminal function selection	uint16	0~30	RW	NO	0	1	Suspension in effect
			Specific description: see section 6.1 for details							
	02 _h	F9 _h	DO1 terminal logic selection	uint16	0~1	RW	NO	0	1	Suspension in effect

Index	Sub-index	Name	Description	Data type	Data range	Access- ibility	Mapp- ability	Factory setting	Unit	Activate method
			Specific description: see section 6.1 for details							
	03 _h	FA _h	DO2 terminal function selection	uint16	0~30	RW	NO	0	1	Suspension in effect
	04 _h	FB _h	DO2 terminal logic selection	uint16	0~1	RW	NO	0	1	Suspension in effect
	05 _h	FC _h	DO3 terminal function selection	uint16	0~30	RW	NO	0	1	Suspension in effect
	06 _h	FD _h	DO3 terminal logic selection	uint16	0~1	RW	NO	0	1	Suspension in effect
	07 _h	FE _h	DO4 terminal function selection	uint16	0~30	RW	NO	0	1	Suspension in effect
	08 _h	FF _h	DO4 terminal logic selection	uint16	0~1	RW	NO	0	1	Suspension in effect
	09 _h	100 _h	DO5 terminal function selection	uint16	0~30	RW	NO	0	1	Suspension in effect
	0A _h	101 _h	DO5 terminal logic selection	uint16	0~1	RW	NO	0	1	Suspension in effect
2005_h (position control parameters)	01 _h	10D _h	Location command source	uint16	0~65535	RW	NO	1	1	Suspension in effect
			Specific description: 0-pulse, 1-step amount							
	05 _h	112 _h	step size	int16	-32768~32767	RW	NO	100	inc	Suspension in effect
	1C	12E _h	Origin return time limit	uint16	0~65535	RW	NO	10000	ms	Suspension in effect
2006_h (speed control)	01 _h	148 _h	Main Speed Command A Source	uint16	0~65535	RW	NO	0	1	Suspension in effect

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
parameters)	02 _h	149 _h	Auxiliary Speed Command B Source	uint16	0~65535	RW	NO	0	1	Suspension in effect
			Specific description: 0-digit given (2006 _h : 04 _h set value)							
	03 _h	14A _h	Speed command selection	uint16	0~65535	RW	NO	0	1	Suspension in effect
			Specific description: 0-A (only 2006 _h : 01 _h is in effect), 1-B (only 2006 _h : 02 _h is in effect), 2-A+B (2006 _h : 01 _h and 2006 _h : 02 _h are in effect at the same time)							
	04 _h	14B _h	Speed command keypad setpoint	int16	-32768~32767	RW	NO	10	1rpm	immediate effect
	06 _h	14D _h	Effective speed setting value	int16	-32768~32767	RW	NO	0	1rpm	immediate effect
	07 _h	14E _h	Speed command acceleration ramp time constant	uint16	0~65535	RW	NO	10	1ms	immediate effect
	08 _h	14F _h	Speed command deceleration ramp time constant	uint16	0~65535	RW	NO	10	1ms	immediate effect
	09 _h	150 _h	Maximum RPM Threshold	uint16	0~65535	RW	NO	6000	1rpm	immediate effect
	0A _h	151 _h	Forward velocity threshold	uint16	0~65535	RW	NO	4000	1rpm	immediate effect
	0B _h	152 _h	Reverse velocity threshold	uint16	0~65535	RW	NO	4000	1rpm	immediate effect
	12 _h	159	Select 606C _n Units for Speed Feedback	uint16	0~65535	RW	NO	0	1	Suspension in effect
			Specific description: 0 ~							

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
			606C _h unit for rpm, 1 ~ 606C _h unit for user unit							
2007 _h (torque control parameters)	01 _h	15E _h	Main Torque Command A Source	uint16	0~65535	RW	NO	0	1	Suspension in effect
			Specific description: 0~digit given (set value of 2007 _h : 04 _h)							
	02 _h	15F _h	Auxiliary Torque Command B Source	uint16	0~65535	RW	NO	0	1	Suspension in effect
			Specific description: 0-digit given (2007 _h : 04 _h set values)							
	03 _h	160 _h	Torque command selection	uint16	0~65535	RW	NO	0	1	Suspension in effect
			Specific description: 0-A (only 2007 _h : 01 _h is in effect), 1-B (only 2007 _h : 02 _h is in effect), 2-A+B (2007 _h : 01 _h and 2007 _h : 02 _h are in effect at the same time)							
	04 _h	161 _h	Torque command keypad set value	int16	-32768~32767	RW	NO	10	0.1%	Suspension in effect
	05 _h	162 _h	Effective torque command setting	int16	-32768~32767	RW	NO	10	0.1%	Suspension in effect
	06 _h	163 _h	Torque command filter time constant	uint16	0~65535	RW	NO	0	0.01ms	immediate effect
			Too large a setting will reduce answerability.							
	0A _h	167 _h	Positive internal torque limit	uint16	0~65535	RW	NO	1000	0.1%	immediate effect
	0B _h	168 _h	Reverse internal torque limitation	uint16	0~65535	RW	NO	1000	0.1%	immediate effect
	10 _h	16D _h	Torque control forward speed limit value	uint16	0~65535	RW	NO	3000	1rpm	immediate effect
	11 _h	16E _h	Torque control reverse	uint16	0~65535	RW	NO	3000	1rpm	immediate

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
			speed limit value							effect
	13 _h	170 _h	Detecting torque while searching for home position in blocked rotation	uint16	0~65535	RW	NO	500	0.1%	
	15 _h	172 _h	Detection time when blocking rotation to find the home position	uint16	0~65535	RW	NO	500	ms	
2008_h (Gain parameters)	01 _h	178 _h	Velocity Loop Gain	uint16	1~20000	RW	NO	500	0.1Hz	Running the settings takes effect immediately
			Description: Set the proportional gain of the speed ring. This parameter determines the response of the speed ring, the larger the response of the speed ring, the faster the response of the speed ring, but too large a setting may cause vibration. In position mode, if you want to increase the position loop gain, you need to increase the speed loop gain at the same time.							
	02 _h	179 _h	Velocity loop integration time constant	uint16	0~51200	RW	NO	800	0.01ms	Running the settings takes effect immediately
			Specific description: Set the integration time constant of the speed ring. The smaller the value set, the stronger the integration effect is, and the deviation value at stopping is closer to 0 sooner. when this parameter is set to 51200, there is no integration effect.							
	03 _h	17A _h	Position Loop Gain	uint16	0~20000	RW	NO	1500	1	Running

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
2008_h (Gain parameters)										the settings takes effect immediately
			Specific description: Set the proportional gain of the position loop. This parameter determines the responsiveness of the position loop. Setting a larger position loop gain can shorten the positioning time, but setting it too large may cause vibration.							
	04 _h	17B _h	Second velocity loop gain	uint16	1~20000	RW	NO	1	0.1Hz	immediate effect
	05 _h	17C _h	Second velocity loop integration time constant	uint16	0~51200	RW	NO	15	0.01ms	immediate effect
	06 _h	17D _h	Second position loop gain	uint16	0~20000	RW	NO	0	1	immediate effect
	08 _h	17F _h	Second gain mode setting	uint16	0~9	RW	NO	0	1	immediate effect
			9~Actual speed, the state in which the absolute value of the actual speed exceeds (rank + time lag) [rpm] lasts during the delay time period] switches to the second gain, and the state in which the absolute value of the actual speed is less than (rank - time lag) [rpm] lasts during the delay time period returns to the first gain.							
	09 _h	180 _h	Gain switching condition selection	uint16	0~10	RW	NO	0	1	immediate effect
			Specific description: 0~ Group 1 gain, 1~ Group 2 gain							
	0A _h	181 _h	Gain switching delay time	uint16	0~10000	RW	NO	0	0.1ms	immediate effect
	0B _h	182 _h	Gain switching level	uint16	0~20000	RW	NO	0	1	immediate effect
			The generation of the actual switching action is influenced by a combination of both grade and time lag conditions							

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
			in the manner described in 2008 _h :08 _h . Depending on the gain switching mode, the units of the switching level change.							
	0C _h	183 _h	Gain switching time lag	uint16	0~20000	RW	NO	0	1	immediate effect
			The generation of the actual switching action is influenced by a combination of both grade and time lag conditions in the manner described in 2008 _h :08 _h . Depending on the gain switching mode, the units of the switching level change.							
	0F _h	186 _h	Velocity feed-forward filtering time constant	uint16	0~65535	RW	NO	0	0.01ms	immediate effect
	10 _h	187 _h	Velocity Feed Forward Gain	uint16	0~65535	RW	NO	0	0.1%	immediate effect
			When making adjustments, you should repeatedly adjust 2008 _h : 0F _h and 2008 _h : 10 _h to find a well-balanced setting.							
	11 _h	188 _h	Torque feed-forward filtering time constant	uint16	0~65535	RW	NO	0	0.01ms	immediate effect
	12 _h	189 _h	Torque Feed Forward Gain	uint16	0~65535	RW	NO	0	0.001	immediate effect
			When making adjustments, you should repeatedly adjust 2008 _h : 11 _h and 2008 _h : 12 _h to find a well-balanced setting.							
	14 _h	18B _h	Velocity feedback low-pass filter cutoff frequency	uint16	0~4000	RW	NO	900	1Hz	immediate effect
			Specific description: the smaller the setting, the smaller the speed feedback fluctuation, but the feedback delay is also larger, generally keep the default parameters can be.							
	06 _h	197 _h	Parameter offline recognition status display	uint16	0~65535	RO	NO	0	1	-

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
2009_h (gain parameters)	0D _h	19E _h	Group 1 Trap Frequency	uint16	0~2000	RW	NO	0	1Hz	immediate effect
			Specific description: Set the center frequency of the trap, which is the mechanical resonance frequency.							
	0E _h	19F _h	Trap width of group 1 traps	uint16	0~2000	RW	NO	0	1Hz	immediate effect
			Specific description: Setting the bandwidth on either side of the center frequency of the mechanical resonance							
	0F _h	1A0 _h	Group 1 Trap Depth	uint16	0~100	RW	NO	0	%	immediate effect
			Specific descriptions: 0~ no trapping, 100~ maximum trap depth							
	10 _h	1A1 _h	Group 2 Trap Frequency	uint16	0~2000	RW	NO	0	1Hz	immediate effect
	11 _h	1A2 _h	Trap width of group 2 traps	uint16	0~2000	RW	NO	0	1Hz	immediate effect
	12 _h	1A3 _h	Group 2 trap depth	uint16	0~100	RW	NO	0	1	immediate effect
	13 _h	1A4 _h	Group 3 Trap Frequency	uint16	0~2000	RW	NO	0	1Hz	immediate effect
	14 _h	1A5 _h	Trap width of group 3 traps	uint16	0~2000	RW	NO	0	1Hz	immediate effect
	15 _h	1A6 _h	Group 3 trap depth	uint16	0~100	RW	NO	0	1	immediate effect
	16 _h	1A7 _h	Group 4 Trap Frequency	uint16	0~2000	RW	NO	0	1Hz	immediate effect
	17 _h	1A8 _h	Trap width of group 4 traps	uint16	0~2000	RW	NO	0	1Hz	immediate effect
	18 _h	1A9 _h	Group 4 trap depth	uint16	0~100	RW	NO	0	1	immediate

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
										effect
200Ah (fault and protection parameters)	06h	1BC _h	Overspeed Fault Threshold	uint16	0~65535	RW	NO	0	1	immediate effect
200B_h (monitoring parameters)	01 _h	1DE _h	Motor Driver Internal Status	uint16	0~12	RO	NO	0	1	-
			Specific description: 0~not ready, 1~ready, 6~position closed-loop control, 8~speed closed-loop control, 9~torque control, 10~open-loop control, 12~error							
	02 _h	1DF _h	Actual motor speed	int16	-32768~32767	RO	NO	-	1rpm	-
	04 _h	1E1 _h	Internal Torque Command	int16	-32768~32767	RO	NO	0	0	-
	05 _h	1E2 _h	Input signal (DI signal) monitoring	uint16	0~65535	RO	NO	0	1	-
	06 _h	1E3 _h	Output signal (DO signal) monitoring	uint16	0~65535	RO	NO	0	1	-
	0A _h	1E8 _h	Input PWM frequency	uint16	0~65535	RO	NO	0	1Hz	-
	0F _h	1F0 _h	Total power-up time	uint32	0~4294967295	RO	NO	0	s	-
	10	1F2 _h	AI1 Sampling Voltage Value	uint16	-1200-1200	RO	NO	-1200	mV	
	11	1F3 _h	AI2 Sampling Voltage Value	uint16	-1200-1200	RO	NO	-1200	mV	
	12 _h	1F4 _h	RMS value of phase A current	uint16	0~65535	RO	NO	0	0.01A	-
	13 _h	1F5 _h	RMS value of phase B current	uint16	0~65535	RO	NO	0	0.01A	-
	14 _h	1F6 _h	RMS phase C current	uint16	0~65535	RO	NO	0	0.01A	-

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
	15 _h	1F7 _h	Busbar voltage value	uint16	0~65535	RO	NO	0	0.1V	-
	16 _h	1F8 _h	Module Temperature Value	int16	-32768~32767	RO	NO	0	1°C	-
	2D _h	211 _h	Actual motor speed	uint16	0~65535	RO	NO	-	0.1rpm	-
200C_h (communication parameters)	01 _h	22F _h	Communication method selection	uint16	0~2	RW	NO	1	1	Re-energized.
			Specific description: 0~External pulse control (default CAN communication), 1~EtherCAT, 2~CAN							
	02 _h	230 _h	Drive Axis Address	uint16	1~247	RW	NO	1	1	Re-energized.
			1~247: When multiple motors are grouped for networking, each motor can only have a unique address, otherwise it will result in abnormal or no communication.							
	03 _h	231 _h	Serial Baud Rate Setting	uint16	0~9	RW	NO	5	1	Re-energized.
			The communication rate of the motor must be the same as the communication rate of the host computer, otherwise it cannot communicate.							
	18 _h	246 _h	Synchronization Mode Enable	uint16	0~1	RW	NO	0	1	Re-energized.
200E_h (fault code)	01 _h	25B _h	Motor overload	int32	-214748364~2147483647	RW	NO	67183377	1	immediate effect
	02 _h	25D _h	motor stalling	int32	-214748364~2147483647	RW	NO	8978	1	immediate effect
	03 _h	25F _h	power overvoltage	int32	-214748364~2147483647	RW	NO	78352	1	immediate effect
	04 _h	261 _h	Power supply undervoltage	int32	-214748364~2147483647	RW	NO	16855584	1	immediate effect

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
200E_h (fault code)	05 _h	263 _h	overheating	int32	-214748364~2147483647	RW	NO	82448	1	immediate effect
	06 _h	265 _h	too low a temperature	int32	-214748364~2147483647	RW	NO	82464	1	immediate effect
	07 _h	267 _h	Parameter setting error	int32	-214748364~2147483647	RW	NO	90912	1	immediate effect
	08 _h	269 _h	Motor overspeed	int32	-214748364~2147483647	RW	NO	94992	1	immediate effect
	09 _h	26B _h	communications failure	int32	-214748364~2147483647	RW	NO	95489	1	immediate effect
	0A _h	26D _h	Origin return timeout error	int32	-214748364~2147483647	RW	NO	34320	1	immediate effect
	0B _h	26F _h	position overshooting error	int32	-214748364~2147483647	RW	NO	34321	1	immediate effect
	0C _h	271 _h	software overrun fault	int32	-214748364~2147483647	RW	NO	50431507	1	immediate effect
	0D _h	273 _h	Overrun switch failure	int32	-214748364~2147483647	RW	NO	50431507	1	immediate effect
	0E _h	275 _h	Output phase failure	int32	-214748364~2147483647	RW	NO	12933	1	immediate effect
	0F _h	277 _h	Errors in curve planning calculations	int32	-214748364~2147483647	RW	NO	67208725	1	immediate effect
	10 _h	279 _h	Target position overflow	int32	-214748364~2147483647	RW	NO	99862	1	immediate effect

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
200E_h (fault code)	11 _h	27B _h	Curve planning parameters too small	int32	-214748364~2147483647	RW	NO	83985943	1	immediate effect
200F (encoder parameters)	0A _h	28B _h	Multi-turn absolute encoder function test	int32	-2147483648~2147483647	RO	NO	0	1	Suspension in effect
	0B _h	28C _h	Multi-turn absolute encoder battery voltage	int32	-2147483648~2147483647	RO	NO	0	mv	Suspension in effect
	0C _h	28D _h	Multiturn Absolute Encoder Calibration Instructions	int32	-2147483648~2147483647	RW	NO	0	1	immediate effect
	0D _h	28E _h	Multiturn Absolute Encoder Calibration Completion Detection Command	int32	-2147483648~2147483647	RO	NO	0	1	immediate effect
	0E _h	28F _h	Multi-turn absolute encoder zero absolute A	int32	-2147483648~2147483647	RW	NO	0	1	immediate effect
	0F _h	290 _h	Multiturn absolute encoder zero absolute B	int32	-2147483648~2147483647	RW	NO	0	1	immediate effect
	01 _h	291 _h	Multi-stage position operation mode	uint16	0~2	RW	NO	0	1	Suspension in effect
			Specific description: see section 5.16.4 for details							
	02 _h	292 _h	Number of position	uint16	1~16	RW	NO	1	1	Suspension

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
2011_h (Multi-segment position function parameters)			instruction end segments							in effect
			Specific description: Setting the total number of segments for multi-segment position commands							
	04 _h	294 _h	Number of multisegment position cycles	uint16	0~65535	RW	NO	0	1	Suspension in effect
			Specific description: number of cycles in which the multi-segment position operation mode is 1							
	05 _h	295 _h	Position command type selection	uint16	0~1	RW	NO	0	1	Suspension in effect
			Specific description: 0-relative displacement; 1-absolute displacement							
	06 _h	296 _h	Multi-segment positional loop starting segment	uint16	0~16	RW	NO	0	1	Suspension in effect
			Specific description: Starting segment of a multi-segment position operating mode 1							
	07 _h	297 _h	Paragraph 1 mobile displacement	int32	-2147483648~2147483647	RW	NO	-1073741824	user unit	Suspension in effect
	08 _h	299 _h	Maximum operating speed for 1st displacement	uint16	0~3000	RW	NO	1	rpm	Suspension in effect
	09 _h	29A _h	1st displacement acceleration and deceleration time	uint16	0~65535	RW	NO	0	ms	Suspension in effect
			Specific description: Setting the time for the first motor of the multi-stage position to go from 0rpm to 1000rpm.							
	0A _h	29B _h	Waiting time after completion of the first displacement	uint16	0~65535	RW	NO	0	ms	Suspension in effect
			Specific description: the waiting time after the 1st displacement of a multi-segment position has been run and before the next displacement is run							

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
2011_h (Multi-segment position function parameters)	0B _h	29C _h	Paragraph 2 mobile displacement	int32	-2147483648~2147483647	RW	NO	-1073741824	user unit	Suspension in effect
	0C _h	29E _h	Maximum operating speed for 2nd displacement	uint16	0~3000	RW	NO	1	rpm	Suspension in effect
	0D _h	29F _h	2nd displacement plus deceleration time	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	0E _h	2A0 _h	Waiting time after completion of the 2nd displacement	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	0F _h	2A1 _h	Paragraph 3 mobile displacement	int32	-2147483648~2147483647	RW	NO	-1073741824	user unit	Suspension in effect
	10 _h	2A3 _h	Maximum operating speed for 3rd displacement	uint16	0~3000	RW	NO	1	rpm	Suspension in effect
	11 _h	2A4 _h	3rd displacement plus deceleration time	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	12 _h	2A5 _h	Waiting after the 3rd displacement is completed timing	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	13 _h	2A6 _h	Paragraph 4 mobile displacement	int32	-2147483648~2147483647	RW	NO	-1073741824	user unit	Suspension in effect
	14 _h	2A8 _h	Maximum operating speed for segment 4 displacements	uint16	0~3000	RW	NO	1	rpm	Suspension in effect

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
2011_h (Multi-segment position function parameters)	15 _h	2A9 _h	4th displacement plus deceleration time	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	16 _h	2AA _h	Waiting time after completion of paragraph 4 displacement	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	17 _h	2AB _h	Paragraph 5 mobile displacement	int32	-2147483648~2147483647	RW	NO	-1073741824	user unit	Suspension in effect
	18 _h	2AD _h	Maximum operating speed for segment 5 displacements	uint16	0~3000	RW	NO	1	rpm	Suspension in effect
	19 _h	2AE _h	Paragraph 5 displacement plus deceleration time	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	1A _h	2AF _h	Waiting time after completion of paragraph 5 displacement	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	1B _h	2B0 _h	Paragraph 6 mobile displacement	int32	-2147483648~2147483647	RW	NO	-1073741824	user unit	Suspension in effect
	1C _h	2B2 _h	Maximum operating speed for segment 6 displacements	uint16	0~3000	RW	NO	1	rpm	Suspension in effect
	1D _h	2B3 _h	Paragraph 6 displacement acceleration and deceleration times	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	1E _h	2B4 _h	Waiting time after	uint16	0~65535	RW	NO	0	ms	Suspension

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
2011_h (Multi-segment position function parameters)			completion of paragraph 6 displacement							in effect
	1F _h	2B5 _h	Paragraph 7 mobile displacement	int32	-2147483648~2147483647	RW	NO	-1073741824	user unit	Suspension in effect
	20 _h	2B7 _h	Maximum operating speed for segment 7 displacements	uint16	0~3000	RW	NO	1	rpm	Suspension in effect
	21 _h	2B8 _h	Paragraph 7 displacement plus deceleration time	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	22 _h	2B9 _h	Waiting time after completion of paragraph 7 displacement	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	23 _h	2BA _h	Paragraph 8 mobile displacement	int32	-2147483648~2147483647	RW	NO	-1073741824	user unit	Suspension in effect
	24 _h	2BC _h	Maximum operating speed for segment 8 displacements	uint16	0~3000	RW	NO	1	rpm	Suspension in effect
	25 _h	2BD _h	Paragraph 8 displacement plus deceleration time	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	26 _h	2BE _h	Waiting time after completion of paragraph 8 displacement	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	27 _h	2BF _h	Paragraph 9 mobile displacements	int32	-2147483648~2147483647	RW	NO	-1073741824	user unit	Suspension in effect

Index	Sub-index	Name	Description	Data type	Data range	Access-ability	Mapp-ability	Factory setting	Unit	Activate method
2011_h (Multi-segment position function parameters)	28 _h	2C1 _h	Maximum operating speed for paragraph 9 displacements	uint16	0~3000	RW	NO	1	rpm	Suspension in effect
	29 _h	2C2 _h	Paragraph 9 displacement plus deceleration time	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	2A _h	2C3 _h	Waiting time after completion of paragraph 9 displacement	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	2B _h	2C4 _h	Paragraph 10 mobile displacement	int32	-2147483648~2147483647	RW	NO	-1073741824	user unit	Suspension in effect
	2C _h	2C6 _h	Maximum operating speed for paragraph 10 displacements	uint16	0~3000	RW	NO	1	rpm	Suspension in effect
	2D _h	2C7 _h	Paragraph 10 displacement acceleration and deceleration times	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	2E _h	2C8 _h	Waiting time after completion of paragraph 10 displacement	uint16	0~65535	RW	NO	0	ms	Suspension in effect
	2F _h	2C9 _h	Paragraph 11 mobile displacement	int32	-2147483648~2147483647	RW	NO	-1073741824	user unit	Suspension in effect
	30 _h	2CB _h	Maximum operating speed for paragraph 11 displacements	uint16	0~3000	RW	NO	1	rpm	Suspension in effect