
Window t: acquire active IMUs
Estimate reliability of active IMUs
Fuse predictions and compute entropy
Check cost budget and dwell state
KEEP / ACTIVATE / DEACTIVATE / PROBE
Window t+1: acquire selected IMUs