

- a) Add U1&U2 but not R1,R2,R3,R4 if you connect the Adapter directly to the MiSTer FPGA SNAC Port. b) Add R1,R2,R3,R4 (OR,SMD 0805) but not U1&U2 if you connect the Adapter using a SNAC Port Level
- Shifter Adapter to the MiSTer FPGA SNAC Port. c) Add C1 (4.7uF,SMD 0805) if you draw more than 500ma on J3 or the power cable is longer than 20cm.
- d) For SRQ usage (C128), solder LV,HV,GND and one Channel for LV5/HV5 onto a "stacked" Level-Shifter.

Converts the MiSTer FPGA SNAC Port into a Commodore IEC/CBM (Serial) Bus Port.

Sheet: /

File: SNAC2IEC_Breakout.kicad_sch

Titl	e:	SNA	C2	IEC

Size: A4	Rev: v1.2
KiCad E.D.A. kicad (6.0.11)	ld: 1/1