Essae Label Printer Driver Installation Guide (ARM64)

Prepared By	Venkatesh M	venkatesh.muninagaraju@essae.com
Reviewed By	Nagarajan V	nagarajan@essae.com

Version: v2.0

Architecture: ARM64 (for Rockchip RK3568 board)

Project Folder: Essae_WSLPR_v2.0

1. Files Required

Ensure the following application files are compiled and placed in the appropriate folder:

File	Description
Essae_WSLPR_server_v2.0	ARM64 binary for label printing server
Essae_WSLPR_client_v2.0.py	Python GUI client
SQL_LFT_Files.db	SQLite3 database with label formats
config.json	Configuration file

These files will be installed into /usr/local/bin/ via the .deb package.


2. Directory Structure for .deb Package

Prepare the .deb package folder with the following structure:

essae-label-driver-arm64/

--- DEBIAN/

— control



3. control File Content

Location: DEBIAN/control

Package: essae-label-driver

Version: 2.0

Architecture: arm64

Maintainer: venkatesh m venkatesh.muninagaraju@essae.com>

Depends: python3, python3-pyqt5, libsqlite3-0, libjson-c5

Description: Essae Label Printer Driver with GUI and user-space service.

4. Systemd Service File

Location: etc/systemd/system/essae-label-driver.service

[Unit]

Description=Essae Label Driver Service

After=network.target

[Service]

ExecStart=/usr/local/bin/Essae_WSLPR_server_v2.0

Restart=always

User=root

WorkingDirectory=/usr/local/bin

StandardOutput=journal

StandardError=journal

[Install]

WantedBy=multi-user.target

5. Desktop Shortcut

Location: usr/share/applications/EssaeLabelClient.desktop

[Desktop Entry]

Version=1.0

Name=Essae Label Printer GUI

Exec=python3/usr/local/bin/Essae WSLPR client v2.0.py

Icon=utilities-terminal

Terminal=false

Type=Application

Categories=Utility;

6. Build the .deb Package

Navigate to the main project folder Essae_WSLPR_v2.0 and run the following commands:

\$ gcc -o Essae_WSLPR_server_v2.0 Essae_WSLPR_server_v2.0.c -ljson-c -lsqlite3 -lm

\$ dpkg-deb --build essae-label-driver-arm64

Output:

essae-label-driver-arm64.deb

7. Install on ARM64 Device (e.g., RK3568)

Transfer the .deb file to your ARM64 device, then install it:

\$ sudo apt install ./essae-label-driver-arm64.deb

To uninstall:

\$ sudo apt remove essae-label-driver

8. Enable and Start the Service

Run the following commands to enable and start the service:

\$ sudo systemctl daemon-reload

\$ sudo systemctl enable essae-label-driver.service

\$ sudo systemctl start essae-label-driver.service

\$ sudo systemctl status essae-label-driver.service

9. Launch the GUI

You can launch the GUI in one of two ways:

Option 1: From Terminal

\$ python3 /usr/local/bin/Essae_WSLPR_client_v2.0.py

Option 2: From Application Menu

Navigate to:

Applications > Utility > Essae Label Printer GUI