

Notices

© Agilent Technologies, Inc. 2000-2015, 2016

No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior agreement and written consent from Agilent Technologies, Inc. as governed by United States and international copyright laws.

Manual Part Number

G2938-90034 Rev. C

Edition

12/2016

Printed in Germany

Agilent Technologies Hewlett-Packard-Strasse 8 76337 Waldbronn

For Research Use Only

Not for use in diagnostic procedures

Warranty

The material contained in this document is provided "as is," and is subiect to being changed, without notice. in future editions. Further, to the maximum extent permitted by applicable law, Agilent disclaims all warranties, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. Agilent shall not be liable for errors or for incidental or consequential damages in connection with the furnishing, use, or performance of this document or of any information contained herein. Should Agilent and the user have a separate written agreement with warranty terms covering the material in this document that conflict with these terms, the warranty terms in the separate agreement shall control.

Technology Licenses

The hardware and/or software described in this document are furnished under a license and may be used or copied only in accordance with the terms of such license.

Restricted Rights Legend

If software is for use in the performance of a U.S. Government prime contract or sub-contract, Software is delivered and licensed as "Commercial computer software" as defined in DFAR 252.227-7014 (June 1995), or as a "commercial item" as defined in FAR 2.101(a) or as "Restricted computer software" as defined in FAR 52.227-19 (June 1987) or any equivalent agency regulation or contract clause. Use, duplication or disclosure of Software is subject to Agilent Technologies' standard commercial license terms, and non-DOD Departments and Agencies of the U.S. Government will

receive no greater than Restricted Rights as defined in FAR 52.227-19(c)(1-2) (June 1987). U.S. Government users will receive no greater than Limited Rights as defined in FAR 52.227-14 (June 1987) or DFAR 252.227-7015 (b)(2) (November 1995), as applicable in any technical data.

Safety Notices

CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

WARNING

A WARNING notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING notice until the indicated conditions are fully understood and met.

Contents

1	Agilent RNA 6000 Nano Kit 4
2	Required Equipment for RNA 6000 Nano Assay 6
3	Setting up the Assay Equipment and Bioanalyzer 7
	Setting up the Chip Priming Station 8 Setting up the Bioanalyzer 9 Vortex Mixer 9
	Starting the 2100 Expert Software 10
1	Essential Measurement Practices 11
5	Preparing the RNA Ladder after Arrival 13
6	Agilent RNA 6000 Nano Assay Protocol 14
	Decontaminating the Electrodes 14 Preparing the Gel 15
	Preparing the Gel-Dye Mix 16
	Loading the Gel-Dye Mix 17
	Loading the RNA 6000 Nano Marker 18
	Loading the Ladder and Samples 19 Inserting a Chip in the Agilent 2100 Bioanalyzer 20
	Starting the Chip Run 22
	Cleaning Electrodes after a RNA 6000 Nano Chip Run 24
7	Checking Your Agilent RNA 6000 Nano Assay Results 25
	RNA 6000 Nano Ladder Well Results 25
	RNA 6000 Nano Sample Well Results 26



Agilent RNA 6000 Nano Kit

 Table 1
 Agilent RNA 6000 Nano Kit (reorder number 5067-1511)

Agilent RNA 6000 Nano Chips	Agilent RNA 6000 Nano Reagents (reorder number 5067-1512) & Supplies (yellow) Agilent RNA 6000 Ladder (reorder number 5067-1529)		
25 RNA Nano Chips			
2 Electrode Cleaners	• (blue) RNA Nano Dye Concentrate ¹		
	• (green) Agilent RNA 6000 Nano Marker (2 vials)		
Syringe Kit	• (red) Agilent RNA 6000 Nano Gel Matrix (2 vials)		
1 Syringe	4 Spin Filters		
Tubes for Gel-Dye Mix			

³⁰ Safe-Lock Eppendorf Tubes PCR clean (DNase/RNase free) for gel-dye mix



[&]quot;This product is provided under a license by Life Technologies Corporation to Agilent Technologies. The purchase of this product conveys to the buyer the non-transferable right to use the purchased amount of the product and components of the product only as described in accompanying product literature. The sale of this product is expressly conditioned on the buyer not using the product or its components (1) in manufacturing; (2) to provide a service, information, or data to an unaffiliated third party for payment; (3) for therapeutic, diagnostic or prophylactic purposes; (4) to resell, sell or otherwise transfer this product or its components to any third party, or use for any use other than use in the subfields of research and development, quality control, forensics, environmental analysis, biodefense or food safety testing. For information on purchasing a license to this product for purposes other than described above contact Life Technologies Corporation, Cell Analysis Business Unit, Business Development, 29851 Willow Creek Road, Eugene, OR 97402, Tel: (541) 465-8300. Fax: (541) 335-0354."

 Table 2
 Physical Specifications

Туре	Specification	
Analysis run time	30 min	
Number of samples	12 samples/chip	
Sample volume	1 μL	
Kit stability	= 4 months at 4 °C	
Kit size	25 chips	
	12 samples/chip	
	= 300 samples/kit	

 Table 3
 Analytical Specifications

Specification	Total RNA Assay	mRNA Assay
Quantitative range	25 – 500 ng/μL	25 – 250 ng/μL
Qualitative range	5 – 500 ng/μL	5 – 250 ng/μL
Sensitivity (S/N>3)	5 ng/μL in water	25 ng/μL in water
Quantitation reproducibility (within a chip)	10 % CV	10 % CV
Quantitation accuracy ¹	20 %	20 %
Maximum sample buffer strength	100 mM Tris 0.1 mM EDTA or 125 mM NaCl 15 mM MgCl ₂	100 mM Tris 0.1 mM EDTA or 125 mM NaCl 15 mM MgCl ₂

¹ Determined analyzing the RNA ladder as sample



Equipment Supplied with the Agilent 2100 Bioanalyzer

- Chip priming station (reorder number 5065-4401)
- IKA vortex mixer
- 16-pin bayonet electrode cartridge (reorder number 5065-4413)

Additional Material Required (Not Supplied)

- RNaseZAP® recommended for electrode decontamination (Ambion, Inc. cat. no. 9780)
- · RNase-free water
- Pipettes (10 μ l and 1000 μ l) with compatible tips (RNase-free, no filter tips, no autoclaved tips)
- 1.5 ml microcentrifuge tubes (RNase-free)
- Microcentrifuge (≥ 1300 g)
- Heating block or water bath for ladder/sample denaturation

Check the Agilent Lab-on-a-Chip webpage for details on assays: www.agilent.com/chem/labonachip.





Setting up the Assay Equipment and Bioanalyzer

Before beginning the chip preparation protocol, ensure that the chip priming station and the bioanalyzer are set up and ready to use.

You have to

- replace the syringe at the chip priming station with each new kit
- · adjust the base plate of the chip priming station
- adjust the syringe clip at the chip priming station
- set up the vortex mixer
- finally, make sure that you start the software before you load the chip.

NOTE

The RNA 6000 Nano assay is a high sensitivity assay. Please read this guide carefully and follow all instructions to guarantee satisfactory results.

Setting up the Chip Priming Station

NOTE

Replace the syringe with each new reagent kit.

1 Replace the syringe:

- **a** Unscrew the old syringe from the lid of the chip priming station.
- **b** Release the old syringe from the clip. Discard the old syringe.
- **c** Remove the plastic cap of the new syringe and insert it into the clip.
- **d** Slide it into the hole of the luer lock adapter and screw it tightly to the chip priming station.

2 Adjust the base plate:

- **a** Open the chip priming station by pulling the latch.
- **b** Using a screwdriver, open the screw at the underside of the base plate.
- **c** Lift the base plate and insert it again in position C. Retighten the screw.

3 Adjust the syringe clip:

a Release the lever of the clip and slide it up to the top position.







Setting up the Bioanalyzer

1 Open the lid of the bioanalyzer and make sure that the electrode cartridge is inserted in the instrument. If not, open the latch and insert the electrode cartridge.



Figure 1 Electrode cartridge inserted in the instrument (graphic shows an example).

2 Remove any remaining chip.

Vortex Mixer

IKA - Model MS3

1 To set up the vortex mixer, adjust the speed knob to 2400 rpm.




Starting the 2100 Expert Software

To start the software:

1 Go to your desktop and double-click the following icon.



The screen of the software appears in the **Instrument** context. The icon in the upper part of the screen represents the current instrument/PC communication status:



2 If more than one instrument is connected to your PC, select the instrument you want to use in the tree view.





Essential Measurement Practices

- Handle and store all reagents according to the instructions on the label of the individual box.
- Avoid sources of dust or other contaminants. Foreign matter in reagents and samples or in the wells of the chip will interfere with assay results.
- Allow all reagents to equilibrate to room temperature for 30 min before use. Thaw samples on ice.
- Protect dye and dye mixtures from light. Remove light covers only when
 pipetting. The dye decomposes when exposed to light and this reduces the
 signal intensity.
- Always insert the pipette tip to the bottom of the well when dispensing the liquid. Placing the pipette at the edge of the well may lead to poor results.






- Always wear gloves when handling RNA and use RNase-free tips, microcentrifuge tubes and water.
- It is recommended to heat denature all RNA samples and RNA ladder before use for 2 min and 70 $^{\circ}$ C (once) and keep them on ice.
- Do not touch the Agilent 2100 Bioanalyzer instrument during analysis and never place it on vibrating surface.
- Always vortex the dye concentrate for 10 s before preparing the gel-dye mix and spin down afterwards.
- Use a new syringe and electrode cleaners with each new kit.

4 Essential Measurement Practices

Starting the 2100 Expert Software

- Use loaded chips within 5 min after preparation. Reagents might evaporate, leading to poor results.
- To prevent contamination (e.g. RNase), it is strongly recommended to use a dedicated electrode cartridge for RNA assays.
- Perform the RNase decontamination procedure for the electrodes daily before running any assays. Refer to the Kit Guide for details on electrode cleaning and decontamination.



Preparing the RNA Ladder after Arrival

For proper handling of the ladder, following steps are necessary:

- 1 After reagent kit arrival, spin ladder down. The ladder can be ordered separately (reorder number 5067-1529).
- **2** Heat denature the ladder for 2 min at 70 °C.
- **3** Immediately cool the vial on ice.
- **4** Prepare aliquots in RNase- free vials with the required amount for a typical daily use.
- **5** Store aliquots at -70 °C.
- **6** Before use, thaw ladder aliquots and keep them on ice (avoid extensive warming upon thawing process).



Agilent RNA 6000 Nano Assay Protocol

After completing the initial steps in "Setting up the Assay Equipment and Bioanalyzer" on page 7, you can prepare the assay, load the chip, and run the assay, as described in the following procedures.

NOTE

If you use the RNA 6000 Nano kit for the first time, you must read these detailed instructions. If you have some experience, you might want to use the *Agilent RNA 6000 Nano Quick Start Guide*.

Decontaminating the Electrodes

To avoid decomposition of your RNA sample, follow this electrode decontamination procedure on a daily basis before running any RNA Nano assays.

NOTE

Perform the following RNase decontamination procedure on a daily basis before running any assays.

- 1 Slowly fill one of the wells of an electrode cleaner with 350 µl RNaseZAP.
- **2** Open the lid and place the electrode cleaner in the Agilent 2100 Bioanalyzer.
- **3** Close the lid and leave it closed for about 1 minute.
- 4 Open the lid and remove the electrode cleaner. Label the electrode cleaner and keep it for future use. You can reuse the electrode cleaner for all 25 chips in the kit.
- 5 Slowly fill one of the wells of another electrode cleaner with 350 μ l RNase-free water.



- 6 Place electrode cleaner in the Agilent 2100 Bioanalyzer.
- **7** Close the lid and leave it closed for about 10 seconds.
- **8** Open the lid and remove the electrode cleaner. Label the electrode cleaner and keep it for future use.
- **9** Wait another 10 seconds to allow the water on the electrodes to evaporate before closing the lid.

Preparing the Gel

- 1 Allow all reagents to equilibrate to room temperature for 30 minutes before use.
- 2 Place 550 µL of Agilent RNA 6000 Nano gel matrix (red ●) into the top receptacle of a spin filter.
- 3 Place the spin filter in a microcentrifuge and spin for 10 minutes at $1500 \text{ g} \pm 20 \%$ (for Eppendorf microcentrifuge, this corresponds to 4000 rpm).
- 4 Aliquot 65 μ l filtered gel into 0.5 ml RNase-free microcentrifuge tubes that are included in the kit. Store the aliquots at 4 °C and use them within one month of preparation.


Preparing the Gel-Dye Mix

WARNING

Handling DMS0

Kit components contain DMSO. Because the dye binds to nucleic acids, it should be treated as a potential mutagen and used with appropriate care.

- Wear hand and eye protection and follow good laboratory practices when preparing and handling reagents and samples.
- → Handle the DMSO stock solutions with particular caution as DMSO is known to facilitate the entry of organic molecules into tissues.
- 1 Allow all reagents to equilibrate to room temperature for 30 minutes before use. Protect the dye concentrate from light while bringing it to room temperature.
- **2** Vortex RNA 6000 Nano dye concentrate (blue •) for 10 seconds and spin down.
- 3 Add 1 μl of blue-capped RNA 6000 Nano dye concentrate (blue •) to a 65 μl aliquot of filtered gel (prepared as described in "Preparing the Gel" on page 15).



- **4** Cap the tube, vortex thoroughly and visually inspect proper mixing of gel and dye. Store the dye concentrate at 4 °C in the dark again.
- **5** Spin tube for 10 minutes at room temperature at 13000 g (for Eppendorf microcentrifuge, this corresponds to 14000 rpm). Use prepared gel-dye mix within one day.

NOTE


A larger volume of gel-dye mix can be prepared in multiples of the 65+1 ratio, if more than one chip will be used within one day. Always re-spin the gel-dye mix at 13000 g for 10 minutes before each use.

Loading the Gel-Dye Mix

NOTE

Before loading the gel-dye mix, make sure that the base plate of the chip priming station is in position (C) and the adjustable clip is set to the top position. Refer to "Setting up the Chip Priming Station" on page 8 for details.

- 1 Allow the gel-dye mix to equilibrate to room temperature for 30 minutes before use. Protect the gel-dye mix from light during this time.
- 2 Take a new RNA chip out of its sealed bag.
- **3** Place the chip on the chip priming station.
- 4 Pipette 9.0 μl of the gel-dye mix at the bottom of the well marked **G** and dispense the gel-dye mix.



NOTE

When pipetting the gel-dye mix, make sure not to draw up particles that may sit at the bottom of the gel-dye mix vial. Insert the tip of the pipette to the bottom of the chip well when dispensing. This prevents a large air bubble forming under the gel-dye mix. Placing the pipette at the edge of the well may lead to poor results.





5 Set the timer to 30 seconds, make sure that the plunger is positioned at 1 ml and then close the chip priming station. The lock of the latch will click when the chip priming station is closed correctly.

6 Agilent RNA 6000 Nano Assay Protocol

Loading the RNA 6000 Nano Marker

- **6** Press the plunger of the syringe down until it is held by the clip.
- **7** Wait for exactly 30 seconds and then release the plunger with the clip release mechanism.
- **8** Visually inspect that the plunger moves back at least to the 0.3 ml mark.
- **9** Wait for 5 seconds, then slowly pull back the plunger to the 1 ml position.
- **10** Open the chip priming station.
- 11 Pipette 9.0 µl of the gel-dye mix in each of the wells marked **G**





NOTE

Please discard the remaining vial with gel-dye mix.

Loading the RNA 6000 Nano Marker



NOTE

Do not leave any wells empty or the chip will not run properly. Unused wells must be filled with 5 μ l of the green-capped RNA 6000 Nano marker (green •) plus 1 μ l of the buffer in which the samples are diluted.


Loading the Ladder and Samples

NOTE

Always use RNase-free microcentrifuge tubes, pipette tips and water.

- 1 Before use, thaw ladder aliquots and keep them on ice (avoid extensive warming upon thawing process).
- 2 To minimize secondary structure, heat denature (70 °C, 2 minutes) the samples before loading on the chip.
- 3 Pipette 1 μl of the RNA ladder into the well marked with the ladder symbol §.
- 4 Pipette 1 μl of each sample into each of the 12 sample wells.
- **5** Set the timer to 60 seconds.
- **6** Place the chip horizontally in the adapter of the IKA vortex mixer and make sure not to damage the buldge that fixes the chip during vortexing.
 - If there is liquid spill at the top of the chip, carefully remove it with a tissue.





CAUTION

Wrong vortexing speed

If the vortexing speed is too high, liquid spill that disturbs the analysis may occur for samples generated with detergent containing buffers.

→ Reduce vortexing speed to 2000 rpm!

6 Agilent RNA 6000 Nano Assay Protocol

Inserting a Chip in the Agilent 2100 Bioanalyzer

- 7 Vortex for 60 seconds at 2400 rpm.
- **8** Refer to the next topic on how to insert the chip in the Agilent 2100 Bioanalyzer. Make sure that the run is started within 5 minutes.

NOTE

Depending on the RNA isolation protocol, varying results can be expected. Known dependencies include: salt content, cell fixation method and tissue stain. Best results are achieved for RNA samples which are dissolved in deionized and RNase-free water. Avoid genomic DNA contamination by including DNase treatment in the preparation protocol.

Inserting a Chip in the Agilent 2100 Bioanalyzer

- 1 Open the lid of the Agilent 2100 Bioanalyzer.
- 2 Check that the electrode cartridge is inserted properly. Refer to "Setting up the Bioanalyzer" on page 9 for details.
- **3** Place the chip carefully into the receptacle. The chip fits only one way.


CAUTION

Sensitive electrodes and liquid spills

Forced closing of the lid may damage the electrodes and dropping the lid may cause liquid spills resulting in bad results.

- → Do not use force to close the lid and do not drop the lid onto the inserted chip.
- **4** Carefully close the lid. The electrodes in the cartridge fit into the wells of the chip.
- **5** The 2100 Expert Software screen shows that you have inserted a chip and closed the lid by displaying the chip icon at the top left of the **Instrument** context.

Inserting a Chip in the Agilent 2100 Bioanalyzer




Starting the Chip Run

Starting the Chip Run

NOTE

Please note that the order of executing the chip run may change if the Agilent Security Pack software (only applicable for Agilent 2100 Expert Software Revision B.02.02 and higher) is installed. For more details please read the 'User's Guide' which is part of the Online Help of your 2100 Expert Software.


1 In the **Instrument** context, select the appropriate assay from the Assay menu.



2 Accept the current File Prefix or modify it.


NOTE

Run sample numbers can vary between assays.



Data will be saved automatically to a file with a name using the prefix you have just entered. At this time you can also customize the file storage location and the number of samples that will be analyzed.

3 To enter sample information like sample names and comments, complete the sample name table.



4 Click the **Start** button in the upper right of the window to start the chip run. The incoming raw signals are displayed in the **Instrument** context.



CAUTION

Contamination of electrodes

Leaving the chip for a period longer than 1 hour (e.g. over night) in the Bioanalyzer may cause contamination of the electrodes.

- → Immediately remove the chip after a run.
- **5** After the chip run is finished, remove the chip from the receptacle of the bioanalyzer and dispose of it according to good laboratory practices.

Cleaning Electrodes after a RNA 6000 Nano Chip Run

When the assay is complete, *immediately* remove the used chip from the Agilent 2100 Bioanalyzer and dispose of it according to good laboratory practice. After a chip run, perform the following procedure to ensure that the electrodes are clean (no residues are left over from the previous assay).

NOTE

Use a new electrode cleaner with each new kit.

CAUTION

Leak currents between electrodes

Liquid spill might cause leak currents between the electrodes.

- → Never fill too much water in the electrode cleaner.
- 1 Slowly fill one of the wells of the electrode cleaner with 350 μ l of fresh RNase-free water.
- **2** Open the lid and place the electrode cleaner in the Agilent 2100 Bioanalyzer.
- **3** Close the lid and leave it closed for about 10 seconds.
- **4** Open the lid and remove the electrode cleaner.
- **5** Wait another 10 seconds to allow the water on the electrodes to evaporate before closing the lid.

NOTE

After 5 chip runs, empty and refill the electrode cleaner.

After 25 chip runs, replace the used electrode cleaner by a new one.

NOTE

Remove the RNase-free water out of the electrode cleaner at the end of the day. For a more thorough cleaning of the electrodes, refer to the *2100 Expert Maintenance and Troubleshooting Guide* which is part of the Online Help of the 2100 bioanalyzer software.



RNA 6000 Nano Ladder Well Results

To check the results of your run, select the Gel or Electropherogram tab in the **Data** context. The electropherogram of the ladder well window should resemble those shown below.




Figure 2 RNA 6000 Nano ladder

7 Checking Your Agilent RNA 6000 Nano Assay Results

RNA 6000 Nano Sample Well Results

Major features of a successful ladder run are:

- · 1 marker peak
- 6 RNA peaks (2100 Expert Software calls for 5 first ladder peaks only)
- · All 7 peaks are well resolved
- · Correct peak size assignment in the electropherogram

If the electropherogram of the ladder well window does not resemble the one shown above, refer to the 2100 Expert Maintenance and Troubleshooting Guide for assistance.

RNA 6000 Nano Sample Well Results

To review the results of a specific sample, select the sample name in the tree view and highlight the *Results* sub-tab. The electropherogram of the sample well window for total RNA (eukaryotic) should resemble the one shown here.




Figure 3 RNA peaks of a successful sample run

Major features of a successful total RNA run are:

- 1 marker peak
- 2 ribosomal peaks (with successful sample preparation)

By selecting the *Results* sub-tab, values for the calculated RNA concentration, the ribosomal ratio and the RNA Integrity Number (RIN), implemented with 2100 Expert Software version B.02.02 or higher, are displayed.

NOTE

You can change the baseline by shifting the left and right dashed lines. This will alter your results. For information on the RNA alignment please refer to the 2100 Expert User's Guide or Online Help.

The electropherogram of the sample well window for mRNA should resemble the one shown here.




Figure 4 mRNA peaks of a successful sample run

Major features of a successful mRNA run are:

- 1 marker peak
- Broad hump (with successful sample preparation)
- Contamination with ribosomal RNA shown as 2 overlaid peaks (if present)

www.agilent.com

In This Book

you find the procedure to analyze RNA samples with the Agilent RNA 6000 Nano reagent kit and the Agilent 2100 Bioanalyzer instrument.

© Agilent Technologies 2000-2015, 2016

Printed in Germany 12/2016



G2938-90034

