




Microcontroller




Power +3V3 / +5V




Button




Power +28V




Solenoid Channels




Stepper Driver




External LED




USB




V2 Link



Mechanical / Production





V2 drum


Versio Duo

Percussion Controller

Polarity Protection

2/10

2026-05-25



V2 drum

Versio Duo


Percussion Controller

Power +5V

3/10

2026-05-25


Voltage Sense



Power Switch

Voltage divider - 100R : load

Supplies a reference voltage to measure the load resistance while the supply power is switched off.



V2 drum


Versio Duo


Percussion Controller


PWM Power


4/10

2026-05-25









V2 drum


Versio Duo

Percussion Controller

LED Strip

8/10

2026-05-25



V2 drum


Versio Duo

Percussion Controller

Link Plug

9/10

2026-05-25



V2 drum

Versio Duo

Percussion Controller

Link Socket

10/10

2026-05-25