





















V2 sax


Versio Duo


Saxophone Controller

Expression Input 3

7/14

2026-03-31 (2026-06-11)





V2 sax


Versio Duo

Saxophone Controller

Expression Input 5

9/14

2026-03-31 (2026-06-11)



V2 sax


Versio Duo

Saxophone Controller

Expression Input 6

10/14

2026-03-31 (2026-06-11)



V2 sax


Versio Duo

Saxophone Controller

Expression Input 7

11/14

2026-03-31 (2026-06-11)



V2 sax


Versio Duo

Saxophone Controller

Expression Input 8

12/14

2026-03-31 (2026-06-11)



V2 sax

Versio Duo

Saxophone Controller

Orientation Sensor

13/14

2026-03-31 (2026-06-11)

