




Microcontroller




Power +3V3




Button




USB



Analog / MIDI




Mechanical / Production




V2 sax
Versio Duo
Saxophone Controller


Rev: 1
Id: 1/10
Sheet: Root
Date: 2024-07-03





MIDI Out

Rev: 2
Id: 2/10
Sheet: MIDI Out
Date: 2024-03-12










Expression Input
Versio Duo

Rev: 4
Id: 6/10
Sheet: Expression Input 4
Date: 2024-03-12



Expression Input
Versio Duo

Rev: 4
Id: 7/10
Sheet: Expression Input 5
Date: 2024-03-12

