




Microcontroller




Power +3V3




Button




USB / Power +5V




Link / PoE




Sensors




Hall Sensors




Mechanical / Production




V2 sax sax
Versio Duo 1/14
Saxophone Controller 2026-03-31 (2026-04-23)






V2 sax
Versio Duo
Saxophone Controller

Power +5V
12/14
2026-03-31 (2026-04-23)





V2 sax


Versio Duo


Saxophone Controller

Expression Input 1

14/14

2026-03-31 (2026-04-23)





V2 sax


Versio Duo


Saxophone Controller


Expression Input 3

16/14

2026-03-31 (2026-04-23)







V2 sax


Versio Duo

Saxophone Controller

Expression Input 6

19/14

2026-03-31 (2026-04-23)



V2 sax

Versio Duo

Saxophone Controller

Expression Input 7

20/14

2026-03-31 (2026-04-23)

