
Important Note:

This capacitor is required and it's not included with the ARS-USB Unit

The capacitor value should be 120-140uF (same as original controller)



Date: 09/09/2013 13:45:13

Sheet: 1/1