

Xtreamer xUSB virtual CD-ROM removal

Requirements

- Xtreamer USB Flash Drive (xUSB).
- A computer running Windows OS (Win 2k/XP/Vista/7) equipped with a USB port.
- "uDisk Tool" program.

Warning!!

This instruction includes format commander that will delete all data. Please don't forget to backup data.

Instructions

- 1. Download <u>uDiskTool</u> utility and save on the Desktop
- 2. Connect xUSB to a USB port.
- 3. Execute uDisk Tool utility.




4. Click CD icon once utility starts.





5. Click "Burn" icon on Partition Setting window.

Note: all data on USB will be deleted.



- 6. Virtual CD-ROM partition removal proceeds.
- 7. Check that CD-ROM partition was removed from the USB.
- 8. Safely remove xUSB.