Sanket PTT — User Guide

Push-to-talk voice radio for police and emergency departments · Android app and web

Web app: https://vibhvesh.github.io/sanketptt/
Android app (APK): https://github.com/vibhvesh/sanketptt/releases/download/v1.0-android/Sanket_PTT.apk

> Pilot / demonstration service. Do not send sensitive information.

1. What it does

- Hold-to-talk voice on named channels, one speaker at a time.
- See who is on the air, with optional location sharing on a map.
- Replay recent transmissions from the session log.
- Send and receive pictures over SSTV (Robot36, Martin M1, Scottie S1, PD120).



2. Install

Android

1. Open the APK link above in the phone's browser.
2. When the download finishes, tap the file to open it.
3. If asked, allow **Install unknown apps** for the browser, then tap **Install**.
4. If Play Protect warns, choose **Install anyway**, then tap **Open**.
5. Allow **Microphone**, **Location** and **Notifications** when asked.

Web: open the web link in Chrome and add it to the home screen. No installation needed.

3. Join a channel

1. Open the channel link from your supervisor, for example `https://vibhvesh.github.io/sanketptt/?ch=unit-name`. The channel is the part after `?ch=`. Do not use the default public channel for official work.
2. Enter your allotted **name or call sign**.
3. Tap **POWER ON · JOIN**. If shown, tap **TAP TO ENABLE AUDIO**.
4. Check that your call sign appears under **ON THE AIR**.

4. Talk

1. Listen first and make sure nobody else is speaking.
2. Press and hold the **PTT** button, wait about one second, then speak.
3. Release the button when you finish so others can reply.
4. Missed something? Play it back from the **Session log**.



5. Share location

1. Tick **SHARE** in Station map only when instructed.
2. Everyone on the channel can see shared locations.
3. Untick **SHARE** when it is no longer needed.

6. Pictures (SSTV)

Send

1. Announce on the channel and wait for acknowledgement.
2. Tap **SSTV · send a picture** and choose the picture.

3. Pick a mode: Robot36 (~37 s, fastest), Martin M1, Scottie S1 or PD120.
4. Tap **SEND IMAGE** and wait. The channel is busy while sending (tap ✕ to cancel).

Receive: stay joined. Pictures decode automatically and appear under **SSTV images**; download them as PNG. Tick **Listen for SSTV via mic** to decode a nearby handset, or **MUTE SSTV AUDIO** to silence the tones.

7. Always on (Android)

1. The screen stays on while the app is open; a "staying on while locked" notification keeps it running when locked.
2. Keep the phone on charge for long shifts.
3. Set the app's battery mode to **Unrestricted** (Settings → Apps → Sanket PTT → Battery).
4. The app loads the live site, so updates arrive automatically. Close and reopen to refresh.

8. Troubleshooting

Problem	Fix
No sound	Tap **TAP TO ENABLE AUDIO**; raise phone volume.
Cannot talk	Allow the microphone permission; wait until the channel is free.
Not in ON THE AIR	Check internet, then tap **POWER ON · JOIN** again.
App stops when locked	Set battery to **Unrestricted**; keep the notification on.
Wrong channel	Reopen the exact link from your supervisor (`?ch=`).

9. Support

Akshat Singh · akshatsingh@canberravision.com