BLOCKCLOCK mini API Cheat Sheet

A single page guide to the most useful API commands to personalize output

Buy yours at store.coinkite.com



Using the API

- You can use either the curl command or your web browser
- Using curl is more practical for scripting sequences.
- You need the IP address of your BLOCKCLOCK mini on the network
- Compose the entire API call like this http://{ip-address}{api}. For example, if your BLOCKCLOCK mini is at IP 21.21.21.21, and you want to flash the lights, then you would use http://21.21.21/api/lights/flash
- If you've set a password on your BLOCKCLOCK mini, then use curl and pass the following options: --digest -u :{password} before the full url

Displaying Large Text

- To show a text value, use /api/show/text/{FOO} where {FOO} is the text to show
- It will be right padded into the seven available panels
- Extra characters will be trimmed from the left side if its too long
- Dot and comma can combine with left-adjacent character, so strings like "1,234,567" can be displayed even though they are longer than 7 characters because "1" and "4" will be shown in a single position

Data Panels

- Use /api/pick/next to move to the next data tag in your programmed sequence
- Use /api/pick/{tag.name} to display the indicated tag.
- Use /api/pick/redraw to redraw the current tag
- Some available tags are

cm.blockchain.block_height		
cm.markets.price		
cm.markets.sats_per_dolla		
cm.mempool.vsize		
cm.nextblock.median_fee		
datetime.world.b halvening.expected		
		holidays.hodl_day.next

 The above is just a small sampling. There are hundreds of different useful data tags that you can see in the Display Setup

Displaying Small Text a.k.a . Over/Under Text

- To show over/under text in a specific panel, use the following format /api/ou_text/{0..6}/{over}/{under}
- The panel positions are from left (0) to right (6)
- The {over} and {under} text can support a max of 4 characters, sometimes 5 or more if they are narrow.
- Text is centered horizontally.
 You can add a series of periods before or after to aid in alignment

Decorations

- These are provided as query string arguments.
- tl={top left} tiny text message
- br={bottom right} tiny text
- pair={over/under} in panel 0
- sym={symbol} to add currency symbol to left of number if space is available. Available symbols are

bitcoin	litecoin
USD	\$

Displaying Numbers

- To show a numeric value, use /api/show/number/{N} where {N} is the number to show
- Numbers will be right justified to seven available panels

Displaying Images

- To show an image in a specific panel, use /api/image/{0..6}/{image name}
- The panel positions are from left (0) to right (6)
- At this time, image names available are

bitcoin	litecoin
bar	od_wordmark
register	honey

 Support for arbitrary images is not available at this time

Lighting Effects

- Lights can be turned on to a set color with optional white using RGB based hex codes
- Use /api/lights/{R}{G}{B}{W}
 where {R} is amount of red, {G}
 is amount of green, {B} is
 amount of blue, and {W} is
 white affecting lightness. For
 example /api/lights/FF00FF40 is
 purple
- Use /api/lights/off to immediately turn off lights
- Use /api/lights/flash to do preconfigured animation when value changes normally

Actions

- Use /api/action/pause to turn off automatic updates
- Use /api/action/update?rate=5 to restore automatic updates.
 The value for rate is in minutes
- Use /api/action/powerdown to power down
- Use /api/action/reboot to reboot the system
- Use /api/action/clear_menu to cancel any menus being shown restoring normal data display

Prepared by @vicariousdrama Last Updated: 2020-12-06