

Add the Suriname admin keys to a CAP node

App only. Authorizes the **Suriname 01** and **Suriname 02** controllers to configure this CAP over LoRa. Repeat on every CAP you want to manage remotely.

1 The two keys

Suriname 01 · host SCU-b827eb3a09e4 · RAK4631 on USB

```
doDt9v0uNXfCXzv5qNgspLC3RZzB3sgfJhZAt4zeITQ=
```

Suriname 02 · host SCU-b827eb399d48 · node on the Pi UART pins

```
JcTyI8whkgLD+o8i3Wvi0dYGcNb0LJYoGpGaL544S1w=
```

Highlighted characters are easy to confuse: **I** = capital i · **l** = lowercase L · **1** = digit one. The **O**s in both keys are letters, not zeros.

Each key is **44 characters** and ends in **=**. **Copy and paste them — never retype.** A single wrong character makes remote admin fail silently, with no error shown.

2 Add them in the app

1. Connect the app by Bluetooth **to the CAP** — not to a Suriname node. Check that the node name at the top of **Settings** is the CAP you mean to configure.
2. Open **Settings** > **Security**.
3. Scroll down past *Packet authenticity* and *Direct Message Key* to the **Admin Keys** card. Its field is **Admin Key** — "The public key authorized to send admin messages to this node." It is a public key, not a password.
4. Tap **Add** and paste the **Suriname 01** key.
5. Tap **Add** again and paste the **Suriname 02** key. A node holds up to 3 admin keys, so one slot stays free.
6. Leave **Managed Device** (in the *Administration* card, further down) **OFF**.
7. Tap **Save & restart**. The CAP reboots and Bluetooth reconnects after about 20 seconds.

DO NOT ENABLE MANAGED DEVICE

It locks all local settings: the node can then only be changed by remote admin. If a key is wrong or both controllers are unreachable, the only way back is a physical factory reset.

3 Check

- Reopen **Settings** > **Security**: the **Admin Keys** card lists both keys.
- Open the **Nodes** tab on the CAP: both Suriname nodes must appear, and each one's node details must show a **Public Key**. The CAP needs that stored key to decrypt their admin messages.
- After the first successful remote admin session, the CAP marks that controller as a **favorite** automatically. That is expected, and a useful sign that it worked.

4 If remote admin fails

CAUSE	FIX
Typo in a key	Delete it in Admin Keys , paste it again, Save & restart .
The CAP has no public key for the controller	On the CAP: Nodes > the Suriname node > request its user info, then retry.
The controller has no public key for the CAP	Same check from the controller side: the CAP must appear in its node list with a key.
A controller's key was regenerated	Its public key changed. Replace the old key in Admin Keys with the new one.