

Do you have Idle Shutdown Vehicle Accessories Relay Driver Circuit (Aftermarket or OEM)	Go to 97-fc339aft (/qs3/pubsys2/xml/en/procedures/97/97-fc339aft.html)
Do you have Idle Shutdown Vehicle Accessories Relay Driver Circuit (Integrated)	Go to 97-fc339int (/qs3/pubsys2/xml/en/procedures/97/97-fc339int.html)

Last Modified: 29-Sep-2004
