

Trainings ▾


Cummins® Engine Nomenclature

The model name provides identification data for the engine.

The graphic illustrates model name identification.

The application codes are:

- A = Agricultural**
- C = Construction**
- D = Generator drive**
- F = Fire pump**
- G = Generator set**
- L = Locomotive**
- M = Marine**
- P = Power unit**
- R = Railcar**
- T = Tactical military.**




00400202

Engine Dataplate

The engine dataplate shows specific information about the engine.

- (1) Engine serial number (ESN)**
- (2) Control parts list (CPL)**
- (3) Model**
- (4) Provide information for ordering parts and service needs.**




ew4piga

The engine dataplate **must not** be changed unless approved by Cummins Inc.

Fuel Pump Dataplate

The fuel pump dataplate is located on the top of the fuel pump. It provides information for fuel pump calibration.



ECM Dataplate

The external ECM dataplate is located on top of the ECM.

The dataplate contains the following:

- ECM part number (P/N)
- ECM serial number (S/N)
- Manufacturer date code (D/C)
- Engine serial number (ESN)
- Calibration loaded in the ECM (ECM code).

On the ECM mounting flange the following information is provided:

- ECM part number
- Voltage rating
- ECM serial number.

