


Trainings ▾

Remove

⚠ WARNING ⚠

This component or assembly weighs greater than 23 kg [50 lb]. To prevent serious personal injury, be sure to have assistance or use appropriate lifting equipment to lift this component or assembly.



Remove the front gear cover spacer plate.

Remove the 14 mounting capscrews from the plate.

Remove the plate and discard the gasket.

Note : Tag the special mounting capscrews for future identification.