


## Trainings ▾

### Remove

#### **⚠ WARNING ⚠**

**This component or assembly weighs greater than 23 kg [50 lb]. To prevent serious personal injury, be sure to have assistance or use appropriate lifting equipment to lift component or assembly.**



Remove the six cylinder head capscrews.

Remove the cylinder head and gasket.

Record the cylinder head gasket part number to determine if the gasket is a standard or oversize thickness.

Discard the gasket.