


## Trainings ▾

### Setup

Use the injection timing tool, Part Number 3824942. The indicators (1) and (2) are identical.

1. Push tube travel indicator
2. Piston travel indicator
3. Piston plunger support assembly
4. Push rod plunger support assembly
5. Hold-down adapter
6. Extension assembly (adapter wrench)
7. Indicator stem extension




The push rod plunger support assembly alignment is critical.

Install the push rod plunger support (4) in the outside slot in the piston plunger support (3).

Align the push rod plunger support with the mark. Tighten the capscrew.

Install the indicators (1) and (2) on the posts. Turn the indicators so they are **not** over the plungers.

Install the stem extension on the piston travel indicator.




Install the injector push rod (8) for cylinder Number 3.

Install the timing tool in the injector bore Number 3. Install the hold-down adapters.

Align the push rod plunger and the rod to be sure they are straight.

Tighten the support lock (9).



### Measure


Use **only** the crankshaft to rotate the engine. The use of the gears will result in false measurement. Gear lash **must** be closed up in the direction of normal rotation.

**Note : Three guide bolts equally spaced in front of the crankshaft will help rotate the engine.**


Turn the crankshaft in the direction of normal rotation while observing both of the timing tool plungers. Both plungers will begin moving upward when the cylinder is on the compression stroke.

Assuming all the gear index marks were aligned when the injection timing process was started, the crankshaft will have to be rotated approximately three-quarters of a revolution to get to the compression stroke for the Number 3 cylinder.

If both plungers are **not** moving upward (one upward and one downward), the engine is on the exhaust stroke. Rotate the crankshaft one revolution to get to the compression stroke.




Establish TDC by slowly rotating the crankshaft in the direction of normal rotation while observing the piston plunger (10). The plunger will move upward, STOP, then begin to move downward. The STOP point of the plunger is TDC. Rotate the engine opposite the direction of normal rotation until the plunger begins to move downward. The cylinder is now before TDC slightly.



Turn the indicator so the stem is touching the plunger. Carefully move the indicator downward until the needle has turned a minimum of five revolutions [0.500 inch]. LOCK the indicator in position.


Slowly turn the crankshaft in the direction of normal rotation until the indicator needle STOPS turning **clockwise** (TDC). Move the indicator downward until there is **only** one revolution [0.100 inch] of travel remaining until the indicator bottoms out.

Adjust the indicator to ZERO.




Turn the push rod indicator so that the stem touches the plunger.

Carefully lower the indicator until it bottoms out. Raise the indicator when the needle has turned a minimum of three revolutions [0.300 inch].



Slowly turn the crankshaft in the direction of normal rotation until the push rod indicator STOPS (1), momentarily reverses direction (2) (this is the crush nose on the camshaft), and STOPS again (3). The cam follower is now on the outer base circle of the camshaft. The piston is now approximately 45 degrees after TDC.



It is important to record the amount of travel remaining in the push rod travel indicator for later reference.


Carefully lower the push rod travel indicator until it bottoms out. Raise the indicator approximately one-half of a revolution [0.050 inch]. LOCK the indicator in position.

Set the indicator at ZERO.

Set the piston at [0.2032 inch] before TDC

Observe the piston travel indicator as you slowly rotate the crankshaft opposite the direction of normal rotation.


Stop rotating the crankshaft when the piston travel indicator indicates the piston is at TDC (ZERO).



The crankshaft **must** be turned slowly to accurately count the indicator revolutions.


Turn the crankshaft opposite the direction of normal rotation until the indicator needle moves two and one-half revolutions [0.250 inch].

The piston is now [0.250 inch] before TDC.



**Only** move the piston to [0.2032 inch] before TDC by turning the crankshaft in the direction of normal rotation. If you accidentally turn the crankshaft too far, you **must** turn the crankshaft opposite the direction of normal rotation more than [0.2032 inch] before TDC. Then very slowly turn the crankshaft in the direction of normal rotation until the indicator indicates that the piston is [0.2032 inch] before TDC.

**Note :** Remember that all QSK19 injection timing specifications are more than one indicator revolution [0.100 inch].




Read the push rod travel indicator **counterclockwise** from zero. This is the injection timing measurement to compare to the specification. An example of [0.118 inch] is shown.

If **not** sure of the number of push rod indicator revolutions, check by:

- Carefully lifting the indicator stem until the indicator has bottomed out
- Lower the stem the amount of excess travel you set in the third preceding step
- Lower the stem to the plunger.
- Read the indicator.

If the injection timing is within specification and you are using a slipper-fit gear, install the standard gear. Refer to Procedure 001-012 in Section (</qs3/pubsys2/xml/en/procedures/20/20-001-012-tr.html>). Repeat the injection timing procedure after the camshaft gear has cooled.




If the injection timing is **not** within specification, repeat the measurement procedure to check the tool setup and the ZERO settings.

If the timing is still **not** within specification, the camshaft key **must** be changed. Refer to Procedure 001-012 in Section (</qs3/pubsys2/xml/en/procedures/20/20-001-012-tr.html>) for instructions to remove the camshaft gear.

Record the orientation of any offset of the key. Use the following worksheet to determine an alternate key.

You **must** confirm the timing measurement after changing the key.



Answer each of the following questions in the spaces provided. The answers to the questions and the use of Tables A, B, and C will determine the timing key required to correct the injection timing.  
A working example is attached for your review to illustrate the use of this worksheet.

1. What is the current timing?

2. What is the timing code?

3. What is the timing specification for this code? ( $\pm 0.002$  inch)

4. Is the current timing a larger or smaller number than the specification?

If larger, advance the timing.

If smaller, retard the timing.

5. What is the difference between the current timing (answer to question 1) and the specification (answer to question 3)?

6. Does the offset of the current key point in the same or opposite direction that the camshaft normally rotates?

7. Use TABLE A to determine the current key part number.

\* What is the amount of the offset of the current key?

| TABLE A               |       |        |
|-----------------------|-------|--------|
| Timing Key (Part No.) | mm    | in     |
| S-302                 | None  | (None) |
| 210294                | 0.069 | 0.0028 |
| 200711                | 0.179 | 0.0070 |
| 200702                | 0.279 | 0.0110 |
| 200706                | 0.379 | 0.0150 |
| 200704                | 0.500 | 0.0197 |
| 200708                | 0.584 | 0.0230 |
| 3000491               | 0.666 | 0.0262 |
| 200706                | 0.833 | 0.0328 |
| 3000492               | 0.914 | 0.0360 |
| 200714                | 0.991 | 0.0393 |
| 3000493               | 1.092 | 0.0430 |
| 3000494               | 1.194 | 0.0470 |
| 3000495               | 1.295 | 0.0510 |

06400106

8. Use TABLE B to determine how to use TABLE C.  
Circle or check the appropriate answer.

| TABLE B              |                      |                            |
|----------------------|----------------------|----------------------------|
| Answer to Question 4 | Answer to Question 6 | Beginning Point on TABLE C |
| Advance              | Same                 | Top of column              |
| Retard               | Opposite             | Bottom of column           |
| Retard               | Same                 | Bottom of column           |
|                      | Opposite             | Top of column              |

9. Answer the following questions BEFORE using TABLE C to determine the new timing key part number.

- Find the current key part number listed at the TOP of the column on TABLE C.
- Move up or down the column (the answer to question 8). Do not pass 0.000 (ZERO)\*.

\*If you pass 0.000 (ZERO), you will be choosing a key that does the opposite of what you want it to do.

STOP when you locate the number nearest ( $\pm 0.002$  inch) to the required change in push rod travel (answer to question 5). Remain in this row. Move your finger to the right. The result is the New Key Part No. and the Direction of Offset the timing key must point.

What is the part number of the new key?

**Note:** Each column on TABLE C indicates the change in the push rod travel. The change will result if the key at the top of the column is removed and the new key indicated in the second column from the right is installed. The Direction of Offset will be pointing as indicated in the last

TABLE C

| S-302  | 200704 | 200706 | 200708 | 200709 | 200711 | 200714 | 216294 | 216782 | 3000491 | 3000492 | 3000493 | 3000494 | 3000495 | New Key Part No. | Direction of Offset |
|--------|--------|--------|--------|--------|--------|--------|--------|--------|---------|---------|---------|---------|---------|------------------|---------------------|
| 0.0256 | 0.0351 | 0.0411 | 0.0366 | 0.0326 | 0.0289 | 0.0441 | 0.0273 | 0.0311 | 0.0391  | 0.0436  | 0.0471  | 0.0491  | 0.0512  | 3000495          | Opposite            |
| 0.0235 | 0.033  | 0.039  | 0.0345 | 0.0305 | 0.0268 | 0.042  | 0.0252 | 0.029  | 0.037   | 0.0415  | 0.045   | 0.0471  | 0.0491  | 3000494          | Opposite            |
| 0.0215 | 0.031  | 0.037  | 0.0325 | 0.0285 | 0.0248 | 0.040  | 0.0232 | 0.027  | 0.035   | 0.0395  | 0.043   | 0.0441  | 0.0471  | 3000493          | Opposite            |
| 0.0185 | 0.028  | 0.034  | 0.0295 | 0.0255 | 0.0218 | 0.037  | 0.0202 | 0.024  | 0.032   | 0.0365  | 0.040   | 0.042   | 0.0441  | 200714           | Opposite            |
| 0.018  | 0.0275 | 0.0335 | 0.029  | 0.025  | 0.0213 | 0.0365 | 0.0197 | 0.0235 | 0.0315  | 0.036   | 0.0395  | 0.0415  | 0.0436  | 3000492          | Opposite            |
| 0.0155 | 0.025  | 0.031  | 0.0265 | 0.0225 | 0.0188 | 0.034  | 0.0172 | 0.021  | 0.029   | 0.0335  | 0.037   | 0.039   | 0.0411  | 200706           | Opposite            |
| 0.0135 | 0.023  | 0.029  | 0.0245 | 0.0205 | 0.0168 | 0.032  | 0.0152 | 0.019  | 0.027   | 0.0315  | 0.035   | 0.037   | 0.0391  | 3000491          | Opposite            |
| 0.011  | 0.0205 | 0.0265 | 0.022  | 0.018  | 0.0143 | 0.0295 | 0.0127 | 0.0165 | 0.0245  | 0.029   | 0.0325  | 0.0345  | 0.0366  | 200708           | Opposite            |
| 0.0095 | 0.019  | 0.025  | 0.0205 | 0.0165 | 0.0128 | 0.028  | 0.0112 | 0.015  | 0.023   | 0.0275  | 0.031   | 0.033   | 0.0351  | 200704           | Opposite            |
| 0.007  | 0.0165 | 0.0225 | 0.018  | 0.014  | 0.0103 | 0.0255 | 0.0087 | 0.0125 | 0.0205  | 0.025   | 0.0285  | 0.0305  | 0.0326  | 200709           | Opposite            |
| 0.0055 | 0.015  | 0.021  | 0.0165 | 0.0125 | 0.009  | 0.024  | 0.0072 | 0.011  | 0.019   | 0.0235  | 0.027   | 0.029   | 0.0311  | 216782           | Opposite            |
| 0.0033 | 0.0128 | 0.0188 | 0.0143 | 0.0103 | 0.006  | 0.0218 | 0.005  | 0.009  | 0.0168  | 0.0213  | 0.0248  | 0.0268  | 0.0289  | 200711           | Opposite            |
| 0.0017 | 0.0112 | 0.0172 | 0.0127 | 0.0087 | 0.0051 | 0.0202 | 0.0034 | 0.0072 | 0.0152  | 0.0197  | 0.0232  | 0.0252  | 0.0273  | 216294           | Opposite            |
| 0.000  | 0.0095 | 0.0155 | 0.011  | 0.007  | 0.003  | 0.0185 | 0.0017 | 0.006  | 0.0135  | 0.018   | 0.0205  | 0.0235  | 0.0256  | S-302            | N/A                 |
| 0.0017 | 0.0078 | 0.0138 | 0.0093 | 0.0053 | 0.0016 | 0.0168 | 0.000  | 0.0038 | 0.0118  | 0.0163  | 0.0198  | 0.0218  | 0.0239  | 216294           | Same                |
| 0.0033 | 0.0062 | 0.0122 | 0.0077 | 0.0037 | 0.000  | 0.0152 | 0.0016 | 0.002  | 0.0102  | 0.0147  | 0.0182  | 0.0202  | 0.0223  | 200711           | Same                |
| 0.0055 | 0.004  | 0.010  | 0.0055 | 0.0015 | 0.002  | 0.013  | 0.0038 | 0.000  | 0.008   | 0.0125  | 0.016   | 0.018   | 0.0201  | 216782           | Same                |
| 0.007  | 0.0025 | 0.0085 | 0.004  | 0.000  | 0.0037 | 0.0115 | 0.0053 | 0.0015 | 0.0065  | 0.011   | 0.0145  | 0.0165  | 0.0186  | 200709           | Same                |
| 0.0095 | 0.000  | 0.006  | 0.0015 | 0.0025 | 0.0062 | 0.009  | 0.0078 | 0.004  | 0.004   | 0.0085  | 0.012   | 0.014   | 0.0161  | 200704           | Same                |
| 0.011  | 0.0015 | 0.0045 | 0.000  | 0.004  | 0.0077 | 0.0075 | 0.0093 | 0.0055 | 0.0025  | 0.007   | 0.0105  | 0.0125  | 0.0146  | 200708           | Same                |
| 0.0135 | 0.004  | 0.002  | 0.0025 | 0.0065 | 0.0102 | 0.005  | 0.0118 | 0.008  | 0.000   | 0.0045  | 0.008   | 0.010   | 0.0121  | 3000491          | Same                |
| 0.0155 | 0.006  | 0.000  | 0.0045 | 0.0085 | 0.012  | 0.003  | 0.0138 | 0.010  | 0.002   | 0.0025  | 0.006   | 0.008   | 0.0101  | 200706           | Same                |
| 0.018  | 0.0085 | 0.0025 | 0.007  | 0.011  | 0.0147 | 0.0005 | 0.0163 | 0.0125 | 0.0045  | 0.000   | 0.0035  | 0.0055  | 0.0076  | 3000492          | Same                |
| 0.0185 | 0.009  | 0.003  | 0.0075 | 0.0115 | 0.0152 | 0.000  | 0.0168 | 0.013  | 0.005   | 0.0005  | 0.003   | 0.005   | 0.0071  | 200714           | Same                |
| 0.0215 | 0.012  | 0.006  | 0.0105 | 0.0145 | 0.0182 | 0.003  | 0.0198 | 0.016  | 0.008   | 0.0035  | 0.000   | 0.002   | 0.0041  | 3000493          | Same                |
| 0.0235 | 0.014  | 0.008  | 0.0125 | 0.0165 | 0.0202 | 0.005  | 0.0218 | 0.018  | 0.010   | 0.0055  | 0.002   | 0.000   | 0.0021  | 3000494          | Same                |
| 0.0256 | 0.0161 | 0.010  | 0.0146 | 0.0186 | 0.0223 | 0.0071 | 0.0239 | 0.0202 | 0.0121  | 0.0076  | 0.0041  | 0.0021  | 0.000   | 3000495          | Same                |

06400106

## Finishing Steps

### with Mechanically Actuated Injector

- Install the injector from cylinder Number 3. Refer to Procedure 006-026 in Section 6.  
(/qs3/pubsys2/xml/en/procedures/20/20-006-026-tr.html)
- Install the rocker lever assembly from cylinder Number 3. Refer to Procedure 003-009 in Section 3.  
(/qs3/pubsys2/xml/en/procedures/20/20-003-009-tr.html)
- Install the rocker lever cover. Refer to Procedure 003-011 in Section 3. (/qs3/pubsys2/xml/en/procedures/20/20-

©Cummins Inc.



ck800wa

003-011-tr.html)

- Operate the engine and check for leaks.

---

**Last Modified: 13-Nov-2018**

---