

Trainings ▾

Inspect

To provide continued reliable operation, the filter **must** be checked at regular intervals.

The operating indicator is used to check the operation of the hydraulic motor.

Check the operating indicator daily at low idle condition. If the indicator makes one revolution between 227 - 650 seconds, the Eliminator™ hydraulic motor is operating properly. If it does **not** make the revolution in this time period, contact a Cummins® Authorized Repair Location.

