

Trainings ▾

Inspect for Reuse

Inspect the fan shroud for the correct fan clearance. Refer to the vehicle manufacturer's specifications and the appropriate Installation Recommendations Bulletin.

Visually inspect the shroud for cracks, air leaks, or other damage. Replace the part if damaged. Refer to the manufacturer's instructions.

