


Trainings ▾

Install

Install the gasket. Install the water pump drive assembly.

The drive will be secured in position by the stud.



Water Pump Drive Capscrew	45 n.m	[33 ft-lb]
------------------------------	--------	------------