

Trainings ▾

Install

Marine Applications

Install the turbocharger heat shield.

Install and tighten the turbocharger heat shield mounting capscrews.

Torque Value: 35 n•m [25 ft-lb]

