

Trainings ▾

General Information

Most of the maintenance operations described in this manual can be performed with common hand tools (metric and SAE wrenches, sockets, and screwdrivers).

The following is a list of special service tools required for some maintenance operations:

Tool Part Number	Description
ST-1293	Belt Tension Gauge (V-Belts)
3400157	Oil Filter Wrench (Band Type), Filter Diameter 118 to 130 mm [4.7-5.12 in]
3400158	Water, Fuel, Oil Filter Wrench (Strap Type), Filter Diameter up to 152 mm [6.0 in]
3822524	Belt Tension Gauge (Click Type) 63-203 N•m [50-150 ft-lb]
3822525	Belt Tension Gauge (Click Type) 136-407 N•m [100-300 ft-lb]
3164795	Torque Wrench (Dial Type) 0-34 N•m [0-300 in-lb]
3824901	Valve Lash Gauge Kit
3164794	Torque Wrench (Click Type) 14-136 N•m [10-100 ft-lb]
CC2602	Fleetguard Coolant Test Kit
CC2800	Fleetguard Battery Refractometer
4918282	Cylinder Head Protective Cover

- Refer to the appropriate sections for a description of the tools and how to use them.
- Contact your nearest Cummins Authorized Repair Location for the required service tools.