


Trainings ▾

Remove

⚠ CAUTION ⚠

Make sure that the engine is switched off and any starting mechanisms are isolated before any inspections are made.

If applicable, remove the alternator guard.




Clean

⚠ WARNING ⚠

Wear appropriate eye and face protection when using compressed air. Flying debris and dirt can cause personal injury.

Using a compressed air line, blow through the alternator from the front side in the direction shown until the air comes out clean.



Install

If applicable, reinstall the alternator guard.

Cummins Inc.

